

Yealink SIP VP-T49G Release Notes of Version 22

Table of Contents

ink SIP VP-T49G Release Notes of Version 22	1
ink SIP IP Phones Release Notes of Version 51.22.0.5	2
Introduction	2
New Features	2
Optimization	2
Bug Fixes	2
New Features Descriptions	3
Optimization Descriptions	.14
Configuration Parameters Enhancements	.15
Configuration Parameters Update	.28
Default Value Setting Changes	.30
	ink SIP VP-T49G Release Notes of Version 22 ink SIP IP Phones Release Notes of Version 51.22.0.5 Introduction New Features Optimization Bug Fixes New Features Descriptions Optimization Descriptions Configuration Parameters Enhancements Configuration Parameters Update Default Value Setting Changes



Yealink SIP IP Phones Release Notes of Version

51.22.0.5

1. Introduction

• Firmware Version:

T49G: 51.21.0.1 upgrades to 51.22.0.5

- Applicable Model: T49G
- Release Date: Feb 14th, 2017.

2. New Features

- 1. Added the feature that SIP VP-T49G is compatible with Yealink VC/Zoom/BlueJeans/Pexip/Mind/Custom Cloud-based video communications service.
- 2. Added the feature of H.323 Account Registration.
- 3. Added the feature of Dual-Stream Protocol (BFCP&H.239).
- 4. Added the feature of Output Resolution.
- 5. Added the feature of Video Conferencing.
- 6. Added the feature of Videoconferencing Key.
- 7. Added the feature of Virtual Meeting Rooms (VMR).

3. Optimization

- 1. Optimized the feature that you can use onscreen keyboard in dialing screen.
- 2. Optimized the dialing modes.
- 3. Added a VC Account page in the web user interface under the Account menu.

4. Bug Fixes

- 1. Fixed the issue that if the phone crashed during the call, after reboot, all the account information disappear from the phone user interface.
- 2. Fixed the issue that in the phone user interface, when you check the call stats, the Frame Rate is always 0 fbs.
- 3. Fixed the issue that when you use T49G IP phone to make a call, the Device Info displayed on other endpoint is wrong.



5. New Features Descriptions

1. Added the feature that SIP VP-T49G is compatible with Yealink VC/Zoom/BlueJeans/Pexip/Mind/Custom Cloud-based video communications service.

Description: SIP VP-T49G IP phones only support SIP account by default, after enabling the video conferencing feature, the IP phone can also support Cloud account. The IP phones are compatible with Yealink VC/Zoom/BlueJeans/Pexip/Mind/Custom Cloud-based video communications service. Meanwhile, you can enable or disable the video conferencing feature to display the related cloud account configuration at the web path of Settings->Video->Video Conferencing Features.

The parameters in the auto provision template are described as follows:

vcaccount.enable =

cloud.account.X.type =

cloud.account.X.label =

cloud.account.X.user_name =

cloud.account.X.alias =

cloud.account.X.register_name =

cloud.account.X.sip_server.address =

cloud.account.X.password =

cloud.account.X.sip_server.transport_type =

cloud.account.X.srtp_encryption =

cloud.account.X.dtmf.type =

cloud.account.X.dtmf.info_type =

cloud.account.X.dtmf.dtmf_payload =

cloud.account.X.keep_alive_interval =

To configure the type of Cloud account via phone user interface:

Tap 🔡 -> Advanced (default password: admin) -> VC Account -> Cloud Account -> Type.

'ealink YEALINK NETWORK TECHNOLOGY CO., LTD. www.yealink.com Yealink Cloud Туре Account Туре Yealink Cloud \odot Network V Zoom Phone Lock 0 Pexip Set Password 8 0 BlueJeans Set AES Key Mind Auto Provision 2 Ð 5 *

To configure the type of Cloud account via web user interface:

Click Account -> Cloud Account -> Type

Veglink				Log Out
ICCIIII K 1149G	Status Account Netwo	ork DSSKey Fea	tures Settings	Directory Security
General Account	Account	Account 1	Type Yealink Cloud	NOTE
Register	Cloud Account	Desistened	Pexip BlueJeans Mind	account-cloud-note
Basic	User Name	888888612	Custom	You can click here to get
Codec	Password	•••••	0	more guides.
Advanced	Advanced Setting			
VC Account	DTMF Type DTMF Info Type	DTMF-Relay	0	
Cloud Account	DTMF Payload Type(96~127)	101	0	
H.323	Confirm	Cancel		
SIP IP Call				

2. Added the feature of H.323 Account Registration.

Description: The SIP VP-T49G IP phone only support SIP protocol by default, after enabling the video conferencing feature, the IP phone can also support H.323 call protocols. You can register an H.323 account to directly communicate with H.323 endpoints.

The parameters in the auto provision template are described as follows:

account_h323.auto_answer = features.h323_protocol.enable = account_h323.enable =





account_h323.extension =

account_h323.gk_server.Y.address =

account_h323.gk_server.Y.port =

account_h323.gk_mode =

account_h323.gk_auth.enable =

account_h323.gk_username =

account_h323.gk_password =

account_h323.h460.enable =

account_h323.tunneling.enable =

account_h323.h235_type =

account_h323.h323_port =

h323.user_cap.enable =

h323.video_sdp_report_twice =

To register an H.323 account via phone user interface:

Tap 🔡 -> Advanced (default password: admin) -> VC Account -> H323.

1000	H323	16 59 Thu, Aug 18
a Account	2. H.323 Protocol:	Enabled
🐵 VC Account	3. H.323 Account:	Enabled
Network	4. H.323 Name:	9008
Phone Lock	5. H.323 Extension:	9008
Set Password	6. Gatekeeper Mode:	Manual Mode
Set AES Key	7. Gatekeeper Server1:	10.2.1.43
Auto Provision	8. Gatekeeper Port 1:	1719
đ	Save	*

To register an H.323 account via web user interface:

Click Account -> H.323

Yealink

YEALINK NETWORK TECHNOLOGY CO., LTD.

CUII	IIK			www.yealink.com
Vaalink				Log Out
	Status Account Netwo	rk DSSKey F	eatures Settin	gs Directory Security
General Account	Register Status	Unregistered		NOTE
	H.323 Protocol	Enabled	✓ 🕜	account-h323-note
Register	H.323 Account	Enabled	✓ ⑦	
Basic	H.323 Auto Answe	Disabled	✓ ⑦	You can click here to get
Codec	H.323 Name		0	more guides.
Advanced	H.323 Extension		0	
Auvanceu	Gatekeeper Mode	Disabled	✓ ⑦	
VC Account	Gatekeeper IP Address 1		Port 1719	0
Cloud Account	Gatekeeper IP Address 2		Port 1719	0
	Gatekeeper Authentication	Disabled	✓ ⑦	
H.323	Gatekeeper Username		0	
SIP IP Call	Gatekeeper Password	•••••	0	
	H.460 Active	Disabled	✓ ⑦	
	H.323 Tunneling	Disabled	✓ ⑦	
	H235 Encryption	Disabled	✓ ⑦	
	Protocol Monitor Port	1720	0	
	DTMF Type	Auto	✓ Ø	
	Local Early Media	Disabled	✓ Ø	
	H.239	Enabled	✓ Ø	
	Confirm	Cancel		
	Confirm	Cancer		

3. Added the feature of Dual-Stream Protocol (BFCP&H.239).

Description: The SIP VP-T49G IP phones support the standard H.239 protocol and BFCP (Binary Floor Control Protocol). H.239 protocol is used when sharing content with the far site in H.323 calls. BFCP protocol is used when sharing content with the far site in SIP calls. You can configure the BFCP for Cloud account (except Yealink Cloud account) and SIP IP call respectively. Before enabling the desired protocol, ensure that the protocol is supported and enabled by the far site you wish to call.

The parameters in the auto provision template are described as follows:

h323.h239.enable =

cloud.account.X.bfcp.enable =

To configure H.239 protocol via phone user interface:

Tap **H** -> **Advanced** (default password: admin) -> **VC Account** -> **H.323**.

Yealink

YEALINK NETWORK TECHNOLOGY CO., LTD.

www.yealink.c	com
---------------	-----

Tario 8638	H.323		15:30 Thu, Dec 29
🕿 Account	14. H.460 Active:	Disabled	
🐼 VC Account	15. H.323 Tunneling:	Disabled	
Network	16. H235 Encryption:	Disabled	
Phone Lock	17. Protocol Monitor Port:	1720	
Set Password	18. DTMF Type:	Auto	
Set AES Key	19. Local Early Media:	Disabled	
Auto Provision	20. H.239:	Enabled	
5	Save		*

To configure BFCP protocol for SIP IP call via phone user interface:

 Tap
 -> Advanced (default password: admin) -> VC Account -> SIP IP Call.

C Mario 8638	SIP IP Call		11 16 Tue, Dec 27
Account	4. SRTP:	Disabled	
🐵 VC Account	5. DTMF Type:	RFC2833	
Network	6. DTMF Info Type:	DTMF-Relay	
Phone Lock	7. DTMF Payload Type:	101	
Set Password	8. RPort:	Disabled	
Set AES Key	9. NAT:	Disabled	
2 Auto Provision	10. BFCP:	Enabled	
to	Save		A

To configure H.239 protocol via web user interface:

Click Account -> H.323.



YEALINK NETWORK TECHNOLOGY CO.,LTD.

	_							in in incyce		_
									Log Out	
Yealink T49G										
	Status	Account	Network	DSSKey	Featu	ires	Settings	Directory	Security	
General Account	Re	egister Status		Unregistered				NOTE		
	н.	.323 Protocol		Enabled	~	0		account-h323-	note	ī.
Register	н.	.323 Account		Enabled	~	?				
Basic	н.	.323 Auto Answe		Disabled	~	0		Vou can c	ick here to get	
Codec	н.	.323 Name				0		more guides.		
A down and	н.	.323 Extension				0				
Advanced	Ga	atekeeper Mode		Disabled	~	0				
VC Account	Ga	atekeeper IP Addres	s 1			Port 1	719			
Cloud Account	Ga	atekeeper IP Addres	s 2			Port 1	719			
	Ga	atekeeper Authentica	ation	Disabled	~	0				
H.323	Ga	atekeeper Username	ł			0				
SIP IP Call	Ga	atekeeper Password		•••••		0				
	H.	.460 Active		Disabled	~	0				
	н.	.323 Tunneling		Disabled	~	0				
	H2	235 Encryption		Disabled	~	0				
	Pro	otocol Monitor Port		1720		0				
	DT	TMF Type		Auto	~	0				
	Lo	ocal Early Media		Disabled	~	0				
	н.	.239		Enabled	~	0				
		Г	Carlina							
			Confirm	Ca	incel					

To configure BFCP protocol for Cloud account (except Yealink Cloud account) via web user interface:

Click Account -> Cloud Account.

Yealink	Status Account Netwo	rk DSSKey Features Settings	Log Out Directory Security
General Account	Account	Account 3 - Type Zoom -	
Register	Register Status Label	Registered Zoom	account-cloud-note
Basic	Server Host	zoomcrc.com	You can click here to get
Codec	Transport	TCP 👻	more guides.
Advanced	SRTP	Disabled 👻 🕐	
VC Account	DTMF Type DTMF Info Type	RFC2833 RFC2833	
Cloud Account	DTMF Payload Type(96~127)	101	
H323	Keep Alive Interval(Seconds)	30	
SIP IP Call	BFCP	Enabled - Cancel	

4. Added the feature of Output Resolution.

Description: SIP VP-T49G IP phones support output resolution adjustment. You can adjust output resolution of IP phone or external monitor.

Make sure the external monitor has been connected to the SIP VP-T49G IP phone before configuration.

The parameters in the auto provision template are described as follows: features.hdmi_out.resolution =



features.video_min_framerate =

account.X.video.max_resolution =

To configure the maximum video resolution via web user interface:

Click Account -> Basic.

Vealink				Log Out
	Status Account Network	DSSKey Features	Settings	Directory Security
General Account	Account	Account 1 🔹	?	NOTE
	Proxy Require		0	Basic
Register	Local Anonymous	Off 🔹 🌔	0	The basic parameters for
Basic	Local Anonymous Rejection	Off 🔹	0	auministrator.
Codec	Send Anonymous Code	Off Code 👻	0	Proxy Require A special parameter just for Nortel server. If you login to
Advanced	On Code		0	Nortel server, the value should
Advanced	Off Code		0	be: com.nortelnetworks.firewall
	Send Anonymous Rejection Code	Off Code 👻	0	You can click here to get
	On Code		0	more guides.
	Off Code		0	
	Missed Call Log	Enabled 👻 🕻	0	
	Auto Answer	Disabled 👻	0	
	Ring Type	Common 👻	0	
	Video Resolution	1920x1080 -	0	
	Confirm	Cancel		

To configure the output resolution of external monitor via web user interface: Click Settings -> Video.

					Log Out
Yealink 17496	Status Account Netw	ork DSSKey	Features	Settings	Directory Security
Preference	Video Settings 🕜				NOTE
Time & Date	Video Active Auto Start Video	Enabled	- 0		Video The video parameters for administrator
Call Display	Auto Answer Video Mute	Disabled	• 0		aurimisciacoi.
Upgrade	Uplink Bandwidth	Auto	• 0		You can click here to get more guides.
Auto Provision	Downlink Bandwidth	Auto	• 0		3
Configuration	Video Conferencing Features Output Resolution	Disabled	- (2)	1	
Dial Plan	Display	Auto	• 0		
Voice	Confirm	1920 x 1080 60Hz 1280 x 1024 60Hz			
Ring		1280 x 720 60Hz 720 x 480 60Hz 640 x 480 60Hz			
Tones				-	
Softkey Layout					
TR069					
Voice Monitoring					
SIP					
Camera					
Video					

5. Added the feature of Video Conferencing.

Description: You can enable video conferencing feature to be able to configure or use the following features:



- Setup Wizard
- Cloud Account Registration
- H.323 Account Registration
- Cloud Phone Book
- Direct IP Call
- Auto Answer
- Receiving Presentations
- Virtual Meeting Rooms (VMR)
- Call Stats
- Videoconferencing Key

The parameters in the auto provision template are described as follows:

vcaccount.enable =

To configure video conferencing feature via web user interface:

Click Settings -> Video.

Valink			Log Out
	Status Account Network	DSSKey Features	Settings Directory Security
Preference	Video Settings 🕜		NOTE
Time & Date	Video Active Auto Start Video	Enabled	Video The video parameters for
Call Display	Auto Answer Video Mute	Disabled 👻 🕜	administrator.
Upgrade	Uplink Bandwidth	Auto 🗸 🕜	You can click here to get
Auto Provision	Downlink Bandwidth	Auto 🔹 🤇	more guides.
Confirmation	Video Conferencing Features	Enabled 👻 🕜	
Connguration	Output Resolution		
Dial Plan	Display	No devices •	
Voice	Confirm	Cancel	
Ring			
Tones			
Softkey Layout			
TR069			
Voice Monitoring			
SIP			
Camera			
Video			

To configure video conferencing feature via phone user interface:

Tap 🚼 -> Basic -> Video Setting.



Tario 8638	Video Setting		17:37 Tue, Dec 27
Change PIN	1. Video Enable:	Enabled	
8 Bluetooth	2. Auto Start Video:	Enabled	
察 Wi-Fi	3. Auto Answer Video Mute:	Disabled	
🚱 Camera Setting	4. Uplink Bandwidth:	Auto	
■ Video Setting	5. Downlink Bandwidth:	Auto	
Site Name	6. Video Conferencing Fe	Enabled	
👻 HDMI			
5	Save		*

6. Added the feature of Videoconferencing Key.

Description: You can use videoconferencing key to make a video call, to set up a video conference or add a party to the conference. Before configuring a videoconferencing key, you should enable the video conferencing feature first.

The parameters in the auto provision template are described as follows:

linekey.X.type =87

To configure a videoconferencing key via phone user interface:

T1000	DssKey 4	15:20 Mon, Dec 19
😂 Call Forward	1. Туре:	Videoconferencing
🕲 Call Waiting	2. Account ID:	Line 1
A Auto Answer	3. Label:	
DSS Keys	4. IP/URI:	192.168.0.1
OND		
Intercom		
Anonymous		
÷	Save	*

Tap 🔛 -> Features -> DSS Keys.

To configure a videoconferencing key via web user interface:



Click **DSSKey** -> Line key.

alink							Log Ou
ATTE I 1 496	Status	Account	Network	DSSKey	Features	Settings	Directory Security
ne Kev1-11	Label Length	Default	•				NOTE
,.	Key	Туре	Value	Label	Line	Extension	Key Type
ne Key12-20	Line Key1	Line 👻		888882536	Line 1	•	The free function key 'Types' Speed Dial, Key Event,
ne Key21-29	Line Key2	Line 👻		曾洵	Line 2	-	Intercom.
ogramable Key	Line Key3	Videoconferen			Line 3	•	Key Event Key events are predefined
	Line Key4	e Key4 Hold	^		Line 4	•	shortcuts to phone and call functions.
	Line Key5	ReCall			Line 5	-	Intercom
	Line Key6	SMS Record			Line 6	•	 Enable the 'Intercom' mode a it is useful in an office
	Line Key7	Multicast Paging			Line 7	-	 environment as a quick access to connect to the operator or
	Line Key8	Group Listening Private Hold			Line 8	•	the secretary.
	Line Key9	ACD			Line 9	-	_
	Line Key10	Zero Touch URL			Line 10	•	 You can click here to get more guides.
	Line Key11	Directory Paging List	=		Line 11	•	
		Mobile Account 3rd-Party VMR	onfirm	Cancel			
		Videoconferencing	*				

Veglink							Log Out
	Status	Account	Network	DSSKey	Features	Settings	Directory Security
Line Key1-11	Label Length	Default	•				NOTE
	Кеу	Туре	Value	Label	Line	Extension	Кеу Туре
Line Key12-20	Line Key1	Line 🔹		888882536	Line 1	•	The free function key 'Types' Speed Dial, Key Event.
Line Key21-29	Line Key2	Line -		曾洵	Line 2	•	Intercom.
Programable Key	Line Key3	Videoconferen 👻			Auto	•	Key Event Key events are predefined
	Line Key4	Line 🗸			Line 4	•	 shortcuts to phone and call functions.
	Line Key5	Line 👻			Line 5	•	Intercom
	Line Key6	Line 🔹			Line 6	•	 Enable the 'Intercom' mode and it is useful in an office
	Line Key7	Line 🗸			Line 7	•	 environment as a quick access to connect to the operator or
	Line Key8	Line 🗸			Line 8	•	the secretary.
	Line Key9	Line 👻			Line 9	•	
	Line Key10	Line -			Line 10	•	 You can click here to get more guides.
	Line Key11	Line 💌			Line 11	•	-
			Confirm	Cancel			

7. Added the feature of Virtual Meeting Rooms (VMR).

Description: You can access Virtual Meeting Rooms(VMR) using SIP VP-T49G IP phone, whilst benefiting from both the hardware features provided by Yealink, such as 1080p HD video and audio, and software features provided by Zoom/BlueJeans/Pexip/Mind, including high end customization & interoperability.

If you have registered a Cloud account, you can dial out the meeting ID to join the VMR.

If you haven't registered a Cloud account, you can configure a 3rd-party VMR key to quickly join a VMR. It is only applicable to Zoom/BlueJeans/Custom platform. **The parameters in the auto provision template are described as follows:**



linekey.X.type =86

To configure a 3rd-party VMR key via phone user interface:

2 1000	DssKey 3		20:21 Tue, Dec 06
Call Forward	1. Type:	3rd-party VMR	
Call Waiting	2. Platform:	Zoom	
A Auto Answer	3. Label:	Zoom	
DSS Keys	4. Meeting ID:	955488426	
OND	5. IP/FQDN:	zoomcrc.com	
Intercom			
🖹 Anonymous			
5			*

To configure a 3rd-party VMR key via web user interface:

```
Click DSSKey -> Line key
```

							Log Out
Yealink 1496	Status	Account	Network	DSSKey	Features	Settings	Directory Security
Line Key1-11	Label Length	Default	•				NOTE
	Key	Туре	Value	Label	Line	Extension	Key Type
Line Key12-20	Line Key1	Conference 👻			N/A	-	The free function key 'Types'
Line Key21-29	Line Key2	Transfer Hold	*	曾洵	Line 2	•	Intercom.
Programable Key	Line Key3	ReCall			Line 3	•	Key Event Key events are predefined
	Line Key4	Record			Line 4	•	 shortcuts to phone and call functions.
	Line Key5	URL Record Multicast Paging			Line 5	•	Intercom
	Line Key6	Group Listening Private Hold			Line 6	•	 Enable the 'Intercom' mode and it is useful in an office
	Line Key7	ACD			Line 7	•	 environment as a quick access to connect to the operator or
	Line Key8	URL		2122	Line 8	•	- the secretary.
	Line Key9	Directory			Line 9	•	
	Line Key10	Paging List Mobile Account			Line 10	•	 You can click here to get more guides.
	Line Key11	3rd-Party VMR Videoconferencing			Line 11	•	
		(Confirm	Cance	el		



www.yealink.com

							Log Out
YEAIINK T49G	Status	Account	Network	DSSKey	Features	Settings	Directory Security
Line Key1-11	Label Length	Default	•				NOTE
	Кеу	Туре	Value	Label	Line	Extension	Кеу Туре
Line Key12-20	Line Key1	3rd-Party VMR 👻			custom		The free function key 'Types' Speed Dial, Key Event,
Line Key21-29	Line Key2	Line 👻		曾洵	zoom		Intercom.
Programable Key	Line Key3	Line 👻			bluejeans Line J	p	Key Event Key events are predefined
	Line Key4	Line 👻			Line 4	-	 shortcuts to phone and call functions.
	Line Key5	Line 👻			Line 5	•	Intercom
	Line Key6	Line 👻			Line 6	•	 Enable the 'Intercom' mode and it is useful in an office
	Line Key7	Line 👻			Line 7	-	 environment as a quick access to connect to the operator or
	Line Key8	Line 👻		2122	Line 8	•	 the secretary.
	Line Key9	Line 👻			Line 9	•	T
	Line Key10	Line 🔹			Line 10	•	 You can click here to get more guides.
	Line Key11	Line 👻			Line 11	•	-
			Confirm	Cance	el		

6. Optimization Descriptions

1. Optimized the feature that you can use onscreen keyboard in dialing screen.

() 8638				17 38 Tue, Dec 27
Yealink 2531 2531				
Yealink 2271	1	2 ABC	3 DEF	
Yealink 2213				<u> </u>
Yealink 2963	4 сні	5 ж	6 мио	Send
Yealink 2952 2952	7 PQRS	8 TUV	9 wxyz	Kardaard
7020 7020				Reyboard
7018 7018	*.@	0	#send	DSS Key
5	K istory	1 Directory	Keypad	A



2. Optimized the dialing modes.

Description: You can dial using the phone number/SIP URI/IP address/name (User Name for SIP account, H.323 Name for H.323 account). The maximum SIP URI length is 32 characters. For example, SIP URI: 3606@sip.com.

7. Configuration Parameters Enhancements

Auto Provis	Auto Provision Template Flies Change Log									
Firmware Version: [51.21.0.1]-[51.21.0.5]										
	Provisioni	ng syntax								
F	Comparise	on	Permitted	Default	A	Description				
Function 51.21	51.21.0.	51.21.0.		Value	Action	Description	FIIE			
	1	51.22.0.5								
Dual-Strea m Protocol (X ranges from 1 to 16)		account.17.bf cp.enable	0 or 1	1	Add	It enables or disables the BFCP protocol for sharing content in SIP IP calls. 0-Disabled 1-Enabled	MAC.cfg			
Dual-Strea m Protocol (X ranges from 1 to 16)		account.X.bfc p.enable	0 or 1	1	Add	It enables or disables the BFCP protocol for Cloud account X (except Yealink Cloud account).	MAC.cfg			



					0-Disabled	
					1-Enabled	
					It enables or disables the H.323 account	
					0-Disabled	
H.323	account_h32	0 or 1	1	Add	1-Enabled	common.
Account	3.enable				Note: It works only if the value of the parameter "features.h323_protocol.en able" is set to 1 (Enabled).	Стд
H.323 Account	account_h32 3.name	String within 99 characters	Blank	Add	It specifies the name that gatekeepers and gateways use to identify this IP phone.	common. cfg
H.323 Account	account_h32 3.extension	String within 32 characters	Blank	Add	It specifies the extension that gatekeepers and gateways use to identify this IP phones	common. cfg
					It configures the gatekeeper	
					mode.	
					0-Disabled	
					1-Auto	
					2-Manual	
H.323 Account	account_h32 3.gk mode	0, 1 or 2	0	Add	If it is set to 0 (Disabled), the IP phone will not use a gatekeeper.	common. cfg
	0 _				If it is set to 1 (Auto), the IP phone will automatically discovers a gatekeeper.	0
					If it is set to 2 (Manual), you should specify the IP address and port for the gatekeeper manually.	
					It configures the IP address	
	account_h32	String			of the gatekeeper Y.	common
H.323 Account	3.gk_server.Y. address	within 256 characters	Blank	Add	Note: It works only if the value of the parameter "account_h323.gk_mode" is set to 2 (Manual).	common.
H.323	account_h32 3.gk_serverY	Interger from 0 to	1719	Add	It configures the port of the gatekeeper Y.	common. cfg



YEALINK NETWORK TECHNOLOGY CO.,LTD.

					www.yealink.com	
	port	65535			Note: It works only if the value of the parameter "account_h323.gk_mode" is set to 2 (Manual).	
H.323 Account	account_h32 3.gk_auth.en able	0 or 1	0	Add	It enables or disables gatekeeper authentication. O-Disabled 1-Enabled If it is set to 1 (Enabled), the gatekeeper ensures that only trusted H.323 IP phones are allowed to access the gatekeeper.	common. cfg
H.323 Account	account_h32 3.gk_userna me	String within 99 characters	Blank	Add	It specifies the user name for gatekeeper authentication. Note: It works only if the value of the parameter "account_h323.gk_auth.ena ble" is set to 1 (Enabled).	common. cfg
H.323 Account	account_h32 3.gk_passwor d	String within 99 characters	Blank	Add	It specifies the password for gatekeeper authentication. Note: It works only if the value of the parameter "account_h323.gk_auth.ena ble" is set to 1 (Enabled).	common. cfg
H.323 Settings	account_h32 3.h323_port	Integer from 0 to 65535	1720	Add	It specifies the monitor port for the H.323 IP call.	common. cfg
H.323 Settings	account_h32 3.auto_answe r	0 or 1	0	Add	It enables or disables auto answer feature for H.323 calls. O-Disabled 1-Enabled If it is set to 1 (Enabled), the IP phone can automatically answer an incoming H.323 call. Note: The IP phone cannot automatically answer the incoming H.323 call during a	common. cfg



YEALINK NETWORK TECHNOLOGY CO.,LTD.

					www.ycannk.com	
					call even if auto answer is enabled.	
H.323 Settings	account_h32 3.tunneling.e nable	0 or 1	0	Add	It enables or disables the H.323 tunneling. O-Disabled 1-Enabled	common. cfg
H.323 Settings	account_h32 3.h460.enabl e	0 or 1	0	Add	It enables or disables H.460 firewall traversal feature. 0-Disabled 1-Enabled	common. cfg
H.323 Settings	account_h32 3.h235_type	0, 1 or 2	0	Add	It specifies the H.235 type for the H.323 calls. 0-Disabled 1-Optional 2-Compulsory If it is set to 0 (Disabled), the IP phone will not use H.235 in H.323 calls. If it is set to 1 (Optional), the IP phone will negotiate with the far site whether to use H.235. If it is set to 2 (Compulsory), the IP phone will compulsively use H.235 in H.323 calls.	common. cfg
NAT	network.stati c_nat.mode	0, 1 or 2	0	Add	It specifies the static NAT type. 0-Disabled 1-Manual 2-Auto If it is set to 0 (Disabled), the IP phone does not use the static NAT feature. If it is set to 1 (Manual), the IP phone uses the manually configured NAT public address. If it is set to 2 (Auto), the IP	common. cfg



NAT

NAT

NAT

YEALINK NETWORK TECHNOLOGY CO., LTD.

www.yealink.com phone obtains the NAT public address from the Yealink-supplied server. It configures the NAT public address for the IP phone. Example: IP address network.static_nat.addr = network.stati common. or domain Add Blank 218.107.220.201 c nat.addr cfg name Note: It works only if the value of the parameter "network.static_nat.mode" is set to 1 (Manual). It displays the NAT public address automatically obtained from the **IP** address network.stati Yealink-supplied server. common. or domain Blank Add c nat.dynami Note: It works only if the cfg c_addr name value of the parameter "network.static_nat.mode" is set to 2 (Auto). It configures the route traversal type. 0-Auto 1-Compulsory If it is set to 0 (Auto), NAT works only when making a call to public network or receiving a call from the network.stati common. public network. c_nat.effect_t 0 or 1 0 Add cfg If it is set to 1 (Compulsory), ype NAT works when you are in multi-level intranet network to solve the one-way audio or video problem. Note: It works only if the value of the parameter "network.static_nat.mode" is set to 1 (Auto) or 2 (Auto). Intelligent network.intell common. It enables or disables the 0 or 1 Add Firewall igent_firewall 1 cfg intelligent firewall traversal Traversal traversal.en



	able				feature. 0-Disabled 1-Enabled	
VC Accounts	vcaccount.en able	0 or 1	1	Add	It enables or disables the video conferencing feature. 0-Disabled 1-Enabled	common. cfg
H.323 Settings	features.h323 _protocol.ena ble	0 or 1	1	Add	It enables or disables the H.323 protocol. O-Disabled 1-Enabled	common. cfg
H.323 Settings	h323.video_s dp_report_tw ice	0 or 1	0	Add	It enables or disables local early media feature. 0-Disabled 1-Enabled If it is set to 1 (Enabled), the IP phone will send video SDP twice during a call to solve the compatibility between Yealink device and certain devices.	common. cfg
H.323 Settings	h323.h239.en able	0 or 1	1	Add	It enables or disables the H.239 protocol for sharing content in H.323 calls. 0-Disabled 1-Enabled	common. cfg
H.323 Settings	h323.user_ca p.enable	0 or 1	1	Add	It configures the DTMF type for H.323 calls. 0-INBAND 1-Auto If it is set to 0 (INBAND), DTMF digits are transmitted in the voice band. If it is set to 1 (Auto), the IP phone automatically negotiates the way (INBAND, RFC2833 or SIP INFO) to transfer DTMF digits.	common. cfg



Output Resolution	features.hdmi _out.resoluti on	0, 1920x1080f 60, 1280x720f6 0, 720x480f60 , 640x480f60	0	Add	It configures the output resolution of external monitor. 0-Auto (automatically select the highest resolution supported by the external monitor) 1920x1080f60-1920 × 1080 60Hz 1280x720f60-1280 × 720 60Hz 720x480f60-720 × 480 60Hz 640x480f60-640 × 480 60Hz	common. cfg
Output Resolution (X ranges from 1 to 16)	account.X.vid eo.max_resol ution	1920x1080, 1280x720, 704x576, 352x288	1920x10 80	Add	It configure the maximum video resolution of IP phone for SIP account X.	MAC.cfg
Audio Advanced	phone_settin g.audio_code c_byte_order. enable	0 or 1	0	Add	It enables or disables the special audio codec byte sequence. Note: Different devices have different definition about how some Codecs are stored (Big-endian or little-endian), which may lead to the audio incompatibility problems between Yealink and certain devices. You can enable the special audio codec byte sequence feature to solve these incompatibility problems.	MAC.cfg
Cloud Settings (X ranges from 1 to 16)	cloud.account .X.dtmf.type	0, 1, 2 or 3	1	Add	It configures the DTMF type for Cloud account X. 0-INBAND 1-RFC 2833 2-SIP INFO 3-RFC2833 + SIP INFO If it is set to 0 (INBAND),	MAC.cfg



					DTMF digits are transmitted in the voice band. If it is set to 1 (RFC 2833), DTMF digits are transmitted by RTP Events compliant to RFC 2833. If it is set to 2 (SIP INFO), DTMF digits are transmitted by the SIP INFO messages. If it is set to 3 (RFC2833 + SIP INFO), DTMF digits are transmitted by RTP Events compliant to RFC 2833 and the SIP INFO messages.	
Cloud Settings (X ranges from 1 to 16)	cloud.account .X.dtmf.dtmf_ payload	1, 2 or 3	1	Add	It configures the value of DTMF payload for Cloud account X. Note: It works only if the value of parameter "cloud.account.X.dtmf.type" is set to 1 (RFC2833) or 3 (RFC2833 + SIP INFO).	MAC.cfg
Cloud Settings (X ranges from 1 to 16)	cloud.account .X.dtmf.info_t ype	Integer from 96 to 127	101	Add	It configures the DTMF info type for Cloud account X. 1-DTMF-Relay 2-DTMF 3-Telephone-Event Note: It works only if the value of parameter "cloud.account.X.dtmf.type" is set to 2 (SIP INFO) or 3 (RFC2833 + SIP INFO).	MAC.cfg
Cloud Settings (X ranges from 1 to 16)	cloud.account .X.keep_alive _interval	Integer from 15 to 214748364 7	30	Add	It configures the keep-alive interval (in seconds) for Cloud account X (except Yealink Cloud account). Example: cloud.account.1.keep_alive_ interval = 60	MAC.cfg
Cloud Settings	cloud.account .X.srtp_encry	0, 1 or 2	0	Add	It configures whether to use	MAC.cfg



(X ranges	ption				voice/video encryption	
from 1 to					service for Cloud account X	
16)					(except Yealink Cloud	
					account).	
					0-Disabled	
					1-Optional	
					2-Compulsory	
					If it is set to 0 (Disabled) or 1 (Optional), the IP phone will negotiate with the other IP phone what type of encryption to utilize for the session. If it is set to 2 (Compulsory), the IP phone is forced to use SRTP during a call.	
Dual-Strea m Protocol (X ranges from 1 to 16)	cloud.account .X.bfcp.enabl e	0 or 1	1	Add	It enables or disables the BFCP protocol for Cloud account X (except Yealink Cloud account). 0-Disabled 1-Enabled	MAC.cfg
Cloud Account (X ranges from 1 to 16)	cloud.account .X.type	Integer from 0 to 5	1	Add	It configures the type of Cloud account X. O-Custom 1-Yealink 2-Zoom 3-Pexip 4-Bluejeans 5-Mind	MAC.cfg
Cloud Account (X ranges from 1 to 16)	cloud.account .X.label	String within 99 characters	Blank	Add	It configures the label to be displayed on the touch screen for Zoom/Bluejeans/Mind/Cust om Cloud account X. Note: It is a required parameter for Custom Cloud account.	MAC.cfg
Cloud Account	cloud.account .X.user_name	String within 99	Blank	Add	It configures the register user name for	MAC.cfg



(X ranges from 1 to 16)		characters			Custom/Yealink/Pexip Cloud account X.	
Cloud Account (X ranges from 1 to 16)	cloud.account .X.alias	String within 99 characters	Blank	Add	It configures the alias to be displayed on the touch screen for Pexip Cloud account X.	MAC.cfg
Cloud Account (X ranges from 1 to 16)	cloud.account .X.password	String within 99 characters	Blank	Add	It configures the register password for Custom/Yealink/Pexip Cloud account X.	MAC.cfg
Cloud Account (X ranges from 1 to 16)	cloud.account .X.register_na me	String within 99 characters	Blank	Add	It configures the user name for register authentication for Custom Cloud account X.	MAC.cfg
Cloud Account (X ranges from 1 to 16)	cloud.account .X.sip_server. address	String within 256 characters	Blank	Add	It configures the IP address or domain name of the Cloud server for Cloud account X (except Yealink Cloud account). Example: cloud.account.2.sip_server.a ddress = zoomcrc.com	MAC.cfg
Cloud Account (X ranges from 1 to 16)	cloud.account .X.sip_server.t ransport_typ e	Integer from 0 to 4	1	Add	It configures the type of transport protocol for Cloud account X (except Yealink Cloud account). 0-UDP 1-TCP 2-TLS 3-DNS-NAPTR	MAC.cfg
Output Resolution	features.vide o_min_frame rate	Integer from 10 to 30	30	Add	It configures the minimum frame rate of sending video image during the call.	common. cfg
Power Saving	features.pow er_saving.offi ce_hour.idle_ timeout	For SIP VP-T49G: Interger from 1 to	For SIP VP-T49G: The default	Add	It configures the time (in minutes) to wait in the idle state before IP phone enters power-saving mode during	common. cfg



_						
		240 For SIP-T48G/T 46G/T29G: Interger from 1 to 600	value is 120. ForSIP-T 48G/T46 G/T29G: The default value is 480.		the office hours.	
Power Saving	features.pow er_saving.off _hour.idle_ti meout	Integer from 1 to 10	10	Add	It configures the time (in minutes) to wait in the idle state before IP phone enters power-saving mode during the non-office hours.	common. cfg
Power Saving	features.pow er_saving.use r_input_ext.i dle_timeout	Integer from 1 to 20	10	Add	It configures the time (in minutes) to wait in the idle state before IP phone enters power-saving mode when using the IP phone (for example, press a key on the phone, pick up/hang up the handset or tap the touch screen (only applicable to SIP VP-T49G and SIP-T48G)). Note: If you use the IP phone, the idle timeout that applies (User input extension Idle TimeOut or Office Hour/Off Hour Idle TimeOut) is the timeout with the highest value. If the phone has an incoming call or message, the User input extension Idle TimeOut is ignored.	common. cfg
Power Saving	features.pow er_saving.offi ce_hour.mon day	Integer from 0 to 23, Integer from 0 to 23	For SIP VP-T49G: The default value is 7,19 For	Add	For SIP VP-T49G: It configures the starting time and ending time of the day's office hour on Monday. Starting time and ending	common. cfg



	<u> </u>				www.yealink.com	
			SIP-T48G /T46G/T 29G: The default value is 7,12		time are separated by a comma. For SIP-T48G/T46G/T29G: It configures the starting time and duration of the day's office hour on Monday. Starting time and duration are separated by a comma.	
Power Saving	features.pow er_saving.offi ce_hour.tues day	Integer from 0 to 23, Integer from 0 to 23	For SIP VP-T49G: The default value is 7,19 For SIP-T48G /T46G/T 29G: The default value is 7,12	Add	For SIP VP-T49G: It configures the starting time and ending time of the day's office hour on Tuesday. Starting time and ending time are separated by a comma. For SIP-T48G/T46G/T29G: It configures the starting time and duration of the day's office hour on Tuesday. Starting time and duration are separated by a comma.	common. cfg
Power Saving	features.pow er_saving.offi ce_hour.wedn esday	Integer from 0 to 23, Integer from 0 to 23	For SIP VP-T49G: The default value is 7,19 For SIP-T48G /T46G/T 29G: The default value is 7,12	Add	For SIP VP-T49G: It configures the starting time and ending time of the day's office hour on Wednesday. Starting time and ending time are separated by a comma. For SIP-T48G/T46G/T29G: It configures the starting time and duration of the day's office hour on Wednesday. Starting time and duration are separated by a comma.	common. cfg
Power	features.pow	Integer	For SIP	Add	For SIP VP-T49G:	common.



Saving	er_saving.offi	from 0 to	VP-T49G:		It configures the starting	cfg
	ce_hour.thurs	23, Integer	The		time and ending time of the	
	day	from 0 to	default		day's office hour on	
		23	value is		Thursday.	
			7,19		Starting time and ending	
			For		time are separated by a	
			SIP-T48G		comma.	
			/T46G/T		For SIP-T48G/T46G/T29G:	
			The		It configures the starting	
			default		time and duration of the	
			value is		day's office hour on	
			7,12		Thursday.	
					Starting time and duration	
					are separated by a comma.	
			For SIP		For SIP VP-T49G:	
			VP-T49G:		It configures the starting	
			The		time and ending time of the	
			default		day's office hour on Friday.	
	c .	Integer	value is		Starting time and ending	
Dowor	features.pow	from 0 to	7,19 For		time are separated by a	
Saving	er_saving.om	23, Integer		Add	comma.	common.
Javing	v	from 0 to	/T46G/T		For SIP-T48G/T46G/T29G:	CIE
	y	23	29G:		It configures the starting	
			The		time and duration of the	
			default		day's office hour on Friday.	
			value is		Starting time and duration	
			7,12		are separated by a comma.	
			For SIP		For SIP VP-T49G:	
			VP-T49G:		It configures the starting	
			The		time and ending time of the	
			default		day's office hour on	
		Integer	value is		Saturday.	
Devuer	teatures.pow	from 0 to	7,7 5er		Starting time and ending	
Power	er_saving.offi	23, Integer	FOR	Add	time are separated by a	common.
Saving	dav	from 0 to) /табс/т		comma.	CIR
		23	29G:		For SIP-T48G/T46G/T29G:	
			The		It configures the starting	
			default		time and duration of the	
			value is		day's office hour on	
			7,0		Saturday.	



YEALINK NETWORK TECHNOLOGY CO., LTD.

-						www.yealink.com	
						Starting time and duration	
						are separated by a comma.	
Power Saving		features.pow er_saving.offi ce_hour.sund ay	Integer from 0 to 23, Integer from 0 to 23	For SIP VP-T49G: The default value is 7,7 For SIP-T48G /T46G/T 29G: The default value is 7,0	Add	For SIP VP-T49G: It configures the starting time and ending time of the day's office hour on Sunday. Starting time and ending time are separated by a comma. For SIP-T48G/T46G/T29G: It configures the starting time and duration of the day's office hour on Sunday. Starting time and duration are separated by a comma.	common. cfg
Call Display	phone_set ting.conta ct_photo_ display.en able		0 or 1	1	Delete	It enables or disables the IP phone to display the contact avatar when it receives an incoming call, dials an outgoing call or engages in a call. 0-Disabled 1-Enabled	common. cfg
Cloud	cloud.ena ble		0 or 1	1	Delete	It enables or disables the Cloud feature for the IP phone. 0-Disabled 1-Enabled	common. cfg

8. Configuration Parameters Update

Functio n	Provisioning syntax	Permitted Values Comparison		Default	Description	File
		51.21.0.1	51.22.0.5	value		
NAT	account.X.nat.na t_traversal	0 or 1	0, 1 or 2	0	It configures the NAT traversal type for account X. O-Disabled	MAC.cfg



					in in gean in ite	ſ
					1-STUN 2-StaticNat (only applicable to SIP VP-T49G) Note: STUN works only if the value of the parameter "sip.nat_stun.enable" is set to 1 (Enabled). StaticNat works only if the value of the parameter "network.static_nat.mode" is set to 1 (Manul) or 2 (Auto).	
SIP IP Call	account.17.nat.n at_traversal	0 or 1	0, 1 or 2	0	It configures the NAT traversal type for SIP IP call. O-Disabled 1-Enabled 2-StaticNat Note: STUN works only if the value of the parameter "sip.nat_stun.enable" is set to 1 (Enabled). StaticNat works only if the value of the parameter "network.static_nat.mode" is set to 1 (Manul) or 2 (Auto).	MAC.cfg
LineKeyX	linekey.X.line	Integer from 1 to 16	Integer from 1 to 16, 150	When X=1, the default value is 1. When X=2, the default value is 2. When X=3, the default value is 3. When X=16, the default value is 16.	It configures the desired line to apply the key feature. 1-Line 1 2-Line 2 3-Line 3 16-Line 16 150-H.323 account Permitted Value: 1 to 16, 150 (for T49G) 1 to 16 (for T48G/T46G/T29G) 1 to 12 (for T42G)	common. cfg



YEALINK NETWORK TECHNOLOGY CO., LTD.

	ICUI				www.yealink.com	_
					1 to 6 (for T41P/T27P) 1 to 3 (for T40P/T23P/T23G)	
					1 to 2 (for T21(P) E2)	
Jitter Buffer	voice.jib.min	Integer from 0 to 400	Integer from 20 to 300	60	It configures the minimum delay time (in milliseconds) of jitter buffer. Note: It works only if the value of the parameter "voice.jib.adaptive" is set to 1 (Adaptive).	common. cfg
Jitter Buffer	voice.jib.max	Integer from 0 to 400	Integer from 20 to 300	240	It configures the maximum delay time (in milliseconds) of jitter buffer. Note: It works only if the value of the parameter "voice.jib.adaptive" is set to 1 (Adaptive).	common. cfg
Jitter Buffer	voice.jib.normal	Integer from 0 to 400	Integer from 20 to 300	120	It configures the normal delay time (in milliseconds) of jitter buffer. Note: It works only if the value of the parameter "voice.jib.adaptive" is set to 0 (Fixed).	common. cfg

9. Default Value Setting Changes

Default Value Factory Setting Change Log						
Function	Provisioning	Description	Default Value of Factory Setting			
	syntax		51. 21.0.5	51.22.0.5		
		It configures the time (in	For SIP VP-T49G:	For SIP VP-T49G:		
		seconds) to wait in the idle	The default value is	The default value is		
		state before the screen	1800.	600.		
Screen	screensaver.wait_ti	saver starts.	For	For		
saver	me	0-Never	SIP-T48G/T46G/T29	SIP-T48G/T46G/T29		
		15-15s	G:	G:		
		30-30s	The default value is	The default value is		
		60-1min	0.	0.		



		120-2min		
		300-5min		
		600-10min		
		1800-30min		
	network.vlan.pc_po rt_mode	It configures the way the IP		
		phone processes packets		
		for the PC (LAN) port when		
		VLAN is enabled on the PC		
		(LAN) port.		
		0-when packets are sent		
		from the PC port to the		
		Internet port, the IP phone		
		will forward the packets		
		directly.		
		1-when packets are sent		
Notwork A		from the PC port to the		
dvanced		Internet port, and there is	0	1
		no VLAN tag in the packet,		
		the IP phone will tag the		
		packet with the configured		
		tag for the PC port and then		
		forward it.		
		Note: When packets are		
		sent from the Internet port		
		to the PC port, remove the		
		packet's tag if it is the same		
		as the configured tag for		
		the PC port, else forward		
		the packets directly.		