

Yealink



Yealink VC800&VC500 Full HD Video Conferencing System User Guide

Version 31.10
Jan.2018

Copyright

Copyright © 2018 YEALINK (XIAMEN) NETWORK TECHNOLOGY

Copyright © 2018 Yealink (Xiamen) Network Technology CO., LTD. All rights reserved. No parts of this publication may be reproduced or transmitted in any form or by any means, electronic or mechanical, photocopying, recording, or otherwise, for any purpose, without the express written permission of Yealink (Xiamen) Network Technology CO., LTD. Under the law, reproducing includes translating into another language or format.

When this publication is made available on media, Yealink (Xiamen) Network Technology CO., LTD. gives its consent to downloading and printing copies of the content provided in this file only for private use but not for redistribution. No parts of this publication may be subject to alteration, modification or commercial use. Yealink (Xiamen) Network Technology CO., LTD. will not be liable for any damages arising from use of an illegally modified or altered publication.

Trademarks

Yealink®, the logo and the name and marks is trademark of Yealink (Xiamen) Network Technology CO., LTD, which are registered legally in China, the United States, EU (European Union) and other countries.

All other trademarks belong to their respective owners. Without Yealink's express written permission, recipient shall not reproduce or transmit any portion hereof in any form or by any means, with any purpose other than personal use.

Warranty

(1) Warranty

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS GUIDE ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS GUIDE ARE BELIEVED TO BE ACCURATE AND PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF PRODUCTS.

(2) Disclaimer

YEALINK (XIAMEN) NETWORK TECHNOLOGY CO., LTD. MAKES NO WARRANTY OF ANY KIND WITH REGARD TO THIS GUIDE, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. Yealink (Xiamen) Network Technology CO., LTD. shall not be liable for errors contained herein nor for incidental or consequential damages in connection with the furnishing, performance, or use of this guide.

(3) Limitation of Liability

Yealink and/or its respective suppliers are not responsible for the suitability of the information contained in this document for any reason. The information is provided "as is", and Yealink does not provide any warranty and is subject to change without notice. All risks other than risks caused by use of the information are borne by the recipient. In no event, even if Yealink has been suggested the occurrence of damages that are direct, consequential, incidental, special, punitive or whatsoever (Including but not limited to loss of business profit, business interruption or loss of business information), shall not be liable for these damages.

End User License Agreement

This End User License Agreement ("EULA") is a legal agreement between you and Yealink. By installing, copying or otherwise using the Products, you: (1) agree to be bounded by the terms of this EULA, (2) you are the owner or an authorized user of the device, and (3) you represent and warrant that you have the right, authority and capacity to enter into this agreement and to abide by all its terms and conditions, just as if you had signed it. The EULA for this product is available on the Yealink Support page for the product.

Patent Information

China, the United States, EU (European Union) and other countries are protecting one or more patents of accompanying products and/or patents being applied by Yealink.

Customer Feedback

We are striving to improve our documentation quality and we appreciate your feedback. Email your opinions and comments to DocsFeedback@yealink.com.

Technical Support

Visit Yealink WIKI (<http://support.yealink.com/>) for the latest firmware, guides, FAQ, Product documents, and more. For better service, we sincerely recommend you to use Yealink Ticketing system (<https://ticket.yealink.com>) to submit all your technical issues.

GNU GPL INFORMATION

Yealink VC800/VC500 video conferencing system firmware contains third-party software under the GNU General Public License (GPL). Yealink uses software under the specific terms of the GPL. Please refer to the GPL for the exact terms and conditions of the license.

The original GPL license, source code of components licensed under GPL and used in Yealink products can be downloaded online:

<http://www.yealink.com/GPLOpenSource.aspx?BaseInfoCatelId=293&NewsCatelId=293&CatelId=293>.

About This Guide

Thank you for choosing the Yealink VC800&VC500 Full HD video conferencing system. It is an all-in-one unit that supports 1080P-full HD video conferencing and includes outstanding features such as good compatibility, easy deployment and intelligent network adaptability. VC800 is the best choice for middle-to-large enterprise, and VC500 is the best choice for SME. The Yealink VC800&VC500 Full HD video conferencing system is designed to help enterprises organize video conferences easily and efficiently. Users can expect to enjoy the high-quality video conferencing experience very cost-effectively.

This guide provides everything you need to start using your new video conferencing system quickly. First, verify with your system administrator that the IP network is ready for system configuration. Also be sure to read the **Overview** and **Getting Started** sections in this guide before you set up and use the VC800/VC500 video conferencing system.

Chapters in This Guide

Topics provided in this guide include:

- Chapter 1 [Overview](#)
- Chapter 2 [Getting Started](#)
- Chapter 3 [Customizing the VC800/VC500 Video Conferencing System](#)
- Chapter 4 [Using the VC800/VC500 Video Conferencing System](#)
- Chapter 5 [Video Conference Platform](#)
- Chapter 6 [Using the CPW90 Wireless Microphones](#)
- Chapter 7 [Using the CPE90 Wired Expansion Microphones](#)
- Chapter 8 [Using the VCC22 Video Conferencing Camera](#)
- Chapter 9 [Troubleshooting](#)

Documentations

The following table shows documentations available for the VC800/VC500 video conferencing system.

Note

You can download the latest documents online:

<http://support.yealink.com/documentFront/forwardToDocumentFrontDisplayPage>.

Name	Contents	Where found	Language
Yealink VC800 Full HD Video Conferencing System Quick Start Guide	System installation and network configuration	On the website/ In the package	English/Chinese
Yealink VC500 Full HD Video Conferencing Endpoint Quick Start Guide	System installation and network configuration	On the website/ In the package	English/Chinese
Yealink VCC22 Video Conferencing Camera Quick Start Guide	Camera installation	On the website	English/Chinese
Yealink VC800&VC500 Full HD Video Conferencing System User Guide	System/Web user interface settings Customizing and using the system	On the website	English/Chinese
Yealink VC800/VC500 Video Conference Room Deployment Solution	Conference room layout, environmental requirements and installation recommendations for the system	On the website	English/Chinese
Yealink VC800&VC500 Full HD Video Conferencing System Network Deployment Solution	Network deployment for the VC800/VC500 under various scenarios	On the website	English/Chinese

Name	Contents	Where found	Language
Yealink VC800&VC500 Full HD Video Conferencing System Administrator Guide	Functionality and configuration of the Yealink VC800/VC500	On the website	English/Chinese
Yealink VCR11 Remote Control Quick Reference Guide	Using the VCR11 Remote Control	On the website	English/Chinese
Yealink CPW90 Quick Start Guide	How to connect CPW90 wireless expansion microphones to CP960 conference phone	On the website	English/Chinese
Yealink CPW90 Wireless Microphones Quick Start Guide	How to connect CPW90 wireless microphones to VC500 video conference phone	On the website	English/Chinese
Yealink CP960 HD IP Conference Phone Quick Reference Guide	How to use CP960 conference phone.	On the website	English/Chinese

Typographic Conventions

Yealink documentations contain a few typographic conventions.

You need to know the following basic typographic conventions to distinguish types of in-text information:

Convention	Description
Bold	Highlights the web/phone user interface items such as menus, menu selections, soft keys, or directory names when they are involved in a procedure or user action (for example: Click on Setting -> General). Also used to emphasize text
Blue Text	Used for cross references to other sections within this documentation (for example: refer to Troubleshooting).

Convention	Description
<i>Blue Text in Italics</i>	Used for hyperlinks to Yealink resources outside of this documentation such as the Yealink documentations (for example: <i>Yealink VC800&VC500 Full HD Video Conferencing System Administrator Guide</i>).

You also need to know the following writing conventions to distinguish conditional information:

Convention	Description
->	Indicates that you need to select an item from a menu. For example, Settings->Basic Settings indicates that you need to select Basic Settings from the Settings menu.

Summary of Changes

This section describes the changes to this guide for each release and guide version.

Changes for Release 31, Guide Version 31.5

The following sections are new for this version:

- [Output Resolution](#) on page 48
- [Video Call Rate](#) on page 61
- [Silent Mode](#) on page 65
- [EQ Self-adaption](#) on page 67
- [Video Conference Management](#) on page 101
- [Appointing a Lecturer](#) on page 143
- [Using the VCC22 Video Conferencing Camera](#) on page 179

Major updates have occurred to the following sections:

- [Controlling Local Camera](#) on page 26
- [Screen Saver](#) on page 44
- [Configuring Camera Presets](#) on page 53
- [Audio Output](#) on page 65
- [Audio Input](#) on page 68
- [Controlling the Remote Camera](#) on page 113
- [VMR Mode Conference](#) on page 97
- [Configuring Video Recording](#) on page 115
- [Using the Yealink Meeting Server](#) on page 129

- [Using the CPW90 Wireless Microphones](#) on page 165

Changes for Release 30, Guide Version 30.8

Documentations of the newly released VC500 video conferencing endpoints are added.

The following section is new for this version:

- [VC500 Codec](#) on page 5

Major updates have occurred to the following sections:

- [Audio Settings](#) on page 63

Changes for Release 30, Guide Version 30.6

Major updates have occurred to the following sections:

- [Audio Setting](#) on page 63

Table of Contents

About This Guide v

Chapters in This Guide.....	v
Documentations	vi
Typographic Conventions.....	vii
Summary of Changes	viii
Changes for Release 31, Guide Version 31.5	viii
Changes for Release 30, Guide Version 30.8	ix
Changes for Release 30, Guide Version 30.6	ix

Table of Contents..... xi

Overview 1

System Component Instructions.....	1
VC800 Codec	1
VCC22 Video Conferencing Camera	3
VC500 Codec	5
VCH50 Video Conferencing Hub	7
CP960 Conference Phone.....	9
CPE90 Wired Expansion Microphones	11
CPW90 Wireless Microphone	11
VCR11 Remote Control	13
Icon Instructions	15
Icons on Display Device	15
Icons on CP960 Conference Phone	17
LED Instructions.....	18
User Interfaces.....	19
Web User Interface.....	19
Remote Control	20

Getting Started..... 23

Installing Batteries for the Remote Control.....	23
Remote Control Battery Safety Information.....	24
Powering the System On	24
Put the System to Sleep	24
Powering the System Off	25
Setup Wizard	26

Controlling Local Camera	26
Registration	27
Idle Screen	28
Idle Screen of VC800/VC500 Video Conferencing System.....	28
Idle Screen of CP960 Conference Phone.....	29
Navigating Menus and Fields.....	30
Navigating the Display Device.....	30
Navigating the CP960 Conference phone	31
Entering Data and Editing Fields.....	33
Entering Data and Editing Fields Using Remote Control.....	33
Entering Data and Editing Fields Using CP960	35
System Status	40

Customizing the VC800/VC500 Video Conferencing System ..43

General Settings	43
Automatic Sleep Time.....	43
Screen Saver.....	44
Backlight.....	46
Output Resolution	48
Site Name.....	48
Language.....	49
Time & Date.....	50
Configuring Camera Presets.....	53
Website Snapshot.....	58
Adjusting Zoom Level of the Display Device	59
Call Protocol.....	60
Video Call Rate.....	61
Custom Key Type	62
Audio Settings.....	63
Volume.....	63
Key Tone.....	64
Silent Mode.....	65
Audio Output.....	65
EQ Self-adaption.....	67
Audio Input	68
Directory	69
Adding Contacts.....	70
Editing Contacts	72
Deleting Contacts	74
Searching for Contacts	75
Call History Management.....	77
Viewing Call History.....	77
Deleting an Entry from the Call History List.....	79

Adding a Local Contact from the Call History List.....	81
Using the VC800/VC500 Video Conferencing System.....	83
Placing a Call.....	83
Placing a Call by Dialing a Number	83
Placing a Call from the Search Result	86
Placing a Call from the Directory	88
Placing a Call from the Call History	90
Answering or Rejecting Calls.....	91
Auto Answer	91
Do Not Disturb (DND)	93
Ending a Call	96
Conference Room Management.....	96
Conference Type	96
Meeting Password	99
Joining the Meeting	100
Video Conference Management.....	101
Initiating a Conference	101
Removing Conference Participants	104
Muting or Unmuting All Conference Participants	105
Muting or Unmuting a Conference Participant	107
Ending the Conference	108
Call Management.....	109
Call Mute	109
Call Statistics	109
Changing the Video Input Source.....	111
Far Control Near Camera.....	112
Presentation	114
Video Recording.....	114
Screenshot	117
Screen Layout.....	120
Network Quality Tip	124
Video Conference Platform.....	127
Using the Yealink VC Cloud Management Service Platform	127
Dialing Yealink Cloud Accounts	127
Using the Yealink Meeting Server	129
Dialing YMS Accounts.....	129
YMS Video Conference.....	130
Using the StarLeaf Cloud Platform.....	152
Dialing StarLeaf Cloud Numbers	153
Joining the StarLeaf Meeting	154

Using the Zoom Cloud Platform	155
Joining the Zoom Meeting.....	155
Using the BlueJeans Cloud Platform	157
Joining the BlueJeans Meeting.....	157
Using the Pexip Platform	158
Dialing Pexip Alias	158
Joining the Pexip Meeting.....	160
Using the Mind Platform.....	161
Joining the Mind Meeting	161
Using the Custom Platform.....	163
 Using the CPW90 Wireless Microphones.....	165
LED Instructions.....	165
Placing the CPW90	166
Charging the CPW90	167
Turning the CPW90 On or Off	168
Registering CPW90 with the CP960 Conference Phone.....	168
Registering CPW90 with the VC500 Video Conferencing Endpoint	170
Viewing CPW90 Information	173
Finding the Registered CPW90.....	174
Working Frequency	175
 Using the CPE90 Wired Expansion Microphones.....	177
Placing the CPE90	177
Muting or Unmuting the CPE90.....	177
 Using the VCC22 Video Conferencing Camera.....	179
Viewing Camera Information	179
LED Instructions.....	180
Controlling VCC22 Camera	180
Adjusting Camera Layout	182
Controlling the Multiple Remote Cameras.....	183
Layouts of Multiple Display Screens.....	183
Upgrading the Camera firmware	184
Resetting Camera.....	184
 Troubleshooting.....	187
System Diagnostics	187
General Issues.....	190
Camera Issues.....	192
Display Issues.....	193

Video & Audio Issues193

System Maintenance194

Regulatory Notices203

 Service Agreements203

 Limitations of Liability203

 Safety Instructions203

 Restriction of Hazardous Substances.....205

Appendix - Time Zones207

Overview

This chapter provides an overview of the VC800/VC500 video conferencing system. Topics include:

- [System Component Instructions](#)
- [Icon Instructions](#)
- [LED Instructions](#)
- [User Interfaces](#)

If you require additional information, or assistance to help you use your new system, contact your system administrator.

System Component Instructions


Before installing and using the VC800/VC500 video conferencing system, you need to be familiar with the following system components, including:

- [VC800 Codec](#)
- [VCC22 Video Conferencing Camera](#)
- [VC500 Codec](#)
- [VCH50 Video Conferencing Hub](#)
- [CP960 Conference Phone](#)
- [CPE90 Wired Expansion Microphones](#)
- [CPW90 Wireless Microphone](#)
- [VCR11 Remote Control](#)

VC800 Codec


VC800 codec compresses outgoing video and audio data, transmits this information to the far end, and decompresses incoming data. It supports 16:9 and 4:3 aspect ratios. It can be compatible with different audio devices, and can adapt to the display devices automatically.

Front Panel:




The HD camera supports 12 x optical zoom, white balance and automatic gain. The LED indicator in front of the camera indicates different statuses of the system. For more information, refer to [LED Instructions](#) on page 18.

The VC800 camera can be panned (± 100 degrees range), tilted (± 30 degrees range).



Rear panel:




	Port Name	Description
①	Line Out	Connects to an audio output device using an audio cable (3.5mm).
②	Line In	Connects to an audio input device using an audio cable (3.5mm).
③	USB	Inserts a USB flash drive to one of the two USB ports for storing screenshots, recording videos or capturing packets. Note: If two USB flash drives are connected, only the latter one can be identified.
④	VC Hub/Phone	<ul style="list-style-type: none"> If you want to share contents, connect this port to the

	Port Name	Description
		Codec port on the VCH50 video conferencing hub. <ul style="list-style-type: none">If you need an audio device, connect this port to the Internet port on the CP960 Conference phone.
⑤	HDMI 1	Connects to a display device for displaying video images.
⑥	HDMI 2	Connects to secondary display device for displaying video images.
⑦	Internet	Connects to the network device.
⑧	DC48V	Connects to the power source via a power adapter.
⑨	Reset Key	Resets the system to factory defaults.
⑩	Security Slot	Allows you to connect a universal security cable to VC800/VC500 codec, so you can lock it down. The system cannot be removed when locked.

VCC22 Video Conferencing Camera


You can connect up to 8 VCC22 video conferencing cameras to the VC800 video conferencing system. It supports 16:9 and 4:3 aspect ratios. It can adapt to the display devices automatically. VCC22 video conferencing cameras are not applicable to VC500 video conferencing endpoints.

Front panel:




The HD camera supports 12 x optical zoom, white balance and automatic gain. The LED indicator in front of the camera indicates different statuses of the camera. For more information, refer to [LED Instructions](#) on page 180.

The VCC22 can be panned (± 100 degrees range), tilted (± 30 degrees range).



Rear panel:




	Port Name	Description
①	HDMI Out	Connects to a display device for displaying shared content.
②	Camera	Connects to a PoE switch.
③	Reset Key	Resets the camera to factory defaults.
④	Security Slot	Allows you to connect a universal security cable to VCC22, so you can lock it down. The camera cannot be removed when locked.

For more information on how to use VCC22 video conferencing camera, refer to [Using the VCC22 Video Conferencing Camera](#) on page 179.

VC500 Codec


VC500 codec compresses outgoing video and audio data, transmits this information to the far end, and decompresses incoming data. It supports 16:9 and 4:3 aspect ratios. It can be compatible with different audio devices, and can adapt to the display devices automatically.


Front panel:



The HD camera supports 5 x optical zoom, white balance and automatic gain. The LED indicator in front of the camera indicates different statuses of the system. For more information, refer to [LED Instructions](#) on page 18.

The VC500 camera can be panned (± 60 degrees range), tilted (± 40 degrees range).




Rear panel:

	Port Name	Description
①	USB	<ul style="list-style-type: none"> Connects to an audio input device using a USB to Line-in adapter. Connects to an audio output device using a USB to Line-out adapter Inserts a DD10 dongle to one of the two USB ports for connecting the CPW90 wireless microphones. Inserts a USB flash drive to one of the two USB ports for storing screenshots, recording videos or capturing packets. <p>Note:</p> <ul style="list-style-type: none"> The DD10 dongle and USB flash drive can work at the same time. If two USB flash drives are connected, only the latter one can be identified.
②	VC Hub/Phone	<ul style="list-style-type: none"> If you want to share contents, connect this port to the Codec port on the VCH50 video conferencing hub. If you need an audio device, connect this port to the Internet port on the CP960 Conference phone.
③	DC48V	Connects to the power source via a power adapter.
④	HDMI 1	Connects to a display device for displaying video images.
⑤	HDMI 2	Connects to secondary display device for displaying video images.
⑥	Internet	Connects to the network device.

	Port Name	Description
⑦	Reset Key	Resets the system to factory defaults.
⑧	Security Slot	Allows you to connect a universal security cable to VC800/VC500 codec, so you can lock it down. The system cannot be removed when locked.


VCH50 Video Conferencing Hub

The left side of cable hub:




	Port Name	Description
①	Codec	Connects to the VC800/VC500 codec using a 7.5m network cable.

The right side of cable hub:



	Port Name	Description
②	Audio	Connects to the CP960 Conference phone using a 0.5m network cable.

The back of cable hub:




	Port Name	Description
③	MINI DP	Connects to a PC using Mini-DP cable for sharing contents.
④	HDMI	Connects to a PC using HDMI cable for sharing contents.
⑤	USB	Inserts a USB flash drive to the USB port for storing screenshots, recording videos or capturing packets.


CP960 Conference Phone

The CP960 Conference phone supports 360-degree audio pickup at a radius of up to 6 meters.

Connect the CP960 conference phone to the VC800/VC500 codec. It can work as an audio device for the system. You can also place calls, answer calls or view directory and history on the CP960 conference phone.




Hardware component instructions of the phone are:

	Item	Description
①	Three Internal Microphones	Supports 360-degree audio pickup at a radius of up to 6 meters.
②	Mute Touch Keys	<ul style="list-style-type: none"> • Indicate phone and call statuses. • Toggle mute feature.
③	Speaker	Provides hands-free (speakerphone) audio output.
④	Touch Screen	<p>5 inch (720 x 1280) capacitive (5 point) touch screen with two idle screens. Tap to select items and navigate menus. Shows information about calls, messages, time, date and other relevant data:</p> <ul style="list-style-type: none"> • Call information—caller ID, call duration • Icons (for example, ) • Missed call list or second incoming caller information • Prompt text (for example, "Save successfully!") • Time and date
⑤	Volume Touch Keys	Adjust the volume of the speaker, ringer or media.
⑥	HOME Touch Key	Returns to the idle screen.
⑦	Wired Mic Ports	Allow you to connect CPE90 to your phone (optional).
⑧	Internet Port	<ul style="list-style-type: none"> • Connect the VC Hub/Phone port on the VC800/VC500 codec. • Connect to the Audio port on the VCH50 video conferencing hub.
⑨	Security Slot	Allows you to connect a universal security cable to your phone so you can lock down your phone. The phone will not be removed after locked.
⑩	3.5mm Audio-out Port	This port is unavailable when CP960 conference phone works with the VC800/VC500.
⑪	Micro USB Port	This port is unavailable when CP960 conference phone works with the VC800/VC500.
⑫	USB Port	<ul style="list-style-type: none"> • Inserts a USB flash drive to one of the two USB ports for storing screenshots, recording videos or capturing packets. • Connects to the mini USB port on the charge cradle to charge the CPW90 wireless expansion microphones. <p>Note: If two USB flash drives are connected, only the latter one can be identified.</p>

CPE90 Wired Expansion Microphones

The CPE90 can work as expansion microphones of the CP960 conference phone. It supports 360-degree audio pickup at a radius of up to 3 meters. There is a mute button on its top. You can mute or unmute the CPE90 by tapping the mute button.




	Name	Description
①	Built-in Microphones	Support 360-degree audio pickup at a radius of up to 3 meters.
②	Mute Button	<ul style="list-style-type: none"> Indicates phone and call statuses. Toggles mute feature. For more information on the mute indicator LED, refer to LED Instructions on page 18.

For more information on how to use CPE90 wired expansion microphones refer to [Using the CPW90 Wireless Microphones](#) on page 177.

CPW90 Wireless Microphone

The CPW90 is a wireless microphone which can work as the audio input device. It supports 360-degree audio pickup at a radius of up to 3 meters. There are a mute button and a battery indicator LED on its top. You can mute or unmute the CPW90 by tapping the mute button. This mute button is also a switch. You can turn off the CPW90 if it is not in use for a long period of time.




	Name	Description
①	Battery Indicator LED	Indicates the battery information. For more information on the battery indicator LED, refer to LED Instructions on page 165.

	Name	Description
②	Built-in Microphone	Supports 360-degree audio pickup at a radius of up to 3 meters.
③	Mute Button	<ul style="list-style-type: none"> • Turns on or off the CPW90. • Mutes or unmutes the CPW90. For more information on the mute indicator LED, refer to LED Instructions on page 165.
④	Charging Slot	Put the CPW90 on the charging cradle to charge.

For more information on how to use CPW90 wireless microphone, refer to [Using the CPW90 Wireless Microphones](#) on page 165.

VCR11 Remote Control

The VCR11 remote control helps users organize conference easily with intuitive and efficient operation in all screens.



Hardware components of the remote control:


	Item	Description
①	Power Key	<ul style="list-style-type: none">Power the System On and Off.Puts the system to sleep or wakes the system.
②	Video Recording Key	Starts or stops recording video and audio.
③	Layout Key	Adjust layout during a video call.

	Item	Description
④	Custom Key	Assign predefined functions to this key. This key can be configured as a Presentation key (default), Input key, ScreenShot key or Mute Speaker key. For more information, refer to Custom Key Type on page 62.
⑤	Vol+	Increases the system volume.
⑥	Vol-	Decreases the system volume.
⑦	Zoom in Key	<ul style="list-style-type: none"> Increases the camera zoom. Increases the captured image magnifications. Behaves as page up in a multiple page list.
⑧	Zoom out Key	<ul style="list-style-type: none"> Decreases the camera zoom. Decreases the captured image magnifications. Behaves as page down in a multiple page list.
⑨	OK Key	Confirms actions or answers incoming calls.
⑩	Navigation Key	<ul style="list-style-type: none"> Navigate through menu items using the Up, Down, Left, and Right keys. Pan and tilt the camera to adjust the viewing angle.
⑪	Mute Key	Toggles mute feature.
⑫	Home Key	<ul style="list-style-type: none"> Returns to the idle screen when in the menu. Opens Talk Menu during a call.
⑬	Back Key	Returns to the previous menu.
⑭	Off-hook Key	<ul style="list-style-type: none"> Enters the pre-dialing screen. Places a call. Answers a call.
⑮	Delete key	<ul style="list-style-type: none"> Deletes one character at a time. Long press to delete all characters in the input field. Long press it for 2 seconds to start capturing packets and long press it for 2 seconds again to stop capturing packets.
⑯	On-hook Key	<ul style="list-style-type: none"> Ends a call or exits from a conference call. Returns to the idle screen.
⑰	Keypad	<ul style="list-style-type: none"> Enters digits. Enters the pre-dialing screen.
⑱	Character Key	Generates special characters: .@*.

	Item	Description
①9	# Key	Generates a pound key (#).

Infrared Sensor

The infrared sensor locates within the LED indicator. Aim the remote control at the infrared sensor to operate the camera.


































Icon Instructions

Icons on Display Device

Icons appearing on the display device are described in the following table:










Icons	Descriptions
	Network is available
	For VC800: CP960 conference phone is not connected For VC500: CP960 conference phone or CPW90 wireless microphones are not connected
	SIP account is registered
	H.323 account is registered
	Log into the Yealink VC Cloud Management Service/Yealink Meeting Server
	Log into the StarLeaf/Zoom/Pexip/BlueJeans/Mind platform
	VCH50 video conferencing hub is connected to the VC800/VC500 codec
	Auto answer










Icons	Descriptions
	Missed calls (this icon displays on the status bar)
	Output volume is 0
	Do not disturb
	DD10 dongle is connected, while the CPW90 are unregistered (It is only applicable to the VC500 endpoint)
	DD10 dongle is connected, and the CPW90 are registered (It is only applicable to the VC500 endpoint)
	The CPW90 is charging (It is only applicable to the VC500 endpoint)
	The power percent is less than 10% (It is only applicable to the VC500 endpoint)
	Dual-screen mode
	Dual video sources (when a PC is connected)
	A USB flash drive is inserted
	VPN is enabled
	Call mute
	Call encryption
	Call is held
	Output volume is 0 during a call
	Camera that being controlled
	Indicates the content displayed on the second display device
	Records video and audio
	Dialed calls (H.323 account/SIP account/IP Call)
	Dialed calls (Cloud platform)
	Received calls (H.323 account/SIP account/IP Call)

Icons	Descriptions
	Received calls (Cloud platform)
	Missed calls (H.323 account/SIP account/IP Call)
	Missed calls (Cloud platform)
	Local contact
	Conference contact (It is only applicable to the VC800 system with a multipoint license. It is not applicable to VC500 endpoint)
	Yealink Cloud contacts, YMS contacts or third party devices
	Permanent Virtual Meeting Room
	Room system
	Places video calls
	Places voice calls

Icons on CP960 Conference Phone

Icons appearing on the CP960's touch screen are described in the following table:

Icons	Descriptions
	Auto answer
	Missed calls (this icon displays on the status bar)
	Do not disturb
	The number of connected CPW90 wireless expansion microphones
	Call mute
	Call encryption
	Output volume is 0
	Local contact
	Conference contact (It is only applicable to the VC800 system with a multipoint license. It is not applicable to VC500 endpoint)

Icons	Descriptions
	Yealink Cloud contacts, YMS contacts or third party devices
	Permanent Virtual Meeting Room
	Room system
	Dialed calls (H.323 account/SIP account/IP Call)
	Dialed calls (Cloud platform)
	Received calls (H.323 account/SIP account/IP Call)
	Received calls (Cloud platform)
	Missed calls (H.323 account/SIP account/IP Call)
	Missed calls (Cloud platform)

LED Instructions

Indicator LED on the VC800/VC500 codec:

LED Status	Description
Solid green	The VC800/VC500 codec is powered on.
	The VC800/VC500 codec is upgrading firmware.
Solid red	The VC800/VC500 codec is in sleep mode.
Flashing red	The VC800/VC500 codec is upgrading firmware.
Solid orange	System exception (for example: network unavailable, update failure).
Off	The VC800/VC500 codec is powered off, or is not connected to the power adapter.

Mute key LED on the CP960:

LED Status	Description
Solid red	The CP960 conference phone is initializing.
	The CP960 conference phone is muted.
Flashing red	The CP960 conference phone is ringing.
Solid green	The CP960 conference phone is placing a call.
	The CP960 conference phone is in a call and unmuted.
Off	The CP960 conference phone is idle.

LED Status	Description
	The CP960 conference phone is not connected to the VC800/VC500 correctly.

Mute Indicator LED on the CPE90 wired expansion microphones:

LED Status	Description
Solid red	The CP960 conference phone is muted.
Flashing red	The CP960 conference phone is ringing.
Solid green	The CP960 conference phone is placing a call.
	The CP960 conference phone is in a call and unmuted.
Off	The CPE90 is not connected to the CP960 conference phone.
	The CPE90 is idle.

User Interfaces

There are two ways to customize the configurations of your VC800/VC500 video conferencing system:

- [Web User Interface](#)
- [Remote Control](#)



Note

Users can also use the CP960 conference phone to perform call operations. Details will be introduced later.

Web User Interface

You can customize your system via the web user interface. To access the web user interface, you need to know the IP address of your new system.

To obtain the IP address, do one of the following:

- The IP address of the system is shown on the top right corner of the display device.
- Use your remote control to select  (**More** menu), and then select **Status** -> **Network**.
- On your CP960 conference phone, tap  -> **Network**.


The touch screen of the CP960 conference phone displays the network information.

Log into the web user interface:

1. Enter the IP address (for example: <http://192.168.0.10> or 192.168.0.10) in the address bar of a web browser on your PC, and then press the **Enter** key.

2. Enter the administrator user name and password.

The default user name is "admin" (case-sensitive), and the default password is "0000".



The screenshot displays the login page for the Yealink VC800. At the top, there is a graphic of three stylized human figures. Below this, the text 'Welcome to Yealink VC800' is centered. Underneath, there are two input fields: 'Username:' with the text 'admin' entered, and 'Password:' with four dots representing the password. A 'Login' button is positioned at the bottom of the form.

3. Click **Login**.

After you log into the web user interface successfully, you can click **Logout** on the top right corner of the web interface to log out.

Remote Control

You can use the remote control to configure and use the VC800/VC500 video conferencing system. For more information on the function of each key on the remote control, refer to [VCR11 Remote Control](#) on page 13.


The **Advanced** option is only accessible to the administrator. The default administrator password is "0000". For more information on how to view, enter and edit the menu settings on the display device, refer to [Navigating Menus and Fields](#) on page 30 and [Entering Data and Editing Fields](#) on page 33.

Virtual Remote Control

In addition to using the remote control, you can also control the VC800/VC500 video conferencing system via virtual remote control.

To control VC800/VC500 video conferencing system via the virtual remote control:

1. Click **Home->Remote Control** when the system is idle or during a call.



2. Click the keys on the virtual remote control to control the VC800/VC500 video conferencing system.
3. Click **Remote Control** to hide the virtual remote control.

Getting Started

This chapter provides the following basic installation instructions and information for achieving the best performance from your VC800/VC500 video conferencing system. Topics include:


- [Installing Batteries for the Remote Control](#)
- [Powering the System On](#)
- [Put the System to Sleep](#)
- [Powering the System Off](#)
- [Setup Wizard](#)
- [Controlling Local Camera](#)
- [Registration](#)
- [Idle Screen](#)
- [Navigating Menus and Fields](#)
- [Entering Data and Editing Fields](#)
- [System Status](#)

If you require additional information, or assistance to help you use your new phone, contact your system administrator.

Installing Batteries for the Remote Control

Do the following:

1. Open the battery cover on the back of the remote control.
2. Insert the batteries with correct polarity.
3. Replace the battery cover.



Remote Control Battery Safety Information

- Never make wrong polarity connection when charging and discharging battery packs.
- Avoid crushing, puncturing, or putting a high degree of pressure on any battery, as this can cause an internal short-circuit, resulting in overheating.
- Remove the batteries if they are not in use for long period of time. Battery leakage and corrosion can damage the remote control, dispose batteries safely.
- Do not dispose used batteries in domestic waste. Dispose batteries at special collection points or return to stores if applies.
- Do not dispose batteries in a fire.

Powering the System On

To power on the system:

1. Locate the DC48V port on the VC800/VC500 codec, and connect it to the electrical power outlet with the supplied power adapter.


The VC800/VC500 video conferencing system starts up automatically, and the indicator LED on the VC800/VC500 codec then illuminates solid green.


Put the System to Sleep

After a certain amount of time with no activity, the VC800/VC500 video conferencing system goes into sleep mode automatically. You can also put the system to sleep immediately.

Put the system to sleep via the remote control:

1. Press  .

2. Press ▲ or ▼ to scroll to **Sleep** and then press  .



The system goes to sleep immediately. The indicator LED on the VC800/VC500 codec illuminates solid red.

Wake the system via the remote control:

1. Press any button on the remote control.

The indicator LED on the VC800/VC500 codec illuminates solid green.

Wake the system via the CP960 conference phone:

1. Tap the touch screen or any key.


The indicator LED on the VC800/VC500 codec illuminates solid green.

Powering the System Off

To power off the system via the remote control:

1. Press  .

2. Press ▲ or ▼ to scroll to **Shut down** and then press **OK**.



The system shuts down immediately. The indicator LED on the VC800/VC500 codec is off.

To power on the system again via the remote control:

1. Press .

The indicator LED on the VC800/VC500 codec illuminates solid green.

Setup Wizard

VC800/VC500 offers a setup wizard to guide users into configuring their systems step by step, the setup wizard appears automatically at first start up or factory reset. Users can follow the steps using the remote control to configure their systems. Setup wizard is useful to lead users to check and configure the VC800/VC500 settings such as language, network, accounts and etc.

Note You can tap **Exit Boot Wizard** on the CP960 to skip the setup wizard.



Controlling Local Camera

You need to be familiar with how to adjust the angle and focus of the camera when the system is idle or during a call. Avoid physically adjusting the camera to prevent damaging it.

You can control local camera via the remote control, CP960 conference phone or web user interface.


To control local camera via the remote control:



1. Select local video image.
2. Press the navigation keys to adjust the angle of the camera.

3. Press  or  to adjust the focus of the camera.




To control local camera via the CP960 conference phone:

1. Tap  when the phone is idle or tap  ->  when the phone is during a call.



2. Tap the navigation keys to adjust the angle of the camera.
3. Tap  or  to adjust the focus of the camera.

To control local camera via the web user interface:

1. Click **Home**.
2. Hover your cursor over yourself, and then click .
3. Click the navigation keys to adjust the angle of the camera.
4. Click  or  to adjust the focus of the camera.

Registration


You can register the H.323 account, SIP account and log into Cloud platform (Yealink VC Cloud Management Service/Yealink Meeting Server/StarLeaf/Zoom/Pexip/BlueJeans/Mind/Custom platform). Generally, your system administrator will configure the account beforehand, so that after you start up the system, the system will already be registered and ready for use. If your system is not registered, you may have to register it. For more information on how to register an account for the system, refer to [Yealink VC800&VC500 Full HD Video Conferencing System Administrator Guide](#).

Idle Screen





Idle Screen of VC800/VC500 Video Conferencing System

Idle screen of the display device

If the system starts up, the idle screen will be shown. The following figure is an example:



Name	Description
Time and Date	The time and date are displayed on the left of the status bar.
Site name	The site name of the system. For more information on how to change the site name, refer to Site Name on page 48.
Status icon	Status icons are displayed in the center of the status bar. For more information on the status icon, refer to Icons on Display Device on page 15.
IP address	<ul style="list-style-type: none"> LAN: X.X.X.X: Indicates the system has obtained an IP address. Network disconnected: Indicates the system does not connect to a network cable. Please check the network cable. 255.255.255.255: Indicates the system fails to obtain an IP address. Check the connection between the system and the DHCP server, or you can configure a static IP address for the system. For more information on how to configure a static IP address, refer to Setup

Name	Description
	Wizard on page 26.
Registered account	When the VC800/VC500 system is registered with the SIP server, the account icon is  . For more information, refer to Yealink VC800&VC500 Full HD Video Conferencing System Administrator Guide .
	When the VC800/VC500 system is registered with an H.323 gatekeeper, the account icon is  . For more information, refer to Yealink VC800&VC500 Full HD Video Conferencing System Administrator Guide .
	When the VC800/VC500 system logs into Yealink VC Cloud Management Service/Yealink Meeting Server, the icon is  . When the VC800/VC500 system logs into a StarLeaf/Zoom/Pexip/BlueJeans/Mind platform, the icon is  . For more information, refer to Yealink VC800&VC500 Full HD Video Conferencing System Administrator Guide .
Dial	Enter the pre-dialing screen.
More	Configure the video conferencing system.
Video image	Display local video image or local PC content.

Idle Screen of CP960 Conference Phone



NO.	Name	Description
1	Status Bar	Displays the icons and time.
2	Digital Clock Widget	Displays the phone's time and date.
3	Scheduled conference information	When you register a YMS account, this field will display the scheduled conference details. For more information, refer to Scheduled Conference on page 131.
4	Applications	Use the corresponding features.
5	Screen Indicator	Indicates which idle screen is displayed. You can swipe left or right to switch among different screens.














Navigating Menus and Fields

Navigating the Display Device

You can use the remote control to enter the main menu screen, and view the items on the display device.

Note The system will automatically return to the idle screen after 60 seconds of inactivity.

To navigate menus and fields, you can:

If you want to	You can
Return to the idle screen.	Press  or  .
Go back to the previous menu.	Press  .
Navigate through menus.	Press  or  to select a menu. Press  or  to select an item.
Expand pull-down list.	Press  or  to expand a pull-down list.
Select an option from the pull-down list.	From the pull-down list, Press  or  to scroll to the setting and then press  .
Enable or disable features.	Press  .


Navigating the CP960 Conference phone

The following sections introduce how to navigate CP960 Conference phone. Topics include:

- [Navigating Touch Screen](#)
- [Gestures](#)
- [Control Center/Notification Center](#)





Navigating Touch Screen

To operate your phone, follow these tips:

If you want to	Action
Return to the idle screen.	Tap HOME touch key on the CP960 conference phone.
Go back to the previous menu.	Tap  .
Select an item.	Tap the item.
Scroll through items page by page.	Drag up and down to scroll. (You can wait for the scrolling to come to a stop, or touch the screen to stop it immediately.)
Scroll through values for a field.	Drag up and down to scroll through values.
Select a value for a field.	Tap the value or scroll to the value in the pop-up dialog box.

Gestures


To operate your phone using gestures, follow these tips:


Gesture		Action
Tap		Touch an item on the screen with your finger, and then lifting your finger. For example: tap  to enter directory.
Swipe		Tap and move. When you want to scroll quickly, swipe your finger across the screen, either up, down, left or right.
Drag		Touch and hold, then move. To stop scrolling, stop the dragging motion.

Control Center/Notification Center

Control center or notification center allows you to access to common features or view important notifications quickly.

Swipe down from the top of the screen to enter the control center and the notification center:



No.	Name		Description
1	Time and date		Display the phone's time and date. For more information, refer to Time & Date on page 50.
2			<ul style="list-style-type: none"> Indicate the number of connected CPW90 wireless expansion microphones. Tap to enter the wireless expansion microphone settings screen. For more information, refer to Registering CPW90 with the CP960 Conference Phone on page 168.
3	Control Center	Backlight Slider	Drag the slider to adjust the screen brightness quickly. You can also enter the Backlight setting screen to adjust the screen brightness. For more information, refer to Backlight on page 46.
		Mute	Tap to turn mute on or off quickly. For more information, refer to Call Mute on page 109.
		DND	Tap to turn DND on or off quickly. For more information, refer to Do Not Disturb (DND) on page 93.
		Auto Answer	Tap to turn auto answer on or off quickly. For more information, refer to Auto Answer on page 91.

No.	Name		Description
		Silent	Tap to turn silent mode on or off quickly. For more information, refer to Volume on page 63.
4	Notification Center		<ul style="list-style-type: none"> • Tap the desired notification message to view the details. • Swipe left or right to delete a specific notification. • Tap Clear to delete all notifications.

To exit the control center and the notification center, do one of the following:

- Swipe up from the bottom of the screen.
- Tap the Home touch key.

Entering Data and Editing Fields


Entering Data and Editing Fields Using Remote Control




VC800/VC500 video conferencing system provides onscreen keyboard and keypad on the remote control to enter data. Keypad on the remote control provides standard key layout, which enable users to use existing or familiar key positions. You can enter data and edit fields using the onscreen keyboard or keypad on the remote control.

Using the Onscreen Keyboard

Before using the onscreen keyboard, you need to know the function of the keys on the onscreen keyboard. VC800/VC500 video conferencing system supports two kinds of input methods: English and Russian. For more information, refer to [Keyboard Input Method](#) on page 34.

The following takes English input method as an example:



No.	Item	Description
1	26 English Letters	Enter characters.
2		Switches to the uppercase input mode.
3	&123	Switches to the numeric&symbolic input mode.
4		Switches between the Russian or English input mode.
5	Space Key	Enter a space.
6	Cursor	Position a cursor
7		Hides the onscreen keyboard
8	Special Characters	Enter the corresponding special character.
9	Delete Key	<ul style="list-style-type: none"> Press once to delete a entered character. Long press to delete two or more characters.

Using the Keypad

Instead of using the onscreen keyboard, you can also press the keypad on the remote control to enter data. The keypad only provides digit keys and #.* keys.





Note


When using the keypad on the remote control, you can select  to use the onscreen keyboard.

Keyboard Input Method

You can enter characters using the enabled input methods only. Onscreen keyboard on the display device supports English and Russian keyboard input methods. You can configure keyboard input method via the web user interface only.

To configure keyboard input method via the web user interface:

1. Click on **Setting** -> **General**.
2. In the **Keyboard IME** block, select the desired list from the **Disabled** column and click  .
The selected input method appears in the **Enabled** column.
3. Repeat step 2 to add more input methods to the **Enabled** column.
4. (Optional.) To remove a list from the **Enabled** column, select the desired list and then click  .
5. To adjust the display order of the enabled input methods, select the desired list, and click  or  .



6. Click **Confirm** to accept the change.

Entering Data and Editing Fields Using CP960


CP960 conference phone provides onscreen keyboard and onscreen dial pad to enter data. Onscreen dial pad provides standard key layout, which enable users to use existing or familiar key positions. You can enter data and edit fields using the onscreen keyboard or onscreen dial pad.

Using the Onscreen Keyboard


Before using the onscreen keyboard, you need to know the function of the keys on the onscreen keyboard. CP960 conference phone supports two kinds of input methods: Android Keyboard (AOSP) – English (US) and Google Pinyin.

Android Keyboard (AOSP) – English (US) Input Method


The English (US) input method supports English languages onscreen keyboard. The following shows an example:





No.	Item		Description
1	26 English Letters		<ul style="list-style-type: none"> • Tap to enter letters. • Long tap a key then slide to choose one of the options to enter an alternate character.
2	Delete Key		<ul style="list-style-type: none"> • Tap to delete the entered characters one by one. • Long tap to delete two or more characters.
3	Label automatically to identify the context-sensitive features.	Next Key	Tap to go to the next field.
		Send Key	Tap to dial out the number.
4	Two Special Characters		<ul style="list-style-type: none"> • Tap to enter special characters. • Long tap point key (.) then slide to choose one of the options to enter an alternate character.
5	Space Key		<ul style="list-style-type: none"> • Tap to enter spaces. • Long tap to change input method.
6	?123		Tap to switch to the numeric&symbolic input mode.


No.	Item	Description
7		Tap to switch to the uppercase input mode.



Tap **?123** to switch to the numeric&symbolic input mode as shown below:



No.	Item		Description
1	Numbers		<ul style="list-style-type: none"> Tap to enter numbers. Long tap a key then slide to choose one of the options to enter an alternate character.
2	Special Characters		<ul style="list-style-type: none"> Tap to enter special characters. Long tap a key then slide to choose one of the options to enter an alternate character.
3	Delete Key		<ul style="list-style-type: none"> Tap to delete the entered characters one by one. Long tap to delete two or more characters.
3	Label automatically to identify the context-sensitive features.	Next Key	Tap to go to the next field.
		Send Key	Tap to dial out the number.
5	Space Key		<ul style="list-style-type: none"> Tap to enter spaces. Long tap to change input method.
6			Tap to switch to the lowercase input mode.
7			Tap to switch to the symbolic input mode.

Tap  to switch to the symbolic input mode as shown below:




No.	Item		Description
1	Special Characters		<ul style="list-style-type: none"> • Tap to enter special characters. • Long tap a key then slide to choose one of the options to enter an alternate character.
2	Delete Key		<ul style="list-style-type: none"> • Tap to delete the entered characters one by one. • Long tap to delete two or more characters.
3	Label automatically to identify the context-sensitive features.	Next Key	Tap to go to the next field.
		Send Key	Tap to dial out the number.
4	Space Key		<ul style="list-style-type: none"> • Tap to enter spaces. • Long tap to change input method.
5			Tap to switch to the lowercase input mode.
6			Tap to switch to the numeric&symbolic input mode.

Google Pinyin Input Method

You can use Google Pinyin input method to enter Chinese. For operating instructions on how to use the Google Pinyin input method, refer to the operating instructions above.






When you change the input method to Google Pinyin, the onscreen keyboard displays the Chinese input mode as shown below by default:







To use onscreen keyboard:

1. Tap the field you want to edit, the onscreen keyboard displays on the touch screen.
2. Enter the information using the onscreen keyboard.
3. Tap **Send** or the non-editable area to hide the onscreen keyboard.

The other things you need to know:


If you want to	Action
Position the cursor.	Tap to position.
Select all characters.	<ol style="list-style-type: none"> 1) Long tap the entered character(s). 2) Do one of the following: <ul style="list-style-type: none"> • Tap  on the top of the touch screen. • Drag  to select all characters.
Cut/Copy characters.	<ol style="list-style-type: none"> 1) Long tap the entered character(s). 2) Drag  to select the characters you want to cut or copy. 3) Tap CUT/POTY or  /  on the top of the touch screen to cut or copy. 4) Long tap the desired field. 5) Tap PASTE.
Delete more characters at a time.	Do one of the following: <ul style="list-style-type: none"> • Long tap the entered character(s).

If you want to	Action
	Drag  /  to select the characters you want to delete, and then tap  . • Long tap  .
Replace characters.	1) Drag your finger to highlight the characters you want to replace. 2) Tap the desired character.

Using the Onscreen Dial Pad

Instead of using the onscreen keyboard, you can also use the dial pad on the dialing screen to enter data. The onscreen dial pad only provides digit keys and **#.@*** key.

Note

When using the onscreen dial pad, you can tap  to display the onscreen keyboard. For more information, refer to [Using the Onscreen Keyboard](#) on page 36.

System Status

When the system is idle, you can view its status via the remote control, CP960 conference phone or web user interface.


Available system status information includes:

- **System information** (device model, firmware, hardware version and product ID)
- **Network status** (LAN type, IP address, MAC, subnet mask, gateway and DNS server, public IP address can be also viewed if the static NAT is enabled)
- **Account status** (register status of SIP account , H.323 account and Cloud platform)
- **Camera** (status, device model, SPEC and hardware version)
- **Audio** (the active microphone and active speaker)
- **VCS Phone** (status, device model, serial number, firmware version, hardware version, IP address and MAC address)
- **Wireless Microphone** (register status, product model, MICPOD IPEI, power percent, idle time and work time)
- **License** (multipoint license installation status)

To view the system status via the remote control:


1. Select  (**More** menu).
2. Press  or  to scroll to **Status** and then press  to enter submenu.

3. Press ▲ or ▼ to view the specific information.



To view the system status via the CP960 conference phone:

1. Tap  .



2. Tap the desired list to view the specific information.

To view the system status via the web user interface:

1. Click **Status**.

The system status is displayed on the web user interface.

The screenshot displays the Yealink VC800 web user interface. At the top, there is a navigation bar with links for 'About', 'Language', and 'Logout'. Below this is a green header bar with the 'Yealink VC800' logo and a menu containing 'Home', 'Status' (which is highlighted), 'Account', 'Network', 'Setting', 'Directory', and 'Security'. On the left side of the main content area, there is a sidebar with a 'Status' tab. The main content area is divided into two sections: 'System' and 'VCS Phone'. The 'System' section lists the following information:

System Model	VC800
Firmware Version	63.31.0.10
Hardware Version	63.0.4.0.0.0.0
Product ID	201712291801
Uptime	0 Days 00:06

The 'VCS Phone' section lists the following information:

Serial Number	201712291809
Firmware Version	73.80.0.45
Hardware Version	73.0.0.9.0.0.0
Model	SIP-CP960
IP	192.168.0.150
MAC	00-15-65-F2-65-67

Customizing the VC800/VC500 Video Conferencing System

You can customize your VC800/VC500 video conferencing system by personally configuring certain settings, for example, site name, time & date and language. You can add contacts to the local directory manually or from the call history.

This chapter provides basic operating instructions for customizing your system. Topics include:

- [General Settings](#)
- [Audio Settings](#)
- [Directory](#)
- [Call History Management](#)

If you require additional information or assistance with your new system, contact your system administrator.











General Settings

Automatic Sleep Time


The system will go to sleep automatically when it has been inactive for a period of time (the default period is 10 minutes). When the system is in sleep mode, it can still accept incoming calls. And the display device will prompt "No Signal".

You can change the automatic sleep time via the remote control or web user interface.

To configure the automatic sleep time via the remote control:

1. Select  (**More** menu).
2. Press  or  to scroll to **Setting** and then press  to expand the menu.
3. Press  or  to scroll to **Basic** and then press  to enter submenu.
4. Press  or  to scroll to **Automatic Sleep Time** and then press  .
5. Select desired time.

If **Always On** is selected, the system will not enter the sleep mode automatically.



6. Press ▲ or ▼ to select **Save** and then press **OK** to accept the change.

Automatic sleep time is configurable via the web user interface at the path **Setting->General->Automatic Sleep Time**.

Screen Saver

The screen saver automatically starts when the system or CP960 conference phone has been idle for the preset waiting time. You can set screen saver for the display device and CP960 conference phone respectively.


The screen saver stops when:

- Press any key on the CP960 conference phone, CPW90 wireless microphones, CPE90 wired expansion microphones or the remote control.
- There is an incoming call.
- A new prompt (for example, USB device available now).


Setting Screen Saver for Display Device

You can configure the waiting time before the display device starts the screen saver.

To configure the screen saver waiting time for the display device via the remote control:

1. Select  (**More** menu).
2. Press ▲ or ▼ to scroll to **Setting** and then press **OK** to expand the menu.
3. Press ▲ or ▼ to scroll to **Basic** and then press ► to enter submenu.
4. Press ▲ or ▼ to scroll to **Screensaver** and then press **OK**.
5. Select the desired time.

If **Never** is selected, the display device will not start screen saver.




6. Press ▲ or ▼ to select **Save** and then press **OK** to accept the change.

Four pictures are displayed like a slide show when screen saver starts.


Configuring Screen Saver for CP960 Conference Phone



The CP960 conference phone supports four types of screen savers: Clock, Colors, Photo Frame and Photo Table. You can choose anyone you like. And you can configure the waiting time before the CP960 conference phone starts the screen saver.

To configure the screen saver via the CP960 conference phone:

1. Tap  -> **Display** -> **Screen Saver**.
2. Tap the **Wait Time** field.
3. Tap the waiting time in the pop-up dialog box.

4. Tap the desired screen saver.



5. Tap  to accept the change or  to cancel.


Backlight

The backlight of the CP960 conference phone is always on by default. You can configure backlight time for the CP960's touch screen via the CP960 conference phone or web user interface.

You can configure the touch screen's backlight time in the following formats:



- **Always On:** Backlight is on permanently.
- **15s, 30s, 1 Min, 2 Min, 5 Min, 10 Min, 30 Min:** Backlight goes out when the phone has been inactive for the time you set.

To configure the backlight of the CP960 conference phone:

1. Tap  -> **Display** -> **Backlight**.
2. Drag the **Active Level** slider to change the intensity of the touch screen.
3. Tap the **Backlight Time** field.

4. Tap the desired time in the pop-up dialog box.




5. Tap  to accept the change or  to cancel.

You can also drag the backlight slider on the control center to change the intensity of the touch screen.

To configure the backlight active level via the control center:

1. Swipe down from the top of the screen to enter the control center.



2. Drag the backlight slider.



Backlight is configurable via the web user interface at the path **Settings->General->Backlight Time**.

Output Resolution

You can adjust output resolution of primary/secondary display device respectively.

You can configure output resolution via the CP960 conference phone or web user interface.

To configure output resolution via the CP960 conference phone:

1. Tap  -> **Display**-> **Output Resolution**.
2. Tap the **Display1/Display2** field.
3. Tap the desired output resolution in the pop-up dialog box.
4. Tap  to accept the change.











Output resolution is configurable via the web user interface at the path **Setting->Video & Audio->Display1/Display2**.


Site Name

Site name is displayed on the status bar of the display device. You can make an IP address call to the other party, the system site name will be displayed on the remote display device. Site name consists of letters, numbers or special characters.

Site name is configurable via the remote control or web user interface.

To configure the site name via the remote control:

1. Select  (**More** menu).
2. Press  or  to scroll to **Setting** and then press  to expand the menu.
3. Press  or  to scroll to **Basic** and then press  to enter submenu.
4. Press  or  to scroll to **Site Name** and then press .
5. Edit the site name.



- Press ▲ or ▼ to select **Save** and then press **OK** to accept the change.


Site name is configurable via the web user interface at the path **Setting->General->Site Name**.


Language

The default language of the display device is English, and you can change it via the remote control. The CP960 conference phone will detect and use the same language as the display device.

The default language of the web user interface is English. You can change the language for the phone user interface and the web user interface respectively.

To change the language for the display device via the remote control:

- Select  (**More** menu).
- Press ▲ or ▼ to scroll to **Setting** and then press **OK** to expand the menu.
- Press ▲ or ▼ to scroll to **Basic** and then press **▶** to enter submenu.
- Press ▲ or ▼ to scroll to **Language** and then press **OK**.
- Select the desired language and then press **OK**.




- Press ▲ or ▼ to select **Save** and then press **OK** to accept the change.

Text displayed on the display device and CP960's touch screen will change to the selected language.

To change the language for the web user interface:

- Click on **Language** at the top right corner of the web page.

2. Select the desired language from the pull-down list of **Language**.



Text displayed on the web user interface will change to the selected language.

Time & Date

Time and date is displayed on the status bar of the display device and CP960 conference phone. You can configure the system to obtain the time and date from the SNTP (Simple Network Time Protocol) server automatically. The SNTP allows the system to synchronize time to a main server. This keeps all network machine clocks on the same time. Enter the NTP Server name that you want to follow.

If the system cannot obtain the time and date from the SNTP server, you can configure the time and date manually, or contact your system administrator for more information.











There are 7 available date formats. For example, for the date format "WWW DD MMM", "WWW" represents the abbreviation of week, "DD" represents the two-digit day, and "MMM" represents the first three letters of the month.


The available date formats you need to know are:




Date Format	Example (2017-5-23)
WWW MMM DD	Tue May 23
DD-MMM-YY	23-May-17
YYYY-MM-DD	2017-05-23
DD/MM/YYYY	23/05/2017
MM/DD/YY	05/23/17
DD MM YYYY	23 May 2017

Date Format	Example (2017-5-23)
WWW DD MMM	Tue 23 May

To configure the NTP server and date & time format via the remote control:

1. Select  (**More** menu).
2. Press  or  to scroll to **Setting** and then press  to expand the menu.
3. Press  or  to scroll to **Basic** and then press  to enter submenu.
4. Press  or  to scroll to **Date & Time** and then press .
5. Select the desired time format from the pull-down list of **Time Format**.
6. Select the desired date format from the pull-down list of **Date Format**.
7. Select **SNTP Settings** from the pull-down list of **Time Type**.
8. Select the time zone that applies to your area from the pull-down list of **Time Zone**.
The default time zone is "+8 China(Beijing)".
9. Enter the domain names or IP addresses in the **NTP Primary Server** and **NTP Secondary Server** fields respectively.
10. Select the desired value from the pull-down list of **Daylight Saving Time**.
When **Automatic** is selected, the system will use daylight saving time corresponding to the selected time zone.





11. Press  or  to select **Save** and then press  to accept the change.


Note


Please refer to [Appendix - Time Zones](#) for the list of available time zones on the system.

To configure the time and date manually via the remote control:

1. Select  (**More** menu).

2. Press ▲ or ▼ to scroll to **Setting** and then press  to expand the menu.
3. Press ▲ or ▼ to scroll to **Basic** and then press ► to enter submenu.
4. Press ▲ or ▼ to scroll to **Date & Time** and then press .
5. Select the desired time format from the pull-down list of **Time**.
6. Select the desired date format from the pull-down list of **Date**.
7. Select the **Manual Settings** from the pull-down list of **Time Type**.
8. Select the desired year from the pull-down list of **Year**.
9. Select the desired month from the pull-down list of **Month**.
10. Select the desired day from the pull-down list of **Day**.
11. Select the desired hour from the pull-down list of **Hour**.
12. Select the desired minute from the pull-down list of **Minute**.
13. Select the desired secondary from the pull-down list of **Secondary**.







14. Press ▲ or ▼ to select **Save** and then press  to accept the change.

To view current time in different cities via the CP960 conference phone:

1. Tap the digital clock.
The touch screen displays current time in selected cities.

2. Tap .



3. Do one of the following:
- Tap  to search for the city.
Enter a few or whole characters of the city in the Search field.
Cities match the characters entered will appear on the touch screen.
 - Tap  to sort the city.
Tap **Sort by name**, unselected cities will be sorted by name.
Tap **Sort by time**, unselected cities will be sorted by time.
4. Tap the desired city to check or uncheck.
5. Tap  to return.
6. You can see current time of the selected cities.

Time and date is configurable via the web user interface at the path **Setting->Date&Time**.

Configuring Camera Presets





Camera presets are stored camera pan, tilt, and zoom settings. Presets enable you to quickly point a camera at pre-defined locations. Presets remain in effect until you change them. Up to 99 presets can be saved.


Camera presets are configurable via the remote control or web user interface.




Storing a Camera Preset

To store a camera preset via the remote control:

1. Do one of the following to enter preset operation interface:




- Select  (**More** menu), and then press ▲ or ▼ to scroll to **Preset Location**.
 - Select local video image, and then press .
2. Press  to select **New Preset**, and then press .




3. If you connect VCC22 video conferencing camera to your VC800 video conferencing system, select the desired camera.
4. Press the navigation key to adjust the angle of the camera or press  or  to adjust the focus of the camera.
5. Press  to store the camera preset.

Moving Local Camera to a Preset Position


To move local camera to a preset position via the remote control:

1. Do one of the following:
 - Enter the preset operation interface when the system is idle.
 - Press  and select **Preset Location** to enter the preset operation interface when the system is during a call.
2. Press  to enter the preset location list.
3. Select a stored preset, and then press  to move local camera to this stored preset.

You can also press the numeric keys (corresponding to 0 to 9 preset positions) on the remote control. But in this way, you can only move local camera to 10 preset positions at most.



To move local camera to a preset position via the web user interface:

1. Click **Home**.
2. Hover your cursor over yourself on the left side of the screen, and then click .
3. Click a number to move local camera to this stored preset.

You can move local camera to 12 preset positions (corresponding to 0 to 12 key on the web user interface).


Updating the Stored Preset

You can update the stored presets to see the current preview screens. It helps you decide where you want your camera to move.

To update the stored preset via the remote control:

1. Enter preset operation interface.

2. Select **Update Preset**, and then press  .





All preview screens will be updated.





Editing the Stored Preset

You can edit the stored presets to adjust camera angle and focus.

To edit the stored preset via the remote control:


1. Enter preset operation interface.
2. Select **Edit**, and then press  .





3. Select a preset, and then press  .
4. Press the navigation key to adjust the angle of the camera or press  or  to adjust the focus of the camera.
5. Press  to store the camera preset.

Placing a Preset at the Top

To place a preset at the top via the remote control:


1. Enter preset operation interface.
2. Select **Stick**, and then press .








3. Select a preset, and then press .
- The selected preset is placed at the top.

Deleting the Stored Preset

To delete the stored presets during a video call:


1. Enter preset operation interface.
2. Select **Delete** and then press .






3. Select the stored presets, and then press .
4. Press  or  to scroll to **OK** and then press  to delete selected presets.

Clearing the Stored Preset

To clear the stored presets during a video call:

1. Enter preset operation interface.
2. Select **Clear** and then press .










3. Press  or  to scroll to **OK** and then press  to clear all presets.

Website Snapshot


You can enable the website snapshot feature to allow the web user interface to show the same content that displayed on your display device.


Website snapshot is configurable via the remote control only and it is enabled by default.

To configure the website snapshot via the remote control:

1. Select  (**More** menu).
2. Press  or  to scroll to **Setting** and then press  to expand the menu.
3. Press  or  to scroll to **Basic** and then press  to enter submenu.

- Press ▲ or ▼ to scroll to **Website Snapshot**, and then press  to enable or disable this feature.






- Press  to return to the idle screen.

Watching website snapshot via the web user interface at the path **Home**.


Adjusting Zoom Level of the Display Device

You can adjust zoom level of the display device according to your needs. It is configurable via the remote control only.

To adjust zoom level of the display device via the remote control:

- Select  (**More** menu).
- Press ▲ or ▼ to scroll to **Setting** and then press  to expand the menu.
- Press ▲ or ▼ to scroll to **Basic** and then press ► to enter submenu.
- Press ▲ or ▼ to scroll to **Display**, and then press .

5. Press ◀ or ▶ to adjust the **Display(90%-100%)** slider to change the zoom level of the display device.



6. Press ▲ or ▼ to select **Save** and then press (OK) to accept the change.
7. Press (Red Phone) to return to the idle screen.

Call Protocol

The VC800/VC500 video conferencing system supports SIP and H.323 call protocols. You can configure which protocol is to be used when the system is making calls. When the **Auto** call protocol is used, the system preferentially uses the H.323 protocol to place calls. If there is no available H.323 account on the system, the system will switch to the SIP protocol. You can also specify the desired protocol for the system to place calls via the remote control or web user interface.


Note

Before configuring call protocol, ensure the remote system supports the call protocol too. For more information, contact your system administrator.

To configure the call protocol via the remote control:

1. Select (More menu).
2. Press ▲ or ▼ to scroll to **Setting** and then press (OK) to expand the menu.
3. Press ▲ or ▼ to scroll to **Call Features** and then press ▶ to enter submenu.
4. Press ▲ or ▼ to scroll to **Call Protocol** and then press (OK) .

5. Select desired type or **Auto** from the pull-down list of **Call Protocol**.



6. Press ▲ or ▼ to select **Save** and then press **OK** to accept the change.

Call protocol is configurable via the web user interface at the path **Setting->Call Features->Call Protocol**.

Video Call Rate


You can specify the maximum video call rate for the system to achieve optimum video. The configurable video call rates on the system are: 64kb/s, 128kb/s, 256kb/s, 384kb/s, 512kb/s, 768kb/s, 1024kb/s, 1280kb/s, 1500kb/s, 2000kb/s, 3000kb/s, 4000kb/s, 5000kb/s, 6000kb/s.


You can configure the video call rate via the remote control or web user interface.


Note




The call rate of audio and PC content are also affected by this configuration.

To configure video call rate via the remote control:

1. Select  (**More** menu).
2. Press ▲ or ▼ to scroll to **Setting** and then press **OK** to expand the menu.
3. Press ▲ or ▼ to scroll to **Call Features** and then press ► to enter submenu.
4. Press ▲ or ▼ to scroll to **Video Call Rate** and then press **OK**.

5. Select the desired value and then press  .



6. Press  or  to select **Save** and then press  to accept the change.

Video call rate is configurable via the web user interface at the path **Setting->Call Features->Video Call Rate**.


Custom Key Type

You can configure a custom type for the  key on the remote control. It is configurable via the web user interface only.

To configure a custom key type via the web user interface:

1. Click on **Setting->Remote Control**.

2. Select the desired value from the pull-down list of **Custom Key Type**.



- **Input:** press to select the video input source.
 - **ScreenShot:** press to capture screen.
 - **Mute Speaker:** press to mute or unmute the speaker.
 - **Presentation:** press to start or stop presentation.
3. Click **Confirm** to accept the change.

Audio Settings

Volume

You can use the remote control or CP960 conference phone to adjust the following volume level:

- **Ringer volume:** adjust the ringer volume when the phone is idle or ringing.
- **Talking volume:** adjust the receiver volume of speakerphone when the system is in use.
- **Key tone volume:**

Adjust the key tone volume when pressing the key on the remote control.

Adjust the key tone volume of the CP960 conference phone when tapping dial pad on the dialing screen.

For more information on key tone, refer to [Key Tone](#) on page 64.

- **Media volume:** adjust the media volume when playing recorded videos.

To adjust the volume via the remote control:

1. Press or on the remote control to decrease or increase the volume.

To adjust the volume via the CP960 conference phone:

1. Press volume touch key to decrease or increase the volume.
You can also drag the volume slider to adjust the volume.

Note











You can still use CP960 conference phone to adjust the system volume even if it is not the active audio device of the system.


Key Tone


You can enable the key tone feature to produce a sound when you press any key on the remote control or tap the onscreen dial pad on the CP960 conference phone.

Key tone is configurable via the remote control or web user interface. Key tone feature is enabled by default.

To configure the key tone via the remote control:

1. Select  (**More** menu).
2. Press  or  to scroll to **Setting** and then press  to expand the menu.
3. Press  or  to scroll to **Basic** and then press  to enter submenu.
4. Press  or  to scroll to **Key Tone**, and then press  to enable or disable this feature.



5. Press  to return to the idle screen.




Key tone is configurable via the web user interface at the path **Setting**->**General**->**Key Tone**.

Silent Mode

If you turn on the silent mode, the VC800/VC500 system will not produce ring tone and key tone.


Silent mode is configurable via the remote control or CP960 conference phone.

Do one of the following to enable silent mode via the remote control:



- Long press  key to decrease the ringer volume to minimum.
 - If  is set to **Mute Speaker** key, press  to turn on the silent mode.
- For more information on how to customize the key, refer to [Custom Key Type](#) on page 62.

Do one of the following to enable silent mode via the CP960 conference phone:

- Long tap the left Volume touch key to decrease the ringer volume to minimum.
- Swipe down from the top of the screen to enter the control center and toggle **Silent** on.



Note


When the silent mode is on, the  icon will appear on the display device. The  icon will appear on the CP960's touch screen.

Audio Output

The system supports the following audio output:











- **Auto** (audio output device with the highest priority is selected automatically)
- **VCS Phone** (CP960 conference phone)
- **HDMI** (built-in speakerphone of the display device)
- **Line Output** (speakerphone connected to the Line Out port on the VC800 codec)
- **USB Line out** (Speakerphone connected to the USB port on the VC500 codec using a USB to Line-out adapter)


By default, the system automatically selects the audio output with the highest priority. If the audio output with the highest priority is removed from, the VC800/VC500 will select the next highest priority device.






You can also specify the desired audio output via the remote control or the web user interface.

To configure the audio output via the remote control:

1. Select  (**More** menu).
2. Press  or  to scroll to **Setting** and then press  to expand the menu.
3. Press  or  to scroll to **Video & Audio** and then press  to enter submenu.
4. Press  or  to scroll to **Audio Settings** and then press .
5. Select desired audio output from the pull-down list of **Audio Output**.



6. Press  or  to select **Save** and then press  to accept the change.


Audio output is configurable via the web user interface at the path **Setting->Video & Audio->Audio Output**.

EQ Self-adaption

The system supports EQ self-adaption to optimize the acoustic effect. You can configure it via the web user interface only.

To configure EQ self-adaption via the web user interface:

1. Click on **Setting->Video & Audio**.
2. Select the desired value from the pull-down list of **EQ Self-adaption**.




3. Click **Confirm** to accept the change.

If you disable this configuration, the EQ self-adaption will start automatically next time you enable this configuration.

The EQ self-adaption starts when one of the following situations occurs:

- The audio output manually or automatically switches to **HDMI** or **Line Output/USB Line out**.
- When the system is powered on, the system finds that the **HDMI** or **Line Output/USB Line out** is current audio output.
- The EQ self-adaption feature changes from disabled to enabled.

During EQ self-adaption process, the display device is as follows:




Audio Input

The system supports the following audio input:











- **Auto** (select the audio input device with the highest priority)
- **VCS Phone** (CP960 conference phone)
- **Wireless Microphone** (CPW90 wireless microphones)
- **Line Input** (audio input device connected to the Line In port on the VC800 codec)
- **USB Line in** (audio input device connected to the USB port on the VC500 codec using a USB to Line-in adapter)

The priority of audio input is:







By default, the VC800/VC500 automatically selects the audio input with the highest priority. If you select “VCS Phone + Wireless Microphone” option, the VC800 will use CP960 conference phone and CPW90 expansion microphones to pick up audio at the same time.

To configure the audio input via the remote control:

1. Select  (**More** menu).
2. Press  or  to scroll to **Setting** and then press  to expand the menu.
3. Press  or  to scroll to **Video & Audio** and then press  to enter submenu.
4. Press  or  to scroll to **Audio Settings** and then press .
5. Select desired audio input from the pull-down list of **Audio Input**.

If **VCS Phone** is selected as the audio output manually or automatically, the audio input must be **VCS Phone** or **VCS Phone+Wireless Microphone**.



6. Press  or  to select **Save** and then press  to accept the change.

Audio input is configurable via the web user interface at the path **Setting->Video & Audio->Audio Input**.

Directory

VC800/VC500 system can display: local contacts, Yealink Cloud contacts and YMS contacts.

- **Local contacts:**

The VC800 system can store up to 500 local contacts and 100 conference contacts (conference contacts are available only when a multipoint license is imported to the VC800 system). A conference contact consists of one or more local contacts. You can establish a conference call quickly by calling conference contacts.

The VC500 endpoint can store up to 500 local contacts, and does not support conference contacts.

- **Yealink Cloud contacts:** If you log into the Yealink VC Cloud Management Service platform, Yealink Cloud contacts which are created by your cloud enterprise administrator, appear in your directory. Note that only the cloud enterprise administrator can add, edit

and delete Yealink Cloud contacts on the Yealink VC Cloud management service. On your VC800/VC500, you can only search for and place calls to the Yealink Cloud contacts. For more information on Yealink VC Cloud management service, refer to [Yealink VC Cloud Management Service Administrator Guide](#).

- **YMS contacts:** If you log into the Yealink Meeting Server, enterprise directory which is created by your enterprise administrator, appears in your directory. Note that only the enterprise administrator can add, edit and delete YMS contacts on Yealink Meeting Server (YMS). For more information on Yealink Meeting Server, please refer to [Yealink Meeting Server Administrator Guide](#). On VC800/VC500, you can only place calls to or search for YMS contacts.

There are four types of YMS contact:

- **User:** The users have YMS accounts. The enterprise administrator can create departments for users.
- **Room system:** The devices registered YMS accounts in the video meeting room.
- **Third party device:** The devices without YMS accounts.
- **VMR:** It is also called the Permanent VMR. The enterprise administrator can determine whether to synchronize the permanent VMR to the VC800/VC500.

Note

StarLeaf/Zoom/BlueJeans/Pexip/Mind platform does not provide Cloud contacts for video conferencing system.










This chapter provides operating instructions for the directory. Topics include:


- [Adding Contacts](#)
- [Editing Contacts](#)
- [Deleting Contacts](#)
- [Searching for Contacts](#)


Adding Contacts


You can add local contacts and conference contacts (conference contacts are only applicable to VC800 system with a multipoint license) via the remote control or web user interface.

To add a local contact via the remote control:






1. Select  (**Dial** menu) or press  to enter the pre-dialing screen.
2. Press  to return to the menu.
3. Press  or  to scroll to **Directory** and then press  to enter submenu.
4. Press  or  to scroll to **New Contact** and then press .
5. Enter contact name in the **Name** field.

6. Enter contact number or IP address in the **Number** field.
7. Press ▲ or ▼ to scroll to **Add New Number**, and then press  to add more numbers.
Up to 3 numbers can be added to a local contact.
8. Select the desired contact bandwidth from the pull-down list of **Bandwidth**.
The default contact bandwidth is **Auto**. The system will select the appropriate bandwidth automatically.



9. Press ▲ or ▼ to select **Save** and then press  to accept the change.


To add a conference contact via the remote control:


1. Select  (**Dial** menu) or press  to enter the pre-dialing screen.
2. Press ◀ to return to the menu.
3. Press ▲ or ▼ to scroll to **Directory** and then press ▶ to enter submenu.
4. Press ▲ or ▼ to scroll to **All Contacts** and then press  to select **Conference Contacts** from the pull-down list.
5. Press ▲ or ▼ to scroll to **New Conference**, and then press .
6. Enter conference name in the **Name** field.
7. Enter a few characters of the contact name or the contact number in the **Search** field.
Contacts whose name or number matches the characters entered will appear on the screen.
8. Press ▲ or ▼ to select the desired local contact, and then press  to add the desired local contacts to the members List.
9. Repeat steps 7 to 8 to add more contacts.

The number of local contacts that you can add to a conference contact depends on the imported multipoint license.

For example, if you import a 24 ways license to your VC800 system, up to 24 local contacts

can be added to a conference contact. For more information on multipoint license, contact your system administrator.





10. Press ▲ or ▼ to select **Save** and then press  to accept the change.


Editing Contacts


You can edit local contacts or conference contacts (conference contacts are only applicable to VC800 system with a multipoint license) via the remote control, CP960 conference phone or web user interface.

To edit a contact via the remote control:



1. Select  (**Dial** menu) or press  to enter the pre-dialing screen.
2. Press ◀ to return to the menu.
3. Press ▲ or ▼ to scroll to **Directory** and then press ▶ to enter submenu.
4. Select **Local** or **Conference Contacts** from the pull-down list of the **All Contacts**.
5. Press ▲ or ▼ to scroll to the desired contact.
6. Press ▶ to enter submenu


7. Press ▲ or ▼ to **Edit** and then press .





8. Edit the contact information.
9. Press ▲ or ▼ to select **Save** and then press  to accept the change.

To edit a contact via the CP960 conference phone:

1. Tap .
2. Tap the **All Contacts** field.
3. Tap the desired type (**Local** or **Conference contacts**) in the pop-up dialog box.
4. Tap  after the desired contact.















The screenshot shows the 'Contact Detail' dialog box. It has a teal header with a close button (X) and the title 'Contact Detail'. Below the header is a contact icon. The dialog lists three actions: 'Video Call', 'Voice Call', and 'Delete'. Below these actions are four input fields: 'Name' (containing 'Jack'), 'Number1' (containing '10.2.20.23'), 'Number2' (empty), and 'Number3' (empty).


5. Edit the contact information.
6. Tap  to accept the change or  to cancel.

Deleting Contacts




You can delete local contacts or conference contacts (conference contacts are only applicable to VC800 system with a multipoint license) via the remote control, CP960 conference phone or web user interface.

To delete a local contact or conference contact via the remote control:



1. Select  (**Dial** menu) or press  to enter the pre-dialing screen.
2. Press  to return to the menu.
3. Press  or  to scroll to **Directory** and then press  to enter submenu.
4. Press  or  to scroll to the desired contact.
5. Press  to enter submenu.
6. Press  or  to **Delete** and then press .




The display device prompts "Delete selected item?"

7. Press  or  to highlight **OK**, and then press  to delete the contact.

To delete a local contact or conference contact via the CP960 conference phone:

1. Tap .
2. Tap the **All Contacts** field.
3. Tap the desired type (**Local** or **Conference contacts**) in the pop-up dialog box.
4. Tap  after the desired contact.
5. Edit the contact information.

6. Tap **Delete**.



The touch device prompts “Delete selected item?”







7. Tap **OK** to accept the change or **Cancel** to cancel.

Searching for Contacts


You can search for local contacts and conference contacts (conference contacts are only applicable to VC800 system with a multipoint license) via the remote control, CP960 conference phone or web user interface.

If you log into the Yealink VC Cloud Management Service platform or Yealink Meeting Server, you can also search for Yealink Cloud contacts or YMS contacts via the remote control or CP960 conference phone.

To search for contacts via the remote control:



1. Select  (**Dial** menu) or press  to enter the pre-dialing screen.
2. Press  to return to the menu.
3. Press  or  to scroll to **Directory** and then press  to enter submenu.
4. Enter a few or all characters of the contact name or numbers in the **Search** field.


The contacts whose names or phone numbers match the characters entered will appear on the display device.



5. You can press ▲ or ▼ to scroll to the desired contact, and then call or edit this contact.

To search a contact via the CP960 conference phone:

1. Tap .
2. Tap .
3. Enter a few or all characters of the contact name or numbers.



The contacts whose names or phone numbers match the characters entered will appear on the touch screen.











Local directory is configurable via the web user interface at the path **Directory->Local Directory**.


Call History Management


The VC800/VC500 video conferencing system maintains call history lists of All Calls, Missed Calls, Placed Calls and Received Calls. The system supports up to 100 history records. You can view the call history, place a call or delete an entry from the call history entries (including local entries and Cloud entries).

To log call history on the system, you need to enable the history record feature in advance. The history record feature is enabled by default, and you can configure it via the remote control or web user interface.

To configure the history record feature via the remote control:

1. Select  (**More** menu).
2. Press  or  to scroll to **Setting** and then press  to expand the menu.
3. Press  or  to scroll to **Call Features** and then press  to enter submenu.
4. Press  or  to scroll to **History Record**, and then press  to enable or disable this feature.





5. Press  to return to the idle screen.

The history record feature is configurable via the web user interface at the path **Setting->Call Features->History Record**.


Viewing Call History

You can view call history via the remote control, CP960 conference phone or web user interface.


To view call history via the remote control:


1. Select  (**Dial** menu) or press  to enter the pre-dialing screen.

2. Press ◀ to return to the menu.
3. Press ▲ or ▼ to scroll to **History** and then press ▶ to enter submenu.
The display device shows recent call history.
4. Select the desired list from the pull-down list of **All Calls**.
5. Press ▲ or ▼ to view the desired call history.




To view call history via the CP960 conference phone:

1. Tap  .
The touch screen displays all call records.



2. Tap the **All Calls** field.
3. Tap the desired list (**All Calls**, **Missed Calls**, **Placed Calls**, or **Received Calls**) in the pop-up dialog box.













4. Tap  after the desired call records.
The touch screen displays details about this call record.


Call history can be viewed via the web user interface at the path **Directory->History**.

Deleting an Entry from the Call History List



You can delete an entry from the call history list via the remote control, CP960 conference phone or web user interface.

To delete an entry from the call history list via the remote control:


1. Select  (**Dial** menu) or press  to enter the pre-dialing screen.
2. Press  to return to the menu.
3. Press  or  to scroll to **History** and then press  to enter submenu.
The display device shows recent call history.
4. Select the desired list from the pull-down list of **All Calls**.
5. Press  or  to scroll to the desired call history and then press  to enter submenu.
6. Press  or  to **Delete** and then press  to delete the entry.



To delete an entry from the call history list via the CP960 conference phone:

1. Tap .
The touch screen displays all call records.
2. Tap the **All Calls** field.
3. Tap the desired list (**All Calls**, **Missed Calls**, **Placed Calls**, or **Received Calls**) in the pop-up dialog box.
4. Tap  after the desired call records.










5. Tap **Delete**.




The touch device prompts “Delete selected item?”

6. Tap **OK** to accept the change or **Cancel** to cancel.


To clear call history via the remote control:

1. Select  (**Dial** menu) or press  to enter the pre-dialing screen.
2. Press  to return to the menu.
3. Press  or  to scroll to **History** and then press  to enter submenu.
4. Press  or  to scroll to the **Clear**, and then press  .















You can also select the call history list you want to clear from the pull-down list of **All Calls**, and then clear the selected list.


The display device prompt “Delete all records?”.




7. Select **OK**, and then press  to clear the call history.

Adding a Local Contact from the Call History List



To add a local contact from the call history list via the remote control:

1. Select  (**Dial** menu) or press  to enter the pre-dialing screen.
2. Press  to return to the menu.
3. Press  or  to scroll to **History** and then press  to enter submenu.
4. Press  or  to scroll to the desired call history and then press  to enter submenu.
5. Press  or  to scroll to **Add to Contact**, and then press .






6. Enter contact name in the **Name** field.
You can add more than one number for the local contact. For more information, refer to [Adding Contacts](#) on page 70.
7. Press  or  to select **Save** and then press  to accept the change.

To add a local contact from the call history list via the CP960 conference phone:

1. Tap .
The touch screen displays all call records.
2. Tap  after the desired call records.

3. Tap **Add to Contact**.



4. Enter contact name in the **Name** field.
5. Add number for the local contact.
6. Tap  to accept the change or  to cancel.

Call history management feature is configurable via the web user interface at the path **Directory->History**.

Using the VC800/VC500 Video Conferencing System

The VC800/VC500 video conferencing system can be used to place calls, answer calls, or conduct a conference call. You can switch layout, record videos or capture screenshots during a call.

This chapter provides basic operating instructions for the VC800/VC500 video conferencing system. Topics include:

- [Placing a Call](#)
- [Answering or Rejecting Calls](#)
- [Ending a Call](#)
- [Conference Room Management](#)
- [Video Conference Management](#)
- [Call Management](#)
- [Network Quality Tip](#)

If you require additional information or assistance with your new phone, contact your system administrator.

Placing a Call

You can place calls in numerous ways easily.

Placing a Call by Dialing a Number

You can use different call type (**Cloud platform/H.323 account/SIP account/H.323 IP Call/SIP IP Call**) to dial a number when more than one account is registered on the system.







By default, the system selects the call type automatically, which means that the system can try each call type in order when dialing a number. The priority of call types is as follows:


- If you dial an account, the priority is: **Cloud platform>H.323 account>SIP account**.
- If you dial an IP address, the priority is: **H.323 IP Call>SIP IP Call**.

For example: system A is registered with a Yealink cloud account and a SIP account. When system A selects a call type automatically and then dials a number, it will use its cloud account (highest priority) to dial the number first. If this call fails, system A continues to use its SIP account (next priority) to dial this number.


You can dial a number via the remote control, CP960 conference phone or web user interface.


To dial a number using the remote control:

1. Select  (**Dial** menu) or press  to enter the pre-dialing screen.
2. Select the desired call type from the pull-down list of **Call Type** before calling.
3. Enter the desired number using the keypad or the on-screen keyboard.
4. Press  to select  (video call) or  (voice call), and then press .



To dial a number using the CP960 conference phone:


1. Tap .
2. Tap the **Auto** field.
3. Tap the desired call type in the pop-up dialog box.



4. Enter the desired number.
5. Tap **Send**.

To dial a number via the web user interface:

1. Click **Home**.
2. Enter the desired number in the **Enter Number** field.
3. (Optional.) Select the desired call type.
4. (Optional.) Select the desired video call rate.
If you select **Auto**, the system will select the appropriate video call rate automatically.
5. Click **Video Call** or **Voice Call**.

**Note**










The system supports placing calls using contact numbers, SIP URI, IP address, H. 323 account, SIP account or Cloud account. SIP URI and IP addresses can be up to 32 characters. For example: SIP URI:2210@sip.com, IP: 192.168.1.15.

For more information, contact your system administrator.


Editing Numbers before Calling

You can edit numbers before calling from the dialing screen or call history. You can edit numbers before calling via the remote control or CP90 conference phone. The following introduces how to edit numbers before calling from the call history.

To edit number before calling via the remote control:



1. Select  (**Dial** menu) or press  to enter the pre-dialing screen.
2. Press  to return to the menu.
3. Press  or  to scroll to **History** and then press  to enter submenu.
4. Press  or  to scroll to the desired history record and then press  to open submenu.


5. Press ▲ or ▼ to scroll to **Edit before calling** and then press .



6. Edit the number and dial out.

To edit numbers before calling via the CP960 conference phone:

1. Tap  .
The touch screen displays all call records.
2. Tap  after the desired call records.
3. Tap **Edit before calling**.



4. Edit the number and tap **Send**.

Placing a Call from the Search Result



You can place calls from the search result via the remote control or CP960 conference phone.


The search source list can be Local Directory, History, Cloud contacts and enterprise directory.

Note

Your system administrator can configure the search source list. Contact your system administrator for more information.


To place a call from search results via the remote control:

1. Select  (**Dial** menu) or press  to enter the pre-dialing screen.
2. Select the desired call type from the pull-down list of **Call Type** before calling.
3. Enter a few continuous characters of the contact name or continuous numbers of the contact number to search for a desired contact.




4. Select a desired contact to dial out.

To place a call from search results via the CP960 conference phone:

1. Tap .
2. Tap the **Auto** field.
3. Tap the desired call type in the pop-up dialog box.

4. Enter a few continuous characters of the contact name or continuous numbers of the contact number to search for a desired contact.











5. Tap the desired contact.


Placing a Call from the Directory

You can place calls to contacts via the remote control, CP960 conference phone or web user interface.


To place a call from the directory via the remote control:


1. Select  (**Dial** menu) or press  to enter the pre-dialing screen.
2. Press  to return to the menu.
3. Press  or  to scroll to **Directory** and then press  to enter submenu.
4. Select the desired contact type from the pull-down list of the **All Contacts**.
5. Press  or  to scroll to the desired contact.

- Press ► to enter submenu, select the desired call type, and then press (OK) to dial out the number.



To place a call from the directory via the CP960 conference phone:

- Tap .
- Tap the **All Contacts** field.
- Tap the desired type in the pop-up dialog box.
- Tap (i) after the desired contact.
- Tap **Video Call** or **Voice Call**.













Placing a call from directory is configurable via the web user interface at the path **Directory->Local Directory**.


Placing a Call from the Call History

You can place a call from the call history list via the remote control, CP960 conference phone or web user interface.



To place a call from the call history list via the remote control:

1. Select  (**Dial** menu) or press  to enter the pre-dialing screen.
2. Press  to return to the menu.
3. Press  or  to scroll to **History** and then press  to enter submenu.
The display device shows recent call history.
4. Select the desired list from the pull-down list of **All Calls**.
5. Press  or  to scroll to the desired call record and then press  to enter submenu.




6. Select **Video Call** or **Voice Call**, and then press  to dial out the number.

To place a call from the call history list via the CP960 conference phone:

1. Tap  .
The touch screen displays all call records.
2. Tap the **All Calls** field.
3. Tap the desired list in the pop-up dialog box.
4. Tap  after the desired call records.

5. Tap **Video Call** or **Voice Call**.



Placing a call from call history is configurable via the web user interface at the path **Directory->History**.

Answering or Rejecting Calls


When the system is receiving a call, you can answer or reject the call in the following ways:

- Using the remote control
- Using the CP960 conference phone

If the system accepts multiple calls, a conference call will be established.



To answer a call:

Do one of the following:

- Press  on the remote control.
- Tap **Answer** on the CP960 conference phone.

To reject a call:

Do one of the following:

- Press  or select **Reject** first, and then press  on the remote control.
- Tap **Reject** on the CP960 conference phone.

Auto Answer

You can enable the auto answer feature for the system to automatically answer the first

















incoming call.


Auto answer features you need to know:


Parameters	Description
Auto Answer	Enables or disables the system to automatically answer the incoming point-to-point call.
Auto Answer Mute	Mute the local microphone automatically when an incoming call is answered automatically. This feature can be enabled only when the auto answer feature is enabled.
Auto Answer Multiway	Enables or disables the system to answer an incoming call automatically when the system is during a call. This feature is available only when the auto answer is enabled.

Auto answer is configurable via the remote control, CP960 conference phone or web user interface.

To configure auto answer via the remote control:


1. Select  (**More** menu).
2. Press  or  to scroll to **Setting** and then press  to expand the menu.
3. Press  or  to scroll to **Call Features** and then press  to enter submenu.
4. Press  or  to scroll to **Auto Answer**, and then press  to enable or disable this feature.
5. Press  or  to scroll to **Auto Answer Mute**, and then press  to enable or disable this feature.
6. Press  or  to scroll to **Auto Answer Multiway**, and then press  to enable or disable this feature.





7. Press  to return to the idle screen.

If the auto answer feature is enabled, the  icon will appear on the status bar of the display device.

To configure auto answer via the CP960 conference phone:

1. Swipe down from the top of the screen.
2. Tap  to enable or disable auto answer.










If the auto answer feature is enabled, the  icon will appear on the status bar of the touch screen.


Auto answer is configurable via the web user interface at the path **Setting-> Call Features->Auto Answer/Auto Answer Mute/Auto Answer Multiway**.


Do Not Disturb (DND)

You can use DND to reject incoming calls automatically via the remote control, CP960 conference phone or web user interface. Callers will receive a busy message. All calls you receive while DND is enabled will be logged to Missed Calls list.


To enable the DND mode via the remote control:

1. Select  (**More** menu).
2. Press  or  to scroll to **Setting** and then press  to expand the menu.
3. Press  or  to scroll to **Call Features** and then press  to enter submenu.

4. Press ▲ or ▼ to scroll to **DND**, and then press  to enable or disable this feature.





5. Press  to return to the idle screen.


The  icon will appear on the status bar of display device, and "Do not disturb now!" will be prompted at intervals.

The system will reject all incoming calls automatically, and the icon and numbers of missed calls are displayed on the status bar of the display device. If the system places a call, after the call is established, the DND mode will be disabled automatically.

To enable the DND mode via the CP960 conference phone:

1. Swipe down from the top of the screen.
2. Tap  to enable DND.




If the DND feature is enabled, the touch screen prompts "  DND mode is enabled".

When misses a call, the prompt message "**n New Missed Call(s)**" ("n" indicates the

number of missed calls) will appear on the CP960 conference phone's touch screen.

To disable the DND mode via the CP960 conference phone:

- Do one of the following:
 - Swipe down from the top of the screen, tap  to disable DND.
 - When the CP960 is idle, tap **Exit DND mode** to disable DND.






DND is configurable via the web user interface at the path **Setting->Call Features->DND**.


DND during an active call


You can use the DND mode to reject incoming calls automatically during an active call.


You can enable/disable the DND mode for the system via the remote control, CP960 conference phone or web user interface. The DND mode will be disabled after the call ends.

To enable the DND mode during an active call via the remote control:




- Press  or  to open **Talk Menu**.
- Press  or  to scroll to **DND** and then press .



The  icon will appear on the status bar of display device, and "Do not disturb now!" will be prompted at intervals.

- Press  to return.

To enable or disable the DND mode during an active call via the CP960 conference phone:

- Tap  during a call to enable DND.
The  icon will appear on the status bar of touch screen.
- Tap  during a call to disable DND.

DND during an active call feature is configurable via the web user interface at the path **Home->DND**.

Ending a Call

You can end a call via the remote control, CP960 conference phone or web user interface.

To end a call via the remote control:

1. Press  .

To end a call via the CP960 conference phone:

1. Tap **EndCall**.

To end a call via the web user interface:

1. Click **Hang Up All** button on the web user interface.

The interface prompts "Hang up?"

2. Click **Confirm** to end the call.

Conference Room Management

Your video conferencing system can act as a virtual meeting room, so that other devices can dial your system to join a meeting.

Conference Type

VC500 video conferencing endpoint and VC800 video conferencing system that has no multipoint license can host a **Regular Mode** conference only.

VC800 video conferencing system with a multipoint license can host a **Regular Mode** conference or a **VMR Mode** conference.

Regular Mode Conference

In **Regular Mode** conference, when participants call the moderator (MCU provider), the moderator will join the meeting.

To configure regular mode conference via the web user interface:

1. Click on **Setting->Conference Setting**.

2. Select **Regular Mode** from the pull-down list of **Conference Type**.

The screenshot shows the Yealink VC800 web interface. The top navigation bar includes links for About, Language, and Logout. Below this is a green header with the Yealink logo and navigation tabs: Home, Status, Account, Network, Setting (highlighted), Directory, and Security. On the left is a sidebar menu with options: General, Date & Time, Call Features, Video & Audio, Camera, Auto-Provision, Configuration, Upgrade, Tones, Wireless Micphone, 3rd-Party VMR, and Conference Setting (highlighted). The main content area is titled 'Conference Setting'. It features a 'Conference Type' dropdown menu set to 'Regular Mode', which is highlighted with a red rectangle. Below this is the 'Multipoint Allocation' section, stating 'This VC800 supports 8 ways built-in MCU'. It includes two rows for 'Virtual Meeting Room 1' and 'Virtual Meeting Room 2', each with a '4 Ways' dropdown. The 'Virtual Meeting Room 1' section also includes a 'Meeting Password' dropdown set to 'Off' and a 'Password' text input field. The 'Virtual Meeting Room 2' section is partially visible at the bottom.

3. Click **Confirm** to accept the change.

For more information on how to join a regular mode conference, refer to [Joining the Meeting](#) on page 100.

Note

For VC500 and VC800 that has no multipoint license, the regular mode conference supports up to one video call and 5 voice calls (a conference moderator and 6 participants).

For VC800 with a multipoint license, the number of participants depends on the multipoint license you imported. For more information, contact your system administrator.


VMR Mode Conference

VMR mode conference is only applicable to VC800 video conferencing system that has a multipoint license. It is not applicable to VC500 video conferencing endpoint.

In VMR mode conference, the MCU of moderator can be used to host two independent conferences (corresponding to virtual meeting room 1 and virtual meeting room 2).

- Virtual meeting room 1: when participants call the virtual meeting room 1, the moderator will join the meeting.

- Virtual meeting room 2: when participants call the virtual meeting room 2, only participants join the meeting, the moderator does not join the meeting.



If you import a multipoint license to the VC800 system, you can allocate the MCU ways between two virtual meeting rooms.

- If you import an 8 ways multipoint license to the VC800 system, $X+Y \leq 8$. Two virtual meeting rooms supports up to 8 ways video calls.
- If you import a 16 ways multipoint license to the VC800 system, $X+Y \leq 16$. Two virtual meeting rooms supports up to 16 ways video calls.
- If you import a 24 ways multipoint license to the VC800 system, $X+Y \leq 24$. Two virtual meeting rooms supports up to 24 ways video calls.

Note

When you import an 8 or 16 ways multipoint license to the VC800 system, the virtual meeting room 1 provides additional 5 voice calls.

To configure VMR mode conference via the web user interface:

1. Click on **Setting->Conference Setting**.
2. Select **VMR Mode** from the pull-down list of **Conference Type**.
3. Select maximum ways of video calls from the pull-down list of **Virtual Meeting Room 1**.

4. Select maximum ways of video calls from the pull-down list of **Virtual Meeting Room 2**.

The screenshot shows the Yealink VC800 web interface. The top navigation bar includes 'About', 'Language', and 'Logout'. The main menu has 'Home', 'Status', 'Account', 'Network', 'Setting' (highlighted), 'Directory', and 'Security'. On the left, a sidebar lists various settings: General, Date & Time, Call Features, Video & Audio, Camera, Auto-Provision, Configuration, Upgrade, Tones, Wireless Micphone, 3rd-Party VMR, **Conference Setting** (highlighted), and Remote Control.

The 'Conference Setting' page is displayed. It includes a 'Conference Type' dropdown set to 'VMR Mode'. A red box highlights the 'Multipoint Allocation' section, which shows 'Virtual Meeting Room 1' and 'Virtual Meeting Room 2' both set to '12 Ways'. Below this, settings for 'Virtual Meeting Room 1' and 'Virtual Meeting Room 2' are listed, including Meeting Password (On), Password (123 for Room 1, 456 for Room 2), Voice Activation (Enabled), and Voice Hold Active Duration (1s).

By default, the MCU are distributed equally between two virtual meeting rooms.

5. Click **Confirm** to accept the change.

For more information on how to join a VMR mode conference, refer to [Joining the Meeting](#) on page 100.

Meeting Password

Depending on how a conference call is set up, you might be required to enter a meeting password to join the call. You can also require far-end systems to enter a meeting password to prevent unauthorized participants from joining conference calls hosted by your system.

If you host a regular mode conference, you need to configure a password for virtual meeting room 1. If you host a VMR mode conference, you need to configure passwords for virtual meeting room 1 and virtual meeting room 2 respectively.

To set up a meeting password via the web user interface:

1. Click on **Setting**->**Conference Setting**.
2. Select **On** from the pull-down list of **Meeting Password**.

3. Enter meeting password in the **Password** field.

The screenshot shows the Yealink VC800 web interface. The top navigation bar includes links for About, Language, and Logout. The main menu has tabs for Home, Status, Account, Network, Setting (active), Directory, and Security. On the left, a sidebar lists various settings categories: General, Date & Time, Call Features, Video & Audio, Camera, Auto-Provision, Configuration, Upgrade, Tones, Wireless Micphone, 3rd-Party VMR, Conference Setting (selected), and Remote Control. The main content area is titled 'Conference Setting'. It includes a 'Conference Type' dropdown set to 'VMR Mode'. Under 'Multipoint Allocation', it states 'This VC800 supports 24 ways built-in MCU'. There are two 'Virtual Meeting Room' sections. 'Virtual Meeting Room 1' has a 'Meeting Password' dropdown set to 'On' and a 'Password' text field containing '123'. 'Virtual Meeting Room 2' has a 'Meeting Password' dropdown set to 'On' and a 'Password' text field containing '456'. At the bottom, 'Voice Activation' is set to 'Enabled' and 'Voice Hold Active Duration' is set to '1s'.

4. Click **Confirm** to accept the change.

Joining the Meeting

Participants can dial **IP##meeting password** or **meeting password@IP** to enter the virtual meeting room.

For example:

- The IP address of moderator is 10.3.6.201.
- 123 is meeting password for virtual meeting room 1.
- 456 is meeting password for virtual meeting room 2.

Participants can dial **10.3.6.201##123** or **123@10.3.6.201** to enter the virtual meeting room 1.

Participants can dial **10.3.6.201##456** or **456@10.3.6.201** to enter the virtual meeting room 2.

Without a meeting password or with a wrong meeting password, the call will fail.

Video Conference Management

The following introduces how to manage video conference.









Initiating a Conference


You can initiate a conference by dialing a group or inviting participants during a call.

You can initiate a conference via the remote control, CP960 conference phone or web user interface.

Initiating a Conference by Dialing a Group

To dial a group via the remote control:


1. Select  (**Dial** menu) or press  to enter the pre-dialing screen.
2. Press  to return to the menu.
3. Press  or  to scroll to **Group Dial** and then press  to enter submenu.
4. Select the desired contacts you want to call.
 - **For VC800 system:** The number of contacts you can call depends on the imported multipoint license.
 - **For VC500 endpoint:** you can select up to 6 contacts.
5. Press  to enter submenu
6. Select **Start conference call**, and then press .




To dial a group via the CP960 conference phone:

1. Tap .






2. Tap the **Call multiple members? Click here** field.




3. Tap the desired contacts you want to call.
 - **For VC800 system:** The number of contacts you can call depends on the imported multipoint license.
 - **For VC500 endpoint:** you can select up to 6 contacts.
- Tap .

Initiating a Conference by Inviting Participants

To invite participants during a call via the remote control:


1. Using your preferred dialing method, call the first site.
2. Press  or  to open **Talk Menu**.
3. Press  or  to scroll to **New Call** and then press  to expand the menu.

4. Do one of the following:




- If you select **Dial**, enter a phone number, and then dial out.
- If you select **Directory**, select a desired contact, and then dial out.
- If you select **Group Dial**, check the desired contacts' checkboxes, and then select **Start conference call**.
- If you select **History**, select the desired history record, and then dial out.

5. Repeat the above steps until all participants are added.


Note You can press  to enter the pre-dialing screen during a call.





If you try to invite a new party when the maximum number has been reached, the system will prompt "Talking Session over max Session number!".

To invite participants during a call via the CP960 conference phone:

1. Using your preferred dialing method, call the first site.
2. Tap .

3. Do one of the following:



- If you tap , enter a phone number and then tap **Invite**.
 - If you tap , tap a desired contact to dial out.
 - If you tap , tap the desired history record to dial out.
 - If you tap **Call multiple members? Click here**, tap the desired contacts you want to call, and then tap .
4. Repeat steps 2 to 3 until all participants are added.

Inviting participants via the web user interface at the path **Home**.


Removing Conference Participants

If you are the moderator of a video conference, you can remove conference participants via the remote control, CP960 conference phone or web user interface.

To remove conference participants during a conference call via the remote control:

1. Press  or  to open **Talk Menu**.


2. Press ▲ or ▼ to scroll to **Remove** and then press ► to enter submenu.





3. Select the party you want to remove, and then press **OK**.

To remove any party via the CP960 conference phone:

1. Tap  during a call.



2. Tap  to remove the desired participant.


To remove any party from a multi-way call via the web user interface, go to the path **Home** (Hover your cursor over of the number of remote system, and then click ).


Muting or Unmuting All Conference Participants

If you are the moderator of a video conference, you can mute or unmute all conference


participants via the CP960 conference phone only.


To mute all conference participants via the CP960 conference phone:

1. Tap  during a call.
The touch screen displays all participants.
2. Tap **All mute** to mute all participant.



To unmute all conference participants via the CP960 conference phone:



1. Tap  during a call.
The touch screen displays all participants.
2. Tap **All unmute** to unmute all participant.






Muting or Unmuting a Conference Participant

If you are the moderator of a video conference, you can mute or unmute any conference participant via the CP960 conference phone only.


To mute a conference participant via the CP960 conference phone:

1. Tap  during a call.
The touch screen displays all participants.
2. Tap  after the participant that you want to mute.






The participant is muted, and the  icon changes to .

To unmute a conference participant via the CP960 conference phone:

1. Tap  during a call.
The touch screen displays all participants.

2. Tap  after the participant that you want to unmute.





The participant is unmuted, and the  icon changes to .

Ending the Conference

If you are the moderator of a video conference, you can end the conference via the remote control, CP960 conference phone or web user interface. After ending the conference, all participants leave the conference.

To end a conference via the remote control:

1. Press  .
The display device prompts "End all active calls?"
2. Select **OK**, and then press .

To end a conference via the CP960 conference phone:

1. Tap **EndCall**.
The CP960's touch screen prompts "End all active calls?"
2. Tap **OK**.

To end a conference via the web user interface:

1. Click **Hang Up All** button on the web user interface.
The interface prompts "Hang up?"
2. Click **Confirm** to end the call.






Call Management

You can enable mute mode, record video, control the video and change screen layout during an active call.

Call Mute

You can enable mute mode to mute the microphone of the active audio device so that other parties cannot hear you.

To mute the microphone, do one of the following:

- Press  on the remote control.
- Tap  on the CP960 conference phone.
- Tap  on the CP960's touch screen.
- Tap  on the CPW90 wireless microphones.
- Tap  on the CPE90 wired expansion microphones.
- Log into the web user interface, check the **Mute** checkbox.

If video conferencing system is muted, the  icon will appear on the local video.






Call Statistics

If voice quality is poor during a call, you can enter the Call Statistics screen to view the current status of the call to find out why.


Codec, bandwidth, total packet lost and other parameters about presentation are included in the call statistics. For example, when a delay occurs or the video has a 'mosaic' look, you can view the total packet loss to check whether the packet has been lost.

Call statistics is configurable via the remote control, CP960 conference phone or web user interface.

To view call statistics via the remote control:

1. Press  or  to open **Talk Menu** during a call.
2. Press  or  to scroll to **Call Statistics** and then press .


3. Press ▲ or ▼ to view call statistics for every participant.





The screenshot shows the 'Call Statistics' screen on a Yealink VC800. The interface includes a top status bar with time (19:40), date (2017-06-07), device name (Yealink VC800), and network status (LAN:10.2.20.232, 2226). A left sidebar contains a 'Back' button and a list of participants, with 'Yealink VC Desktop' (IP: 10.2.20.24) selected. The main area displays a table of statistics for the selected participant.


Type	Total Bandwidth	Recv (130 kb/s)	Send (215 kb/s)
Video	Resolution	640 x 360	352 x 288
	Codec	H264HP	H264HP
	Bandwidth	82 kb/s	167 kb/s
	Frame Rate	2 fps	30 fps
	Jitter	51 ms	0 ms
	Total Packet Lost	0	0
Audio	Codec	G7221C	G7221C
	Bandwidth	48 kb/s	48 kb/s
	Sample Rate	32 k	32 k
	Jitter	0 ms	0 ms
	Total Packet Lost	0	0
Share	Resolution	--	--
	Codec	--	--
	Bandwidth	--	--
	Frame Rate	--	--

Protocol: H323
Total Talk Number: 2
Device Info: Yealink VCDesktop 1.23.0.15 38/2
Total Bandwidth: Recv (185 kb/s), Send (1852 kb/s)

4. Press  to return.


To view call statistics via the CP960 conference phone:

1. Tap  ->  during a call.
The touch screen displays all participants.
2. Tap the desired participant to view call statistics.



The screenshot shows the 'Statistics' screen on a CP960 conference phone. The interface has a teal header with a back arrow and the title 'Statistics'. Below the header, there are two tabs: 'Received' (159 kb/s) and 'Send' (343 kb/s). The main content area displays statistics for 'video', 'Audio', and 'Share' sections.

	Received 159 kb/s	Send 343 kb/s
video		
Resolution	640 x 360	
Codec	H264HP	
Bandwidth	111 kb/s	
Frame rate	2 fps	
Jitter	51 ms	
Total packet lost	0	
Packet lost	0%	
Audio		
Codec	G7221C	
Bandwidth	48 kb/s	
Sample rate	32 k	
Jitter	5 ms	
Total packet lost	0	
Packet lost	0 %	
Share		
Resolution	--	

To view call statistics via the web user interface, go to the path **Home** (Hover your cursor over the other party on the left side of the screen, and then click ).

Changing the Video Input Source






VC800/VC500 video conferencing system supports these video input sources: camera and PC.

You need to connect a PC to the VCH50 video conferencing hub for sharing contents. When the VC800/VC500 system is idle, the display device displays PC content by default.








If two display devices are connected to the VC800/VC500 codec, local video image is shown on the main display device, and the PC content is shown on the secondary display device.


During a call, the display device will display differently depending on whether a secondary display device is connected and the video input source you select. You can change the video input source via the remote control and web user interface.

To change video input when the system is idle via the remote control:



1. If  is set to **Input** key, press  to open video input source.
For more information on how to customize the key, refer to [Custom Key Type](#) on page 62.
The display device shows Camera and PC input sources.
2. Press  or  to select the desired input source, and then press .
The display device shows the selected source.

To change video input during a call via the remote control:

1. Do one of the following to open video input source:
 - If  is set to **Input** key, press .
For more information on how to customize the key, refer to [Custom Key Type](#) on page 62.
 - Press  or  to open **Talk Menu**.
Press  or  to scroll to **Input Choose** and then press  to enter submenu.



The display device shows **Camera**, **Camera +PC** and **PC** input sources.

2. Press ▲ or ▼ to select the desired input source , and then press .
 - If you select **PC**, the remote video image is shown in big size, and the PC content is shown in small size (Picture-in-Picture).
 - If you select **Camera+PC**, the PC content is shown in big size, and other video images are shown in small size.
 - If you select **Camera**, the remote video image is shown in big size, and the local video image is shown in small size (Picture-in-Picture).
3. Press  to return.




Video input is configurable via the web user interface at the path **Home->Input Choose**.


Far Control Near Camera


Local video is displayed on the display device of the far site during a call. For the best view, you can enable the **Far Control Near Camera** feature to allow the far site to control the focus and angle of the local camera.

You can configure the **Far Control Near Camera** feature via the remote control or web user interface.

To configure far control near camera feature via the remote control:

1. Select  (**More** menu).
2. Press ▲ or ▼ to scroll to **Setting** and then press  to expand the menu.
3. Press ▲ or ▼ to scroll to **Video & Audio** and then press ► to enter submenu.
4. Press ▲ or ▼ to scroll to **Far Control Near Camera** and then press  to enable or disable this feature.



5. Press  to return to the idle screen.






Far-end Camera Control is configurable via the web user interface at the path **Setting->Video**


& Audio->Far Control Near Camera.


Controlling the Remote Camera



If the remote camera enables the **Far Control Near Camera** feature and corresponding camera control protocol is enabled (For more information, refer to your system administrator), you can control the remote camera during a video call via the remote control or CP960 conference phone.

To control the remote camera during a video call via the remote control:







1. Press  or  to open **Talk Menu**.
2. Press  or  to scroll to **Near/Far Camera** and then press  to select the remote video.

An  icon (indicates which camera you are controlling) appears in the remote video image.



3. Press the navigation key to adjust the angle or press  or  to adjust the focus of the remote camera.

To control the remote camera during a video call via the CP960 conference phone:

1. Tap  -> .
2. Tap **The current control camera**.
3. Tap the remote video.
An  icon (indicates which camera you are controlling) appears in the remote video image.
4. Tap  to return.
5. Tap the navigation keys to adjust the angle of the camera or tap  or  to adjust the focus of the remote camera.

Presentation





The system supports sharing video and documents on a PC while simultaneously displaying the main video. We recommend using dual display devices for sharing contents.

If a PC is connected to the VCH50 video conferencing hub, the VC800/VC500 system will start presentation automatically. You can also start/stop presentation manually via the remote control or CP960 conference phone. The presentation stops automatically if the PC is disconnected from the system.

During a voice call, only local display device displays the PC content. During a video call, both local and remote display devices display PC contents. Only one content can be shared at a time. A presentation started later will replace the previous one.










To start/stop presentation manually when the system is idle:

If a PC is connected to the VCH50 video conferencing hub, but a presentation does not start automatically, do one of the following to start or stop a presentation manually:

- If  is set to **Presentation** key, press  to start or stop presentation.
For more information on how to customize the key, [Custom Key Type](#) on page 62.
- Tap  on the CP960 conference phone to start presentation.
Tap  on the CP960 conference phone to stop presentation.

To start/stop presentation manually during a call:

If a PC is connected to the VCH50 video conferencing hub, but a presentation does not start automatically, do one of the following to start or stop a presentation manually:

- If  is set to **Presentation** key. Press  to start or stop presentation.
For more information on how to customize the key, refer to [Custom Key Type](#) on page 62.
- Press  or  to open **Talk Menu**.
Press  or  to scroll to **Presentation**, and then press  to start or stop presentation.
- Tap  on the CP960 conference phone to start presentation.
Tap  on the CP960 conference phone to stop presentation.

Note

You can also start a presentation by changing the video input source. For more information, refer to [Changing the Video Input Source](#) on page 111.

Video Recording


Before recording video, make sure a USB flash driver is connected to VC800/VC500 codec, VCH50 video conferencing hub or CP960 conference phone and the USB feature is enabled.

The recorded video will be saved in .mkv format and named as the recorded time and date.

Video can be played on either the system itself or on a computer using an application capable of playing .wav files.

Note

The system supports FAT32 and NTFS format USB flash drive or removable hard drive. When using the NTFS format, only the first partition is supported.

After the USB flash drive is connected and the USB feature is enabled, the display device will prompt "USB device available now". The  icon will appear on the status bar of the display device.

Before recording video, you need to know the following:

- When recording video, it is not allowed to play or delete the video from the menu.
- When recording video, it is not allowed to capture screenshots, but you can view and delete screenshots.
- When playing video recording, it is not allowed to record again.
- When receiving or making a call, it is not allowed to record.
- If you answer an incoming call during recording, the system will go on recording.
- When recording during a video call, the record will be finished automatically after the call ends.
- When playing, recording or pausing video, the system will not go to sleep automatically.
- If you remove the working USB flash drive or insert another USB flash drive during recording, the recording will be stopped.


Configuring Video Recording

To configure video recording via the web user interface:

1. Click on **Setting->Video & Audio**.
2. Select the desired value from the pull-down list of **Recording**.
3. Select the desired value from the pull-down list of **Auto Recording**.

If it is enabled, the system will start recording automatically once a call is established.




4. If you connect dual screen, select the desired screen you want to record from the pull-down list of **Dual Screen Recording Setting**.





5. Click **Confirm** to accept the change.

Recording Videos

To record videos via the remote control when the system is idle or during a call:














1. Press  to start recording and then press  again to stop recording.
When you start recording, the display device will show  and the recording time. When you stop recording, the recording icon disappears from the screen. The display device prompts "USB record succeed".

To record videos via the CP960 conference phone:


1. Tap  to start recording and then tap  to stop recording.
When you start recording, the touch screen will prompt "Recording". When you stop recording, the touch screen prompts "USB record succeed".

Viewing Recorded Videos

To view recorded video via the remote control:

1. Select  (**More** menu).
2. Press  or  to scroll to **Record** and then press  to enter submenu.
3. Press  or  to scroll to **Video** and then press .
4. Press  or  to select desired video, and then press  or select .
5. You can do the following:
 - Select  to pause.
 - Select  to continue playing video.




- To skip forward the video, press ►. Press once to skip forward 4 seconds.
- To rewind the video, press ◀. Press once to rewind 4 seconds.
- To adjust the volume of the speakerphone, press 🔊- or 🔊+.
- Select ⏮ to stop playing video.

You can also press  on the remote control to stop playing video.


If you receive an incoming call while you are playing video, the system will stop playing video automatically.


Deleting Recorded Videos

To delete recorded video via the remote control:

1. Select  (**More** menu).
2. Press ▲ or ▼ to scroll to **Record** and then press ► to enter submenu.
3. Press ▲ or ▼ to scroll to **Video** and then press .
4. Press ▲ or ▼ to scroll to a video.
5. Select  to delete the video.

The display device prompts "Delete this video?"



6. Press ▲ or ▼ to scroll to **OK** and then press .

Screenshot

You can capture the screenshot from the camera via the remote control, CP960 conference phone or web user interface. Make sure a USB flash driver is connected to VC800/VC500 codec, VCH50 video conferencing hub or CP960 conference phone and the USB feature is enabled.


You can view, delete or scale the screenshots via the remote control.

When you capture a screenshot via the web user interface, you can save the screenshots to the

computer. The stored screenshot will be saved in .jpg format and named as the captured time and date. You can view the screenshot using an application capable of viewing .jpg pictures.

Note

The system supports FAT32 and NTFS format USB flash drive or removable hard drive. When using the NTFS format, only the first partition is supported.

After the USB flash drive is connected and the USB feature is enabled, the display device will prompt "USB device available now". The  icon will appear on the status bar of the display device.


Before capturing screenshots, you need to know the following:

- When receiving or making a call, it is not allowed to capture screenshots.
- When recording video, it is not allowed to capture screenshots.
- If multiple USB flash drives are connected, and you remove the working USB flash drive, the remained one can continue to work seamlessly.

Configuring Screenshots

To configure screenshots feature via the web user interface:

1. Click on **Setting**->**Video & Audio**.
2. Select the desired value from the pull-down list of **Screenshot**.





The screenshot shows the Yealink VC800 web interface. The top navigation bar includes 'About', 'Language', and 'Logout'. The main menu has 'Home', 'Status', 'Account', 'Network', 'Setting' (highlighted), 'Directory', and 'Security'. On the left, a sidebar lists various settings categories, with 'Video & Audio' selected. The main content area displays settings for 'Audio Input' (VCS Phone), 'Audio Output' (VCS Phone), 'Presentation' (Mix: On), 'Far-end Camera Control' (Not FECC in call: 15, Far Control Near Camera: Enabled), 'Output Resolution' (Display1: Auto(1920 x 1080 60H, Display2: No devices), and 'USB Config'. Under 'USB Config', 'USB Enable' is Enabled, 'Recording' is Enabled, 'Auto Recording' is Disabled, and 'Screenshot' is Enabled (highlighted with a red box). 'Dual Screen Recording Setting' is set to 'Screen 1 Only'.

3. Click **Confirm** to accept the change.

Capturing Screenshots

To capture screenshots via the remote control when the system is idle or during a call:

1. If  is set to **Screenshot** key, press  to capture screenshot.

For more information on how to customize the key, refer to [Custom Key Type](#) on page 62.

















To capture screenshots via the CP960 conference phone when the system is during a call:


1. Tap  -> .

Capturing the screenshot via the web user interface at the path **Home->Screenshot**.

Viewing Screenshots











To view screenshots via the remote control:

1. Select  (**More** menu).
2. Press  or  to scroll to **Record** and then press  to enter submenu.
3. Press  or  to scroll to **Screenshot**, and then press .
4. Press  or  to select desired screenshots, and then press  or select .
5. Do the following:
 - Press  or  to view previous or next screenshot.
 - Press  or  to zoom screenshot in/out.
 - Select  to exit.


You can also press  on the remote control to exit.

Deleing Screenshots

To delete screenshots via the remote control:

1. Select  (**More** menu).
2. Press  or  to scroll to **Record** and then press  to enter submenu.
3. Press  or  to scroll to **Screenshot**, and then press .
4. Press  or  to select desired screenshots, and then select .

The display device prompts "Delete this screenshot?"













5. Press ▲ or ▼ to scroll to **OK** and then press **OK**.

Screen Layout

The total number of available screen layouts depends on the number of connected callers, whether a single display or a dual display is used, and whether a presentation is being viewed.


Screen layouts appear as one of the following types:


- **OnePlusN** ( / ): In this layout, the assigned participant is given prominence in the largest pane regardless of who is currently speaking. Other participants are displayed in a strip beside the assigned speaker.
- **Selected Speaker** ( / ): In this layout, only the selected speaker is seen in a large pane.
- **Equal N×N** ( / ) : In this layout, every participant is given equal prominence in equal-sized panes.
- **Picture-in-Picture** ( / ): During two-way video calls, one participant is shown in full screen, while the other participant is shown in the PIP (Picture-in-Picture).
- **Speaker View** ( / ): For VC800 system: during multi-way video calls, the active speaker is given prominence in the largest pane. Other participants are displayed in a strip beside the active speaker. Speaker view is not applicable to VC500 endpoint.

Changing Screen Layout


To change screen layout via the remote control:


1. Press  during a call.



2. Select the desired layout, and then press  .

To change screen layout via the CP960 conference phone:


1. Tap  during a call.
2. Tap the desired layout.



Single Display Screen Layouts


Two-way Video Calls

Picture-in-picture layout is used by default.



Two-way Video Call with a Presentation


The PC content is given prominence in the largest pane. Other participants are displayed beside the PC content.



Multi-way Video Calls

Multi-way video calls are only applicable to VC800 system that has a multipoint license. The following takes four-way video calls as an example. Voice activation layout is used by default.


The active speaker is given prominence in the largest pane. Other participants are displayed in a strip beside the active speaker.




Multi-way Video Call with a Presentation

Multi-way video calls are only applicable to VC800 system that has a multipoint license. The following takes four-way video calls as an example. Voice activation layout is used by default.


The PC content is given prominence in the largest pane. Other participants are displayed in a strip beside the PC content. The speaker is fixed at the bottom-left corner.




Dual Display Screen Layouts

To make it easier for users to view video images, users can connect two display devices to Display1 and Display2 ports respectively. When two display devices are connected to the VC800/VC500 codec, the status bar of the primary display device will display  icon.

Two-way Video Calls



Two-way Video Call with Presentation




Multi-way Video Calls

Multi-way video calls are only applicable to VC800 system that has a multipoint license. The following takes four-way video calls as an example. Voice activation layout is used by default.

Primary display device: The active speaker is given prominence in the largest pane. Other participants are displayed in a strip beside the active speaker.

Secondary display device: local image is seen in a large pane.




Multi-way Video Call with Presentation

Multi-way video calls are only applicable to VC800 system that has a multipoint license. The following takes four-way video calls as an example. Voice activation layout is used by default.









Primary display device: The active speaker is given prominence in the largest pane. Other participants are displayed in a strip beside the active speaker.


Secondary display device: PC content is seen in a large pane.



Specifying Content to the Secondary Display Device

To specify the content to be displayed on the secondary display device via the remote control:

1. Press  or  to open **Talk Menu** during a call.
2. Press  or  to scroll to **Focus (Display2)** and then press  to enter submenu.
3. Press  or  to scroll to select the desired content, and then press .

The secondary display device displays the selected content. The  icon is displayed on the focus content.

After reassigning the content, the PC content on the second display device will automatically be displayed on the primary display device.

Network Quality Tip

During a call, if the packet loss that you receive is more than 5%, the device display will prompt "high packet loss rate".

This tip disappears after 3 seconds. Please check your network, and make sure your network meets the requirements.

Video Conference Platform

Yealink video conferencing system can log into the Yealink VC Cloud Management Service/Yealink Meeting Server/StarLeaf/Zoom/Pexip/BlueJeans/Mind/Custom platform.

Users can access Virtual Meeting Rooms(VMR) using Yealink video conferencing system, whilst benefiting from both the features provided by Yealink, such as 1080p HD video and audio, and features provided by StarLeaf/Zoom/Pexip/BlueJeans/Mind, including high end customization & interoperability.

If you don't log into Cloud platform or you only log into the Yealink VC Cloud Management Service platform/Yealink Meeting Server, you can configure the address of the third-party platform in advance. So that your dialing screen will appear this third-party platform, even if you don't log into the third-party platform, you can still select the desired third-party platform to call corresponding VMRs quickly. For more information, refer to [Yealink VC800&VC500 Full HD Video Conferencing System Administrator Guide](#).

This chapter provides the information about using the Cloud platform. Topics include:

- [Using the Yealink VC Cloud Management Service Platform](#)
- [Using the Yealink Meeting Server](#)
- [Using the StarLeaf Cloud Platform](#)
- [Using the Zoom Cloud Platform](#)
- [Using the BlueJeans Cloud Platform](#)
- [Using the Pexip Platform](#)
- [Using the Mind Platform](#)
- [Using the Custom Platform](#)

Using the Yealink VC Cloud Management Service Platform

You can log into the Yealink VC Cloud Management Service platform, and dial other Yealink Cloud accounts to establish calls.


Dialing Yealink Cloud Accounts

To dial Yealink Cloud accounts via the remote control:

1. Select  (Dial menu) or press  to enter the pre-dialing screen.
2. Select **Yealink VC Cloud Management Service** from the pull-down list of **Call Type**

before calling.


3. Enter the desired Yealink Cloud account using the keypad or the on-screen keyboard.



7. Press to select (video call) or (voice call), and then press to dial out the account.

To dial Yealink Cloud accounts via the CP960 conference phone:

1. Tap .
2. Tap the **Auto** field.
3. Tap **Yealink VC Cloud Management Service** in the pop-up dialog box.




4. Enter the desired Yealink Cloud account.

5. Tap **Send**.

Note

If you want to place a call to a Yealink Cloud contact who is in the same Yealink Cloud directory as you, you can enter the 9-digit Cloud number or the extension (the last four Cloud number) to place a call. If you want to place a call to a Yealink Cloud contact who is in different Yealink Cloud directory from you, you should enter the 9-digit Cloud number to place a call.

Cloud call is encrypted by default. You will see an encryption icon  during a Cloud call.



Using the Yealink Meeting Server


You can log into the Yealink VC Cloud Management Service platform.


Dialing YMS Accounts

You can dial other YMS accounts to establish calls.


To dial a YMS account using the remote control:


1. Select  (**Dial** menu) or press  to enter the pre-dialing screen.
2. Select **Yealink Meeting Server** from the pull-down list of **Call Type** before calling.
3. Enter the desired YMS account using the keypad or the on-screen keyboard.



4. Press  to select  (video call) or  (voice call), and then press  to dial out the number.

To dial a YMS account via the CP960 conference phone:

1. Tap  .
2. Tap the **Auto** field.
3. Tap **Yealink Meeting Server** in the pop-up dialog box.



4. Enter the desired YMS account.
5. Tap **Send**.

YMS Video Conference

When you register a YMS account, you can use video conference feature.

There are three types of YMS video conference:

- **Scheduled conference:** You should schedule the conference using the Yealink Meeting Server or Microsoft Outlook software.
- **Meet Now:** You can initiate a meet now conference at any time, without a reservation.
- **Permanent Virtual Meeting Room:** The permanent VMR is created by your enterprise administrator. You can join the permanent VMR at any time without a reservation.

With the YMS video conferencing feature, you can do the following:

- View and join scheduled conferences.
- Initiate and join meet now conferences.
- Join the permanent VMR.
- Manage YMS video conferences.

Note

If more than one endpoint registered the same YMS account join the same conference, the former endpoint which joined the conference will leave the conference automatically. The conference only allows one of them to join the conference.

Scheduled Conference

You can schedule a conference using the Yealink Meeting Server or Microsoft Outlook software. After you schedule the conference, the scheduled conference will be added to all invitees' video conferencing system. And invitee whose YMS account is associated with an email address, will receive an email about how to join the conference.

For more information on how to schedule a conference using the Yealink Meeting Server or Microsoft Outlook software, refer to [Yealink Meeting Server User Guide](#).


Viewing Conference Schedules

When you schedule a conference or receive an invitation to a conference, the conference details will appear on the idle screen and the menu.

If the conference organizer edits the conference content (for example: time and participants) or cancel the conference via Yealink Meeting Server or Microsoft Outlook software after you have sent the invitation, the conference schedule will update in real time. Expired conferences will not be displayed on your VC800/VC500 video conferencing system and CP960 conference phone.

To view your conference schedules on the idle screen:


The idle screen of display device and CP960 conference phone displays the upcoming or ongoing conference schedules for today.



To view your conference schedules on the device display when you are sharing contents:

The idle screen will display the upcoming or ongoing conference schedules for today. And the conference schedule will be hidden in 5 seconds.

The conference schedule will appear again 30 minutes before the conference starts, and then be hidden automatically. And it will appear every 10 minutes until the conference starts. The conference schedule shows the conference details, as below:



The conference reminder will appear 5 minutes before the conference starts. For more information, refer to [Joining a Scheduled Conference](#) on page 134.

To view your conference schedules on the CP960 conference phone:


1. The touch screen displays the upcoming or ongoing conference schedules for today.



To view schedule conferences in the menu via the remote control:

1. Select  (Schedule menu).

Your ongoing conferences and upcoming conferences are listed for the latest month.




2. Press ▲ or ▼ to scroll to the desired conference.

You can view subject, time, organizer, ID, password and participants.

To view schedule conferences in the menu via the CP960 conference phone:

1. Tap .

Your ongoing conferences and upcoming conferences are listed for the latest month.



2. Tap the desired conference.

You can view subject, time, organizer, ID, password and participants.

Joining a Scheduled Conference

You can join conferences in following ways:

- Joining a scheduled conference from a conference reminder
- Joining a scheduled conference from a conference Invitation
- Joining a scheduled conference from the conference schedule
- Joining a scheduled conference from notification center of CP960
- Dialing to join a scheduled conference


Note



By default, you can join a scheduled conference that is about to take place in 5 minutes or less. The enterprise administrator can configure when participants can join the scheduled conference. For more information, please contact your administrator.


Joining a Scheduled Conference from a Conference Reminder

A reminder pop-up is displayed 5 minutes before the conference starts. The reminder shows the main information of the schedule, including subject, date & time and organizer.


Do one of the following via the remote control:



- Select **Join**, and press  to join the scheduled conference.
- Select **Detail**, and press  to view conference details.

- Select **Ignore**, and press  to remove the reminder from the screen and stop all future reminders for this schedule.

Do one of the following via the CP960 conference phone:



- Tap **Join** to join the scheduled conference.
- Tap **Detail** to view conference details.
- Tap **Ignore** to remove the reminder from the screen and stop all future reminders for this schedule.

Note

When the system is in a call, the conference reminder will not pop up. After the call ends and the scheduled conference is still ongoing, the reminder will pop up. But if the scheduled conference ends, the reminder will not pop up.


Joining a Scheduled Conference from a Conference Invitation

When the scheduled conference begins, the system will receive a call that invites you to join the conference.

Note


This feature is available only if the enterprise administrator enables the automatic dialing feature on the Yealink Meeting Server. For more information, refer to [Yealink_Meeting_Server_Administrator_Guide](#).

If you receive a conference invitation, do one of the following via the remote control:



- Select **Answer**, and press **OK** to join the scheduled conference.
- Select **Reject**, and press **OK** to remove the invitation.

If you receive a conference invitation, do one of the following via the remote control:





- Tap **Answer** to join the scheduled conference.
- Tap **Reject** to remove the invitation.


Note

If you enable the auto answer feature, the system will join the scheduled conference automatically once it receives a conference invitation.


Joining a Scheduled Conference from Conference Schedules

To join a schedule conferences from conference schedule via the remote control:


1. Select  (**Schedule** menu).
Your ongoing conferences and upcoming conferences are listed for the latest month.
2. Press ▲ or ▼ to scroll to the desired conference.
When the conference is about to take place in 5 minutes or less, a **Join** soft key appears by default.
3. Select the **Join** soft key, and then press .




To join a schedule conferences from conference schedule via the CP960 conference phone:

1. Tap .
2. Your ongoing conferences and upcoming conferences are listed for the latest month.
3. Tap the desired conference.
4. When the conference is about to take place in 5 minutes or less, the **Join** soft key turns green by default.

5. Tap **Join**.




Joining a Scheduled Conference from Notification Center

By default, when the conference is about to take place in 5 minutes, the status bar of CP960 conference phone displays the icon  and the notification center displays the conference information. You can tap the desired conference notification to join the conference in advance.

To join a schedule conferences from notification center via the CP960 conference phone:

1. Swipe down from the top of the screen to enter the notification center.
2. Tap the desired conference notification to join the conference.



Dialing into a Scheduled Conference

If you schedule a conference or you are invited to a scheduled conference, you can obtain the

conference information in following ways:

- Invitee will receive an email, which includes the IP address, conference ID and conference password.

Hello,
Test invites you to join video conference!

Subject: Test
Time: 2017-11-24 15:30:00 ~ 2017-11-24 16:00:00 (UTC+08:00)
Location:
ID: 72620
Password: 355321

The way to join conference:

- 1) One-button to join conference from Yealink VC device which receives conference reminder.
- 2) The device which has registered YMS account, please follow the voice prompt to enter conference ID 72620 & password 355321 , and end with # key.
- 3) The device which hasn't registered YMS account, please dial 110.87.96.13 or 10.86.0.199 first, then follow the voice prompt to enter conference ID 72620 & password 355321, and end with # key.
- 4) To join from a SIP device, please dial [72620**355321@110.87.96.13](https://110.87.96.13:8442/#/login?t=qOWgOHWlSERxZQuPh+ZaNQ==) or [72620**355321@10.86.0.199](https://10.86.0.199:8442/#/login?t=qOWgOHWlSERxZQuPh+ZaNQ==) and join the conference.
- 5) To join from a H.323 device, please dial 110.87.96.13##72620**355321 or 10.86.0.199##355321**355321 and join the conference.
- 6) To join from a browser, please access <https://110.87.96.13:8442/#/login?t=qOWgOHWlSERxZQuPh+ZaNQ==> or <https://10.86.0.199:8442/#/login?t=qOWgOHWlSERxZQuPh+ZaNQ==> and join the conference.

Yealink Team www.yealink.com.cn

- VC800/VC500 video conferencing system will display conference information, which includes the conference ID and conference password. For more information, refer to [Viewing Conference Schedules](#) on page 131.
- Contact the conference participants.

To dial into the scheduled conference, do one of the following:

- If you register a YMS account, dial the **conference ID** to join the conference.
Obtain the conference information from VC800/VC500 video conferencing system, your email or the other conference participants.
- If you do not register a YMS account, dial the **IP address of server** to join the conference.
Obtain the conference information from the other conference participants.
- To join from a SIP device, dial **conference ID** conference password@ IP address of**

server or **IP address of server##conference ID** conference password** to join the conference.

Obtain the conference information from your email and the other conference participants.

- To join from a H.323 device, dial **IP address of server##conference ID** conference password** to join the conference.

Obtain the conference information from your email and the other conference participants.

Note

If the system fails to join the scheduled conference, please refer to [General Issues](#) on page 190.

Meet Now


When you log into the VC800/VC500 system using an YMS account, you can use **Meet Now** feature.

Initiating a Meet Now Conference


You can initiate a meet now conference at any time.

In meet now conference, if you receive a call from YMS contacts, a reminder will prompt that you can allow or refuse the contact to join the conference.

To initiate the meet now conference via the remote control:

1. Select  (**Meet Now** menu).
The conference is initiated successfully.

To initiate the meet now conference via the CP960 conference phone:

1. Tap  .
The conference is initiated successfully.

Dialing to Join a Meet Now Conference

You can dial to join a meet now conference that is initiated by others. And you can obtain the conference information from the conference participants.

To dial to join a meet now conference:

1. Do one of the following:
 - If you register a YMS account, dial the **conference ID** to join the conference.
 - To join from a SIP device, dial **conference ID** @ IP address of server** or **IP address of server##conference ID** to join the conference.
 - To join from a H.323 device, dial **IP address of server ##conference ID** to join the conference.

Permanent Virtual Meeting Room

The enterprise administrator can configure the permanent VMR via the Yealink Meeting Server.














You can join a permanent VMR in following ways at any time, without a reservation.


- Dialing from enterprise directory
- Dialing to join a permanent VMR

Join a Permanent VMR from Enterprise Directory


The enterprise administrator can determine whether synchronize the permanent VMR to the VC800/VC500. It is enabled by default.


To join a permanent VMR from enterprise directory via the remote control:


1. Select  (**Dial** menu) or press  to enter the pre-dialing screen.
2. Press  to return to the menu.
3. Press  or  to scroll to **Directory** and then press  to enter submenu.
4. Select **Enterprise directory** from the pull-down list of the **All Contacts**.
5. Press  or  to scroll to **Virtual Meeting Room** and then press .
6. Press  or  to scroll to the desired permanent VMR.
7. Press  to enter submenu, select the desired call type, and then press  to dial out the permanent VMR.



To join a permanent VMR from enterprise directory via the CP960 conference phone:

1. Tap .
2. Tap the **All Contacts** field.
3. Tap **Enterprise directory** in the pop-up dialog box.
4. Tap **Virtual Meeting Room**.

5. Tap  after the desired permanent VMR.
6. Tap **Video Call** or **Voice Call**.



Dialing to Join a Permanent Virtual Meeting Room

Do one of the following to dial to join a permanent VMR.

- a) If you register a YMS account, dial the **conference ID** to join the permanent VMR.
- b) If you do not register a YMS account and the permanent VMR requires no password:
 - To join from a SIP device, dial **conference ID**@IP address of the server** or **IP address of the server ##conference ID** to join the permanent VMR.
 - To join from a H.323 device, dial **IP address of the server ##conference ID** to join the permanent VMR.
- c) If you do not register a YMS account and the permanent VMR requires a password:
 - To join from a SIP device, dial **conference ID** conference password@ IP address of server** or **IP address of the server ##conference ID**conference password** to join the permanent VMR.
 - To join from a H.323 device, dial **IP address of the server ##conference ID**conference password** to join the permanent VMR.

YMS Video Conference Management

The following introduces how to manage YMS video conference. The YMS video conferences include scheduled conferences, meet now conferences and permanent Virtual Meeting Room (VMR).



Appointing a Lecturer

There are two modes for scheduled conferences and permanent VMR: **Discussion mode** and **Training mode**. The conference mode can be configured by enterprise administrator on the Yealink Meeting Server only. For more information, refer to [Yealink Meeting Server User Guide](#).



- In **Discussion mode** scheduled conference/permanent VMR, participants can speak freely.
- In **Training mode** scheduled conference/permanent VMR, all guests need to wait for the moderator to appoint lecturers.

If you are the moderator (or an organizer) of **Training mode** conference, you can start speaking as a lecturer via the CP960 conference phone.

To start speaking via the CP960 conference phone:

1. During a conference, tap  -> .

To finish speaking via the CP960 conference phone:

1. During a conference, tap  -> .
- You are not a lecturer now.


Note


You do not need to specify a lecturer for meet now conference.

Applying for Speaking

In **Training mode** scheduled conference/permanent VMR, all guests are muted automatically except the moderator (or the organizer). If guests want to speak, they should apply for speaking. Only when the moderator allows the application, can they speak freely.

To apply for speaking via the remote control:


Join the **Training mode** scheduled conference/permanent VMR, muted participants' display device prompts: "Please press  to apply for speaking" in first 30 seconds.

1. Press  on the remote control.

The applicant's display device prompts "You are sending speaking application".

To apply for speaking via the CP960 conference phone:

When enter the **Training mode** conference, do one of the following to apply for speaking:

- Tap  on the CP960's touch screen.
- Tap the mute key on the CP960 conference phone.
- Tap the mute key on the CPW90 wireless microphones.
- Tap the mute key on the CPE90 wired expansion microphones.

The touch screen prompts "Apply to speak, please wait".

Note


You do not need to apply for speaking in a meet now conference.



Processing the Application


If you are the moderator (or an organizer) of a **Training mode** conference, you can allow or refuse the applicant to speak via the CP960 conference phone.

To process application via the CP960 conference phone:

1. Do one of the following:
 - Tap **Allow** to allow the applicant to speak.



- Tap  during a call.
- Tap  to allow the applicant to speak or tap **Clear handup** to clear all requests.








Note


You do not need to process the application in a meet now conference.


Inviting Conference Participants

During the YMS video conference, you can use the remote control or CP960 conference call to invite other YMS contacts to join the conference.






To invite participants during a YMS video conference via the remote control:

1. Press  or  to open **Talk Menu**.
2. Press  or  to scroll to **Invite** and then press  to expand the menu.



3. Do one of the following:
 - If you select **Dial**, enter a YMS account, and then dial out.
 - If you select **Group Dial**, select the desired department and check the desired YMS contacts' checkboxes, and then press  to select **Start conference call**.
4. Repeat above steps until all participants are added.

To invite participants during a YMS video conference via the CP960 conference phone:

1. Tap .
2. Do one of the following:
 - If you tap , select the desired department and tap the desired YMS contacts, and then tap  to dial out.
 - If you tap , enter a YMS account, and then tap **Add Members**. Repeat this step to add more members, and then tap  to dial out.






Note


If you fail to send invitation, you can re-send the invitation according to the prompt or contact your enterprise administrator.


Removing Conference Participants

If you are the organizer/moderator of a YMS video conference, you can remove conference participants via the remote control or CP960 conference phone.


To remove conference participants via the remote control:

1. Press  or  to open **Talk Menu** during a call.
2. Press  or  to scroll to **Remove** and then press  to enter the submenu.




3. Select a member that you want to remove, and then press .

To remove conference participants via the CP960 conference phone:

1. Tap  during a call.
The touch screen displays all participants.

2. Tap  after the participant that you want to remove.




Muting or Unmuting All Conference Participants


If you are the organizer/moderator of a YMS video conference, you can use the CP960 conference phone to mute or unmute all conference participants except for yourself.

In **Training mode** conference, conferences participants muted by an organizer/moderator cannot unmute themselves.

To mute all conference participants via the CP960 conference phone:

1. Tap  during a call.
The touch screen displays all participants.

2. Tap **All mute** or **All unmute** to mute/unmute all participants.





Muting or Unmuting a Conference Participant


If you are the organizer/moderator of a YMS video conference, you can use the CP960 conference phone to mute or unmute any conference participants.



In **training mode** conference, conference participants muted by an organizer/moderator cannot unmute themselves.

To mute a conference participant via the CP960 conference phone:



1. Tap  during a call.
The touch screen displays all participants.


2. Tap  after the participant that you want to mute.





The participant is muted, and the  icon changes to .

To unmute a conference participant via the CP960 conference phone:

1. Tap  during a call.
The touch screen displays all participants.
2. Tap  after the participant that you want to unmute.



The participant is unmuted, and the  icon changes to .


Leaving Conference

All participants can leave the conference at any time via the remote control or video conferencing phone. Other participants remain connected.

To leave a conference via the remote control:

If you are a moderator (or organizer) of a YMS video conference, do the following:

1. Press .



2. Select **Leave, others keep going**.


If you are not a moderator (or organizer) of a YMS video conference, do the following:

1. Press .

To leave a conference via CP960 conference phone:

If you are a moderator (or organizer) of a YMS video conference, do the following:

1. Tap **EndCall**.



2. Tap **Leave, others keep going**.


If you are not a moderator (or organizer) of a YMS video conference, do the following:


1. Tap **EndCall**.

Ending Conference

If you are a moderator (or organizer) of a YMS video conference, you can end the conference. After ending the conference, all participants leave the conference.

To end a conference via remote control:


1. Press .



2. Select **End conference**.

To end the conference via the CP960 conference phone:

1. Tap **EndCall**.



2. Tap **End conference**.

Using the StarLeaf Cloud Platform



You can log into the StarLeaf Cloud platform.


When you place a call using the StarLeaf Cloud account, you can:





- Call the other StarLeaf Cloud account to establish a point to point call.
- Call the conference ID to join the Virtual Meeting Rooms.
- Call between StarLeaf Cloud account and Microsoft Skype for Business/Lync account.

Dialing StarLeaf Cloud Numbers

To dial StarLeaf Cloud numbers via the remote control:

1. Select  (**Dial** menu) or press  to enter the pre-dialing screen.
2. Select StarLeaf Cloud number from the pull-down list of **Call Type** before calling.




3. Enter a StarLeaf Cloud number using the keypad or the on-screen keyboard.
4. Press  to select  (video call) or  (voice call), and then press  to dial out the number.

To dial StarLeaf Cloud numbers via the CP960 conference phone:

1. Tap  .
2. Tap the **Auto** field.

3. Tap StarLeaf Cloud number in the pop-up dialog box.




4. Enter the desired StarLeaf Cloud number.
5. Tap **Send**.

Joining the StarLeaf Meeting


To join the StarLeaf meeting via the remote control:


1. Select (**Dial** menu) or press to enter the pre-dialing screen.
2. Select StarLeaf Cloud number from the pull-down list of **Call Type** before calling.



3. Enter a conference ID using the keypad or the on-screen keyboard.
4. Press to select (video call) or (voice call), and then press to dial out the number.

To join the StarLeaf meeting via the CP960 conference phone:

1. Tap  .
2. Tap the **Auto** field.
3. Tap the StarLeaf Cloud number in the pop-up dialog box.





4. Enter a conference ID.
5. Tap **Send**.

Using the Zoom Cloud Platform


You can log into the Zoom Cloud platform, and join the Zoom meeting.




Joining the Zoom Meeting

To join the Zoom meeting via the remote control:


1. Select  (**Dial** menu) or press  to enter the pre-dialing screen.


2. Select **Zoom** from the pull-down list of **Call Type** before calling.



3. Enter a conference ID using the keypad or the on-screen keyboard.
4. Press ► to select  (video call) or  (voice call), and then press  to dial out the number.
5. Follow the voice prompt to join the Zoom meeting.

To join the Zoom meeting via the CP960 conference phone:

1. Tap .
2. Tap the **Auto** field.
3. Tap **Zoom** in the pop-up dialog box.



4. Enter a conference ID.
5. Tap **Send**.

- Follow the voice prompt to join the Zoom meeting.

Note



If you enter nothing or enter wrong information, you can still be sent to the Zoom welcome screen.


Using the BlueJeans Cloud Platform





You can log into the BlueJeans Cloud platform, and join the BlueJeans meeting.

Joining the BlueJeans Meeting

To join the BlueJeans meeting via the remote control:

- Select  (**Dial** menu) or press  to enter the pre-dialing screen.
- Select **BlueJeans** from the pull-down list of **Call Type** before calling.




- Enter a conference ID using the keypad or the on-screen keyboard.
- Press  to select  (video call) or  (voice call), and then press  to dial out the number.
- Follow the voice prompt to join the BlueJeans meeting.

To join the bluejeans meeting via the CP960 conference phone:

- Tap .
- Tap the **Auto** field.

3. Tap **BlueJeans** in the pop-up dialog box.



4. Enter a conference ID.
5. Tap **Send**.
6. Follow the voice prompt to join the BlueJeans meeting.

Note

If you enter nothing or enter wrong information, you can still be sent to the BlueJeans welcome screen.

Using the Pexip Platform



You can register the Pexip account.

When you place a call using the Pexip account, you can:


- Call the device alias to establish a point to point call.
- Call the aliases to join the Virtual Meeting Rooms, Virtual Auditoriums or Virtual Receptions.
- Call between Pexip account and Microsoft Skype for Business/Lync account.




Dialing Pexip Alias

To dial Pexip alias via the remote control:


1. Select  (**Dial** menu) or press  to enter the pre-dialing screen.


2. Select the registered alias from the pull-down list of **Call Type** before calling.



3. Enter the device alias or URI using the keypad or the on-screen keyboard.
4. Press ► to select  (video call) or  (voice call), and then press  to dial out the number.

To dial Pexip alias via the CP960 conference phone:



1. Tap .
2. Tap the **Auto** field.
3. Tap the registered alias in the pop-up dialog box.








4. Enter the device alias or URI.
5. Tap **Send**.

Joining the Pexip Meeting

To join the Pexip meeting via the remote control:

1. Select  (**Dial** menu) or press  to enter the pre-dialing screen.
2. Select the registered alias from the pull-down list of **Call Type** before calling.




3. Enter the conference alias or URI using the keypad or the on-screen keyboard.
4. Press  to select  (video call) or  (voice call), and then press  to dial out the number.
5. Follow the voice prompt to join the Pexip meeting.

To dial Pexip alias via the CP960 conference phone:

1. Tap .
2. Tap the **Auto** field.

3. Tap the registered alias in the pop-up dialog box.




4. Enter the conference alias or URI.
5. Tap **Send**.

Using the Mind Platform


You can log into the Mind platform, and join the Mind meeting.




Joining the Mind Meeting

To join the Mind meeting via the remote control:


1. Select  (**Dial** menu) or press  to enter the pre-dialing screen.


2. Select **Mind** from the pull-down list of **Call Type** before calling.



3. Enter a conference ID using the keypad or the on-screen keyboard.
4. Press ► to select  (video call) or  (voice call), and then press  to dial out the number.
5. Follow the voice prompt to join the Mind meeting.

To join the Mind meeting via the CP960 conference phone:

1. Tap .
2. Tap the **Auto** field.
3. Tap **Mind** in the pop-up dialog box.



4. Enter a conference ID.
5. Tap **Send**.

6. Follow the voice prompt to join the Mind meeting.

Using the Custom Platform

When you register a custom account, you can use the corresponding platform feature.

Using the CPW90 Wireless Microphones

This chapter provides basic operating instructions for the CPW90 wireless microphones. Topics include:

- [LED Instructions](#)
- [Charging the CPW90](#)
- [Turning the CPW90 On or Off](#)
- [Registering CPW90 with the CP960 Conference Phone](#)
- [Registering CPW90 with the VC500 Video Conferencing Endpoint](#)
- [Viewing CPW90 Information](#)
- [Finding the Registered CPW90](#)
- [Working Frequency](#)

If you require additional information or assistance with your new phone, contact your system administrator.

LED Instructions

Battery indicator LED on the CPW90 wireless microphones:

LED Status	Description
Solid green for one second and then off	The CPW90 is turned on.
Solid green for 3 seconds and then off	The CPW90 is in the idle mode.
Solid green	The CPW90 is fully charged.
Solid red	The CPW90 is being charged.
Fast flashing red 3 times and then off	The battery capacity is too low to turn on the CPW90.
Slowly flashing red	The battery capacity is less than 10%.
Off	If you tap the mute button, the battery indicator LED on the CPW90 is still off, it means the CPW90 is turned off.

Mute indicator LED on the CPW90 wireless microphones:

LED Status	Description
Solid green	The CP960 enters the pre-dialing screen.
	The system is in a call and unmuted.

LED Status	Description
Slowly flashing red	The system is receiving an incoming call.
Solid red	The system is muted.
Fast flashing yellow	The CPW90 is in the registration mode.
Slowly flashing yellow	The CPW90 has registered with the CP960/VC500, but the CP960/VC500 is out of range.
	The CPW90 has registered with the CP960/VC500, but the CP960/VC500 is turned off.
Flashing red and green alternately	The CP960/VC500 is searching for the CPW90 which has registered with it.
Off	The CPW90 is in the idle mode.


Placing the CPW90

The CPW90 has a rubber pad on its base to prevent it from sliding. You can place the CPW90 on a conference table and pay attention to the following:


- Make sure the distance between the CPW90 and the connected device is less than 20 meters.
- Place the CPW90 on a stable surface and keep it away from obstacles so that it can effectively pick up sounds.

Choose the desired method to place your CPW90 according to the package you purchase.

If your CPW90 is working with CP960 conference phone, do the following to ensure optimal voice quality:



If your CPW90 is working with VC500 video conferencing endpoint, do the following to ensure optimal voice quality:




Charging the CPW90

If the CPW90 is not in use, we recommend you to charge the CPW90 even when the battery is full.

Choose the desired method to charge your CPW90 according to the package you purchase.


If your CPW90 is working with CP960 conference phone, do the following to charge the CPW90:

1. Put the CPW90 on the charging cradle.
2. Connect the micro USB port on the charging cradle to the USB port on the CP960 using a 0.3m USB cable.



If your CPW90 is working with VC500 video conferencing endpoint, do the following to charge the CPW90:

1. Put the CPW90 on the charging cradle.
2. Connect to the power source using a 1.8m USB cable.



During charging, the battery LED indicator on the CPW90 illuminates solid red. When the battery capacity reaches 100%, the battery LED indicator on the CPW90 will illuminate solid green.

Note

If it is the first time you use the CPW90, you need to fully charge the CPW90 for normal use.

Turning the CPW90 On or Off

After the CPW90 starts, it registers with the CP960 conference phone or VC500 video conferencing endpoint (according to the package you purchase) automatically. You can turn off CPW90 if it is not in use for a long period of time.

To turn on the CPW90:

1. Do one of the following:
 - Put the CPW90 on a charging cradle, the CPW90 will turn on automatically.
 - Long tap the mute button on the CPW90 for 3 seconds.

To turn off the CPW90:

1. Long tap the mute button on the CPW90, until the battery indicator LED on the CPW90 illuminates solid red for 3 seconds and then goes out.


Registering CPW90 with the CP960 Conference Phone


If the CPW90 has registered with the CP960 conference phone, you can skip this chapter. If the CPW90 is not registered with the CP960 conference phone, you should register the CPW90 with the CP960 conference phone manually. So that the CPW90 can work as expansion microphones of the CP960 conference phone.

To register the CPW90 to the CP960 conference phone:

1. Do the following on the CP960 conference phone:


Tap  -> **Wireless Microphone**.

Tap  to search for a CPW90.



2. Turn on the CPW90.

The CPW90 enters the registration mode automatically. And the mute indicator LED on the CPW90 fast flashes yellow.



The CPW90 registers with the CP960 conference phone automatically. If the registration is successful, the mute indicator LED on the CPW90 goes out and the touch screen of CP960 conference phone prompts the CPW90 information: battery, work time and standby time.


Note

You can register up to two wireless expansion microphones to a CP960 conference phone.

To deregister the CPW90:

1. Tap  -> **Wireless Microphone**.
2. Select the desired microphone, and then tap **Detail**.

3. Tap **Unbind** to deregister the CPW90.




The CPW90 can only be registered with one CP960 conference phone. If you want to register the CPW90 to another CP960 conference phone, the CPW90 will be deregistered from the previous CP960 conference phone automatically.

To register the CPW90 with another CP960 conference phone:

1. Do the following on another CP960 conference phone:

Tap  -> **Wireless Microphone**.

Tap  to search for a CPW90.

2. Put the CPW90 on the charging cradle and make sure it is charging.
3. Long tap the mute button on the CPW90 for 5 seconds.

The CPW90 enters the registration mode. And the mute indicator LED on the CPW90 fast flashes yellow.


4. The CPW90 registers with the CP960 conference phone automatically.


Registering CPW90 with the VC500 Video Conferencing Endpoint

To ensure good voice quality, CPW90 wireless microphones can be connected to the VC500 video conferencing endpoint to act as the audio input devices.



To connect the CPW90 to the VC500 video conferencing endpoint, do the following:

1. Connect the DD10 USB dongle to one of the USB ports on the VC500 codec.




The display device prompts "Dongle connected!", and the  (unregistered) icon appears on the status bar.

2. Turn on the CPW90.

The CPW90 wireless microphones and DD10 USB dongle are automatically paired from the factory, so that the CPW90 registers with the VC500 automatically, the  (unregistered) icon will change to  (registered).

To remove the CPW90 from the VC500 video conferencing endpoint, do the following:

1. Remove the DD10 USB dongle from the VC500 codec.

The display device prompts "Dongle remove!". And the icon  disappears from the status bar.


You may need to deregister or register the CPW90 wireless microphones manually if a new CPW90 needs to register to the dongle.

You can only register and unregister the CPW90 manually via the web user interface.

To deregister the CPW90 via the web user interface:

1. Click on **Setting->Wireless Micphone**.

2. Click **Deregistration**.




3. Click **Confirm** to deregister the wireless microphone.

The paired information will be cleared.

To register the CPW90 via the web user interface:

1. Click on **Setting**-> **Wireless Microphone**.
2. Click **Search Mic**.



The web user interface starts 240-second countdown for pairing the dongle and wireless microphone.

3. Tap and hold the mute button on the CPW90 wireless microphones for 5 seconds until the mute indicator LED flashes yellow.

The CPW90 wireless microphones and the dongle will be paired automatically.








Viewing CPW90 Information


You can view CPW90 status via the remote control, CP960 conference phone or web user interface.

Available information of CPW90 includes:

- Register Status
- MIC Model
- MICROPHONE IPEI
- Battery Status
- Work Time(estimated working time)
- Standby Time (estimated standby time)

To view the CPW90 information via the remote control:

1. Select  (**More** menu).
2. Press  or  to scroll to **Status** and then press  to enter submenu.
3. Press  or  to scroll to **Wireless Microphone** and then press .




4. Select the desired wireless microphone to view details.

To view the CPW90 information via the CP960 conference phone:

1. Tap  -> **Wireless Microphone**.

2. Tap **Detail** to view details.





Finding the Registered CPW90

Choose the desired method to find your CPW90 according to the package you purchase.

If your CPW90 is working with CP960 conference phone, do the following to find the CPW90 which has registered with your CP960 conference phone.

To find the registered CPW90 via the CP960 conference phone:

1. Tap  -> **Wireless Microphone**.
2. Select the desired microphone, and then tap **Find**.




The mute indicator LED on the CPW90 flashes red and green alternately.

3. Tap **Exit**.

If your CPW90 is working with VC500 video conferencing endpoint, do the following to find the CPW90 which has registered with your VC500 video conferencing endpoint.

To find the registered CPW90 via the web user interface:

1. Click on **Setting->Wireless Microphone**.
2. Select the desired microphone, and then click **Find**.



The mute indicator LED on the CPW90 flashes red and green alternately.

3. Click **Stop Find**.

Working Frequency

For reference, the Frequency/Channels of CPW90 used in each Region are tabulated below:

Freq (MHz)	RF Carrier Index (DECT tester Numbering)						
	EU	Taiwan	US	LA	Korea	Brazil	Japan
1881.792	9	9					
1883.520	8	8					
1885.248	7	7					
1886.976	6	6					
1888.704	5	5					
1890.432	4	4					
1892.160	3	3					
1893.888	2	2					

Freq (MHz)	RF Carrier Index (DECT tester Numbering)						
	EU	Taiwan	US	LA	Korea	Brazil	Japan
1895.616	1						4(F1)
1897.344	0						3(F2)
1899.072							2(F3)
1900.800							1(F4)
1902.528							0(F5)
1904.256							
1905.984							
1907.712							
1909.440							
1911.168						4	
1912.896				9		3	
1914.624				8		2	
1916.352				7		1	
1918.080				6		0	
1919.808				5			
1921.536			4	4			
1923.264			3	3			
1924.992			2	2			
1926.720			1	1			
1928.448			0	0			
1787.616					8		
1789.344					7		
1791.072					6		

Using the CPE90 Wired Expansion Microphones


This chapter provides basic operating instructions for the CPE90 wired expansion microphones. Topics include:

- [Placing the CPE90](#)
- [Muting or Unmuting the CPE90](#)


If you require additional information or assistance with your new phone, contact your system administrator.

Placing the CPE90

The CPE90 has a rubber pads on its base to prevent it from sliding. You can place the CPE90 on a stable surface and keep it away from obstacles so that it can effectively pick up sounds.



Muting or Unmuting the CPE90

If you connect the CPE90 wired expansion microphones to the CP960 conference phone to expand the audio range, you can tap  on the CPE90 to mute or unmute the microphone.

Using the VCC22 Video Conferencing Camera

You can connect up to 8 VCC22 video conferencing cameras to the VC800 video conferencing system. VCC22 video conferencing camera is not applicable to VC500 video conferencing endpoint.

Before you use the VCC22 video conferencing camera, you should read the [Yealink VCC22 Video Conferencing Camera Quick Start Guide](#) first to know the package and installation.

This chapter provides basic operating instructions for the VCC22 video conferencing camera.

Topics include:

- [Viewing Camera Information](#)
- [LED Instructions](#)
- [Controlling VCC22 Camera](#)
- [Adjusting Camera Layout](#)
- [Controlling the Multiple Remote Cameras](#)
- [Layouts of Multiple Display Screens](#)
- [Upgrading the Camera firmware](#)
- [Resetting Camera](#)

If you require additional information or assistance with your VCC22 video conferencing camera, contact your system administrator.


Viewing Camera Information

You can view VCC22 information via the web user interface only.

To view the VCC22 information via the web user interface:

1. Click **Setting->Camera**.

2. Select the desired camera from the pull down list of **Camera**.



The VCC22 information is displayed on the web user interface.

LED Instructions

Indicator LED on the VCC22 video conferencing camera:


LED Status	Description
Solid green	The VC800 codec is powered on.
	The VC800 codec is upgrading firmware.
	The VCC22 video conferencing camera is working.
Solid red	The VC800 codec is in sleep mode.
	The VCC22 video conferencing camera is disabled.
Flashing red	The VCC22 video conferencing camera is upgrading firmware.
Solid orange	The VCC22 video conferencing camera is not selected.
Off	The VCC22 video conferencing camera is not connected to the PoE switch.

Controlling VCC22 Camera



When the system is idle, you can choose the desired camera to capture video images.

To control the VCC22 camera via the remote control:


1. Press ► to enter the cameras list.


- Press ▲ or ▼ to scroll to the desired camera and then press .






- Press the navigation key to adjust the angle of the camera.
- Press  or  to adjust the focus of the camera.

To control the VCC22 camera via the CP960 conference phone:

- Tap .
- Tap **The current control camera**.
- Tap the desired camera.



- Tap  to return.
- Tap the navigation keys to adjust the angle of the camera.
- Tap  or  to adjust the focus of the camera.

Controlling VCC22 Camera is configurable via the web user interface at the path







Home->Camera Layout.

Adjusting Camera Layout


During a call, all video streams captured from the connected cameras are synthesized to one video stream, and then sent to the far site.


You can change the camera layout during a call via the remote control, CP960 conference phone or web user interface.


Camera layouts appear as one of the following types:

- **OnePlusN** ( / ): the selected camera is given prominence in the largest pane. Other cameras are displayed in small panes.
- **Selected Speaker** ( / ): the selected camera is seen in a large pane.
- **Equal N×N** ( / ): every camera is given equal prominence in equal-sized panes.

To adjust camera layout via the remote control:

1. Press  or  to open **Talk Menu**.
2. Press  or  to scroll to **Camera Layout** and then press  to enter submenu.




3. Select the desired camera layout, and then press  .

To adjust camera layout via the CP960 conference phone:

1. Tap  .

2. Tap the desired camera layout.



Adjusting camera layout is configurable via the web user interface at the path **Home->Camera Layout**.

Controlling the Multiple Remote Cameras

You can control the remote camera during a video call via the remote control or CP960 conference phone.

When the far-end connects multiple VCC22 video conferencing cameras, you can do one the following:

- When camera layout of far-end is **OnePlusN**, you can control the camera that displays the largest video.
- When camera layout of far-end is **Selected Speaker**, you can control the camera that displays full-screen video.
- When camera layout of far-end is **Equal N×N**, you can control the VC800 camera.

For more information on how to control the remote cameras, refer to [Controlling the Remote Camera](#) on page 113.

Layouts of Multiple Display Screens

If two display devices already connect to the VC800 codec, a third display device can still connect to HDMI OUT port on the VCC22 video conferencing camera. The third display device is used for viewing shared content. If multiple display devices connect to the VCC20 video conferencing cameras, all display devices show the same shared content.

If VC800 video conferencing system only connects a display device or no content is being

shared to others, the display screen connected to the VCC22 video conferencing camera shows a static image only.


Upgrading the Camera firmware

The newly released firmware version may add new features. Because of this, Yealink recommends you to update the latest firmware. You can upgrade the firmware via the web user interface only.

The firmware name of the VCC22 camera is 63.x.x.x.rom (x is the actual firmware version). You can download the latest firmware version from the Yealink website.

To upgrade camera firmware via the web user interface:

1. Click on **Setting**->**Upgrade**.
2. In the **Upgrade VCC22 Firmware** field, click **Browse** to locate the VCC22 firmware from your local system.



3. Click **Upgrade** to upgrade the firmware.

The browser pops up the dialog box "Firmware will be updated. It will take 5 minutes to complete. Please don't power off!".

4. Click **Confirm** to confirm upgrading.

Note

Caution! Don't remove the Ethernet cable and power cord during the upgrade process. Don't close or refresh the web page when upgrading the firmware via web user interface.

Resetting Camera


Reset the camera to factory to clear all customized settings. You can reset the VCC22 video

conferencing camera via reset key.

To reset the VCC22 video conferencing camera via the rest key:

Using tiny objects (for example, the paper clip) to press and hold the reset button for 15 seconds until the screen turns black.

Do not power off the system during the factory restore process. The VC800 video conferencing system, CP960 conference phone and VCC22 video conferencing camera are reset synchronously.



Note

When VC800 video conferencing system is reset, the connected VCC22 video conferencing camera is reset too. For more information, refer to [System Maintenance](#) on page 194.

Troubleshooting

This chapter provides general troubleshooting information to help you solve problems you might encounter when using your VC800/VC500 system. If you require additional information or assistance with your new phone, contact your system administrator.




Ensure the system has not been physically damaged when experiencing a problem. Check whether the cables are loose and the connections are correct and secure. These are common causes of problems.

System Diagnostics


Diagnostic menus include:

- **Audio Diagnose:** Check whether the audio device can pick up voice and play audio normally.
- **Camera Diagnose:** Check whether the camera can pan and change focus normally.
- **Ping:** Check whether the network between the local and the remote system is connected.
- **Trace Route:** Display the route (path) and measure transit delays of packets across an Internet Protocol (IP) network.

Audio Diagnose:

1. Select  (**More** menu).
2. Press ▲ or ▼ to scroll to **Setting** and then press  to expand the menu.
3. Press ▲ or ▼ to scroll to **Diagnose** and then press ► to enter submenu.
4. Press ▲ or ▼ to scroll to **Audio Diagnose** and then press .


5. Speak into the microphone.






6. Check whether the microphone can pick up audio normally.
7. If the microphone picks up audio and plays back audio normally, it means that the audio works well.
8. Press **OK** to stop audio diagnostics.

Camera Diagnose:














1. Select **More** (More menu).
2. Press **▲** or **▼** to scroll to **Setting** and then press **OK** to expand the menu.
3. Press **▲** or **▼** to scroll to **Diagnose** and then press **▶** to enter submenu.
4. Press **▲** or **▼** to scroll to **Camera Diagnose** and then press **OK**.




5. Press **▲** or **▼** to adjust the camera position.

6. Press  or  to adjust the focus.
7. If the camera can move and zoom normally, it means that the camera is working well.
8. Press  to stop camera diagnostics.


Network diagnosis:

1. Select  (**More** menu).
2. Press  or  to scroll to **Setting** and then press  to expand the menu.
3. Press  or  to scroll to **Diagnose** and then press  to enter submenu.
4. Press  or  to scroll to **Ping** and then press .
5. Press  or  to scroll to **Start** and then press .














You can also enter other IP address (for example, the IP address of the remote system) in the **Ping** field.




It measures the round-trip time from transmission to reception and reports errors and packet loss. The results of the test include a statistical summary of the response packets received, including the minimum, maximum, and the mean round-trip times.

6. Press  to return to Diagnose menu.


Trace Route:

1. Select  (**More** menu).
2. Press  or  to scroll to **Setting** and then press  to expand the menu.
3. Press  or  to scroll to **Diagnose** and then press  to enter submenu.
4. Press  or  to scroll to **Trace Route** and then press .
5. Press  or  to scroll to **Start** and then press .

You can also enter other IP address (for example, the IP address of the remote system) in the **Trace Route** field.



If the test is successful, the VC800/VC500 system lists the hops between the system and the IP address you entered. You can check whether congestion happens via the time cost between hops.

6. Press  to return to Diagnose menu.

General Issues

Why can't the system place a call?

- Check the network is available.
- When making a call using an account, check that the account is registered.
- Ensure the remote system supports the same call protocol as the local system. If you want to place a call using another protocol, refer to [Call Protocol](#) on page 60.

Why can't the system receive calls?

- Check the network is available.
- When receiving a call using an account, check that the account is registered.
- Check that DND (Do Not Disturb) mode is deactivated on your system. Refer to [Do Not Disturb \(DND\)](#) on page 93.


Why doesn't the display device display the time and date correctly?

Check whether you have configured the system to obtain the time and date from the SNTP server automatically. If the system fails to connect to the SNTP server, contact your system administrator for more information. You can also configure the time and date manually. For

more information, refer to [Time & Date](#) on page 50.

How to obtain the IP address of the system?

There are three ways to obtain the IP address of the system:

- The IP address of the system is shown on the top right corner of the display device.
- Select  (**More** menu).
Press ▲ or ▼ to scroll to **Status** and then press ► to select **Network**.
- Tap **Settings**-> **Network** on the CP960 conference phone.

Why does the system fail to call the far site?

- Check whether the network of the near site is available.
- Check whether the network of the far site is available.
- Check whether the far site enables the DND feature.
- Check whether the accounts are registered correctly, and the system uses the appropriate account to call the far site.
- Check whether the local system can ping the IP address of the remote system successfully.
- Ensure that the entered call information is correct.
- Ensure that the called party is powered on.
- Check whether the far site rejects your call.
- Check whether the firewall blocks the inbound traffics from the other site.
- Check whether the far site has already up to maximum call-in limitation.
- If the near site is forced to use encryption, ensure that the far site enables encryption too.
- Ensure that the far site supports the same call protocol as the near site.

You can also troubleshoot the problems according to the following prompts:

Prompts	Description
Call Fail Busy Here	<ul style="list-style-type: none"> • Remote system rejects your SIP call. • Remote system does not answer your SIP call. • Remote system has reached maximum sessions when you place a SIP call.
Call Fail Remote endpoint refused call	<ul style="list-style-type: none"> • Remote system rejects your H.323 call • Remote system does not answer your H.323 call. • Remote system has reached maximum sessions

Prompts	Description
	when you place an H.323 call.
Network disconnected	Local network is disconnected.
Maximum number of sessions reached	Local system has reached maximum sessions.

Why does the system fail to call the far site via IP address?

- Ensure that the network is connected correctly.
- Ping the IP address of the far site. Contact your system administrator if it fails.

Camera Issues

How to adjust room lighting?

You can alter the environmental lighting and background colors of your environment to obtain the best video quality. If light levels are too low you may consider adding artificial lighting. Reflected light from pale walls often produces excellent results.

Avoid the following situations:

- Direct sunlight on the display device, the background, or the camera lens which creates harsh contrasts.
- Colored lighting.

Why can't I adjust the camera angle and focus?

- You can adjust the camera when the system is idle or during a call. The camera cannot be adjusted when the system is in the menu screen.
- Ensure that the batteries in the remote control are in good working condition, and installed correctly.
- Aim the remote control at the sensor when you perform a task.
- Ensure that no objects are obstructing the sensor on the front of the camera.
- Ensure that the LED on the front of the camera flashes green when you use the remote control to perform a task.
- Ensure that what you are controlling is the local camera.
- Reboot the system.
- If the above suggestions cannot solve your problem, perhaps the remote control is broken. You can contact your system administrator for help.

Why is the video quality bad?

- Ensure that the display device has suitable resolution.
- Check whether the packet has been lost. For more information on packet loss, refer to [Call Statistics](#) on page 109.
- Contact your administrator to adjust the camera brightness and white balance.

Display Issues

Why is there no video on the display device?

- Ensure that the display device is turned on.
- Ensure that the display device is properly connected to VC800/VC500codec.
- Ensure that the VC800/VC500 video conferencing system is turned on.
- Ensure that you have selected the correct video input source.

Why can't the display device start presentation?

- Ensure that a PC is properly connected to the VC800/VC500 video conferencing system.
- Ensure that the PC is turned on.
- Ensure that the VCH50 video conferencing hub is not broken.
- Contact your administrator for help.



Video & Audio Issues

Why can't I hear the audio during a call?

- Ensure that the system has selected an available audio output device.
- If you select **VCS Phone** as the audio output device, ensure that the CP960 conference phone is connected to the VC800/VC500 codec, and LED indicators on the phone illuminate solid green.
- Ensure the proper volume level on the system.
- Ensure that the microphone on the remote system is not muted.

Why can't I hear a ring tone when receiving a call?

- Ensure that the system has selected an available audio output device.
- If you select **VCS Phone** as the audio output device, ensure that the CP960 conference phone is connected to the VC800/VC500 codec, and LED indicators on the phone illuminate solid green.

- Ensure that the ring volume is not set to 0. If it is, the  icon will appear on the status bar of the display device, and the  icon will appear on the CP960's touch screen.
- Adjust the ring volume when the system is idle via the remote control or CP960 conference phone. For more information, refer to [Volume](#) on page 63.

Why can't I hear the other site clearly during a call?

- Ensure that the speaker volume of the far site is not set too low.
- Muffled audio reception from the far side may be caused by highly reverberant rooms. Speak in close proximity to the phone.
- Adjust the priority order for your audio codec if you have chosen a low-bandwidth audio codec to be first.
- For best results, ensure that the caller is using a Yealink video conferencing system. Audio quality from your video conferencing system will vary when calling a non-Yealink system.
- Dust and debris may cause audio quality. Do not use any kind of liquid or aerosol cleaner on the phone. A soft, slightly damp cloth should be sufficient to clean the top surface of the phone if necessary.








Why is the voice quality poor?

Users may receive poor voice quality during a call, such as intermittent voice, low volume, echo or other noise. It is difficult to diagnosis the root causes of the voice anomalies. The possible reasons are:

- Users sit too far from or near to the microphone.
- The audio pickup device is moved frequently.
- Intermittent voice is probably caused by voice packet loss or jitter. Voice packet loss may occur due to network congestion. Jitter may occur due to information reorganization of the transmission or receiving equipment, such as, delay processing, retransmission mechanism or buffer overflow.
- Noise devices, such as computers or fans, may make it difficult to hear each other's voices clearly.
- Wires may also cause this problem. Replace the old with the new cables, and then reconnect to check whether the new cables provide better connectivity.


System Maintenance

To reboot the system via the remote control:

1. Select  (**More** menu).
2. Press  or  to scroll to **Setting** and then press  to expand the menu.
3. Press  or  to scroll to **Advanced** and then press .

4. Enter admin password (default password: 0000) in the **Password** field.
5. Press **OK**.
6. Press **▲** or **▼** to scroll to **Reboot & Reset** and then press **OK**.
7. Press **▲** or **▼** to scroll to **Reboot** and then press **OK**.

The display device prompts "Reboot the system?".



8. Select **OK**, and then press **OK**.

You can reboot the system via the web user interface at the path **Setting->Upgrade->Reboot**.

How to export PCAP trace?

We may need you to provide a PCAP trace to help analyze your problem. Exporting PCAP trace is configurable via the web user interface and remote control.

To capture packets via the web user interface:



1. Click on **Setting->Configuration**.
2. Enter the desired value in the **Packet Capture Count** field.
3. Enter the desired value in the **Packet Capture Clip Bytes** field.
4. Select the desired value from the pull-down list of **Pcap Filter Type**.
If **Custom** is selected, enter the desired packet filter string in the **Packet Filter String** field.
5. Click **Start** to start capturing signal traffic.
6. Reproduce the issue to get stack traces.
7. Click **Stop** to stop capturing.

8. Click **Export** to open the file download window, and then save the file to your local system.

The screenshot shows the Yealink VC800 web interface. The top navigation bar includes 'About', 'Language', and 'Logout'. The main menu has 'Home', 'Status', 'Account', 'Network', 'Setting' (highlighted), 'Directory', and 'Security'. On the left, a sidebar lists various configuration categories: General, Date & Time, Call Features, Video & Audio, Camera, Auto-Provision, Configuration (highlighted), Upgrade, Tones, Wireless Micphone, 3rd-Party VMR, Conference Setting, and Remote Control. The main content area is divided into two columns. The left column contains 'Import Configuration' with a 'Browse...' button and 'Import' button, and 'Export Configuration' with an 'Export' button. The right column contains the 'Pcap Feature' section, which is highlighted with a red box. This section includes 'Start', 'Stop', and 'Export' buttons, followed by 'Packet Capture Count' (5), 'Packet Capture Clip Bytes' (1024), 'Pcap Filter Type' (Custom), and 'Packet Filter String'. Below this is the 'Export System Log' section, which has 'Local' and 'Server' radio buttons (with 'Server' selected), an 'Export' button, 'Server Name' (10.200.110.199), and 'System Log Level' (6).

To export a PCAP trace via remote control:

Before capturing packets, make sure a USB flash driver is connected to VC800/VC500 codec, VCH50 video conferencing hub or CP960 conference phone and the USB feature is enabled.

1. Long press  when the system is idle or during a call.
The display device prompts "Onekey-capture has been turned on, press the Backspace key for 2s to turn off it".
2. Long press  for 2 seconds to stop capturing packets.
The packets are saved in the yealink.debug folder on your USB flash driver.

How to export system log?

We may need you to provide your phone configurations to help analyze your problems. You can export the system log to the local system or designated log server.

To export the system log to a local PC via the web user interface:

1. Click on **Setting->Configuration**.
2. Mark the **Local** radio box in the **Export System Log** field.
3. Select **6** from the pull-down list of **System Log Level**.

The default system log level is 6.

The screenshot shows the Yealink VC800 web interface. The 'Configuration' menu item is selected in the left sidebar. In the main content area, the 'Export System Log' section is highlighted with a red box. It contains two radio buttons: 'Local' (selected) and 'Server'. To the right of these buttons is an 'Export' button. Below this, the 'System Log Level' is set to 6 in a dropdown menu.

4. Click **Confirm** to accept the change.

The web user interface prompts "Operating...Please wait...".

Export the system log referring to the following steps.

5. Recreate the error to be documented in the trace.
6. Click **Export** to save the file to your local system.

How to export/import the system configurations?

We may need you to provide your system configurations to help analyze problems. In some instance, you may need to import configurations to your system.

To export the system configurations via the web user interface:


1. Click on **Setting->Configuration**.
2. Click **Export**.

The screenshot shows the Yealink VC800 web interface. The 'Configuration' menu item is selected in the left sidebar. In the main content area, the 'Export Configuration' button is highlighted with a red box. Other visible settings include 'Import Configuration', 'Pcap Feature', 'Packet Capture Count' (5), 'Packet Capture Clip Bytes' (1024), and 'Pcap Filter Type' (Custom).

3. Click **Confirm** to export the configurations.

To import the system configurations via the web user interface:

1. Click on **Setting**->**Configuration**.
2. Click **Browse** to locate a configuration file from your local system.



3. Click **Import** to import the configuration file.

Note

The file format of configuration file must be *.bin.

How to upgrade VC800/VC500 firmware?


The newly released firmware version may add new features. Because of this, Yealink recommends you to update the latest firmware. You can upgrade the firmware via the web user interface.

The firmware name of the VC800/VC500 video conferencing system is 63.x.x.x.rom and the firmware name of the CP960 conference phone is: 73.x.x.x.rom (x is the actual firmware version). You can download the latest firmware version from the Yealink website.

To upgrade firmware via the web user interface:

1. Click on **Setting**->**Upgrade**.
2. Do one of the following:
 - In the **Upgrade Firmware** field, click **Browse** to locate the VC800/VC500 firmware from your local system.

- In the **Upgrade CP Firmware** field, click **Browse** to locate the CP960 firmware from your local system.



3. Click **Upgrade** to upgrade the firmware.

The browser pops up the dialog box "Firmware will be updated. It will take 5 minutes to complete. Please don't power off!".

4. Click **Confirm** to confirm upgrading.

Note















Caution! Don't remove the Ethernet cable and power cord during the upgrade process. Don't close or refresh the web page when upgrading the firmware via web user interface.

How to reset the system?


Reset the system to factory configurations after you have tried all appropriate troubleshooting suggestions but have still do not solved the problem. You need to note that all customized settings will be overwritten after reset. You can reset the system via the remote control or web user interface.


Reset of the system may take a few minutes. Do not power off until the phone starts up successfully.

To reset the system via the remote control:

1. Select  (**More** menu).
2. Press  or  to scroll to **Setting** and then press  to expand the menu.
3. Press  or  to scroll to **Advanced** and then press .
4. Enter admin password (default password: 0000) in the **Password** field.
5. Press .
6. Press  or  to scroll to **Reboot & Reset** and then press .
7. Press  or  to scroll to **Reset** and then press .

The display device prompts "Reset to Factory?"




8. Select **OK**, and then press .

To reset the system via the rest key on the VC800/VC500 codec:

Using tiny objects (for example, the paper clip) to press and hold the reset button for 15 seconds until the screen turns black.

Do not power off the system during the factory restore process. The system reverts to the default factory settings and restarts automatically. This will take a few minutes.



The VC800 video conferencing system, CP960 conference phone and VCC22 video conferencing camera are reset synchronously.

Resetting the system is configurable via the web user interface at the path
Setting->Upgrade->Reset to Factory.

Regulatory Notices

Service Agreements

Contact your Yealink Authorized Reseller for information about service agreements applicable to your product.

Limitations of Liability

TO THE FULL EXTENT ALLOWED BY LAW, YEALINK EXCLUDES FOR ITSELF AND ITS SUPPLIERS ANY LIABILITY, WHETHER BASED IN CONTRACT OR TORT (INCLUDING NEGLIGENCE), FOR INCIDENTAL, CONSEQUENTIAL, INDIRECT, SPECIAL, OR PUNITIVE DAMAGES OF ANY KIND, OR FOR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR DATA, OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE SALE, INSTALLATION, MAINTENANCE, USE, PERFORMANCE, FAILURE, OR INTERRUPTION OF ITS PRODUCTS, EVEN IF YEALINK OR ITS AUTHORIZED RESELLER HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, AND LIMITS ITS LIABILITY TO REPAIR, REPLACEMENT, OR REFUND OF THE PURCHASE PRICE PAID, AT YEALINK'S OPTION. THIS DISCLAIMER OF LIABILITY FOR DAMAGES WILL NOT BE AFFECTED IF ANY REMEDY PROVIDED HEREIN SHALL FAIL OF ITS ESSENTIAL PURPOSE.

Safety Instructions

Save these instructions. Read these safety instructions before use!

The following basic safety precautions should always be followed to reduce the risk of fire, electrical shock, and other personal injury.



General Requirements

- Before you install and use the device, read the safety instructions carefully and monitor the situation during operation.
- During the process of storage, transportation, and operation, please always keep the device dry and clean.
- During the process of storage, transportation, and operation, please avoid collision and an impact to the device.
- Please do not attempt to dismantle the device by yourself. In case of any discrepancy, please contact the appointed maintenance center for repair.
- Without prior written consent, no organization or individual is permitted to make any change to the structure or the safety design of the device. Yealink is under no circumstance liable to consequences or legal issues caused by such changes.
- Please refer to the relevant laws and statutes while using the device. The legal rights of others should be respected as well.



Environmental Requirements

- Place the device in a well-ventilated place. Do not expose the device to direct sunlight.
- Keep the device dry and free of dust.
- Place the device on a stable and level platform.
- Please do not place any heavy objects on the device in case of damage and deformation caused by the heavy load.
- Keep at least 10 cm between the device and the closest object for heat dissipation.
- Do not place the device on or near any inflammable or fire-vulnerable object, such as rubber-made materials.
- Keep the device away from any heat source or bare fire, such as a candle or an electric heater.
- Keep the device away from any household appliance with a strong magnetic field or electromagnetic field, such as a microwave oven or a refrigerator.



Operating Requirements

- Do not let a child operate the device without guidance.
- Do not let a child play with the device or any accessory in case of accidental swallowing.
- Please only use accessories provided or authorized by the manufacturer only.
- The power supply of the device shall meet the requirements of the input voltage of the device. Please only use the surge protection power socket provided.
- Before plugging or unplugging any cable, ensure that your hands are completely dry.
- Do not spill liquid of any kind on the product or use the equipment near water, for example, near a bathtub, washbowl, kitchen sink, wet basement or near a swimming pool.
- Do not tread on, pull, or over-bend any cable in case of malfunction of the device.
- During a thunderstorm, stop using the device and disconnect it from the power supply. Unplug the power plug and the Asymmetric Digital Subscriber Line (ADSL) twisted pair (the radio frequency cable) to avoid lightning strike.
- If the device is left unused for a rather long time, disconnect it from the power supply and unplug the power plug.
- When smoke or an abnormal noise or smell is emitted from the device, disconnect the device from the power supply, and unplug the power plug immediately. Contact the specified maintenance center for repair.
- Do not insert any object into equipment slots that is not part of the product or auxiliary product.
- Before connecting a cable, connect the grounding cable of the device first. Do not disconnect the grounding cable until you disconnect all other cables.



Cleaning Requirements

- Before cleaning the device, stop using it and disconnect it from the power supply.
- Use a piece of soft, dry and anti-static cloth to clean the device.

- Keep the power plug clean and dry. Using a dirty or wet power plug may lead to electric shock or other perils.

Restriction of Hazardous Substances

Restriction of Hazardous Substances (RoHS) is a Chinese government regulation which aims to restrict certain dangerous substances commonly used in electronic and electronic equipment.

The following table lists the names and content of toxic and hazardous substances or elements probably contained in the products:

Parts Name	Toxic or Hazardous Substance and Elements					
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent Chromium (Cr ⁺⁶)	Polybrominated Biphenyls (PBB)	Polybrominated Diphenyl Ethers (PBDE)
Plastic and Polymeric Parts	O	O	O	O	O	O
Metal Parts	X	O	O	O	O	O
PCBA	X	O	O	O	O	O
Cables and Cable Assemblies	O	O	O	O	O	O
LCD Screen	O	O	O	O	O	O
Batteries	O	O	O	O	O	O
Packing Material	O	O	O	O	O	O

O: Indicates that toxic substances contained in all homogeneous materials in this product are below the limit requirement in GB/T26572-2011 standard.

X: Indicates that toxic substances contained in all homogeneous materials in this product are above the limit requirement in GB/T26572-2011 standard.

This table lists the toxic and hazardous substances contained in the machine. Based on the material type, the data is provided by the supplier and has already been validated by Yealink company.

Some harmful substances contained in the material cannot be replaced according to the current technology. We constantly strive to improve our products.

Appendix - Time Zones

Time Zone	Time Zone Name
-11:00	Samoa
-10:00	United States-Hawaii-Aleutian
-10:00	United States-Alaska-Aleutian
-09:30	French Polynesia
-09:00	United States-Alaska Time
-08:00	Canada(Vancouver, Whitehorse)
-08:00	Mexico(Tijuana, Mexicali)
-08:00	United States-Pacific Time
-07:00	Canada(Edmonton, Calgary)
-07:00	Mexico(Mazatlan, Chihuahua)
-07:00	United States-Mountain Time
-07:00	United States-MST no DST
-06:00	Canada-Manitoba(Winnipeg)
-06:00	Chile(Easter Islands)
-06:00	Mexico(Mexico City, Acapulco)
-06:00	United States-Central Time
-05:00	Bahamas(Nassau)
-05:00	Canada(Montreal, Ottawa, Quebec)
-05:00	Cuba(Havana)
-05:00	United States-Eastern Time
-04:30	Venezuela(Caracas)
-04:00	Canada(Halifax, Saint John)
-04:00	Chile(Santiago)
-04:00	Paraguay(Asuncion)
-04:00	United Kingdom-Bermuda(Bermuda)
-04:00	United Kingdom(Falkland Islands)
-04:00	Trinidad&Tobago
-03:30	Canada-New Foundland(St.Johns)
-03:00	Denmark-Greenland(Nuuk)
-03:00	Argentina(Buenos Aires)
-03:00	Brazil(no DST)
-03:00	Brazil(DST)
-02:30	Newfoundland and Labrador
-02:00	Brazil(no DST)
-01:00	Portugal(Azores)
0	GMT

Time Zone	Time Zone Name
0	Greenland
0	Denmark-Faroe Islands(Torshavn)
0	Ireland(Dublin)
0	Portugal(Lisboa, Porto, Funchal)
0	Spain-Canary Islands(Las Palmas)
0	United Kingdom(London)
0	Morocco
+01:00	Albania(Tirane)
+01:00	Austria(Vienna)
+01:00	Belgium(Brussels)
+01:00	Caicos
+01:00	Chad
+01:00	Spain(Madrid)
+01:00	Croatia(Zagreb)
+01:00	Czech Republic(Prague)
+01:00	Denmark(Kopenhagen)
+01:00	France(Paris)
+01:00	Germany(Berlin)
+01:00	Hungary(Budapest)
+01:00	Italy(Rome)
+01:00	Luxembourg(Luxembourg)
+01:00	Macedonia(Skopje)
+01:00	Netherlands(Amsterdam)
+01:00	Namibia(Windhoek)
+01:00	Poland (Warsaw)
+02:00	Estonia(Tallinn)
+02:00	Finland(Helsinki)
+02:00	Gaza Strip(Gaza)
+02:00	Greece(Athens)
+02:00	Israel(Tel Aviv)
+02:00	Jordan(Amman)
+02:00	Latvia(Riga)
+02:00	Lebanon(Beirut)
+02:00	Moldova(Kishinev)
+02:00	Russia(Kaliningrad)
+02:00	Romania(Bucharest)
+02:00	Syria(Damascus)
+02:00	Turkey(Ankara)
+02:00	Ukraine(Kyiv, Odessa)
+03:00	East Africa Time
+03:00	Iraq(Baghdad)

Time Zone	Time Zone Name
+03:00	Russia(Moscow)
+03:30	Iran(Teheran)
+04:00	Armenia(Yerevan)
+04:00	Azerbaijan(Baku)
+04:00	Georgia(Tbilisi)
+04:00	Kazakhstan(Aktau)
+04:00	Russia(Samara)
+04:30	Afghanistan(Kabul)
+05:00	Kazakhstan(Aqtobe)
+05:00	Kyrgyzstan(Bishkek)
+05:00	Pakistan(Islamabad)
+05:00	Russia(Chelyabinsk)
+05:30	India(Calcutta)
+05:45	Nepal(Katmandu)
+06:00	Kazakhstan(Astana, Almaty)
+06:00	Russia(Novosibirsk, Omsk)
+06:30	Myanmar(Naypyitaw)
+07:00	Russia(Krasnoyarsk)
+07:00	Thailand(Bangkok)
+08:00	China(Beijing)
+08:00	Singapore(Singapore)
+08:00	Australia(Perth)
+08:00	Russia(Irkutsk, Ulan-Ude)
+08:45	Eucla
+09:00	Korea(Seoul)
+09:00	Japan(Tokyo)
+09:00	Russia(Yakutsk, Chita)
+09:30	Australia(Adelaide)
+09:30	Australia(Darwin)
+10:00	Australia(Sydney, Melbourne, Canberra)
+10:00	Australia(Brisbane)
+10:00	Australia(Hobart)
+10:00	Russia(Vladivostok)
+10:30	Australia(Lord Howe Islands)
+11:00	New Caledonia(Noumea)
+11:00	Russia(Srednekolymsk Time)
+11:30	Norfolk Island
+12:00	New Zealand(Wellington, Auckland)
+12:00	Russia(Kamchatka Time)
+12:45	New Zealand(Chatham Islands)
+13:00	Tonga(Nukualofa)

Time Zone	Time Zone Name
+13:30	Chatham Islands
+14:00	Kiribati