

Skype for Business[®] HD IP Phone Administrator Guide



Copyright

Copyright © 2017 YEALINK(XIAMEN) NETWORK TECHNOLOGY CO.,LTD

Copyright © 2017 Yealink(Xiamen) Network Technology CO., LTD. All rights reserved. No parts of this publication may be reproduced or transmitted in any form or by any means, electronic or mechanical, photocopying, recording, or otherwise, for any purpose, without the express written permission of Yealink(Xiamen) Network Technology CO., LTD. Under the law, reproducing includes translating into another language or format.

When this publication is made available on media, Yealink(Xiamen) Network Technology CO., LTD. gives its consent to downloading and printing copies of the content provided in this file only for private use but not for redistribution. No parts of this publication may be subject to alteration, modification or commercial use. Yealink(Xiamen) Network Technology CO., LTD. will not be liable for any damages arising from use of an illegally modified or altered publication.

Warranty

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS GUIDE ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS GUIDE ARE BELIEVED TO BE ACCURATE AND PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF PRODUCTS.

YEALINK(XIAMEN) NETWORK TECHNOLOGY CO.,LTD. MAKES NO WARRANTY OF ANY KIND WITH REGARD TO THIS GUIDE, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. YEALINK(XIAMEN)NETWORK TECHNOLOGY CO.,LTD. shall not be liable for errors contained herein nor for incidental or consequential damages in connection with the furnishing, performance, or use of this guide.

Declaration of Conformity



Hereby, Yealink(Xiamen) Network Technology CO., LTD. declares that this phone is in conformity with the essential requirements and other relevant provisions of the CE, FCC.
Statements of compliance can be obtained by contacting support@yealink.com.

CE Mark Warning

These devices are marked with the CE mark in compliance with EC Directives 2014/35/EU and 2014/30/EU.

Part 15 FCC Rules

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device is compliant with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Industry Canada (IC)

This Class [B] digital apparatus complies with Canadian ICES-003 Rules.

Class B Digital Device or Peripheral

Note: This device is tested and complies with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experience radio/TV technician for help.

WEEE Warning



To avoid the potential effects on the environment and human health as a result of the presence of hazardous substances in electrical and electronic equipment, end users of electrical and electronic equipment should understand the meaning of the crossed-out wheeled bin symbol. Do not dispose of WEEE as unsorted municipal waste and have to collect such WEEE separately.

Customer Feedback

We are striving to improve our documentation quality and we appreciate your feedback. Email your opinions and comments to DocsFeedback@yealink.com.

GNU GPL INFORMATION

Yealink Skype for Business phone firmware contains third-party software under the GNU General Public License (GPL). Yealink uses software under the specific terms of the GPL. Please refer to the GPL for the exact terms and conditions of the license.

The original GPL license, source code of components licensed under GPL and used in Yealink products can be downloaded from Yealink web site:

<http://www.yealink.com/GPLOpenSource.aspx?BaseInfoCateId=293&NewsCateId=293&CateId=293>.

About This Guide

Yealink administrator guide is intended for administrators who need to properly configure, customize, manage, and troubleshoot the Skype for Business phones rather than end-users. This guide will help you understand the Voice over Internet Protocol (VoIP) network and Session Initiation Protocol (SIP) components, and provides descriptions of all available phone features.

This guide describes three methods for configuring phones: central provisioning, web user interface and phone user interface. It will help you perform the following tasks:

- Configure your phone on a provisioning server
- Configure your phone's features and functions via web/phone user interface
- Troubleshoot some common phone issues

Many of the features described in this guide involve network settings, which could affect the phone's performance in the network. So an understanding of IP networking and a prior knowledge of IP telephony concepts are necessary.

The information detailed in this guide is applicable to firmware version 8 or higher. The firmware format is like x.x.x.x.rom. The second x from left must be greater than or equal to 8 (T46G Skype for Business phone: 28.8.1.65.rom).

Chapters in This Guide

This administrator guide includes the following chapters:

- Chapter 1, "[Product Overview](#)" describes the SIP phones and expansion modules.
- Chapter 2, "[Getting Started](#)" describes how Yealink phones fit in your network and how to install and connect phones, and also gives you an overview of phone's initialization process.
- Chapter 3, "[Setting Up Your System](#)" describes some essential information on how to set up your phone network and set up your phone with a provisioning server.
- Chapter 4, "[Configuring Basic Features](#)" describes how to configure the basic features on phones.
- Chapter 5, "[Configuring Advanced Features](#)" describes how to configure the advanced features on phones.
- Chapter 6, "[Configuring Audio Features](#)" describes how to configure the audio features on phones.
- Chapter 7, "[Configuring Security Features](#)" describes how to configure the security features on phones.
- Chapter 8, "[Troubleshooting](#)" describes how to troubleshoot phones and provides some

common troubleshooting solutions.

- Chapter 9, "[Appendix](#)" provides the glossary, time zones, trusted certificates, auto provisioning flowchart, reference information about phones compliant with [RFC 3261](#), SIP call flows and some other function lists (e.g., DSS keys, reading icons).

Documentations

This guide covers T48G/T46G/T42G/T41P/T40P Skype for Business phones. The following related documents are available:

- Quick Start Guides, which describe how to assemble Skype for Business phones and configure the most basic features available on Skype for Business phones.
- User Guides, which describe the basic and advanced features available on Skype for Business phones.
- Auto Provisioning Guide, which describes how to provision Skype for Business phones using the configuration files.

The purpose of *Auto Provisioning Guide* is to serve as a basic guidance for provisioning Yealink phones with a provisioning server. If you are new to this process, it is helpful to read this guide.

- Description of Configuration Parameters in CFG Files, which describes all configuration parameters in configuration files.

Note that Yealink administrator guide contains most parameters. If you want to find out more parameters which are not listed in this guide, please refer to Description of Configuration Parameters in CFG Files guide.

- <y0000000000xx>.cfg and <MAC>.cfg template configuration files.
- Deployment Guide, which describes how to deploy phones in a Microsoft Skype for Business Server environment.
- Updating Phone Firmware from Microsoft Skype for Business Server Guide, which describes how to upgrade firmware via Skype for Business Server.

For support or service, please contact your Yealink reseller or go to Yealink Technical Support online: <http://support.yealink.com/>.

Conventions Used in Yealink Documentations

Yealink documentations contain a few typographic conventions.

You need to know the following basic typographic conventions to distinguish types of in-text information:

Convention	Description
Bold	Highlights the web/phone user interface items such as menus, menu selections, soft keys, or directory names when they are involved in a procedure or user action (e.g., Click on Security -> License). Also used to emphasize text (e.g., Configuration File).
<i>Italics</i>	Used to show the format of examples (e.g., <i>http(s)://[IPv6 address]</i>), or to show the title of a section in the reference documentations available on the Yealink Technical Support Website (e.g., <i>Triggering the Skype for Business phone to Perform the Auto Provisioning</i>).
Blue Text	Used for cross references to other sections within this documentation (e.g., refer to Troubleshooting).
<i>Blue Text in Italics</i>	Used for hyperlinks to Yealink resources outside of this documentation such as the Yealink documentations (e.g., Yealink_Skype_for_Business_HD_IP_Phones_Auto_Provisioning_Guide).

You also need to know the following writing conventions to distinguish conditional information:

Convention	Description
<>	Indicates that you must enter specific information. For example, when you see <MAC>, enter your phone's 12-digit MAC address. If you see <phoneIPAddress>, enter your phone's IP address.
->	Indicates that you need to select an item from a menu. For example, Settings -> Basic Settings indicates that you need to select Basic Settings from the Settings menu.

Reading the Configuration Parameter Tables

Most features described in this guide include two tables. One is a summary table of provisioning methods that you can use to configure the features. The other is a table of details of the configuration parameters that you configure to make the features work.

This brief section describes the conventions used in the summary table and configuration parameter table. In order to read the tables and successfully perform configuration changes, an understanding of these conventions is necessary.

Summary Table Format

The following summary table indicates three provisioning methods (central provisioning, web user interface and phone user interface, refer to [Provisioning Methods](#) for more information) you can use to configure a feature. Note that the types of provisioning methods available for each feature will vary; not every feature uses all these three methods.

The central provisioning method requires you to configure parameters located in CFG format configuration files that Yealink provides. For more information on configuration files, refer to [Configuration Files](#) on page 94. As shown below, the table specifies the configuration file name and the corresponding parameters. That is, the <MAC>.cfg file contains the *account.1.auto_answer* parameter, and the <y0000000000xx>.cfg file contains the *features.auto_answer_delay* parameter.

The web user interface method requires you to configure features by navigating to the specified link. This navigation URL can help you quickly locate the webpage where you can configure the feature.

Provisioning method		Configuration file name	Feature explanation
Provisioning method	Central Provisioning (Configuration File)	<MAC>.cfg	Configure auto-answer. Parameter: account.1.auto_answer
		<y0000000000xx>.cfg	Specify a period of delay time for auto-answer. Parameter: features.auto_answer_delay
	Web User Interface		Configure auto-answer. Navigate to: http://<phoneIPAddress>/servlet?method=mod_data&p=account-basic&q=load&acc=0
Manual provisioning method		Phone User Interface	Configure auto-answer.

Configuration Parameter Table Format

The following configuration parameter table describes the parameter that you can configure to make the feature (e.g., auto answer) work.

Parameters ¹⁾	Permitted Values ²⁾	Default ³⁾
account.1.auto_answer⁴⁾	0 or 1⁵⁾	0⁶⁾
Description⁷⁾ Enables or disables auto-answer feature for account. ⁸⁾		
Meaning of the parameter value 0 Disabled 1 Enabled		
If it is set to 1 (Enabled), the Skype for Business phone can automatically answer an incoming call. ⁹⁾		
Note: The Skype for Business phone cannot automatically answer the incoming call during a call even if auto answer is enabled. ¹⁰⁾		
Web User Interface¹¹⁾ Account->Basic->Auto Answer ¹²⁾		
Phone User Interface¹³⁾ Menu->Features->Auto Answer->Line 1->Auto Answer ¹⁴⁾		

Note

Sometimes you will see the words "Refer to the following content" in the **Permitted Values** or **Default** field. It means the permitted value or the default value of the parameter has the model difference or there are many permitted values of the parameter, you can get more details from the following **Description** field.

The word "None" in the **Web User Interface** or **Phone User Interface** field means this feature cannot be configured via web/phone user interface.


The above table also indicates three methods for configuring the feature.

Method 1: Central Provisioning

This table specifies the details of *account.1.auto_answer* parameter, which enables or disables the auto answer feature. This parameter is disabled by default. If you want to enable the auto answer feature, open the MAC.cfg file and locate the parameter name *account.1.auto_answer*. Set the parameter value to "1" to enable the auto answer feature or "0" to disable the auto answer feature.


Note that some parameters described in this guide contain one or more variables (e.g., X or Y). But the variables in the parameters described in the CFG file are all replaced with specific value in the scope of variable. You may need to assign a value to the variable before you search and locate the specific parameter in the CFG file.

For example, if you want to configure the dial-now rule, you need to locate the `dialplan.dialnow.rule.X` in the `Common.cfg` file and then configure it as required (e.g., `dialplan.dialnow.rule.1 = 123`).



If you want to enable the audio codec 1 for account 1, you can locate the `account.1.codec.Y.enable` in the `MAC.cfg` file and configure it as required (e.g., `account.1.codec.1.enable = 1`).


The following shows a segment of `MAC.cfg` file:



Method 2: Web User Interface

As described in the chapter [Summary Table Format](#), you can directly navigate to the specified webpage to configure the feature. You can also first log into the web user interface, and then locate the feature field according to the web path (e.g., **Account->Basic->Auto Answer**) to configure it as required.

As shown in the following illustration:




To successfully log into the web user interface, you may need to enter the user name (default: admin) and password (default: admin). For more information, refer to [Web User Interface](#) on

page 93.

Method 3: Phone User Interface

You can configure features via phone user interface. Access to the desired feature according to the phone path (e.g., **Menu->Features->Auto Answer->Line1->Auto Answer**) and then configure it as required.

As shown in the following illustration:



Recommended References

For more information on configuring and administering other Yealink products not included in this guide, refer to product support page at [Yealink Technical Support](#).

To access the latest Release Notes or other guides for Yealink phones, refer to the Document Download page for your phone at [Yealink Technical Support](#).

If you want to find Request for Comments (RFC) documents, type <http://www.ietf.org/rfc/rfcNNNN.txt> (NNNN is the RFC number) into the location field of your browser.

This guide mainly takes the T46G Skype for Business phones as example for reference. For more details on other Skype for Business phones, refer to [Yealink phone-specific user guide](#).

For other references, look for the hyperlink or web info throughout this administrator guide.

Understanding VoIP Principle and SIP Components

This section mainly describes the basic knowledge of VoIP principle and SIP components, which will help you have a better understanding of the phone's deployment scenarios.

VoIP Principle

VoIP

VoIP (Voice over Internet Protocol) is a technology using the Internet Protocol instead of traditional Public Switch Telephone Network (PSTN) technology for voice communications.

It is a family of technologies, methodologies, communication protocols, and transmission techniques for the delivery of voice communications and multimedia sessions over IP networks. The H.323 and Session Initiation Protocol (SIP) are two popular VoIP protocols that are found in widespread implementation.

H.323

H.323 is a recommendation from the ITU Telecommunication Standardization Sector (ITU-T) that defines the protocols to provide audio-visual communication sessions on any packet network. The H.323 standard addresses call signaling and control, multimedia transport and control, and bandwidth control for point-to-point and multi-point conferences.

It is widely implemented by voice and video conference equipment manufacturers, is used within various Internet real-time applications such as GnuGK and NetMeeting and is widely deployed by service providers and enterprises for both voice and video services over IP networks.

SIP

SIP (Session Initiation Protocol) is the Internet Engineering Task Force's (IETF's) standard for multimedia conferencing over IP. It is an ASCII-based, application-layer control protocol (defined in [RFC 3261](#)) that can be used to establish, maintain, and terminate calls between two or more endpoints. Like other VoIP protocols, SIP is designed to address functions of signaling and session management within a packet telephony network. Signaling allows call information to be carried across network boundaries. Session management provides the ability to control attributes of an end-to-end call.

SIP provides capabilities to:

- Determine the location of the target endpoint -- SIP supports address resolution, name mapping, and call redirection.
- Determine media capabilities of the target endpoint -- Via Session Description Protocol (SDP), SIP determines the "lowest level" of common services between endpoints. Conferences are established using only media capabilities that can be supported by all endpoints.
- Determine the availability of the target endpoint -- A call cannot be completed because the target endpoint is unavailable, SIP determines whether the called party is already on the phone or does not answer in the allotted number of rings. It then returns a message indicating why the target endpoint is unavailable.
- Establish a session between the origin and target endpoint -- The call can be completed,

SIP establishes a session between endpoints. SIP also supports mid-call changes, such as the addition of another endpoint to the conference or the change of a media characteristic or codec.

- Handle the transfer and termination of calls -- SIP supports the transfer of calls from one endpoint to another. During a call transfer, SIP simply establishes a session between the transferee and a new endpoint (specified by the transferring party) and terminates the session between the transferee and the transferring party. At the end of a call, SIP terminates the sessions between all parties.

SIP Components

SIP is a peer-to-peer protocol. The peers in a session are called User Agents (UAs). A user agent can function as one of following roles:

- User Agent Client (UAC) -- A client application that initiates the SIP request.
- User Agent Server (UAS) -- A server application that contacts the user when a SIP request is received and that returns a response on behalf of the user.

User Agent Client (UAC)

The UAC is an application that initiates up to six feasible SIP requests to the UAS. The six requests issued by the UAC are: INVITE, ACK, OPTIONS, BYE, CANCEL and REGISTER. When the SIP session is being initiated by the UAC SIP component, the UAC determines the information essential for the request, which is the protocol, the port and the IP address of the UAS to which the request is being sent. This information can be dynamic and will make it challenging to put through a firewall. For this reason, it may be recommended to open the specific application type on the firewall. The UAC is also capable of using the information in the request URI to establish the course of the SIP request to its destination, as the request URI always specifies the host which is essential. The port and protocol are not always specified by the request URI. Thus if the request does not specify a port or protocol, a default port or protocol is contacted. It may be preferential to use this method when not using an application layer firewall. Application layer firewalls like to know what applications are flowing through which ports and it is possible to use content types of other applications other than the one you are trying to let through what has been denied.

User Agent Server (UAS)

UAS is a server that hosts the application responsible for receiving the SIP requests from a UAC, and on reception it returns a response to the request back to the UAC. The UAS may issue multiple responses to the UAC, not necessarily a single response. Communication between UAC and UAS is client/server and peer-to-peer.

Typically, a SIP endpoint is capable of functioning as both a UAC and a UAS, but it functions only as one or the other per transaction. Whether the endpoint functions as a UAC or a UAS depends on the UA that initiates the request.

Summary of Changes

This section describes the changes to this guide for each release and guide version.

Changes for Release 8, Guide Version 8.65

The following sections are new for this edition:

- [Team-Call Group](#) on page 224
- [Response Group](#) on page 227
- [Boss-Line Ringtone](#) on page 242
- [Delegates-call Ringtone](#) on page 243
- [Muting the Ringtone](#) on page on page 283

Major updates have occurred to the following section:

- [Quality of Experience](#) on page 271

Changes for Release 8, Guide Version 8.60

The following sections are new for this edition:

- [Reading the Configuration Parameter Tables](#) on page vii
- [Recommended References](#) on page xi
- [What IP Phones Need to Meet](#) on page 9
- [Setting Up Your System](#) on page 21
- [Signing into Skype for Business](#) on page 112
- [Outlook Contacts](#) on page 194

Major updates have occurred to the following section:

- [Connecting the Skype for Business Phones](#) on page 9
- [Quality of Experience](#) on page 271
- [Troubleshooting Solutions](#) on page 370

Changes for Release 8, Guide Version 8.50

The following sections are new for this version:

- [DHCP Option 160 and Option 161](#) on page 30
- [Remembering Password](#) on page 124
- [Bluetooth](#) on page 138
- [Hotline](#) on page 175

- [Monitoring Status Changes using Line Key LED Indicator](#) on page 181
- [History Record Contacts Avatar](#) on page 202
- [Music on Hold](#) on page 219
- [Call Forward](#) on page 220
- [Monitoring Status Changes using EXP Key LED Indicator](#) on page 255
- [Quality of Experience](#) on page 271
- [Private Line Tones](#) on page 284
- [Sending Volume](#) on page 300
- [Memory Information](#) on page 351
- [Skype for Business Status](#) on page 352

Major update has occurred to the following sections:

- [Signing into Skype for Business](#) on page 112
- [Key As Send](#) on page 166
- [BToE](#) on page 250
- [Viewing Global Log Files](#) on page 355

Changes for Release 8, Guide Version 8.21

This version is updated to incorporate T46G, T42G, T41P and T40P Skype for Business phones. And T22/T22P Skype for Business phones are removed from version 8.

The following sections are new for this version:

- [Conventions Used in Yealink Documentations](#) on page vii
- [Expansion Module](#) on page 6
- [Signing Out of Skype for Business](#) on page 126
- [Updating Status Automatically](#) on page 127
- [Contrast](#) on page 134
- [Loading Language Packs](#) on page 158
- [Contact Management](#) on page 178
- [Boss-Admin Feature](#) on page 239
- [Calendar](#) on page 244
- [EXP40 Expansion Module](#) on page 254
- [Multicast Paging](#) on page 259
- [Action URI](#) on page 268
- [Pre Dial Tone](#) on page 277
- [Voice Mail Tone](#) on page 293

- [Skype for Business Feature License](#) on page 325

Major update has occurred to the following sections:

- [Physical Features of Skype for Business Phones](#) on page 1
- [Connecting the Skype for Business Phones](#) on page 9
- [Reading Icons](#) on page 17
- [PPPoE](#) on page 42
- [LLDP](#) on page 55
- [802.1X Authentication](#) on page 81
- [Configuration Files](#) on page 94
- [Signing into Skype for Business](#) on page 112
- [Save Call Log](#) on page 198
- [E911](#) on page 235
- [BToE](#) on page 250
- [Phone Lock](#) on page 330
- [Viewing Global Log Files](#) on page 355

Table of Contents

About This Guide	V
Chapters in This Guide.....	v
Documentations.....	vi
Conventions Used in Yealink Documentations	vii
Reading the Configuration Parameter Tables.....	vii
Summary Table Format.....	viii
Configuration Parameter Table Format	ix
Recommended References	xi
Understanding VoIP Principle and SIP Components	xi
VoIP Principle.....	xii
SIP Components	xiii
Summary of Changes	xiv
Changes for Release 8, Guide Version 8.65.....	xiv
Changes for Release 8, Guide Version 8.60.....	xiv
Changes for Release 8, Guide Version 8.50.....	xiv
Changes for Release 8, Guide Version 8.21.....	xv
Table of Contents.....	xvii
Product Overview.....	1
Phone Models	1
Physical Features of Skype for Business Phones	1
Key Features of Skype for Business Phones.....	5
Expansion Module.....	6
Getting Started.....	9
What IP Phones Need to Meet	9
Connecting the Skype for Business Phones	9
Attaching the Stand and the Optional Wall Mount Bracket	10
Connecting the Handset and Optional Headset.....	12
Connect the Optional Bluetooth USB Dongle	13
Connecting the Power and Network	13
Initialization Process Overview	15
Verifying Startup	16
Reading Icons	17

Setting Up Your System 21

Setting Up Your Phone Network	21
DHCP	22
DHCP Option.....	26
Configuring Network Parameters Manually	37
PPPoE	42
Configuring Transmission Methods of the Internet Port and PC Port	45
Configuring PC Port Mode	48
Web Server Type	50
VLAN	54
IPv6 Support	69
Quality of Service (QoS)	78
802.1X Authentication	81
Branch Office Resiliency	91
Setting Up Your Phones with a Provisioning Server.....	92
Provisioning Points to Consider	92
Provisioning Methods.....	92
Configuration Files and Resource Files	94
Setting Up a Provisioning Server	97
Upgrading Firmware.....	100
Upgrading Firmware via Web User Interface	101
Upgrading Firmware from the Provisioning Server	101
Updating Phone Firmware from Skype for Business Server	106

Configuring Basic Features111

Signing into Skype for Business.....	112
User Sign-in.....	112
PIN Authentication.....	116
Web Sign-in.....	119
Signing in via PC.....	124
Remembering Password	124
Signing Out of Skype for Business	126
Updating Status Automatically	127
Always On Line.....	129
Power Indicator LED	131
Contrast	134
Backlight.....	135
Bluetooth	138
Time and Date	140
NTP Time Server	141
Time and Date Settings	146
Daylight Saving Time	150

Language	157
Loading Language Packs	158
Specifying the Language to Use.....	164
Key As Send	166
Dial Plan.....	170
Dial-now	171
Hotline	175
Contact Management	178
Skype for Business Directory	178
Local Directory	183
Outlook Contacts.....	194
Call Log.....	198
Save Call Log.....	198
Missed Call Log	201
History Record Contacts Avatar	202
Dial Search Delay.....	204
Live Dialpad	206
Call Waiting.....	207
Auto Answer.....	210
Busy Tone Delay.....	212
Return Code When Refuse	214
Early Media.....	215
180 Ring Workaround	215
Call Hold.....	217
Music on Hold.....	219
Call Forward	220
Team-Call Group	224
Setting up Team-call Group.....	224
Team-Call Ringtone	225
Response Group	227
Response Group Ringtone.....	228
Allow Trans Exist Call.....	229
Call Number Filter.....	231
Allow Mute	233
Voice Mail without PIN	234
E911.....	235
E911 Location Tip.....	237
Boss-Admin Feature	239
Assigning Delegates	239
Removing Delegates.....	240
Boss-Line Ringtone	242
Delegates-call Ringtone	243
Calendar	244
Setting up a Skype Conference in Outlook	244

Setting up an Appointment in Outlook.....	245
Setting up a Meeting in Outlook.....	245
Setting up an Event in Outlook	246
Using the Calendar	247
BToE.....	250
EXP40 Expansion Module	254
Assigning Contacts to EXP40	254
Monitoring Status Changes using EXP Key LED Indicator	255

Configuring Advanced Features.....259

Multicast Paging	259
Sending RTP Stream.....	259
Receiving RTP Stream	263
Action URI.....	268
Configuring Trusted IP Address for Action URI.....	268
Capturing the Current Screen of the Phone.....	270
Quality of Experience.....	271

Configuring Audio Features.....277

Pre Dial Tone.....	277
Phone Ring Tones	278
Muting the Ringtone	283
Private Line Tones	284
Redial Tone	286
Tones	287
Voice Mail Tone.....	293
Headset Prior	295
Ringer Device for Headset	297
Dual Headset.....	299
Sending Volume.....	300
Audio Codecs	302
Acoustic Clarity Technology.....	309
Acoustic Echo Cancellation	309
Background Noise Suppression (BNS).....	310
Automatic Gain Control (AGC).....	310
Voice Activity Detection (VAD)	311
Comfort Noise Generation (CNG).....	312
Jitter Buffer	314
DTMF.....	316
Methods of Transmitting DTMF Digit	317
Suppress DTMF Display.....	318
Transfer via DTMF	320
Play Local DTMF Tone	322

Configuring Security Features.....325

Skype for Business Feature License	325
User and Administrator Passwords.....	327
Auto-Logout Time.....	329
Phone Lock	330
Account Lock	333
Transport Layer Security.....	335
Encrypting Configuration Files	344

Troubleshooting.....351

Troubleshooting Methods	351
Memory Information	351
Skype for Business Status	352
Viewing Global Log Files	355
Capturing Packets	364
Enabling Watch Dog Feature	367
Getting Information from Status Indicators.....	368
Analyzing Configuration File	368
Troubleshooting Solutions	370
IP Address Issues	370
Time and Date Issues.....	371
Display Issues	371
Directory Issues.....	371
Audio Issues	371
Bluetooth Issues	372
Firmware and Upgrading Issues	373
Provisioning Issues.....	374
System Log Issues.....	374
Resetting Issues	374
Rebooting Issues.....	375
Protocols and Ports Issues.....	377
Password Issues.....	379
Power and Startup Issues	379
Other Issues	379

Appendix.....381

Appendix A: Glossary.....	381
Appendix B: Time Zones	382
Appendix C: Trusted Certificates	384
Appendix D: SIP (Session Initiation Protocol).....	385
RFC and Internet Draft Support	386

SIP Request.....	389
SIP Header	390
SIP Responses	391
SIP Session Description Protocol (SDP) Usage	394
Appendix E: SIP Call Flows.....	394
Successful Call Setup and Disconnect	394
Unsuccessful Call Setup—Called User is Busy	397
Unsuccessful Call Setup—Called User Does Not Answer	399
Successful Call Setup and Call Hold	401
Successful Call Setup and Call Waiting	404
Call Transfer without Consultation	408
Call Transfer with Consultation.....	411
Call Conference.....	416
Index	421

Product Overview

This chapter contains the following information about Skype for Business phones:

- [Phone Models](#)
- [Expansion Module](#)

Phone Models

This section introduces T48G/T46G/T42G/T41P/T40P Skype for Business phone models. They are designed to work with Skype for Business Server. These Skype for Business phones are characterized by a large number of functions, which simplify business communication with a high standard of security.

The T48G/T46G/T42G/T41P/T40P Skype for Business phones provide a powerful and flexible IP communication solution for Ethernet TCP/IP networks, delivering excellent voice quality. When these phones register Skype for Business accounts, you can interact with your Skype for Business contacts list on your phones through Microsoft's Active Directory.

Skype for Business phones comply with the SIP standard ([RFC 3261](#)), and they can only be used within a network that supports this model of phone.

For a list of key features available on Yealink Skype for Business phones running the latest firmware, refer to [Physical Features of Skype for Business Phones](#) on page 1.

Physical Features of Skype for Business Phones

This section lists the available physical features of T48G/T46G/T42G/T41P/T40P Skype for Business phones.

T48G



Physical Features:

- 7" 800 x 480 pixel color touch screen with backlight
- 24 bit depth color
- 1 Skype for Business account
- HD Voice: HD Codec, HD Handset, HD Speaker
- 26 keys including 7 feature keys
- 1*RJ9 (4P4C) handset port
- 1*RJ9 (4P4C) headset port
- 2*RJ45 10/100/1000Mbps Ethernet ports
- 1*RJ12 (6P6C) expansion module port
- 4 LEDs: 1*power, 1*mute, 1*headset, 1*speakerphone
- Power adapter: AC 100~240V input and DC 5V/2A output
- Power over Ethernet (IEEE 802.3af)
- Built-in USB port, support Bluetooth headset
- Wall Mount

T46G



Physical Features:

- 4.3" 480 x 272 pixel color display with backlight
- 24 bit depth color
- 1 Skype for Business account
- HD Voice: HD Codec, HD Handset, HD Speaker
- 36 dedicated hard keys and 4 context-sensitive soft keys
- 1*RJ9 (4P4C) handset port
- 1*RJ9 (4P4C) headset port

- 2*RJ45 10/100/1000Mbps Ethernet ports
- 1*RJ12 (6P6C) expansion module port
- 14 LEDs: 1*power, 10*line, 1*mute, 1*headset, 1*speakerphone
- Power adapter: AC 100~240V input and DC 5V/2A output
- Power over Ethernet (IEEE 802.3af)
- Built-in USB port, support Bluetooth headset
- Wall Mount

T42G



Physical Features:

- 192 x 64 graphic LCD
- 1 Skype for Business account
- HD Voice: HD Codec, HD Handset, HD Speaker
- 30 dedicated hard keys and 4 context-sensitive soft keys
- 1*RJ9 (4P4C) handset port
- 1*RJ9 (4P4C) headset port
- 2*RJ45 10/100/1000Mbps Ethernet ports
- 1*RJ12 (6P6C) EHS36 headset adapter port
- 10 LEDs: 1*power, 6*line, 1*mute, 1*headset, 1*speakerphone
- Power adapter: AC 100~240V input and DC 5V/1.2A output
- Power over Ethernet (IEEE 802.3af)
- Wall Mount、

T41P



Physical Features:

- 192 x 64 graphic LCD
- 1 Skype for Business account
- HD Voice: HD Codec, HD Handset, HD Speaker
- 30 dedicated hard keys and 4 context-sensitive soft keys
- 1*RJ9 (4P4C) handset port
- 1*RJ9 (4P4C) headset port
- 2*RJ45 10/100Mbps Ethernet ports
- 1*RJ12 (6P6C) EHS36 headset adapter port
- 10 LEDs: 1*power, 6*line, 1*mute, 1*headset, 1*speakerphone
- Power adapter: AC 100~240V input and DC 5V/1.2A output
- Power over Ethernet (IEEE 802.3af)
- Wall Mount

T40P



Physical Features:

- 132 x 64 graphic LCD
- 1 Skype for Business account
- HD Voice: HD Codec, HD Handset, HD Speaker
- 27 dedicated hard keys and 4 context-sensitive soft keys
- 1*RJ9 (4P4C) handset port
- 1*RJ9 (4P4C) headset port
- 2*RJ45 10/100Mbps Ethernet ports
- 1*RJ12 (6P6C) EHS36 headset adapter port
- 4 LEDs: 1*power, 3*line
- Power adapter: AC 100~240V input and DC 5V/600mA output
- Power over Ethernet (IEEE 802.3af)
- Wall Mount

Key Features of Skype for Business Phones

In addition to physical features introduced above, Skype for Business phones also support the following key features when running the latest firmware:

- **Phone Features**

- **Call Options:** emergency call, call waiting, call hold, call mute, call forward, call transfer, group pickup and audio conference.
- **Basic Features:** live dialpad, dial plan, caller identity, auto answer.

- **Codecs and Voice Features**

- Wideband codec: G.722
- Narrowband codec: G.711, G.726, G.729, iLBC, G723 (G723 is not applicable to T40P Skype for Business phones)
- VAD, CNG, AEC, PLC, AJB, AGC
- Full-duplex speakerphone with AEC

- **Network Features**

- SIP v1 (RFC2543), v2 (RFC3261)
- Proxy mode and peer-to-peer SIP link mode
- IP assignment: Static/DHCP/PPPoE (PPPoE is not applicable to T42G/T41P/T40P Skype for Business phones)
- VLAN assignment: LLDP/Static/DHCP/CDP

- Bridge mode for PC port
- HTTP/HTTPS server
- DNS client
- DHCP server
- IPv6 support
- **Management**
 - FTP/TFTP/HTTP auto-provision
 - Configuration: browser/phone/auto-provision
 - Dial number via SIP server
 - Dial URL via SIP server
- **Security**
 - HTTPS (server/client)
 - Transport Layer Security (TLS)
 - VLAN (802.1q), QoS
 - Digest authentication using MD5/MD5-sess
 - Secure configuration file via AES encryption
 - Phone lock for personal privacy protection
 - Admin/User configuration mode
 - 802.1X authentication

Expansion Module

This section introduces EXP40 expansion modules. EXP40 is only applicable to T48G/T46G Skype for Business phones.

The Yealink EXP40 Expansion Module, with a LCD display, is console you can connect to T48G/T46G Skype for Business phones to add additional lines. You can assign contacts to EXP keys on your EXP40, so that you can quickly call contacts by pressing the corresponding EXP key. You can also monitor your Skype for Business contacts' presence status from your Expansion Module. For more information on assigning contacts to EXP keys, refer to [Yealink phone-specific user guide](#).

The following lists the available physical features of the currently supported LCD expansion modules:

EXP40



Physical Features:

- Rich visual experience with 160 x 320 graphic LCD
- 20 physical keys each with a dual-color LED
- 20 additional keys through page switch
- Supports up to 6 modules daisy-chain
- Expansion module (≤ 2) is powered by the host phone
- Expansion module (> 2) is powered by the power adapter (AC 100~240V input and DC 5V/1.2A output)
- 2*RJ-12 (6P6C) ports for data in and out
- Wall Mount

Getting Started

This chapter provides basic information and installation instructions of Skype for Business phones.

This chapter provides the following sections:

- [What IP Phones Need to Meet](#)
- [Connecting the Skype for Business Phones](#)
- [Initialization Process Overview](#)
- [Verifying Startup](#)
- [Reading Icons](#)

What IP Phones Need to Meet

In order to operate as SIP endpoints in your network successfully, Skype for Business phones must meet the following requirements:

- A working IP network is established.
- VoIP gateways are configured for SIP.
- The latest (or compatible) firmware of Skype for Business phones is available.
- The Skype for Business Server is active and configured to receive and send SIP messages.

Connecting the Skype for Business Phones

This section introduces how to install T48G/T46G/T42G/T41P/T40P Skype for Business phones with components in packaging contents.

1. Attach the stand and the optional wall mount bracket
2. Connect the handset and optional headset
3. Connect the optional Bluetooth USB Dongle
4. Connect the network and power


Note

The optional accessories are not included in packaging contents. You need to purchase them separately if required.


Attaching the Stand and the Optional Wall Mount Bracket

To attach the stand and the optional wall mount bracket:

For T48G Skype for Business phones:




Desk Mount Method




Wall Mount Method (Optional)

Note The top two slots on T48G Skype for Business phones are plugged up by silica gel. You need to pull out silica gel before attaching the wall mount bracket.

For T46G Skype for Business phones:




Desk Mount Method




Wall Mount Method (Optional)

For T42G/T41P/T40P Skype for Business phones:



Desk Mount Method



Wall Mount Method (Optional)

Note

The hookswitch tab has a lip which allows the handset to stay on-hook when the Skype for Business phone is mounted vertically.


For more information on how to attach the wall mount bracket for T48G/T46G, refer to [Yealink Wall Mount Quick Installation Guide for SIP-T29_T27_T46_T48 IP Phones](#).

For more information on how to attach the wall mount bracket for T42G/T41P/T40P, refer to [Yealink Wall Mount Quick Installation Guide for SIP-T40_T41_T42 IP Phones](#).


Connecting the Handset and Optional Headset

To connect the handset and optional headset:

For T48G/T46G Skype for Business phones:



For T42G/T41P/T40P Skype for Business phones:



Note

Wireless headset adapter EHS36 should be purchased separately. For more information on how to use the EHS36 on the phone, refer to [Yealink EHS36 User Guide](#).


The EXT port on T48G/T46G Skype for Business phones can also be used to connect the expansion module EXP40. For more information on how to connect the EXP40, refer to [Yealink phone-specific user guide](#).

Connect the Optional Bluetooth USB Dongle

You can connect a Bluetooth USB dongle to T48G/T46G Skype for Business phones for connecting a Bluetooth headset.

To connect a Bluetooth USB dongle:

1. Insert a BT40 Bluetooth USB dongle into the USB port on the phone.



Note

The Bluetooth USB dongle BT40 should be purchased separately. For more information on how to use the BT40, refer to [Yealink Bluetooth USB Dongle BT40 User Guide](#).


Connecting the Power and Network

AC Power (Optional)

To connect the AC power and network:

1. Connect the DC plug of the power adapter to the DC5V port on the Skype for Business phone and connect the other end of the power adapter into an electrical power outlet.

2. Connect the included or a standard Ethernet cable between the Internet port on the Skype for Business phone and the one on the wall or switch/hub device port.



Note

The Skype for Business phone should be used with Yealink original power adapter only. The use of the third-party power adapter may cause the damage to the phone.

Power specifications are listed below:


Phone Model	Power Specification
T48G	5V/2A
T46G	5V/2A
T42G	5V/1.2A
T41P	5V/1.2A
T40P	5V/600mA

Power over Ethernet

With the included or a regular Ethernet cable, Skype for Business phones can be powered from a PoE-compliant switch or hub.

To connect the PoE:

- 1) Connect the Ethernet cable between the Internet port on the Skype for Business phone and an available port on the in-line power switch/hub.

**Note**

If in-line power switch/hub is provided, you don't need to connect the phone to the power adapter. Make sure the switch/hub is PoE-compliant.

The Skype for Business phone can also share the network with another network device such as a PC (personal computer). It is an optional connection.

Important! Do not unplug or remove the power while the Skype for Business phone is updating firmware and configurations.

Initialization Process Overview

The initialization process of the Skype for Business phone is responsible for network connectivity and operation of the phone in your local network.

Once you connect your Skype for Business phone to the network and to an electrical supply, the Skype for Business phone begins its initialization process.

During the initialization process, the following events take place:

Loading the ROM file

The ROM file resides in the flash memory of the Skype for Business phone. The Skype for Business phone comes from the factory with a ROM file preloaded. During initialization, the Skype for Business phone runs a bootstrap loader that loads and executes the ROM file.

Configuring the VLAN

If the Skype for Business phone is connected to a switch, the switch notifies the Skype for Business phone of the VLAN information defined on the switch (if using LLDP or CDP). The Skype for Business phone can then proceed with the DHCP request for its network settings (if using DHCP).

Querying the DHCP (Dynamic Host Configuration Protocol) Server

The Skype for Business phone is capable of querying a DHCP server. DHCP is enabled on the Skype for Business phone by default. The following network parameters can be obtained from the DHCP server during initialization:

- IP Address
- Subnet Mask
- Gateway
- Primary DNS (Domain Name Server)
- Secondary DNS

You need to configure network parameters of the Skype for Business phone manually if any of them is not supplied by the DHCP server. For more information on configuring network parameters manually, refer to [Configuring Network Parameters Manually](#) on page 37.

Contacting the provisioning server

If the phone is configured to obtain configurations from the provisioning server, it will connect to the provisioning server, download the configuration file(s) during startup. The phone will be able to resolve and update configurations written in the configuration file(s). If the phone does not obtain configurations from the provisioning server, the phone will use configurations stored in the flash memory. For more information, refer to [Setting Up Your Phones with a Provisioning Server](#) on page 92.

Updating firmware

If the access URL of firmware is defined in the configuration file, the phone will download firmware from the provisioning server. If the MD5 value of the downloaded firmware file differs from that of the image stored in the flash memory, the phone will perform a firmware update.

You can manually upgrade firmware if the phone does not download firmware from the provisioning server. For more information, refer to [Upgrading Firmware](#) on page 100.

Downloading the resource files

In addition to configuration file(s), the Skype for Business phone may require resource files before it can deliver service. These resource files are optional, but if some particular features are being deployed, these files are required.

The followings show examples of resource files:

- Language packs
- Ring tones

For more information on resource files, refer to [Resource Files](#) on page 95.

Verifying Startup
























After connected to the power and network, the Skype for Business phone begins the initializing




























































process by cycling through the following steps:
































1. The power indicator LED illuminates solid red.
2. The message "Welcome Initializing... please wait" appears on the LCD screen when the Skype for Business phone starts up.
3. The Skype for Business phone enters the login screen.

Reading Icons

Icons associated with different features may appear on the LCD screen. The following table provides a description for each icon on Skype for Business phones.

T48G	T46G	T42G/T41P	T40P	Description
/	/			Network is unavailable
			/	Local Favorites
				Call Mute
	/	/	/	Call Forward
	/	/	/	Place a call/ Answer a call
	/	/	/	Search contacts
				Call Hold
	/	/	/	Call Resume
	/	/	/	Add a new call
	/	/	/	View more soft keys
	/	/	/	Consultative transfer
	/	/	/	Blind transfer
	/	/	/	Call Park
	/	/	/	Invite a new call to the Skype for Business conference
	/	/	/	View the conference participants
	/	/	/	View the dial-in number and conference ID

T48G	T46G	T42G/T41P	T40P	Description
	/	/	/	Forward incoming calls to voice mail
	/	/	/	Enter message center
	/	/	/	Reject or cancel a call
				Received Calls
				Placed Calls
				Missed Calls
/				Forwarded Calls
		/	/	Bluetooth mode is on
		/	/	Bluetooth headset is both paired and connected
	/	/	/	Return to previous screen
				Hands-free speakerphone mode
		/	/	Location is not set
/	/			Voice Mail
/				Auto Answer
				Unread voice mail
				Read voice mail
	/	/	/	Enable the conference announcement
	/	/	/	Disable the conference announcement
/				Conference organizer
				Conference presenter
				Conference attendee
				Conference lock

T48G	T46G	T42G/T41P	T40P	Description
/				Ringer volume is 0
				Phone Lock
				Available
				Busy
				DND (Do Not Disturb)
				Be Right Back/Off Work/Away
				Off Line
				Unknown

Setting Up Your System

This section describes essential information on how to set up your phone network and set up your phones with a provisioning server. It also provides instructions on how to set up a provisioning server, how to deploy Yealink phones from the provisioning server, how to upgrade firmware, and how to keep user personalized settings after auto provisioning.

This chapter provides the following sections:

- [Setting Up Your Phone Network](#)
- [Setting Up Your Phones with a Provisioning Server](#)

Setting Up Your Phone Network

Yealink phones are operated on an Ethernet local area network (LAN). Local area network design varies by organization and Yealink phones can be configured to accommodate a number of network designs.

In order to get your phones running, you must perform basic network setup, such as IP address and subnet mask configuration. You can configure the IPv4 or IPv6 network parameters for the phone. You can also configure the appropriate security (VLAN and/or 802.1X authentication) and Quality of Service (QoS) settings for the phone.

This chapter describes how to configure all the network parameters for phones, and it provides the following sections:

This chapter describes how to configure all the network parameters for phones, and it provides the following sections:

- [DHCP](#)
- [DHCP Option](#)
- [Configuring Network Parameters Manually](#)
- [PPPoE](#)
- [Configuring Transmission Methods of the Internet Port and PC Port](#)
- [Configuring PC Port Mode](#)
- [Web Server Type](#)
- [VLAN](#)
- [IPv6 Support](#)
- [Quality of Service \(QoS\)](#)
- [802.1X Authentication](#)
- [Branch Office Resiliency](#)

DHCP

DHCP (Dynamic Host Configuration Protocol) is a network protocol used to dynamically allocate network parameters to network hosts. The automatic allocation of network parameters to hosts eases the administrative burden of maintaining an IP network. Phones comply with the DHCP specifications documented in [RFC 2131](#). If using DHCP, phones connected to the network become operational without having to be manually assigned IP addresses and additional network parameters.

Procedure

DHCP can be configured using the configuration files or locally.

Configuration File	<MAC>.cfg	Configure DHCP on the Skype for Business phone. Parameter: network.internet_port.type
Local	Web User Interface	Configure DHCP on the Skype for Business phone. Navigate to: <a href="http://<phoneIPAddress>/servlet?parameter=network&q=load">http://<phoneIPAddress>/servlet?parameter=network&q=load
	Phone User Interface	Configure DHCP on the Skype for Business phone.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
network.internet_port.type	0, 1 or 2	0
<p>Description: Configures the Internet (WAN) port type for IPv4.</p> <p>0-DHCP 1-PPPoE (not applicable to T42G/T41P/T40P Skype for Business phones) 2-Static IP Address</p> <p>Note: It works only if the value of the parameter "network.ip_address_mode" is set to 0 (IPv4) or 2 (IPv4 & IPv6). If you change this parameter, the Skype for Business phone will reboot to make the change take effect.</p> <p>Web User Interface: Network->Basic->IPv4 Config</p>		

Parameters	Permitted Values	Default
Phone User Interface: Menu->Advanced (default password: admin) ->Network->WAN Port->IPv4		

To configure DHCP via web user interface:

1. Click on **Network->Basic**.
2. In the **IPv4 Config** block, mark the **DHCP** radio box.

3. Click **Confirm** to accept the change.
A dialog box pops up to prompt that settings will take effect after a reboot.
4. Click **OK** to reboot the Skype for Business phone.

To configure DHCP via phone user interface:

1. Press **Menu->Advanced** (default password: admin) ->**Network->WAN Port->IPv4**.
2. Press **Left** or **Right**, or the **Switch** soft key to select **DHCP** from the **Type** field.
3. Press the **Save** soft key to accept the change.

The Skype for Business phone reboots automatically to make settings effective after a period of time.

Static DNS

Static DNS address(es) can be configured and used even though DHCP is enabled.

Procedure

Static DNS can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the static DNS feature. Parameters: network.static_dns_enable
---------------------------	---------------------	--

	<MAC>.cfg	Configure static DNS address. Parameters: network.primary_dns network.secondary_dns
Local	Web User Interface	Configure the static DNS feature. Configure static DNS address. Navigate to: http://<phoneIPAddress>/servlet?p=network&q=load
	Phone User Interface	Configure the static DNS feature. Configure static DNS address.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
network.static_dns_enable	0 or 1	0
Description: Triggers the static DNS feature to on or off. 0 -Off 1 -On If it is set to 0 (Off), the Skype for Business phone will use the IPv4 DNS obtained from DHCP. If it is set to 1 (On), the Skype for Business phone will use manually configured static IPv4 DNS. Note: It works only if the value of the parameter "network.internet_port.type" is set to 0 (DHCP). If you change this parameter, the Skype for Business phone will reboot to make the change take effect. Web User Interface: Network->Basic->IPv4 Config->Static DNS Phone User Interface: Menu->Advanced (default password: admin)->Network->WAN Port->IPv4->DHCP->Static DNS		
network.primary_dns	IPv4 Address	Blank
Description: Configures the primary IPv4 DNS server.		

Parameters	Permitted Values	Default
<p>Example:</p> <p>network.primary_dns = 202.101.103.55</p> <p>Note: It works only if the value of the parameter "network.static_dns_enable" is set to 1 (On). If you change this parameter, the Skype for Business phone will reboot to make the change take effect.</p> <p>Web User Interface:</p> <p>Network->Basic->IPv4 Config->Static IP Address->Primary DNS</p> <p>Phone User Interface:</p> <p>Menu->Advanced (default password: admin) ->Network->WAN Port->IPv4->DHCP->Static DNS (Enabled)->Primary DNS</p>		
network.secondary_dns	IPv4 Address	Blank
<p>Description:</p> <p>Configures the secondary IPv4 DNS server.</p> <p>Example:</p> <p>network.secondary_dns = 202.101.103.54</p> <p>Note: It works only if the value of the parameter "network.static_dns_enable" is set to 1 (On). If you change this parameter, the Skype for Business phone will reboot to make the change take effect.</p> <p>Web User Interface:</p> <p>Network->Basic->IPv4 Config->Static IP Address->Secondary DNS</p> <p>Phone User Interface:</p> <p>Menu->Advanced (default password: admin) ->Network->WAN Port->IPv4->DHCP->Static DNS (Enabled)->Secondary DNS</p>		

To configure static DNS address when DHCP is used via web user interface:

1. Click on **Network->Basic**.
2. In the **IPv4 Config** block, mark the **DHCP** radio box.
3. In the **Static DNS** block, mark the **On** radio box.

- Enter the desired values in the **Primary DNS** and **Secondary DNS** fields.

The screenshot shows the Yealink T46G web interface. The 'Network' tab is selected. Under 'Internet Port', 'Mode(IPv4/IPv6)' is set to 'IPv4'. In the 'IPv4 Config' section, 'DHCP' is selected. Under 'Static DNS', the 'On' radio button is selected. The 'Primary DNS' field contains '202.201.101.55' and the 'Secondary DNS' field contains '202.201.101.54'. A red box highlights the 'Static DNS' section. The 'NOTE' panel on the right contains information about DHCP, Static IP Address, and PPPoE.

- Click **Confirm** to accept the change.

A dialog box pops up to prompt that settings will take effect after a reboot.

- Click **OK** to reboot the Skype for Business phone.

To configure static DNS when DHCP is used via phone user interface:

- Press **Menu->Advanced** (default password: admin) -> **Network->WAN Port->IPv4->DHCP**.
- Press **Left** or **Right**, or the **Switch** soft key to select **Enabled** from the **Static DNS** field.
- Enter the desired values in the **Primary DNS** and **Secondary DNS** fields respectively.
- Press the **Save** soft key to accept the change.

The Skype for Business phone reboots automatically to make settings effective after a period of time.

DHCP Option

DHCP provides a framework for passing information to TCP/IP network devices. Network and other control information are carried in tagged data items that are stored in the options field of the DHCP message. The data items themselves are also called options.

DHCP can be initiated by simply connecting the phone with the network. phones broadcast DISCOVER messages to request the network information carried in DHCP options, and the DHCP server responds with specific values in corresponding options.

The following table lists common DHCP options supported by Skype for Business phones.

Parameter	DHCP Option	Description
Subnet Mask	1	Specify the client's subnet mask.
Time Offset	2	Specify the offset of the client's subnet in seconds from Coordinated Universal Time (UTC).
Router	3	Specify a list of IP addresses for routers on the client's subnet.
Time Server	4	Specify a list of time servers available to the client.
Domain Name Server	6	Specify a list of domain name servers available to the client.
Log Server	7	Specify a list of MIT-LCS UDP servers available to the client.
Host Name	12	Specify the name of the client.
Domain Server	15	Specify the domain name that client should use when resolving hostnames via DNS.
Broadcast Address	28	Specify the broadcast address in use on the client's subnet.
Network Time Protocol Servers	42	Specify a list of NTP servers available to the client by IP address.
Vendor-Specific Information	43 (vendor class ID: CPE-OCPHONE)	Specify virtual local area network (VLAN) ID.
	43 (vendor class ID: MS-UC-Client)	Specify Skype for Business Server pool certificate provisioning service URL.
Vendor Class Identifier	60	Identify the vendor type.
TFTP Server Name	66	Identify a TFTP server when the 'sname' field in the DHCP header has been used for DHCP options.
Boot file Name	67	Identify a boot file when the 'file' field in the DHCP header has been used for DHCP options.
Skype for Business Server	120	Specify a list of Skype for Business Servers available to the client.

For more information on DHCP options, refer to [RFC 2131](#) or [RFC 2132](#).

If you do not have the ability to configure the DHCP options for discovering the provisioning

server on the DHCP server, an alternate method of automatically discovering the provisioning server address is required. Connecting to the secondary DHCP server that responds to DHCP INFORM queries with a requested provisioning server address is one possibility. For more information, refer to [RFC 3925](#). If a single alternate DHCP server responds, this is functionally equivalent to the scenario where the primary DHCP server responds with a valid provisioning server address. If no DHCP servers respond, the INFORM query process will retry and eventually time out.

DHCP Option 66 and Option 43

Yealink Skype for Business phones support obtaining the provisioning server address by detecting DHCP options during startup.

The phone will automatically detect the option 66 for obtaining the provisioning server address. DHCP option 66 is used to identify the TFTP server. DHCP option 43 is a vendor-specific option, which is used to transfer the vendor-specific information.

The administrator can use vendor class identifier, specified by DHCP option 60, to send the Skype for Business phone a customized configuration in option 43. Depending on the vendor class ID it is configured for, the option 43 might have different values. Two vendor class identifiers are used when deploying with the Skype for Business Server: a VLAN ID request (vendor class ID: CPE-OCPHONE) and a certificate provisioning service URL request (vendor class ID: MS-UC-Client). For more information on DHCP option 60, refer to [DHCP Option 60](#) on page 32.

To use DHCP option 66 and option 43, make sure the DHCP Active feature is enabled.

Procedure

DHCP active can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure DHCP active. Parameters: auto_provision.dhcp_option.enable
Local	Web User Interface	Configure DHCP active. Navigate to: <a href="http://<phoneIPAddress>/servlet?p=settings-autop&q=load">http://<phoneIPAddress>/servlet?p=settings-autop&q=load

Details of Configuration Parameters:

Parameters	Permitted Values	Default
auto_provision.dhcp_option.enable	0 or 1	1
<p>Description:</p> <p>Triggers the DHCP Option feature to on or off.</p> <p>0-Off</p> <p>1-On</p> <p>If it is set to 1 (On), the Skype for Business phone will obtain the provisioning server address by detecting DHCP options.</p> <p>Web User Interface:</p> <p>Settings->Auto Provision->DHCP Active</p> <p>Phone User Interface:</p> <p>None</p>		

To configure the DHCP active feature via web user interface:

1. Click on **Settings->Auto Provision**.
2. Mark the **On** radio box in the **DHCP Active** field.

The screenshot displays the Yealink T46G web interface. The top navigation bar includes 'Status', 'Account', 'Network', 'Features', 'Settings', 'Directory', and 'Security'. The left sidebar lists various configuration categories. The 'Auto Provision' section is active, showing a list of settings. The 'DHCP Active' setting is highlighted with a red rectangle, showing the 'On' radio button selected. Other settings include 'PNP Active' (On), 'Custom Option(128~254)' (empty), 'DHCP Option Value' (MS-UC-Client), 'Server URL' (empty), 'User Name' (empty), 'Password' (masked), 'Common AES Key' (masked), 'MAC-Oriented AES Key' (masked), 'Zero Active' (Enabled), 'Wait Time(0~100s)' (5), 'Power On' (On), 'Repeatedly' (On), 'Interval(Minutes)' (1440), 'Weekly' (On), 'Time' (00:00 - 00:00), and 'Day of Week' (all days selected). A 'NOTE' box on the right provides additional information about the Auto Provision feature.

3. Click **Confirm** to accept the change.

DHCP Option 160 and Option 161

Yeastar Skype for Business phones also support obtaining the provisioning server address by detecting DHCP custom option during startup.

If DHCP Option 66 is not available, you can use custom option (160 or 161) with the URL or IP address of the provisioning server. The phone will automatically detect the option 160 or 161 for obtaining the provisioning server address.

To use DHCP option 160 or option 161, make sure the DHCP Active feature is enabled and custom option is configured.

Procedure

DHCP active can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure DHCP active. Parameters: auto_provision.dhcp_option.enable
		Configures the custom DHCP option for requesting provisioning server address. auto_provision.dhcp_option.list_user_options
Local	Web User Interface	Configure the custom option. Navigate to: <a href="http://<phoneIPAddress>/servlet?p=settings-autop&q=load">http://<phoneIPAddress>/servlet?p=settings-autop&q=load

Details of Configuration Parameters:

Parameters	Permitted Values	Default
auto_provision.dhcp_option.enable	0 or 1	1
Description: Triggers the DHCP Option feature to on or off. 0 -Off 1 -On If it is set to 1 (On), the Skype for Business phone will obtain the provisioning server address by detecting DHCP options. Web User Interface: Settings->Auto Provision->DHCP Active Phone User Interface: None		

Parameters	Permitted Values	Default
auto_provision.dhcp_option.list_user_options	Integer from 128 to 254	160,161
<p>It configures the custom DHCP option for requesting provisioning server address. Multiple DHCP options are separated by commas.</p> <p>Note: It works only if the value of the parameter "auto_provision.dhcp_option.enable" is set to 1 (On).</p> <p>Web User Interface:</p> <p>Settings->Auto Provision->Custom Option(128~254)</p> <p>Phone User Interface:</p> <p>None</p>		

To configure the custom option via web user interface:

1. Click on **Settings->Auto Provision**.
2. Mark the **On** radio box in the **DHCP Active** field.
3. Enter the custom option (160 or 161) in the **Custom Option(128~254)** field.

4. Click **Confirm** to accept the change.

Note

The phones also support obtaining the provisioning server address via Skype for Business Server (if configured) during sign-in process. This method for obtaining provisioning server address has higher priority than the DHCP option.

DHCP Option 60

DHCP option 60 is used to identify the vendor class ID. By default, the vendor class ID is MS-UC-Client (case-sensitive).

Procedure

DHCP option 60 can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure DHCP option 60. Parameters: auto_provision.dhcp_option.option60_value
Local	Web User Interface	Configure DHCP option 60. Navigate to: http://<phoneIPAddress>/servlet?p=settings-autop&q=load

Details of Configuration Parameters:

Parameters	Permitted Values	Default
auto_provision.dhcp_option.option60_value	String within 99 characters	MS-UC-Client
Description: Configures the value (vendor class ID) of DHCP option 60. Web User Interface: Settings->Auto Provision->DHCP Option Value Phone User Interface: None		

To configure DHCP option 60 on the Skype for Business phone via web user interface:

1. Click on **Settings->Auto Provision**.

2. Enter the desired host name in the **DHCP Option Value** field.

3. Click **Confirm** to accept the change.

DHCP Option 42 and Option 2

Yealink Skype for Business phones support using the NTP server address offered by DHCP.

DHCP option 42 is used to specify a list of NTP servers available to the client by IP address. NTP servers should be listed in order of preference. DHCP option 2 is used to specify the offset of the client's subnet in seconds from Coordinated Universal Time (UTC).

To update time with the offset time offered by the DHCP server, make sure the DHCP Time feature is enabled at the path **Settings->Time & Date->DHCP Time**. For more information on how to configure DHCP time feature, refer to [NTP Time Server](#) on page 141.

DHCP Option 12 Hostname on the Skype for Business phone

This option specifies the host name of the client. The name may or may not be qualified with the local domain name (based on RFC 2132). See RFC 1035 for character restrictions.

Procedure

DHCP option 12 hostname can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the DHCP option 12 hostname. Parameters:
---------------------------	---------------------	--

		network.dhcp_host_name
Local	Web User Interface	<p>Configure the DHCP option 12 hostname.</p> <p>Navigate to:</p> <p>http://<phoneIPAddress>/servlet?p=features-general&q=load</p>

Details of Configuration Parameters:

Parameters	Permitted Values	Default
network.dhcp_host_name	String within 99 characters	Refer to the following content
<p>Description:</p> <p>Configures the DHCP option 12 hostname on the Skype for Business phone.</p> <p>For T48G Skype for Business phones:</p> <p>The default value is SIP-T48G.</p> <p>For T46G Skype for Business phones:</p> <p>The default value is SIP-T46G.</p> <p>For T42G Skype for Business phones:</p> <p>The default value is SIP-T42G.</p> <p>For T41P Skype for Business phones:</p> <p>The default value is SIP-T41P.</p> <p>For T40P Skype for Business phones:</p> <p>The default value is SIP-T40P</p> <p>Note: If you change this parameter, the Skype for Business phone will reboot to make the change take effect.</p> <p>Web User Interface:</p> <p>Features->General Information->DHCP Hostname</p> <p>Phone User Interface:</p> <p>None</p>		

To configure DHCP option 12 hostname on the Skype for Business phone via web user interface:

1. Click on **Features->General Information**.

- Enter the desired host name in the **DHCP Hostname** field.

The screenshot shows the Yealink T46G web interface. The 'General Information' tab is selected. The 'DHCP Hostname' field is highlighted with a red box and contains the value 'SIP-T46G'. Other settings visible include 'Call Waiting' (Enabled), 'Key As Send' (#), 'Hotline Number', 'Hotline Delay(0~10s)' (4), 'Busy Tone Delay (Seconds)' (0), 'Return code when refuse' (603 (Decline)), 'Diversion/History-Info' (Disabled), 'Auto-Logout Time(1~1000min)' (5), 'Call Number Filter', 'Voice Mail Tone' (Enabled), 'E911 Location Tip' (Enabled), 'Update Checking Time' (24), 'Use DHCP Option 120' (Disabled), 'SFB Cert. Service URL', 'Enable SFB Automation' (Disabled), 'SFB Inactive Time' (5), 'SFB Away Time' (5), 'Web Sign in' (Enabled), 'Remember Password' (Disabled), and 'History Record Contacts Avatar' (Enabled). A 'NOTE' section on the right provides information about 'Call Waiting' and 'Key As Send' features.

- Click **Confirm** to accept the change.
A dialog box pops up to prompt that settings will take effect after a reboot.
- Click **OK** to reboot the Skype for Business phone.

DHCP Option 120

Yealink Skype for Business phones support obtaining Skype for Business Server address from DHCP. DHCP option 120 is used to specify a list of Skype for Business Servers available to the client.

Procedure

DHCP option 120 can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure DHCP option 120. Parameters: sip.option120_get_lynx_server.enable
Local	Web User Interface	Configure DHCP option 120. Navigate to: http://<phoneIPAddress>/servlet?p=features-general&q=load

Details of Configuration Parameters:

Parameters	Permitted Values	Default
sip.option120_get_lynx_server.enable	0 or 1	0
<p>Description:</p> <p>Enables or disables the Skype for Business phones to obtain the Skype for Business Server address from DHCP by detecting DHCP option 120.</p> <p>0-Disabled 1-Enabled</p> <p>Web User Interface:</p> <p>Features->General Information->Use DHCP Option 120</p> <p>Phone User Interface:</p> <p>None</p>		

To configure DHCP option 120 on the Skype for Business phone via web user interface:

1. Click on **Features->General Information**.
2. Select desired value from the pull-down list of **Use DHCP Option 120**.

The screenshot shows the Yealink T46G web interface. The 'Features' tab is selected, and the 'General Information' sub-tab is active. A list of configuration parameters is displayed, including 'Call Waiting', 'Key As Send', 'Hotline Number', 'Hotline Delay', 'Busy Tone Delay', 'Return code when refuse', 'Diversion/History-Info', 'Auto-Logout Time', 'Call Number Filter', 'Voice Mail Tone', 'DHCP Hostname', 'E911 Location Tip', 'Update Checking Time', 'Use DHCP Option 120', 'SFB Cert. Service URL', 'Enable SFB Automation', 'SFB Inactive Time', 'SFB Away Time', 'Web Sign in', 'Remember Password', and 'History Record Contacts Avatar'. The 'Use DHCP Option 120' parameter is highlighted with a red rectangular box, and its value is set to 'Enabled'. To the right of the configuration list, there is a 'NOTE' section with information about 'Call Waiting' and 'Key As Send' features. At the bottom of the page, there are 'Confirm' and 'Cancel' buttons.

3. Click **Confirm** to accept the change.

Configuring Network Parameters Manually

If DHCP is disabled or Skype for Business phones cannot obtain network parameters from the DHCP server, you need to configure them manually. The following parameters should be configured for Skype for Business phones to establish network connectivity:

- IP Address
- Subnet Mask
- Default Gateway
- Primary DNS
- Secondary DNS

Procedure

Network parameters can be configured manually using the configuration files or locally.

Configuration File	<MAC>.cfg	<p>Configure network parameters of the Skype for Business phone manually.</p> <p>Parameters:</p> <p>network.internet_port.type network.ip_address_mode network.internet_port.ip network.internet_port.mask network.internet_port.gateway network.primary_dns network.secondary_dns</p>
Local	Web User Interface	<p>Configure network parameters of the Skype for Business phone manually.</p> <p>Navigate to:</p> <p><a href="http://<phoneIPAddress>/servlet?parameter=network&q=load">http://<phoneIPAddress>/servlet?parameter=network&q=load</p>
	Phone User Interface	<p>Configure network parameters of the Skype for Business phone manually.</p>

Details of Configuration Parameters:

Parameters	Permitted Values	Default
network.internet_port.type	0, 1 or 2	0

Parameters	Permitted Values	Default
<p>Description:</p> <p>Configures the Internet (WAN) port type for IPv4.</p> <p>0-DHCP</p> <p>1-PPPoE (not applicable to T42G/T41P/T40P Skype for Business phones)</p> <p>2-Static IP Address</p> <p>Note: It works only if the value of the parameter "network.ip_address_mode" is set to 0 (IPv4) or 2 (IPv4 & IPv6). If you change this parameter, the Skype for Business phone will reboot to make the change take effect.</p> <p>Web User Interface:</p> <p>Network->Basic->IPv4 Config</p> <p>Phone User Interface:</p> <p>Menu->Advanced (default password: admin)->Network->WAN Port->IPv4</p>		
network.ip_address_mode	0, 1 or 2	0
<p>Description:</p> <p>Configures the IP address mode.</p> <p>0-IPv4</p> <p>1-IPv6</p> <p>2-IPv4 & IPv6</p> <p>Note: If you change this parameter, the Skype for Business phone will reboot to make the change take effect.</p> <p>Web User Interface:</p> <p>Network->Basic->Internet Port->Mode(IPv4/IPv6)</p> <p>Phone User Interface:</p> <p>Menu->Advanced (default password: admin) ->Network->WAN Port->IP Mode</p>		
network.internet_port.ip	IPv4 Address	Blank
<p>Description:</p> <p>Configures the IPv4 address.</p> <p>Example:</p> <p>network.internet_port.ip = 192.168.1.20</p> <p>Note: It works only if the value of the parameter "network.ip_address_mode" is set to 0 (IPv4) or 2 (IPv4 & IPv6), and "network.internet_port.type" is set to 2 (Static IP Address). If you change this parameter, the Skype for Business phone will reboot to make the change take effect.</p> <p>Web User Interface:</p>		

Parameters	Permitted Values	Default
Network->Basic->IPv4 Config->Static IP Address->IP Address Phone User Interface: Menu->Advanced (default password: admin) ->Network->WAN Port->IPv4->Static IP ->IP Address		
network.internet_port.mask	Subnet Mask	Blank
Description: Configures the IPv4 subnet mask. Example: network.internet_port.mask = 255.255.255.0 Note: It works only if the value of the parameter "network.ip_address_mode" is set to 0 (IPv4) or 2 (IPv4 & IPv6), and "network.internet_port.type" is set to 2 (Static IP Address). If you change this parameter, the Skype for Business phone will reboot to make the change take effect. Web User Interface: Network->Basic->IPv4 Config->Static IP Address->Subnet Mask Phone User Interface: Menu->Advanced (default password: admin) ->Network->WAN Port->IPv4->Static IP->Subnet Mask		
network.internet_port.gateway	IPv4 Address	Blank
Description: Configures the IPv4 default gateway. Example: network.internet_port.gateway = 192.168.1.254 Note: It works only if the value of the parameter "network.ip_address_mode" is set to 0 (IPv4) or 2 (IPv4 & IPv6), and "network.internet_port.type" is set to 2 (Static IP Address). If you change this parameter, the Skype for Business phone will reboot to make the change take effect. Web User Interface: Network->Basic->IPv4 Config->Static IP Address->Gateway Phone User Interface: Menu->Advanced (default password: admin) ->Network->WAN Port->IPv4->Static IP->Gateway		
network.primary_dns	IPv4 Address	Blank

Parameters	Permitted Values	Default
<p>Description: Configures the primary IPv4 DNS server.</p> <p>Example: network.primary_dns = 202.101.103.55</p> <p>Note: It works only if the value of the parameter "network.ip_address_mode" is set to 0 (IPv4) or 2 (IPv4 & IPv6), and "network.internet_port.type" is set to 2 (Static IP Address). If you change this parameter, the Skype for Business phone will reboot to make the change take effect.</p> <p>Web User Interface: Network->Basic->IPv4 Config->Static IP Address->Primary DNS</p> <p>Phone User Interface: Menu->Advanced (default password: admin) ->Network->WAN Port->IPv4->Static IP->Primary DNS</p>		
network.secondary_dns	IPv4 Address	Blank
<p>Description: Configures the secondary IPv4 DNS server.</p> <p>Example: network.secondary_dns = 202.101.103.54</p> <p>Note: It works only if the value of the parameter "network.ip_address_mode" is set to 0 (IPv4) or 2 (IPv4 & IPv6), and "network.internet_port.type" is set to 2 (Static IP Address). If you change this parameter, the Skype for Business phone will reboot to make the change take effect.</p> <p>Web User Interface: Network->Basic->IPv4 Config->Static IP Address->Secondary DNS</p> <p>Phone User Interface: Menu->Advanced (default password: admin) ->Network->WAN Port->IPv4->Static IP->Secondary DNS</p>		

To configure the IP address mode via web user interface:

1. Click on **Network->Basic**.

2. Select desired value from the pull-down list of **Mode(IPv4/IPv6)**.

Yealink T46G

Status Account **Network** Features Settings Directory Security

Basic PC Port Advanced

Internet Port

Mode(IPv4/IPv6) IPv4 ?

IPv4 Config

☒ DHCP ?

☐ Static IP Address ?

IP Address

Subnet Mask

Gateway

Static DNS ☐ On ☒ Off

Primary DNS

Secondary DNS

NOTE

DHCP
The network configurations will be acquired from DHCP server.

Static IP Address
Specify the IP address, Subnet Mask, Default Gateway, Primary DNS, Secondary DNS fields manually.

PPPoE
Contact your ISP if it should be used.

You can click here to get more guides.

3. Click **Confirm** to accept the change.
A dialog box pops up to prompt that settings will take effect after a reboot.
4. Click **OK** to reboot the Skype for Business phone.

To configure a static IPv4 address via web user interface:

1. Click on **Network->Basic**.
2. In the **IPv4 Config** block, mark the **Static IP Address** radio box.
3. Enter the desired values in the **IP Address**, **Subnet Mask**, **Gateway**, **Primary DNS** and **Secondary DNS** fields.

Yealink T46G

Status Account **Network** Features Settings Directory Security

Basic PC Port Advanced

Internet Port

Mode(IPv4/IPv6) IPv4 ?

IPv4 Config

☐ DHCP ?

☒ Static IP Address ?

IP Address 192.168.1.10

Subnet Mask 255.255.255.0

Gateway 192.168.1.254

Static DNS ☒ On ☐ Off

Primary DNS 202.101.103.55

Secondary DNS 202.101.103.54 x

NOTE

DHCP
The network configurations will be acquired from DHCP server.

Static IP Address
Specify the IP address, Subnet Mask, Default Gateway, Primary DNS, Secondary DNS fields manually.

PPPoE
Contact your ISP if it should be used.

You can click here to get more guides.



4. Click **Confirm** to accept the change.
A dialog box pops up to prompt that settings will take effect after a reboot.
5. Click **OK** to reboot the Skype for Business phone.

To configure the IP mode via phone user interface:

1. Press **Menu->Advanced** (default password: admin) -> **Network->WAN Port**.
2. Press **Left** or **Right**, or the **Switch** soft key to select **IPv4**, **IPv6** or **IPv4 & IPv6** from the **IP Mode** field.
3. Press the **Save** soft key to accept the change.

The Skype for Business phone reboots automatically to make settings effective after a period of time.

To configure a static IPv4 address via phone user interface:

1. Press **Menu**->**Advanced** (default password: admin) ->**Network**->**WAN Port**->**IPv4**.
2. Press  or , or the **Switch** soft key to select the **Static IP** from the **Type** field.
3. Enter the desired value in the **IP Address**, **Subnet Mask**, **Gateway**, **Primary DNS** and **Secondary DNS** field respectively.
4. Press the **Save** soft key to accept the change.

The Skype for Business phone reboots automatically to make settings effective after a period of time.

PPPoE

PPPoE (Point-to-Point Protocol over Ethernet) is a network protocol used by Internet Service Providers (ISPs) to provide Digital Subscriber Line (DSL) high speed Internet services. PPPoE allows an office or building-full of users to share a common DSL connection to the Internet. PPPoE connection is supported by the Skype for Business phone Internet port. Contact your ISP for the PPPoE user name and password. PPPoE is not applicable to T42G/T41P/T40P Skype for Business phones.

Procedure

PPPoE can be configured using the configuration files or locally.

Configuration File	<MAC>.cfg	Configure PPPoE on the Skype for Business phone. Parameters: network.internet_port.type
	<y0000000000xx>.cfg	Configure the user name and password for PPPoE on the Skype for Business phone. Parameters: network.pppoe.user network.pppoe.password
Local	Web User Interface	Configure PPPoE on the Skype for Business phone. Configure the user name and password for PPPoE on the Skype for Business phone. Navigate to: <a href="http://<phoneIPAddress>/servlet?p">http://<phoneIPAddress>/servlet?p

		=network&q=load
	Phone User Interface	<p>Configure PPPoE on the Skype for Business phone.</p> <p>Configure the user name and password for PPPoE on the Skype for Business phone.</p>

Details of Configuration Parameters:

Parameters	Permitted Values	Default
network.internet_port.type	0, 1 or 2	0
<p>Description:</p> <p>Configures the Internet (WAN) port type for IPv4.</p> <p>0-DHCP</p> <p>1-PPPoE (not applicable to T42G/T41P/T40P Skype for Business phones)</p> <p>2-Static IP Address</p> <p>Note: It works only if the value of the parameter "network.ip_address_mode" is set to 0 (IPv4) or 2 (IPv4 & IPv6). If you change this parameter, the Skype for Business phone will reboot to make the change take effect.</p> <p>Web User Interface:</p> <p>Network->Basic->IPv4 Config</p> <p>Phone User Interface:</p> <p>Menu->Advanced (default password: admin)->Network->WAN Port->IPv4</p>		
network.pppoe.user	String within 32 characters	Blank
<p>Description:</p> <p>Configures the user name for PPPoE connection.</p> <p>Example:</p> <p>network.pppoe.user = Xmyl0592123</p> <p>Note: It works only if the value of the parameter "network.ip_address_mode" is set to 0 (IPv4) or 2 (IPv4 & IPv6), and "network.internet_port.type" is set to 1 (PPPoE). If you change this parameter, the Skype for Business phone will reboot to make the change take effect. It is not applicable to T42G/T41P/T40P Skype for Business phones.</p> <p>Web User Interface:</p> <p>Network->Basic->IPv4 Config->PPPoE->User Name</p> <p>Phone User Interface:</p>		

Parameters	Permitted Values	Default
Menu->Advanced (default password: admin) ->Network->WAN Port->IPv4->PPPoE->PPPoE User		
network.pppoe.password	String within 99 characters	Blank
<p>Description:</p> <p>Configures the password for PPPoE connection.</p> <p>Example:</p> <p>network.pppoe.password = yealink123</p> <p>Note: It works only if the value of the parameter "network.ip_address_mode" is set to 0 (IPv4) or 2 (IPv4 & IPv6), and "network.internet_port.type" is set to 1 (PPPoE). If you change this parameter, the Skype for Business phone will reboot to make the change take effect. It is not applicable to T42G/T41P/T40P Skype for Business phones.</p> <p>Web User Interface:</p> <p>Network->Basic->IPv4 Config->PPPoE->Password</p> <p>Phone User Interface:</p> <p>Menu->Advanced (default password: admin) ->Network->WAN Port->IPv4->PPPoE->PPPoE Password</p>		



To configure PPPoE via web user interface:

1. Click on **Network->Basic**.
2. In the **IPv4 Config** block, mark the **PPPoE** radio box.
3. Enter the user name and password in corresponding fields.

The screenshot shows the Yealink T46G web interface. The top navigation bar includes 'Status', 'Account', 'Network', 'Features', 'Settings', 'Directory', and 'Security'. The 'Network' tab is selected. On the left sidebar, 'Basic' is selected under the 'Network' category. The main content area shows the 'Internet Port' configuration. Under 'IPv4 Config', the 'PPPoE' radio button is selected. The 'User Name' field is filled with 'Xmyl0592123' and the 'Password' field is masked with dots. A red box highlights these two fields. The 'IPv6 Config' section is also visible below, with 'DHCP' selected.

4. Click **Confirm** to accept the change.
A dialog box pops up to prompt that settings will take effect after a reboot.
5. Click **OK** to reboot the Skype for Business phone.

To configure PPPoE via phone user interface:

1. Press **Menu**->**Advanced** (default password: admin)->**Network**->**WAN Port**->**IPv4**.
2. Press  or , or the **Switch** soft key to select the **PPPoE** from the **Type** field.
3. Enter the user name and password in the corresponding fields.
4. Press the **Save** soft key to accept the change.

The Skype for Business phone reboots automatically to make settings effective after a period of time.

Configuring Transmission Methods of the Internet Port and PC Port

Yealink T48G/T46G/T42G/T41P/T40P Skype for Business phones support two Ethernet ports: Internet port and PC port. Three optional methods of transmission configuration for Skype for Business phone Internet or PC Ethernet ports:

- Auto-negotiate
- Half-duplex
- Full-duplex


Auto-negotiate is configured for both Internet and PC ports on the Skype for Business phone by default.

Auto-negotiate

Auto-negotiate means that two connected devices choose common transmission parameters (e.g., speed and duplex mode) to transmit voice or data over Ethernet. This process entails devices first sharing transmission capabilities and then selecting the highest performance transmission mode supported by both. You can configure the Internet port and PC port on the Skype for Business phone to automatically negotiate during the transmission.


Half-duplex

Half-duplex transmission refers to transmitting voice or data in both directions, but in one direction at a time; this means one device can send data on the line, but not receive data simultaneously. You can configure the half-duplex transmission on both Internet port and PC port for the Skype for Business phone to transmit in 10Mbps or 100Mbps.



Full-duplex

Full-duplex transmission refers to transmitting voice or data in both directions at the same time; this means one device can send data on the line while receiving data. You can configure the full-duplex transmission on both Internet port and PC port for the Skype for Business phone to transmit in 10Mbps, 100Mbps or 1000Mbps (1000Mbps is only applicable to T48G/T46G/T42G Skype for Business phones).



Procedure

The transmission methods of Ethernet ports can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the transmission methods of the Internet (WAN) port. Parameters: network.internet_port.speed_duplex
---------------------------	---------------------	--

		network.pc_port.speed_duplex
Local	Web User Interface	<p>Configure the transmission methods of the Internet (WAN) port.</p> <p>Navigate to:</p> <p>http://<phoneIPAddress>/servlet?p=network-adv&q=load</p>


Details of Configuration Parameters:

Parameters	Permitted Values	Default
network.internet_port.speed_duplex	0, 1, 2, 3, 4 or 5	0
<p>Description:</p> <p>Configures the transmission method of the Internet (WAN) port.</p> <p>0-Auto Negotiate</p> <p>1-Full Duplex 10Mbps</p> <p>2-Full Duplex 100Mbps</p> <p>3-Half Duplex 10Mbps</p> <p>4-Half Duplex 100Mbps</p> <p>5-Full Duplex 1000Mbps (only applicable to T48G/T46G/T42G Skype for Business phones)</p> <p>Web User Interface:</p> <p>Network->Advanced->Port Link->WAN Port Link</p> <p>Phone User Interface:</p> <p>None</p>		
network.pc_port.speed_duplex	0, 1, 2, 3, 4 or 5	0
<p>Description:</p> <p>Configures the transmission method of the PC (LAN) port.</p> <p>0-Auto Negotiate</p> <p>1-Full Duplex 10Mbps</p> <p>2-Full Duplex 100Mbps</p> <p>3-Half Duplex 10Mbps</p> <p>4-Half Duplex 100Mbps</p> <p>5-Full Duplex 1000Mbps (only applicable to T48G/T46G/T42G Skype for Business phones)</p> <p>Note: It works only if the value of the parameter "network.pc_port.enable" is set to 1 (Auto Negotiate). For T48G/T46G/T42G Skype for Business phones, you can set the transmission speed to 1000Mbps/Auto Negotiate to transmit in 1000Mbps. Make sure the Skype for Business phone is connected to a switch that supports Gigabit Ethernet. We recommend</p>		

Parameters	Permitted Values	Default
that you do not change this parameter. If you change this parameter, the Skype for Business phone will reboot to make the change take effect.		
Web User Interface:		
Network->Advanced->Port Link->PC Port Link		
Phone User Interface:		
None		

To configure the transmission methods of Ethernet ports via web user interface:

1. Click on **Network->Advanced**.
2. Select the desired value from the pull-down list of **WAN Port Link**.
3. Select the desired value from the pull-down list of **PC Port Link**.



4. Click **Confirm** to accept the change.

Configuring PC Port Mode

The PC port on the back of the Skype for Business phone is used to connect a PC. You can enable or disable the PC (LAN) port on the Skype for Business phones via web user interface or using configuration files.

Procedure

PC port mode can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the PC (LAN) port.
---------------------------	---------------------	------------------------------


		Parameter: network.pc_port.enable
Local	Web User Interface	Configure the PC (LAN) port. Navigate to: http://<phoneIPAddress>/servlet?p =network-pcport&q=load

Details of Configuration Parameters:

Parameters	Permitted Values	Default
network.pc_port.enable	0 or 1	1
<p>Description: Enables or disables the PC (LAN) port.</p> <p>0-Disabled 1-Auto Negotiation</p> <p>Note: If you change this parameter, the Skype for Business phone will reboot to make the change take effect.</p> <p>Web User Interface: Network->PC Port->PC Port Active</p> <p>Phone User Interface: None</p>		

To enable the PC port via web user interface:

1. Click on **Network->PC Port**.
2. Select **Auto Negotiate** from the pull-down list of **PC Port Active**.




3. Click **Confirm** to accept the change.
A dialog box pops up to prompt that settings will take effect after a reboot.
4. Click **OK** to reboot the Skype for Business phone.

To disable the PC port via web user interface:

1. Click on **Network->PC Port**.

2. Select **Disabled** from the pull-down list of **PC Port Active**.




3. Click **Confirm** to accept the change.
A dialog box pops up to prompt that settings will take effect after a reboot.
4. Click **OK** to reboot the Yealink for Business phone.

Web Server Type


Web server type determines access protocol of the phone's web user interface. Phones support both HTTP and HTTPS protocols for accessing the web user interface. This can be disabled when it is not needed or when it poses a security threat. For more information on accessing the web user interface, refer to [Web User Interface](#) on page 93.

HTTP is an application protocol that runs on top of the TCP/IP suite of protocols. HTTPS is a web protocol that encrypts and decrypts user page requests as well as pages returned by the web server. Both HTTP and HTTPS port numbers are configurable.

When you enable user to access web user interface of the phone using the HTTP/HTTPS protocol (take HTTPS protocol for example):



When you disable user to access web user interface of the phone using the HTTP/HTTPS protocol (take HTTPS protocol for example):



Procedure

Web server type can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the web access type, HTTP port and HTTPS port. Parameters: wui.http_enable network.port.http wui.https_enable network.port.https
Local	Web User Interface	Configure the web access type, HTTP port and HTTPS port. Navigate to: http://<phoneIPAddress>/servlet?p=network-adv&q=load
	Phone User Interface	Configure the web access type, HTTP port and HTTPS port.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
wui.http_enable	0 or 1	1

Parameters	Permitted Values	Default
<p>Description:</p> <p>Enables or disables the user to access web user interface of the Skype for Business phone using the HTTP protocol.</p> <p>0-Disabled 1-Enabled</p> <p>Note: If you change this parameter, the Skype for Business phone will reboot to make the change take effect.</p> <p>Web User Interface: Network->Advanced->Web Server->HTTP</p> <p>Phone User Interface: Menu->Advanced (default password: admin) ->Network->Webserver Type->HTTP Status</p>		
network.port.http	Integer from 1 to 65535	80
<p>Description:</p> <p>Configures the HTTP port for the user to access web user interface of the Skype for Business phone using the HTTP protocol.</p> <p>Note: If you change this parameter, the Skype for Business phone will reboot to make the change take effect.</p> <p>Web User Interface: Network->Advanced->Web Server->HTTP Port(1~65535)</p> <p>Phone User Interface: Menu->Advanced (default password: admin) ->Network->Webserver Type->HTTP Port</p>		
wui.https_enable	0 or 1	1
<p>Description:</p> <p>Enables or disables the user to access web user interface of the Skype for Business phone using the HTTPS protocol.</p> <p>0-Disabled 1-Enabled</p> <p>Note: If you change this parameter, the Skype for Business phone will reboot to make the change take effect.</p> <p>Web User Interface: Network->Advanced->Web Server->HTTPS</p> <p>Phone User Interface: Menu->Advanced (default password: admin) ->Network->Webserver Type->HTTPS Status</p>		

Parameters	Permitted Values	Default
network.port.https	Integer from 1 to 65535	443
<p>Description:</p> <p>Configures the HTTPS port for the user to access web user interface of the Skype for Business phone using the HTTPS protocol.</p> <p>Note: If you change this parameter, the Skype for Business phone will reboot to make the change take effect.</p> <p>Web User Interface:</p> <p>Network->Advanced->Web Server->HTTPS Port(1~65535)</p> <p>Phone User Interface:</p> <p>Menu->Advanced (default password: admin) ->Network->Webserver Type->HTTPS Port</p>		

To configure web server type via web user interface:

1. Click on **Network->Advanced**.
2. Select the desired value from the pull-down list of **HTTP**.
3. Enter the desired HTTP port number in the **HTTP Port(1~65535)** field.
The default HTTP port number is 80.
4. Select the desired value from the pull-down list of **HTTPS**.
5. Enter the desired HTTPS port number in the **HTTPS Port(1~65535)** field.

The default HTTPS port number is 443.

The screenshot shows the Yealink T466 web interface. The 'Network' tab is selected. On the left, there are tabs for 'Basic', 'PC Port', and 'Advanced'. The 'Web Server' section is highlighted with a red box. It contains the following settings:

- HTTP**: Enabled (dropdown)
- HTTP Port (1~65535)**: 80 (text input)
- HTTPS**: Enabled (dropdown)
- HTTPS Port (1~65535)**: 443 (text input)

Other sections visible include:

- LLDP**: Active (dropdown), Packet Interval (1~3600s): 60 (text input)
- CDP**: Active (dropdown), Packet Interval (1~3600s): 60 (text input)
- 802.1x**: 802.1x Mode: Disabled (dropdown), Identity: (text input), MD5 Password: (password field), CA Certificates: (upload button), Device Certificates: (upload button)
- Span to PC**: Span to PC Port: Disabled (dropdown)

At the bottom, there are 'Confirm' and 'Cancel' buttons. On the right, there is a 'NOTE' section with information about VLAN, QoS, and Local RTP Port.

- Click **Confirm** to accept the change.

A dialog box pops up to prompt that settings will take effect after a reboot.

- Click **OK** to reboot the Skype for Business phone.

To configure web server type via phone user interface:

- Press **Menu**->**Advanced** (default password: admin)->**Network**->**Webserver Type**.
- Press **Left** or **Right**, or the **Switch** soft key to select the desired value from the **HTTP Status** field.
- Enter the desired HTTP port number in the **HTTP Port** field.
- Press **Left** or **Right**, or the **Switch** soft key to select the desired value from the **HTTP Status** field.
- Enter the desired HTTPS port number in the **HTTPS Port** field.
- Press the **Save** soft key to accept the change.

The Skype for Business phone reboots automatically to make settings effective after a period of time.

VLAN

VLAN (Virtual Local Area Network) is used to logically divide a physical network into several broadcast domains. VLAN membership can be configured through software instead of physically relocating devices or connections. Grouping devices with a common set of

requirements regardless of their physical location can greatly simplify network design. VLANs can address issues such as scalability, security and network management.

The purpose of VLAN configurations on the Skype for Business phone is to insert tag with VLAN information to the packets generated by the Skype for Business phone. When VLAN is properly configured for the ports (Internet port and PC port) on the Skype for Business phone, the Skype for Business phone will tag all packets from these ports with the VLAN ID. The switch receives and forwards the tagged packets to the corresponding VLAN according to the VLAN ID in the tag as described in IEEE Std 802.3.

VLAN on Skype for Business phones allows simultaneous access for a regular PC. This feature allows a PC to be daisy chained to a Skype for Business phone and the connection for both PC and Skype for Business phone to be trunked through the same physical Ethernet cable.

In addition to manual configuration, the Skype for Business phone also supports automatic discovery of VLAN via LLDP, CDP or DHCP. The assignment takes effect in this order: assignment via LLDP/CDP, manual configuration, then assignment via DHCP.

For more information on VLAN, refer to [VLAN Feature on Yealink Skype for Business phones](#).

LLDP

LLDP (Linker Layer Discovery Protocol) is a vendor-neutral Link Layer protocol, which allows the Skype for Business phone to receive and/or transmit device-related information from/to directly connected devices on the network that are also using the protocol, and store the information about other devices. LLDP transmits information as packets called LLDP Data Units (LLDPDUs). An LLDPDU consists of a set of Type-Length-Value (TLV) elements, each of which contains a particular type of information about the device or port transmitting it.

LLDP-MED (Media Endpoint Discovery)

LLDP-MED is published by the Telecommunications Industry Association (TIA). It is an extension to LLDP that operates between endpoint devices and network connectivity devices. LLDP-MED provides the following capabilities for the endpoint:

- Capabilities Discovery -- allows LLDP-MED endpoint to determine the capabilities that the connected switch supports and has enabled.
- Network Policy -- provides voice VLAN configuration to notify the Skype for Business phone which VLAN to use and QoS-related configuration for voice data. It provides a “plug and play” network environment.
- Power Management -- provides information related to how the Skype for Business phone is powered, power priority, and how much power the endpoint needs.
- Inventory Management -- provides a means to effectively manage the Skype for Business phone and its attributes, such as model number, serial number and software revision.

TLVs supported by the Skype for Business phone are summarized in the following table:

TLV Type	TLV Name	Description
Mandatory TLVs	Chassis ID	The network address of the Skype for Business phone.
	Port ID	The MAC address of the Skype for Business phone.
	Time To Live	Seconds until data unit expires. The default value is 180s.
	End of LLDPDU	Marks end of LLDPDU.
Optional TLVs	System Name	Name assigned to the Skype for Business phone. The default value is "SIP-T46G".
	System Description	Description of the Skype for Business phone. Description includes firmware version of the Skype for Business phone.
	Capabilities	The supported and enabled phone capabilities. The Telephone capability is supported and enabled by default.
	Port Description	Description of port that sends data unit. The default value is "WAN PORT".
IEEE Std 802.3 Organizationally Specific TLV	MAC/PHY Configuration/Status	Duplex mode and network speed settings of the Skype for Business phone. The Auto Negotiation is supported and enabled by default. The advertised capabilities of PMD. Auto-Negotiation is: 100BASE-TX (full duplex mode) 100BASE-TX (half duplex mode) 10BASE-T (full duplex mode) 10BASE-T (half duplex mode)
TIA Organizationally Specific TLVs	Media Capabilities	The MED device type of the Skype for Business phone and the supported LLDP-MED TLV type can be encapsulated in LLDPDU. The supported LLDP-MED TLV types are: LLDP-MED Capabilities, Network Policy,

TLV Type	TLV Name	Description
		Extended Power via MDI-PD, Inventory.
	Network Policy	Port VLAN ID, application type, L2 priority and DSCP value.
	Extended Power-via-MDI	Power type, source, priority and value.
	Inventory - Hardware Revision	Hardware revision of the Skype for Business phone.
	Inventory - Firmware Revision	Firmware revision of the Skype for Business phone.
	Inventory - Software Revision	Software revision of the Skype for Business phone.
	Inventory - Serial Number	Serial number of the Skype for Business phone.
	Inventory - Manufacturer Name	Manufacturer name of the Skype for Business phone. The default value is "IP_Phone".
	Inventory - Model Name	Model name of the Skype for Business phone. The default value is "T46".
	Asset ID	Assertion identifier of the Skype for Business phone.

Procedure

LLDP can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure LLDP. Parameters: network.lldp.enable network.lldp.packet_interval
Local	Web User Interface	Configure LLDP. Navigate to: http://<phoneIPAddress>/servlet?p=network-adv&q=load
	Phone User Interface	Configure LLDP feature.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
network.lldp.enable	0 or 1	1
<p>Description:</p> <p>Enables or disables the LLDP (Linker Layer Discovery Protocol) feature on the Skype for Business phone.</p> <p>0-Disabled 1-Enabled</p> <p>Note: If you change this parameter, the Skype for Business phone will reboot to make the change take effect.</p> <p>Web User Interface:</p> <p>Network->Advanced->LLDP->Active</p> <p>Phone User Interface:</p> <p>Menu->Advanced (default password: admin) ->Network->LLDP->LLDP Status</p>		
network.lldp.packet_interval	Integer from 1 to 3600	60
<p>Description:</p> <p>Configures the interval (in seconds) for the Skype for Business phone to send the LLDP (Linker Layer Discovery Protocol) request.</p> <p>Note: It works only if the value of the parameter "network.lldp.enable" is set to 1 (Enabled). If you change this parameter, the Skype for Business phone will reboot to make the change take effect.</p> <p>Web User Interface:</p> <p>Network->Advanced->LLDP->Packet Interval (1~3600s)</p> <p>Phone User Interface:</p> <p>Menu->Advanced (default password: admin) ->Network->LLDP->Packet Interval</p>		

To configure LLDP via web user interface:

1. Click on **Network->Advanced**.
2. In the **LLDP** block, select the desired value from the pull-down list of **Active**.

- Enter the desired time interval in the **Packet Interval (1~3600s)** field.

The screenshot shows the Yealink T46G web interface. The 'Network' tab is selected. Under the 'LLDP' section, the 'Active' status is set to 'Enabled' and the 'Packet Interval (1~3600s)' is set to '60'. Other sections visible include CDP, VLAN, and Port Link.

- Click **Confirm** to accept the change.
A dialog box pops up to prompt that settings will take effect after a reboot.
- Click **OK** to reboot the Skype for Business phone.

To configure LLDP feature via phone user interface:

- Press **Menu->Advanced** (default password: admin) -> **Network->LLDP->LLDP Status**.
- Press or , or the **Switch** soft key to select the desired value from the **LLDP Status** field.
- Enter the priority value (1-3600s) in the **Packet Interval** field.
- Press the **Save** soft key to accept the change.

The Skype for Business phone reboots automatically to make settings effective after a period of time.

CDP

CDP (Cisco Discovery Protocol) allows Skype for Business phones to receive and/or transmit device-related information from/to directly connected devices on the network that are also using the protocol, and store the information about other devices.

When CDP feature is enabled on Skype for Business phones, the Skype for Business phones periodically advertise their own information to the directly connected CDP-enabled switch. The Skype for Business phones can also receive CDP packets from the connected switch. When the VLAN configurations on the Skype for Business phones are different from the ones sent by the

switch, the Skype for Business phones perform an update and reboot. This allows the Skype for Business phones to be plugged into any switch, obtain their VLAN IDs, and then start communications with the call control.

Procedure

CDP can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure CDP. Parameters: network.cdp.enable network.cdp.packet_interval
Local	Web User Interface	Configure CDP. Navigate to: http://<phoneIPAddress>/servlet?p=network-adv&q=load
	Phone User Interface	Configure CDP feature.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
network.cdp.enable	0 or 1	1
Description: Enables or disables the CDP (Cisco Discovery Protocol) feature on the Skype for Business phone. 0 -Disabled 1 -Enabled Note: If it is set to 1, the Skype for Business phone will attempt to determine its VLAN ID through CDP. If you change this parameter, the Skype for Business phone will reboot to make the change take effect. Web User Interface: Network->Advanced->CDP->Active Phone User Interface: Menu->Advanced (default password: admin) ->Network->CDP->CDP Status		
network.cdp.packet_interval	Integer from 1 to 3600	60
Description: Configures the interval (in seconds) for the Skype for Business phone to send the CDP		

Parameters	Permitted Values	Default
<p>(Cisco Discovery Protocol) request.</p> <p>Note: It works only if the value of the parameter "network.cdp.enable" is set to 1 (Enabled). If you change this parameter, the Skype for Business phone will reboot to make the change take effect.</p> <p>Web User Interface:</p> <p>Network->Advanced->CDP->Packet Interval (1~3600s)</p> <p>Phone User Interface:</p> <p>Menu->Advanced (default password: admin) ->Network->CDP->Packet Interval</p>		

To configure CDP via web user interface:

1. Click on **Network->Advanced**.
2. In the **CDP** block, select the desired value from the pull-down list of **Active**.
3. Enter the desired time interval in the **Packet Interval (1~3600s)** field.

The screenshot shows the Yealink T46G web interface. The 'Network' tab is selected. Under the 'Advanced' sub-tab, the 'CDP' section is highlighted with a red box. It shows 'Active' selected for the status and '60' for the Packet Interval (1~3600s). Other sections visible include LLDP, VLAN, Port Link, and Voice QoS. A 'NOTE' sidebar on the right provides information about VLAN, QoS, and Local RTP Port.

4. Click **Confirm** to accept the change.
A dialog box pops up to prompt that settings will take effect after a reboot.
5. Click **OK** to reboot the Skype for Business phone.

To configure CDP feature via phone user interface:

1. Press **Menu->Advanced** (default password: admin) -> **Network->CDP->CDP Status**.
2. Press **◀** or **▶**, or the **Switch** soft key to select the desired value from the **CDP Status** field.

3. Enter the priority value (1-3600s) in the **Packet Interval** field.
4. Press the **Save** soft key to accept the change.

The Skype for Business phone reboots automatically to make settings effective after a period of time.

Manual Configuration for VLAN

VLAN is disabled on Skype for Business phones by default. You can configure VLAN for the Internet port and PC port manually. Before configuring VLAN on the Skype for Business phone, you need to obtain the VLAN ID from your network administrator.

Procedure

VLAN can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure VLAN for the Internet port and PC port manually. Parameters: network.vlan.internet_port_enable network.vlan.internet_port_vid network.vlan.internet_port_priority network.vlan.pc_port_enable network.vlan.pc_port_vid network.vlan.pc_port_priority
Local	Web User Interface	Configure VLAN for the Internet port and PC port manually. Navigate to: <a href="http://<phoneIPAddress>/servlet?p=network-adv&q=load">http://<phoneIPAddress>/servlet?p=network-adv&q=load
	Phone User Interface	Configure VLAN for the Internet port and PC port manually.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
network.vlan.internet_port_enable	0 or 1	0
Description: Enables or disables VLAN for the Internet (WAN) port. 0 -Disabled		

Parameters	Permitted Values	Default
1-Enabled Note: If you change this parameter, the Skype for Business phone will reboot to make the change take effect. Web User Interface: Network->Advanced->VLAN->WAN Port->Active Phone User Interface: Menu->Advanced (default password: admin) ->Network->VLAN->WAN Port->VLAN Status		
network.vlan.internet_port_vid	Integer from 1 to 4094	1
Description: Configures VLAN ID for the Internet (WAN) port. Note: If you change this parameter, the Skype for Business phone will reboot to make the change take effect. Web User Interface: Network->Advanced->VLAN->WAN Port->VID (1-4094) Phone User Interface: Menu->Advanced (default password: admin)->Network->VLAN->WAN Port->VID Number		
network.vlan.internet_port_priority	Integer from 0 to 7	0
Description: Configures VLAN priority for the Internet (WAN) port. 7 is the highest priority, 0 is the lowest priority. Note: If you change this parameter, the Skype for Business phone will reboot to make the change take effect. Web User Interface: Network->Advanced->VLAN->WAN Port->Priority Phone User Interface: Menu->Advanced (default password: admin) ->Network->VLAN->WAN Port->Priority		
network.vlan.pc_port_enable	0 or 1	0
Description: Enables or disables VLAN for the PC (LAN) port. 0-Disabled		

Parameters	Permitted Values	Default
1-Enabled Note: If you change this parameter, the Skype for Business phone will reboot to make the change take effect. Web User Interface: Network->Advanced->VLAN->PC Port->Active Phone User Interface: Menu->Advanced (default password: admin) ->Network->VLAN->PC Port->VLAN Status		
network.vlan.pc_port_vid	Integer from 1 to 4094	1
Description: Configures VLAN ID for the PC (LAN) port. Note: If you change this parameter, the Skype for Business phone will reboot to make the change take effect. Web User Interface: Network->Advanced->VLAN->PC Port->VID (1-4094) Phone User Interface: Menu->Advanced (default password: admin) ->Network->VLAN->PC Port->VID Number		
network.vlan.pc_port_priority	Integer from 0 to 7	0
Description: Configures VLAN priority for the PC (LAN) port. 7 is the highest priority, 0 is the lowest priority. Note: If you change this parameter, the Skype for Business phone will reboot to make the change take effect. Web User Interface: Network->Advanced->VLAN->PC Port->Priority Phone User Interface: Menu->Advanced (default password: admin) ->Network->VLAN->PC Port->Priority		

To configure VLAN for Internet port via web user interface:

1. Click on **Network->Advanced**.
2. In the **VLAN** block, select the desired value from the pull-down list of **WAN Port Active**.
3. Enter the VLAN ID in the **VID (1-4094)** field.

4. Select the desired value (0-7) from the pull-down list of **Priority**.

The screenshot shows the Yealink T46G web interface with the 'Network' tab selected. The 'VLAN' section is highlighted with a red box. The 'WAN Port' configuration is as follows:

Section	Parameter	Value
VLAN	Active	Enabled
	VID (1-4094)	1
	Priority	0
PC Port	Active	Disabled
	VID (1-4094)	1
	Priority	0
DHCP VLAN	Active	Enabled
	Option (1-255)	132
Port Link	WAN Port Link	Auto Negotiate
	PC Port Link	Auto Negotiate
Voice QoS	Voice QoS (0~63)	46
	SIP QoS (0~63)	26

NOTE: A VLAN is a logical local area network (or LAN) that extends beyond a single traditional LAN to a group of LAN segments, given specific configurations.

QoS: When the network capacity is insufficient, QoS could provide priority to users by setting the value.

Local RTP Port: Define the port for voice transmission.

You can click here to get more guides.

5. Click **Confirm** to accept the change.
A dialog box pops up to prompt that the settings will take effect after a reboot.
6. Click **OK** to reboot the Skype for Business phone.

To configure VLAN for PC port via web user interface:

1. Click on **Network->Advanced**.
2. In the **VLAN** block, select the desired value from the pull-down list of **PC Port Active**.
3. Enter the VLAN ID in the **VID (1-4094)** field.

4. Select the desired value (0-7) from the pull-down list of **Priority**.

The screenshot shows the Yealink T46G web interface with the 'Network' tab selected. The 'PC Port' settings are highlighted with a red box. The settings are as follows:

Section	Parameter	Value
LLDP	Active	Enabled
	Packet Interval (1~3600s)	60
CDP	Active	Enabled
	Packet Interval (1~3600s)	60
VLAN	WAN Port	Disabled
	VID (1-4094)	1
	Priority	0
PC Port	Active	Enabled
	VID (1-4094)	1
	Priority	0
DHCP VLAN	Active	Enabled
	Option (1-255)	132
Port Link	WAN Port Link	Auto Negotiate
	PC Port Link	Auto Negotiate
Voice QoS	Voice QoS (0~63)	46
	SIP QoS (0~63)	26

NOTE: A VLAN is a logical local area network (or LAN) that extends beyond a single traditional LAN to a group of LAN segments, given specific configurations. QoS: When the network capacity is insufficient, QoS could provide priority to users by setting the value. Local RTP Port: Define the port for voice transmission. You can click here to get more guides.

5. Click **Confirm** to accept the change.
A dialog box pops up to prompt that the settings will take effect after a reboot.
6. Click **OK** to reboot the Skype for Business phone.

To configure VLAN for Internet port (or PC port) via phone user interface:

1. Press **Menu**->**Advanced** (default password: admin) ->**Network**->**VLAN**->**WAN Port** (or **PC Port**).
2. Press **Left** or **Right**, or the **Switch** soft key to select the desired value from the **VLAN Status** field.
3. Enter the VLAN ID (1-4094) in the **VID Number** field.
4. Enter the priority value (0-7) in the **Priority** field.
5. Press the **Save** soft key to accept the change.

The Skype for Business phone reboots automatically to make settings effective after a period of time.

DHCP VLAN

Skype for Business phones support VLAN discovery via DHCP. When the VLAN Discovery method is set to DHCP, the Skype for Business phone will examine DHCP option for a valid VLAN ID. The predefined option 132 is used to supply the VLAN ID by default. You can customize the DHCP option used to request the VLAN ID.

Procedure

DHCP VLAN can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure DHCP VLAN discovery feature. Parameters: network.vlan.dhcp_enable network.vlan.dhcp_option
Local	Web User Interface	Configure DHCP VLAN discovery feature. Navigate to: http://<phoneIPAddress>/servlet?p=network-adv&q=load
	Phone User Interface	Configure DHCP VLAN discovery feature.

Details of Configuration Parameters:


Parameters	Permitted Values	Default
network.vlan.dhcp_enable	0 or 1	1
Description: Enables or disables DHCP VLAN discovery feature on the Skype for Business phone. 0 -Disabled 1 -Enabled Note: If you change this parameter, the Skype for Business phone will reboot to make the change take effect. Web User Interface: Network->Advanced->VLAN->DHCP VLAN->Active Phone User Interface: Menu->Advanced (default password: admin)->Network->VLAN->DHCP VLAN->DHCP VLAN		
network.vlan.dhcp_option	Integer from 1 to 255	132
Description: Configures the DHCP option from which the Skype for Business phone will obtain the VLAN settings. You can configure at most five DHCP options and separate them by commas. Note: If you change this parameter, the Skype for Business phone will reboot to make the		

Parameters	Permitted Values	Default
<p>change take effect.</p> <p>Web User Interface:</p> <p>Network->Advanced->VLAN->DHCP VLAN->Option (1-255)</p> <p>Phone User Interface:</p> <p>Menu->Advanced (default password: admin)->Network->VLAN->DHCP VLAN->Option</p>		

To configure DHCP VLAN discovery via web user interface:

1. Click on **Network->Advanced**.
2. In the **VLAN** block, select the desired value from the pull-down list of **DHCP VLAN Active**.
3. Enter the desired option in the **Option (1-255)** field.

The default option is 132.



4. Click **Confirm** to accept the change.
A dialog box pops up to prompt that settings will take effect after a reboot.
5. Click **OK** to reboot the Skype for Business phone.

To configure DHCP VLAN discovery via phone user interface:

1. Press **Menu->Advanced** (default password: admin)->**Network->VLAN->DHCP VLAN**.
2. Press **Left** or **Right** arrow, or the **Switch** soft key to select the desired value from the **DHCP VLAN** field.
3. Enter the desired option in the **Option** field.
4. Press the **Save** soft key to accept the change.

The Skype for Business phone reboots automatically to make settings effective after a period of time.

IPv6 Support

Because Internet Protocol version 4 (IPv4) uses a 32-bit address, it cannot meet the increased demands for unique IP addresses for all devices that connect to the Internet. Therefore, Internet Protocol version 6 (IPv6) is the next generation network layer protocol, which designed as a replacement for the current IPv4 protocol.

IPv6 is developed by the Internet Engineering Task Force (IETF) to deal with the long-anticipated problem of IPv4 address exhaustion. Yealink Skype for Business phone supports IPv4 addressing mode, IPv6 addressing mode, as well as an IPv4&IPv6 dual stack addressing mode. IPv4 uses a 32-bit address, consisting of four groups of three decimal digits separated by dots; for example, 192.168.1.100. IPv6 uses a 128-bit address, consisting of eight groups of four hexadecimal digits separated by colons; for example, 2026:1234:1:1:215:65ff:fe1f:caa.

VoIP network based on IPv6 can provide end-to-end security capabilities, enhanced Quality of Service (QoS), a set of service requirements to deliver performance guarantee while transporting traffic over the network.

If you configure the network settings on the Skype for Business phone for an IPv6 network, you can set up an IP address for the Skype for Business phone either by using SLAAC (ICMPv6), DHCPv6 or by manually entering an IP address. Ensure that your network environment supports IPv6. Contact your ISP for more information.

IPv6 Address Assignment Method

Supported IPv6 address assignment methods:

- **Manual Assignment:** An IPv6 address and other configuration parameters (e.g., DNS server) for the Skype for Business phone can be statically configured by an administrator.
- **Stateless Address Autoconfiguration (SLAAC)/ ICMPv6:** SLAAC is one of the most convenient methods to assign IP addresses to IPv6 nodes. SLAAC requires no manual configuration of the Skype for Business phone, minimal (if any) configuration of routers, and no additional servers. To use IPv6 SLAAC, the Skype for Business phone must be connected to a network with at least one IPv6 router connected. This router is configured by the network administrator and sends out Router Advertisement announcements onto the link. These announcements can allow the on-link connected Skype for Business phone to configure itself with IPv6 address, as specified in RFC 4862.
- **Stateful DHCPv6:** The Dynamic Host Configuration Protocol for IPv6 (DHCPv6) has been standardized by the IETF through RFC 3315. DHCPv6 enables DHCP servers to pass configuration parameters such as IPv6 network addresses to IPv6 nodes. It offers the capability of automatic allocation of reusable network addresses and additional configuration flexibility. This protocol is a stateful counterpart to "IPv6 Stateless Address Autoconfiguration" ([RFC 2462](#)), and can be used separately or concurrently with the latter to obtain configuration parameters.

How the Skype for Business phone obtains the IPv6 address and network settings?

The following table lists where the Skype for Business phone obtains the IPv6 address and other network settings:

DHCPv6	SLAAC (ICMPv6)	How the Skype for Business phone obtains the IPv6 address and network settings?
Disabled	Disabled	You have to manually configure the static IPv6 address and other network settings.
Disabled	Enabled	The Skype for Business phone can obtain the IPv6 address via SLAAC, but the other network settings must be configured manually.
Enabled	Disabled	The Skype for Business phone can obtain the IPv6 address and the other network settings via DHCPv6.
Enabled	Enabled	The Skype for Business phone can obtain the IPv6 address via SLAAC and obtain other network settings via DHCPv6.

Procedure

IPv6 can be configured using the configuration files or locally.

Configuration File	<MAC>.cfg	Configure the IPv6 address assignment method. Parameters: network.ip_address_mode network.ipv6_internet_port.type network.ipv6_internet_port.ip network.ipv6_prefix network.ipv6_internet_port.gateway network.ipv6_icmp_v6.enable
		Configure the IPv6 static DNS address. Parameters: network.ipv6_primary_dns network.ipv6_secondary_dns
	<y0000000000xx>.cfg	Configure the IPv6 static DNS. Parameter: network.ipv6_static_dns_enable
Local	Web User Interface	Configure the IPv6 address assignment method. Configure the IPv6 static DNS.

		Navigate to: <a href="http://<phoneIPAddress>/servlet?p=network&q=load">http://<phoneIPAddress>/servlet?p=network&q=load
	Phone User Interface	Configure the IPv6 address assignment method. Configure the IPv6 static DNS. Configure the IPv6 static DNS address.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
network.ip_address_mode	0, 1 or 2	0
Description: Configures the IP address mode. 0 -IPv4 1 -IPv6 2 -IPv4 & IPv6 Note: If you change this parameter, the Skype for Business phone will reboot to make the change take effect. Web User Interface: Network->Basic->Internet Port->Mode (IPv4/IPv6) Phone User Interface: Menu->Advanced (default password: admin) ->Network->WAN Port->IP Mode		
network.ipv6_internet_port.type	0 or 1	0
Description: Configures the Internet (WAN) port type for IPv6. 0 -DHCP 1 -Static IP Address Note: It works only if the value of the parameter "network.ip_address_mode" is set to 1 (IPv6) or 2 (IPv4 & IPv6). If you change this parameter, the Skype for Business phone will reboot to make the change take effect. Web User Interface: Network->Basic->IPv6 Config Phone User Interface: Menu->Advanced (default password: admin) ->Network->WAN Port->IPv6		

Parameters	Permitted Values	Default
network.ipv6_static_dns_enable	0 or 1	0
<p>Triggers the static IPv6 DNS feature to on or off.</p> <p>0-Off 1-On</p> <p>If it is set to 0 (Off), the Skype for Business phone will use the IPv6 DNS obtained from DHCP.</p> <p>If it is set to 1 (On), the Skype for Business phone will use manually configured static IPv6 DNS.</p> <p>Note: It works only if the value of the parameter "network.ipv6_internet_port.type" is set to 0 (DHCP). If you change this parameter, the Skype for Business phone will reboot to make the change take effect.</p> <p>Web User Interface: Network->Basic->IPv6 Config->IPv6 Static DNS</p> <p>Phone User Interface: Menu->Advanced (default: admin) ->Network->WAN Port->IPv6->DHCP->Static DNS</p>		
network.ipv6_internet_port.ip	IPv6 address	Blank
<p>Description: Configures the IPv6 address.</p> <p>Example: network.ipv6_internet_port.ip = 2026:1234:1:1:215:65ff:fe1f:caa</p> <p>Note: It works only if the value of the parameter "network.ip_address_mode" is set to 1 (IPv6) or 2 (IPv4 & IPv6), and "network.ipv6_internet_port.type" is set to 1 (Static IP Address). If you change this parameter, the Skype for Business phone will reboot to make the change take effect.</p> <p>Web User Interface: Network->Basic->IPv6 Config->Static IP Address->IP Address</p> <p>Phone User Interface: Menu->Advanced (default password: admin)->Network->WAN Port->IPv6->Static IP->IP Address</p>		
network.ipv6_prefix	Integer from 0 to 128	64
<p>Description:</p>		

Parameters	Permitted Values	Default
<p>Configures the IPv6 prefix.</p> <p>Note: It works only if the value of the parameter "network.ip_address_mode" is set to 1 (IPv6) or 2 (IPv4 & IPv6), and "network.ipv6_internet_port.type" is set to 1 (Static IP Address). If you change this parameter, the Skype for Business phone will reboot to make the change take effect.</p> <p>Web User Interface: Network->Basic->IPv6 Config->Static IP Address->IPv6 Prefix(0~128)</p> <p>Phone User Interface: Menu->Advanced (default password: admin) ->Network->WAN Port->IPv6->Static IP->IPv6 IP Prefix</p>		
network.ipv6_internet_port.gateway	IPv6 address	Blank
<p>Description: Configures the IPv6 default gateway.</p> <p>Example: network.ipv6_internet_port.gateway = 3036:1:1:c3c7:c11c:5447:23a6:255</p> <p>Note: It works only if the value of the parameter "network.ip_address_mode" is set to 1 (IPv6) or 2 (IPv4 & IPv6), and "network.ipv6_internet_port.type" is set to 1 (Static IP Address). If you change this parameter, the Skype for Business phone will reboot to make the change take effect.</p> <p>Web User Interface: Network->Basic->IPv6 Config->Static IP Address->Gateway</p> <p>Phone User Interface: Menu->Advanced (default password: admin) ->Network->WAN Port->IPv6->Static IP->Gateway</p>		
network.ipv6_primary_dns	IPv6 address	Blank
<p>Description: Configures the primary IPv6 DNS server.</p> <p>Example: network.ipv6_primary_dns = 3036:1:1:c3c7: c11c:5447:23a6:256</p> <p>Note: It works only if the value of the parameter "network.ip_address_mode" is set to 1 (IPv6) or 2 (IPv4 & IPv6). In DHCP environment, you also need to make sure the value of the parameter "network.ipv6_static_dns_enable" is set to 1 (On). If you change this parameter, the Skype for Business phone will reboot to make the change take effect.</p>		

Parameters	Permitted Values	Default
Web User Interface: Network->Basic->IPv6 Config->Static IP Address->Primary DNS Phone User Interface: Menu->Advanced (default password: admin) ->Network->WAN Port->IPv6->Static IP->Primary DNS Or Menu->Advanced (default password: admin) ->Network->WAN Port->IPv6->DHCP->Static DNS(Enabled)->Primary DNS		
network.ipv6_secondary_dns	IPv6 address	Blank
Description: Configures the secondary IPv6 DNS server. Example: network.ipv6_secondary_dns = 2026:1234:1:1:c3c7:c11c:5447:23a6 Note: It works only if the value of the parameter "network.ip_address_mode" is set to 1 (IPv6) or 2 (IPv4 & IPv6). In DHCP environment, you also need to make sure the value of the parameter "network.ipv6_static_dns_enable" is set to 1 (On). If you change this parameter, the Skype for Business phone will reboot to make the change take effect. Web User Interface: Network->Basic->IPv6 Config->Static IP Address->Secondary DNS Phone User Interface: Menu->Advanced (default password: admin) ->Network->WAN Port->IPv6->Static IP->Secondary DNS Or Menu->Advanced (default password: admin) ->Network->WAN Port->IPv6->DHCP->Static DNS(Enabled)->Secondary DNS		
network.ipv6_icmp_v6.enable	0 or 1	1
Description: Enables or disables the Skype for Business phone to obtain IPv6 network settings via SLAAC (Stateless Address Autoconfiguration) method. 0 -Disabled 1 -Enabled Note: If you change this parameter, the Skype for Business phone will reboot to make the change take effect. It is only applicable to T48G/T46G Skype for Business phones. SLAAC is enabled on T42G/T41P/T40P Skype for Business phones by default. You are not allowed to configure this parameter for these Skype for Business phones.		

Parameters	Permitted Values	Default
Web User Interface: Network->Advanced->ICMPv6 Status-> Active Phone User Interface: None		

To configure IPv6 address assignment method via web user interface:

1. Click on **Network->Basic**.
2. Select the desired address mode (**IPv6** or **IPv4 & IPv6**) from the pull-down list of **Mode(IPv4/IPv6)**.
3. In the **IPv6 Config** block, mark the **DHCP** or the **Static IP Address** radio box.
 - If you mark the **Static IP Address** radio box, configure the IPv6 address and other configuration parameters in the corresponding fields.

Yealink T46G Log Out

Status Account **Network** Features Settings Directory Security

Basic PC Port Advanced

Internet Port
Mode(IPv4/IPv6) IPv6 ?

IPv4 Config
☒ DHCP ?
☐ Static IP Address ?
IP Address
Subnet Mask
Gateway
Static DNS ☒ On ☐ Off
Primary DNS
Secondary DNS

IPv6 Config
☐ DHCP ?
☒ Static IP Address ?
IP Address 2026:1234:1:1:215:65ff:fe1
IPv6 Prefix(0~128) 64
Gateway 3026:1:1:c3c7:c11c:5447:2
IPv6 Static DNS ☒ On ☐ Off
Primary DNS 3026:1:1:c3c7:c11c:5447:2
Secondary DNS 2026:1234:1:1:c3c7:c11c:5

Confirm Cancel

NOTE
DHCP
The network configurations will be acquired from DHCP server.
Static IP Address
Specify the IP address, Subnet Mask, Default Gateway, Primary DNS, Secondary DNS fields manually.
PPPoE
Contact your ISP if it should be used.
You can click here to get more guides.

- (Optional.) If you mark the **DHCP** radio box, you can configure the static DNS address in the corresponding fields.

The screenshot shows the Yealink T46G web interface. The 'Network' tab is selected, and the 'Internet Port' section is active. Under 'IPv6 Config', the 'Static IP Address' option is selected. The 'IPv6 Static DNS' section is highlighted with a red box, showing the 'On' radio button selected. The 'Primary DNS' field contains '3026:11:c3c7:c11c:5447:2' and the 'Secondary DNS' field contains '2026:1234:11:c3c7:c11c:5'. The 'Confirm' button is visible at the bottom.

Internet Port
Mode(IPv4/IPv6) IPv6

IPv4 Config
☒ DHCP
☐ Static IP Address
IP Address
Subnet Mask
Gateway
Static DNS ☐ On ☒ Off
Primary DNS
Secondary DNS

IPv6 Config
☒ DHCP
☐ Static IP Address
IP Address 2026:1234:11:215:65ff:fe1
IPv6 Prefix(0~128) 64
Gateway 3026:11:c3c7:c11c:5447:2
IPv6 Static DNS ☒ On ☐ Off
Primary DNS 3026:11:c3c7:c11c:5447:2
Secondary DNS 2026:1234:11:c3c7:c11c:5

Confirm Cancel

NOTE
DHCP
The network configurations will be acquired from DHCP server.
Static IP Address
Specify the IP address, Subnet Mask, Default Gateway, Primary DNS, Secondary DNS fields manually.
PPPoE
Contact your ISP if it should be used.
You can click here to get more guides.

4. Click **Confirm** to accept the change.
A dialog box pops up to prompt that the settings will take effect after a reboot.
5. Click **OK** to reboot the Skype for Business phone.

To configure SLAAC feature via web user interface (only applicable to T48G/T46G):

1. Click on **Network->Advanced**.

- In the **ICMPv6 Status** block, select the desired value from the pull-down list of **Active**.

The screenshot shows the Yealink T46G web interface with the 'Network' tab selected. The left sidebar has 'Basic', 'PC Port', and 'Advanced' options. The main content area shows various network settings:

- LLDP**: Active, Enabled (dropdown), Packet Interval (1~3600s): 60
- CDP**: Active, Enabled (dropdown), Packet Interval (1~3600s): 60
- VLAN**: WAN Port: Active, Disabled (dropdown), VID (1-4094): 1, Priority: 0; PC Port: Active, Disabled (dropdown), VID (1-4094): 1, Priority: 0
- Port Link**: WAN Port Link: Auto Negotiate (dropdown), PC Port Link: Auto Negotiate (dropdown)
- ICMPv6 Status**: Active (highlighted with a red box), Enabled (dropdown)

At the bottom are 'Confirm' and 'Cancel' buttons. On the right, there is a 'NOTE' section with information about VLAN, QoS, and Local RTP Port.

- Click **Confirm** to accept the change.
A dialog box pops up to prompt that the settings will take effect after a reboot.
- Click **OK** to reboot the Skype for Business phone.

To configure IPv6 address assignment method via phone user interface:

- Press **Menu->Advanced** (default password: admin) -> **Network->WAN Port**.
- Press **◀** or **▶** to select **IPv4 & IPv6** or **IPv6** from the **IP Mode** field.
- Press **▲** or **▼** to highlight **IPv6** and press the **Enter** soft key.
- Press **▲** or **▼** to select the desired IPv6 address assignment method.

If you select the **Static IP**, configure the IPv6 address and other network parameters in the corresponding fields.

- Press the **Save** soft key to accept the change.

The Skype for Business phone reboots automatically to make settings effective after a period of time.

To configure IPv6 static DNS when DHCP is used via phone user interface:

- Press **Menu->Advanced** (default password: admin) -> **Network->WAN Port->IPv6->DHCP**.
- Press **◀** or **▶**, or the **Switch** soft key to select **Enabled** from the **Static DNS** field.
- Enter the desired values in the **Primary DNS** and **Second DNS** fields respectively.
- Press the **Save** soft key to accept the change.

The Skype for Business phone reboots automatically to make settings effective after a period of time.

Quality of Service (QoS)

Quality of Service (QoS) is the ability to provide different priorities for different packets in the network, allowing the transport of traffic with special requirements. QoS guarantees are important for applications that require fixed bit rate and are delay sensitive when the network capacity is insufficient. There are four major QoS factors to be considered when configuring a modern QoS implementation: bandwidth, delay, jitter and loss.

QoS provides better network service through the following features:

- Supporting dedicated bandwidth
- Improving loss characteristics
- Avoiding and managing network congestion
- Shaping network traffic
- Setting traffic priorities across the network

The Best-Effort service is the default QoS model in IP networks. It provides no guarantees for data delivering, which means delay, jitter, packet loss and bandwidth allocation are unpredictable. Differentiated Services (DiffServ or DS) is the most widely used QoS model. It provides a simple and scalable mechanism for classifying and managing network traffic and providing QoS on modern IP networks. Differentiated Services Code Point (DSCP) is used to define DiffServ classes and stored in the first six bits of the ToS (Type of Service) field. Each router on the network can provide QoS simply based on the DiffServ class. The DSCP value ranges from 0 to 63 with each DSCP specifying a particular per-hop behavior (PHB) applicable to a packet. A PHB refers to the packet scheduling, queuing, policing, or shaping behavior of a node on any given packet.

Four standard PHBs available to construct a DiffServ-enabled network and achieve QoS:

- **Class Selector PHB** -- backwards compatible with IP precedence. Class Selector code points are of the form "xxx000". The first three bits are the IP precedence bits. These class selector PHBs retain almost the same forwarding behavior as nodes that implement IP precedence-based classification and forwarding.
- **Expedited Forwarding PHB** -- the key ingredient in DiffServ model for providing a low-loss, low-latency, low-jitter and assured bandwidth service.
- **Assured Forwarding PHB** -- defines a method by which BAs (Bandwidth Allocations) can be given different forwarding assurances.
- **Default PHB** -- specifies that a packet marked with a DSCP value of "000000" gets the traditional best effort service from a DS-compliant node.

VoIP is extremely bandwidth and delay-sensitive. QoS is a major issue in VoIP implementations, regarding how to guarantee that packet traffic not be delayed or dropped due to interference

from other lower priority traffic. VoIP can guarantee high-quality QoS only if the voice and the SIP packets are given priority over other kinds of network traffic. Skype for Business phones support the DiffServ model of QoS.

Voice QoS

In order to make VoIP transmissions intelligible to receivers, voice packets should not be dropped, excessively delayed, or made to suffer varying delay. DiffServ model can guarantee high-quality voice transmission when the voice packets are configured to a higher DSCP value.

SIP QoS

SIP protocol is used for creating, modifying and terminating two-party or multi-party sessions. To ensure good voice quality, SIP packets emanated from Skype for Business phones should be configured with a high transmission priority.

DSCPs for voice and SIP packets can be specified respectively.

Note

For voice and SIP packets, the Skype for Business phone obtains DSCP info from the network policy if LLDP feature is enabled, which takes precedence over manual settings. For more information on LLDP, refer to [LLDP](#) on page 55.

Procedure

QoS can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the DSCPs for voice packets and SIP packets. Parameters: network.qos.rtplos network.qos.signallos
Local	Web User Interface	Configure the DSCPs for voice packets and SIP packets. Navigate to: <a href="http://<phoneIPAddress>/servlet?p=network-adv&q=load">http://<phoneIPAddress>/servlet?p=network-adv&q=load

Details of Configuration Parameters:

Parameters	Permitted Values	Default
network.qos.rtplos	Integer from 0 to 63	46
Description:		

Parameters	Permitted Values	Default
<p>Configures the DSCP (Differentiated Services Code Point) for voice packets.</p> <p>The default DSCP value for RTP packets is 46 (Expedited Forwarding).</p> <p>Note: If you change this parameter, the Skype for Business phone will reboot to make the change take effect.</p> <p>Web User Interface:</p> <p>Network->Advanced->Voice QoS (0~63)</p> <p>Phone User Interface:</p> <p>None</p>		
network.qos.signaltos	Integer from 0 to 63	26
<p>Description:</p> <p>Configures the DSCP (Differentiated Services Code Point) for SIP packets.</p> <p>The default DSCP value for SIP packets is 26 (Assured Forwarding).</p> <p>Note: If you change this parameter, the Skype for Business phone will reboot to make the change take effect.</p> <p>Web User Interface:</p> <p>Network->Advanced->SIP QoS (0~63)</p> <p>Phone User Interface:</p> <p>None</p>		

To configure DSCPs for voice packets and SIP packets via web user interface:

1. Click on **Network->Advanced**.
2. Enter the desired value in the **Voice QoS (0~63)** field.

3. Enter the desired value in the **SIP QoS (0~63)** field.

The screenshot shows the Yealink T46G configuration interface. The 'Network' tab is selected. On the left, there are sub-tabs: Basic, PC Port, and Advanced. The 'Voice QoS' section is highlighted with a red box. It contains two fields: 'Voice QoS (0~63)' with a value of 46 and 'SIP QoS (0~63)' with a value of 26. Other sections visible include LLDP, CDP, VLAN, and Port Link, each with various configuration options like Active/Disabled, Packet Interval, and Priority.

4. Click **Confirm** to accept the change.
A dialog box pops up to prompt that settings will take effect after a reboot.
5. Click **OK** to reboot the Skype for Business phone.

802.1X Authentication

IEEE 802.1X authentication is an IEEE standard for Port-based Network Access Control (PNAC), part of the IEEE 802.1 group of networking protocols. It offers an authentication mechanism for devices to connect/link to a LAN or WLAN. The 802.1X authentication involves three parties: a supplicant, an authenticator and an authentication server. The supplicant is the phone that wishes to attach to the LAN or WLAN. With 802.1X port-based authentication, the phone provides credentials, such as user name and password, for the authenticator, and then the authenticator forwards the credentials to the authentication server for verification. If the authentication server determines the credentials are valid, the phone is allowed to access resources located on the protected side of the network.

Phones support protocols EAP-MD5, EAP-TLS, EAP-PEAP/MSCHAPv2, EAP-TTLS/EAP-MSCHAPv2, EAP-PEAP/GTC, EAP-TTLS/EAP-GTC and EAP-FAST for 802.1X authentication.

For more information on 802.1X authentication, refer to [Yealink 802.1X Authentication](#).

Procedure

802.1X authentication can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	<p>Configure the 802.1X authentication.</p> <p>Parameters:</p> <p>network.802_1x.mode</p> <p>network.802_1x.identity</p> <p>network.802_1x.md5_password</p> <p>network.802_1x.root_cert_url</p> <p>network.802_1x.client_cert_url</p>
Local	Web User Interface	<p>Configure the 802.1X authentication.</p> <p>Navigate to:</p> <p>http://<phoneIPAddress>/servlet?p=network-adv&q=load</p>
	Phone User Interface	<p>Configure the 802.1X authentication.</p>

Details of Configuration Parameters:

Parameters	Permitted Values	Default
network.802_1x.mode	0, 1, 2, 3, 4, 5, 6 or 7	0
<p>Description:</p> <p>Configures the 802.1x authentication method.</p> <p>0-Disabled</p> <p>1-EAP-MD5</p> <p>2-EAP-TLS</p> <p>3-EAP-PEAP/MSCHAPv2</p> <p>4-EAP-TTLS/EAP-MSCHAPv2</p> <p>5-EAP-PEAP/GTC</p> <p>6-EAP-TTLS/EAP-GTC</p> <p>7-EAP-FAST</p> <p>Note: If you change this parameter, the Skype for Business phone will reboot to make the change take effect.</p> <p>Web User Interface:</p> <p>Network->Advanced->802.1x->802.1x Mode</p> <p>Phone User Interface:</p> <p>Menu->Advanced (default password: admin) ->Network->802.1x->802.1x Mode</p>		

Parameters	Permitted Values	Default
network.802_1x.identity	String within 32 characters	Blank
<p>Description: Configures the user name for 802.1x authentication.</p> <p>Example: network.802_1x.identity = admin</p> <p>Note: It works only if the value of the parameter "network.802_1x.mode" is set to 1, 2, 3, 4, 5, 6 or 7. If you change this parameter, the Skype for Business phone will reboot to make the change take effect.</p> <p>Web User Interface: Network->Advanced->802.1x->Identity</p> <p>Phone User Interface: Menu->Advanced (default password: admin) ->Network->802.1x ->Identity</p>		
network.802_1x.md5_password	String within 32 characters	Blank
<p>Description: Configures the password for 802.1x authentication.</p> <p>Example: network.802_1x.md5_password = admin123</p> <p>Note: It works only if the value of the parameter "network.802_1x.mode" is set to 1, 3, 4, 5, 6 or 7. If you change this parameter, the Skype for Business phone will reboot to make the change take effect.</p> <p>Web User Interface: Network->Advanced->802.1x->MD5 Password</p> <p>Phone User Interface: Menu->Advanced (default password: admin) ->Network->802.1x ->MD5 Password</p>		
network.802_1x.root_cert_url	URL within 511 characters	Blank
<p>Description: Configures the access URL of the CA certificate.</p> <p>Example: network.802_1x.root_cert_url = http://192.168.1.10/ca.pem</p> <p>Note: It works only if the value of the parameter "network.802_1x.mode" is set to 2, 3, 4, 5, 6 or 7. The format of the certificate must be *.pem, *.crt, *.cer or *.der.</p> <p>Web User Interface:</p>		

Parameters	Permitted Values	Default
Network->Advanced->802.1x->CA Certificates Phone User Interface: None		
network.802_1x.client_cert_url	URL within 511 characters	Blank
Description: Configures the access URL of the device certificate. Example: network.802_1x.client_cert_url = http://192.168.1.10/client.pem Note: It works only if the value of the parameter "network.802_1x.mode" is set to 2 (EAP-TLS). The format of the certificate must be *.pem. Web User Interface: Network->Advanced->802.1x->Device Certificates Phone User Interface: None		

To configure the 802.1X authentication via web user interface:

1. Click on **Network->Advanced**.
2. In the **802.1x** block, select the desired protocol from the pull-down list of **802.1x Mode**.
 - a) If you select **EAP-MD5**:
 - 1) Enter the user name for authentication in the **Identity** field.

2) Enter the password for authentication in the **MD5 Password** field.

The screenshot shows the Yealink T46G web interface with the 'Network' tab selected. The left sidebar has 'Basic', 'PC Port', and 'Advanced' options. The main content area is divided into several sections: LLDP, CDP, VLAN, 802.1x, and Span to PC. The 802.1x section is highlighted with a red box, showing the following configuration:

- 802.1x Mode: EAP-MD5 (selected from a dropdown)
- Identity: yealink
- MD5 Password: masked with dots
- CA Certificates: Upload button and Browse... button
- Device Certificates: Upload button and Browse... button
- Span to PC: Span to PC Port dropdown set to Disabled

On the right side, there is a 'NOTE' section with information about VLAN, QoS, and Local RTP Port.

b) If you select **EAP-TLS**:

- 1) Enter the user name for authentication in the **Identity** field.
- 2) Leave the **MD5 Password** field blank.
- 3) In the **CA Certificates** field, click **Browse** to select the desired CA certificate (*.pem, *.crt, *.cer or *.der) from your local system.
- 4) In the **Device Certificates** field, click **Browse** to select the desired client (*.pem or *.cer) certificate from your local system.

5) Click **Upload** to upload the certificates.

The screenshot shows the Yealink T46G Network configuration page. The left sidebar has tabs for Basic, PC Port, and Advanced. The main content area is divided into sections for LLDP, CDP, VLAN, 802.1x, and Span to PC. The 802.1x section is highlighted with a red box. It contains the following fields:

- 802.1x Mode: EAP-TLS (dropdown)
- Identity: yealink (text field)
- MD5 Password: masked with dots (password field)
- CA Certificates: Upload button and Browse... button
- Device Certificates: Upload button and Browse... button

On the right side, there is a NOTE section with information about VLAN, QoS, and Local RTP Port.

c) If you select **EAP-PEAP/MSCHAPv2**:

- 1) Enter the user name for authentication in the **Identity** field.
- 2) Enter the password for authentication in the **MD5 Password** field.
- 3) In the **CA Certificates** field, click **Browse** to select the desired CA certificate (*.pem, *.crt, *.cer or *.der) from your local system.

4) Click **Upload** to upload the certificate.

The screenshot shows the Yealink T46G web interface. The 'Network' tab is selected. On the left, the 'Advanced' section is expanded. The '802.1x' configuration is highlighted with a red box. The fields within this box are: '802.1x Mode' set to 'EAP-PEAP/MSCHAPv2', 'Identity' set to 'yealink', 'MD5 Password' masked with dots, and 'CA Certificates' with an 'Upload' button. Other visible settings include LLDP (Active: Enabled), CDP (Active: Enabled), and VLAN (Active: Disabled, VID: 1, Priority: 0). A 'NOTE' section on the right explains VLAN and QoS.

d) If you select **EAP-TTLS/EAP-MSCHAPv2**:

- 1) Enter the user name for authentication in the **Identity** field.
- 2) Enter the password for authentication in the **MD5 Password** field.
- 3) In the **CA Certificates** field, click **Browse** to select the desired CA certificate (*.pem, *.crt, *.cer or *.der) from your local system.

4) Click **Upload to upload the certificate.**

The screenshot shows the Yealink T46G Network configuration page. The left sidebar has tabs for Basic, PC Port, and Advanced. The main content area is divided into sections for LLDP, CDP, VLAN, and 802.1x. The 802.1x section is expanded, showing fields for 802.1x Mode (set to EAP-TTLS/EAP-MSCHAPv), Identity (set to yealink), MD5 Password (masked with dots), CA Certificates (with an Upload button), and Device Certificates (with an Upload button). A red box highlights the 802.1x Mode, Identity, MD5 Password, and CA Certificates fields. The right sidebar contains a NOTE section with information about VLAN, QoS, and Local RTP Port.

e) If you select **EAP-PEAP/GTC:**

- 1)** Enter the user name for authentication in the **Identity** field.
- 2)** Enter the password for authentication in the **MD5 Password** field.
- 3)** In the **CA Certificates** field, click **Browse** to select the desired CA certificate (*.pem, *.crt, *.cer or *.der) from your local system.

The screenshot shows the Yealink T46G Network configuration page. The left sidebar has tabs for Basic, PC Port, and Advanced. The main content area is divided into sections for LLDP, CDP, VLAN, and 802.1x. The 802.1x section is expanded, showing fields for 802.1x Mode (set to EAP-PEAP/GTC), Identity (set to yealink), MD5 Password (masked with dots), CA Certificates (with a Browse... button), and Device Certificates (with a Browse... button). A red box highlights the 802.1x Mode, Identity, MD5 Password, and CA Certificates fields. The right sidebar contains a NOTE section with information about VLAN, QoS, and Local RTP Port.

4) Click **Upload** to upload the certificate.

f) If you select **EAP-TTLS/EAP-GTC**:

- 1) Enter the user name for authentication in the **Identity** field.
- 2) Enter the password for authentication in the **MD5 Password** field.
- 3) In the **CA Certificates** field, click **Browse** to select the desired CA certificate (*.pem, *.crt, *.cer or *.der) from your local system.

The screenshot shows the Yealink T46G web interface with the 'Network' tab selected. On the left sidebar, 'Basic', 'PC Port', and 'Advanced' are listed, with 'Advanced' being the active section. The main content area displays various network settings:

- LLDP**: Active (Enabled), Packet Interval (1~3600s) (60).
- CDP**: Active (Enabled), Packet Interval (1~3600s) (60).
- VLAN**: WAN Port Active (Disabled), VID (1-4094) (1), Priority (0).
- 802.1x**: 802.1x Mode (EAP-TTLS/EAP-GTC), Identity (yealink), MD5 Password (*****), CA Certificates (Upload, Browse...), Device Certificates (Upload, Browse...).
- Span to PC**: Span to PC Port (Disabled).

A red box highlights the 802.1x configuration fields. On the right, a 'NOTE' section provides information about VLAN, QoS, and Local RTP Port.

4) Click **Upload** to upload the certificate.

g) If you select **EAP-FAST**:

- 1) Enter the user name for authentication in the **Identity** field.
- 2) Enter the password for authentication in the **MD5 Password** field.

- 3) In the **CA Certificates** field, click **Browse** to select the desired CA certificate (*.pem, *.crt, *.cer or *.der) from your local system.

The screenshot shows the Yealink T46G web interface with the 'Network' tab selected. Under the '802.1x' section, the '802.1x Mode' is set to 'EAP-FAST'. The 'Identity' field contains 'yealink' and the 'MD5 Password' field contains a masked password. The 'CA Certificates' field has an 'Upload' button and a 'Browse...' button. The 'Device Certificates' field also has an 'Upload' button and a 'Browse...' button. The 'Span to PC' field is set to 'Disabled'.

- 4) Click **Upload** to upload the certificate.
3. Click **Confirm** to accept the change.
- A dialog box pops up to prompt that settings will take effect after a reboot.
4. Click **OK** to reboot the Skype for Business phone.

To configure the 802.1X authentication via phone user interface:



- Press **Menu**->**Advanced** (default password: admin) ->**Network**->**802.1x**.
- Press **Left** or **Right** or the **Switch** soft key to select the desired value from the **802.1x Mode** field.
 - If you select **EAP-MD5**:
 - Enter the user name for authentication in the **Identity** field.
 - Enter the password for authentication in the **MD5 Password** field.
 - If you select **EAP-TLS**:
 - Enter the user name for authentication in the **Identity** field.
 - Leave the **MD5 Password** field blank.
 - If you select **EAP-PEAP/MSCHAPv2**:
 - Enter the user name for authentication in the **Identity** field.
 - Enter the password for authentication in the **MD5 Password** field.
 - If you select **EAP-TTLS/EAP-MSCHAPv2**:
 - Enter the user name for authentication in the **Identity** field.

- 2) Enter the password for authentication in the **MD5 Password** field.
 - e) If you select **EAP-PEAP/GTC**:
 - 1) Enter the user name for authentication in the **Identity** field.
 - 2) Enter the password for authentication in the **MD5 Password** field.
 - f) If you select **EAP-TTLS/EAP-GTC**:
 - 1) Enter the user name for authentication in the **Identity** field.
 - 2) Enter the password for authentication in the **MD5 Password** field.
 - g) If you select **EAP-FAST**:
 - 1) Enter the user name for authentication in the **Identity** field.
 - 2) Enter the password for authentication in the **MD5 Password** field.
 3. Click **Save** to accept the change.
- The Skype for Business phone reboots automatically to make the settings effective after a period of time.

Branch Office Resiliency

Branch office resiliency is critical for multi-site deployments of Skype for Business where the control servers are located at a central site or data center. It allows branch site users to continue to have Enterprise Voice service and voice mail (if voice mail rerouting settings are configured) when the branch site loses the connection to the central site.

When the WAN connection between the branch site and central site is unavailable, the phone goes into resiliency mode:

- Branch site user on the phone stays signed in with an indication of "Limited service due to outage".
- Presence icon on the phone LCD screen is displayed as Unknown icon:  (T46G/T48G)/  (T42G/T41P/T40P).
- Call between branch site users is established successfully with 2-way audio.
- Conference between branch site users can be established successfully.
- The call history cannot get modified. (Already downloaded call log entries will not be deleted)
- Calls can be placed from the call history on the Skype for Business phone.
- Contact list is unavailable but you can search for a contact on the Skype for Business phone.
- User is not able to change his presence state manually.
- User is not able to use calendar feature.
- User is not able to receive the voice mail as exchange is unreachable and when Skype for Business phone comes out of resiliency mode, it downloads the yet undownloaded voice mail items and updates the voice mail screen.
- Calls between the branch office phones can be transferred to another branch site user.

- Call forward settings cannot be changed.

When the WAN connection between the branch site and central site becomes available, the phone comes out of resiliency mode automatically. Notification of resiliency is automatically dismissed, and you can use phone features as normal.

Note

For more information on branch office resiliency, contact your system administrator.

Setting Up Your Phones with a Provisioning Server

This chapter provides basic instructions for setting up your phones with a provisioning server.

This chapter consists of the following sections:

- [Provisioning Points to Consider](#)
- [Provisioning Methods](#)
- [Configuration Files and Resource Files](#)
- [Setting Up a Provisioning Server](#)

Provisioning Points to Consider


- If you are provisioning a mass of phones, we recommend you to use central provisioning method as your primary configuration method. For more information on central provisioning, refer to [Central Provisioning](#) on page 93.
- A provisioning server maximizes the flexibility you have when installing, configuring, upgrading, and managing the phones, and enables you to store configuration, and contact files on the server. You can set up a provisioning server on the local area network (LAN) or anywhere on the Internet. For more information, refer to [Setting Up a Provisioning Server](#) on page 97.
- If the phone cannot obtain the address of a provisioning server during startup, and has not been configured with settings from any other source, the phone will use configurations stored in the flash memory. If the phone that cannot obtain the address of a provisioning server has previously been configured with settings it will use those previous settings.

Provisioning Methods

Phones can be configured automatically through configuration files stored on a central provisioning server, manually via web user interface or phone user interface, or by a combination of the automatic and manual methods. If a central provisioning server is not available, you can configure most features using manual method.

Central Provisioning

The following figure shows how the phone interoperates with provisioning server when you use the centralized provisioning method:



Skype for Business phones can be centrally provisioned from a provisioning server using the configuration files (<y0000000000xx>.cfg and <MAC>.cfg). You can use a text-based editing application to edit configuration files, and then store configuration files to a provisioning server. For more information on the provisioning server, refer to [Setting Up a Provisioning Server](#) on page 97.

Skype for Business phones can obtain the provisioning server address during startup. Then Skype for Business phones download configuration files from the provisioning server, resolve and update the configurations written in configuration files. This entire process is called auto provisioning. For more information on auto provisioning, refer to [Yealink_Skype_for_Business_HD_IP_Phones_Auto_Provisioning_Guide](#).

Manual Provisioning

There are two ways to manually provision phones:

- [Web User Interface](#)
- [Phone User Interface](#)

Web User Interface

You can configure phones via web user interface, a web-based interface that is especially useful for remote configuration. Because features and configurations vary by phone model and firmware version, options available on each page of the web user interface can vary.

An administrator or a user can configure phones via web user interface; but accessing the web user interface requires password. The default user name and password for the administrator are

both "admin" (case-sensitive). The default user name and password for the user are both "user" (case-sensitive). For more information on configuring passwords, refer to [User and Administrator Passwords](#) on page 327.

This method enables you to perform configuration changes on a per-phone basis. Note that the features can be configured via web user interface are limited. So, you can use the web user interface method as the sole configuration method or in conjunction with central provisioning method and phone user interface method.

Phones support both HTTP and HTTPS protocols for accessing the web user interface. For more information, refer to [Web Server Type](#) on page 50.

Phone User Interface

You can configure phones via phone user interface on a per-phone basis. As with the web user interface, phone user interface makes configurations available to users and administrators; but the **Advanced/Advanced Settings** option is only available to administrators and requires an administrator password (default: admin). For more information on configuring password, refer to [User and Administrator Passwords](#) on page 327.

If you want to reset all settings made from the phone user interface to default, refer to [Yealink phone-specific user guide](#).

Configuration Files and Resource Files

When phones are configured with central provisioning method, they will request to download the configuration files and resource files from the provisioning server.

The following sections describe the details of configuration files and resource files:

- [Configuration Files](#)
- [Resource Files](#)
- [Obtaining Configuration Files/Resource Files](#)

Configuration Files

The configuration files are valid CFG files that can be created or edited using a text editor such as UltraEdit. An administrator can deploy and maintain a mass of Yealink phones automatically through configuration files stored on a provisioning server.

Yealink configuration files consist of:

- [Common CFG File](#)
- [MAC-Oriented CFG File](#)

Common CFG File

Common CFG file, named <y0000000000xx>.cfg, contains parameters that affect the basic operation of the phone, such as language and volume. It will be effectual for all phones of the same model. The common CFG file has a fixed name.

The following table lists the name of the common CFG file for each phone model:

IP Phone Model	Common CFG file
T48G	y000000000035.cfg
T46G	y000000000028.cfg
T42G	y000000000029.cfg
T41P	y000000000036.cfg
T40P	y000000000054.cfg

MAC-Oriented CFG File

MAC-Oriented CFG file, named <MAC>.cfg, contains parameters unique to a particular phone, such as account registration. It will only be effectual for a specific phone.

The MAC-Oriented CFG file is named after the MAC address of the phone. MAC address, a unique 12-digit serial number assigned to each phone, can be obtained from the bar code on the back of the phone. For example, if the MAC address of a phone is 00156574B150, the name of the MAC-Oriented CFG file must be 00156574b150.cfg (case-sensitive).

Resource Files

When configuring some particular features, you may need to upload resource files to phones. Resource files are optional, but if the particular feature is being employed, these files are required.

If the resource file is to be used for all phones of the same model, the access URL of resource file is best specified in the common CFG file. However, if you want to specify the desired phone to use the resource file, the access URL of resource file should be specified in the MAC-Oriented CFG file. During provisioning, the phones will request the resource files in addition to the configuration files. For more information on the access URL of resource file, refer to the corresponding section in this guide.

The followings show examples of resource files:

- Language packs
- Ring tones
- Local contact file

For more information on resource files, refer to [Obtaining Configuration Files/Resource Files](#) on

page 96.

If you want to delete resource files from a phone at a later date - for example, if you are giving the phone to a new user - you can reset the phone to factory configuration settings. For more information, refer to 374 on page [Resetting Issues](#).

Obtaining Configuration Files/Resource Files

Yealink supplies some template configuration files and resource files for you, so you can directly edit and customize the files as required. You can ask the distributor or Yealink FAE for template files. You can also obtain the template files online:

<http://support.yealink.com/documentFront/forwardToDocumentFrontDisplayPage>.


The names of the Yealink-supplied template files are:

Template File		File Name	Description
Configuration Files	Common CFG File	Common.cfg	Allow you to deploy and maintain a mass of Yealink phones. For more information, refer to Common CFG File and MAC-Oriented CFG File on page 95.
	MAC-Oriented CFG File	MAC.cfg	
Resource Files	AutoDST Template	AutoDST.xml	Allows you to add or modify time zone and DST settings for your area. For more information, refer to Customizing an AutoDST Template File on page 154.
	Language Packs	For example, 000.GUI.English.lang 1.English.js	Allow you to customize the translation of the existing language on the phone/web user interface. For more information, refer to Loading Language Packs on page 158.
	Keypad Input Method File	ime.txt	Existing input methods on Yealink phones.
	Dial Now Template	dialnow.xml	Allows you to customize multiple dial now rules for phone. For more information, refer to Customizing Dial-now Template File on page 173.
	Local Contact File	contact.xml	Allows you to add or modify multiple local contacts at a time for your phone. For more information, refer to Customizing a Local Contact File on page 183.

To download template files:

1. Go to Yealink [Document Download](#) page and select the desired phone model.
2. Download and extract the combined files to your local system.

For example, the following illustration shows the template files available for T46G Skype for Business phones running firmware version 8.



3. Open the folder you extracted and identify the template file you will edit according to the table introduced above.

For some features, you can customize the filename as required. The following table lists the special characters supported by Yealink phones:

Platform	Server	HTTP/HTTPS	TFTP/FTP
Windows	Server	Support: ~ ` ! @ \$ ^ () _ - , . ' ; [] { } (including space) Not Support: < > : " / \ * ? # % & = +	Support: ~ ` ! @ \$ ^ () _ - , . ' ; [] { } % & = + (including space) Not Support: < > : " / \ * ? #
	Linux	Support: ~ ` ! @ \$ ^ () _ - , . ' ; [] { } < > : " (including space) Not Support: / \ * ? # % & = +	Support: ~ ` ! @ \$ ^ () _ - , . ' ; [] { } < > : " % & = + (including space) Not Support: / \ * ? #

Setting Up a Provisioning Server

This chapter provides basic instructions for setting up a provisioning server and deploying phones from the provisioning server.

This chapter consists of the following sections:

- [Why Using a Provisioning Server?](#)
- [Supported Provisioning Protocols](#)

- [Configuring a Provisioning Server](#)
- [Deploying Phones from the Provisioning Server](#)

Why Using a Provisioning Server?

You can use a provisioning server to configure your phones. A provisioning server allows for flexibility in upgrading, maintaining and configuring the phone. Configuration files and resource files are normally located on this server.

When phones are triggered to perform auto provisioning, it will request to download the configuration files from the provisioning server. During the auto provisioning process, the phone will download and update configuration files to the phone flash. For more information on auto provisioning, refer to [Yealink_Skype_for_Business_HD_IP_Phones_Auto_Provisioning_Guide](#).

Supported Provisioning Protocols

Phones perform the auto provisioning function of uploading log files (if configured), uploading contact files (if configured), downloading boot files, downloading configuration files, downloading resource files and upgrading firmware. The transfer protocol is used to download files from the provisioning server. Phones support several transport protocols for provisioning, including FTP, TFTP, HTTP, and HTTPS protocols. And you can specify the transport protocol in the provisioning server address, for example, `http://xxxxxxx`. If not specified, the TFTP protocol is used. The provisioning server address can be IP address, domain name or URL. If a user name and password are specified as part of the provisioning server address, for example, `http://user:pwd@server/dir`, they will be used only if the server supports them.

Note

A URL should contain forward slashes instead of back slashes and should not contain spaces. Escape characters are not supported.

If a user name and password are not specified as part of the provisioning server address, the User Name and Password of the provisioning server configured on the phone will be used.

There are two types of FTP methods—active and passive. Phones are not compatible with active FTP.

Configuring a Provisioning Server

The provisioning server can be set up on the local LAN or anywhere on the Internet. Use the following procedure as a recommendation if this is your first provisioning server setup. For more information on how to set up a provisioning server, refer to [Yealink_Skype_for_Business_HD_IP_Phones_Auto_Provisioning_Guide](#).

To set up the provisioning server:

1. Install a provisioning server application or locate a suitable existing server.
2. Create an account and home directory.
3. Set security permissions for the account.

4. Create configuration files and edit them as desired.
5. Copy the configuration files and resource files to the provisioning server.

For more information on how to deploy phones using boot files and configuration files, refer to [Deploying Phones from the Provisioning Server](#) on page 99.

Note

Typically all phones are configured with the same server account, but the server account provides a means of conveniently partitioning the configuration. Give each account a unique home directory on the server and change the configuration on a per-line basis.

Deploying Phones from the Provisioning Server

The parameters in the new downloaded configuration files will override the duplicate parameters in files downloaded earlier. During auto provisioning, Skype for Business phones download the common configuration file first, and then the MAC-Oriented file. Therefore any parameter in the MAC-Oriented configuration file will override the same one in the common configuration file.

Yealink supplies configuration files for each phone model, which is delivered with the Skype for Business phone firmware. The configuration files, supplied with each firmware release, must be used with that release. Otherwise, configurations may not take effect, and the Skype for Business phone will behave without exception. Before you configure parameters in the configuration files, Yealink recommends that you create new configuration files containing only those parameters that require changes.

To deploy Skype for Business phones from the provisioning server:

1. Create per-phone configuration files by performing the following steps:
 - a) Obtain a list of phone MAC addresses (the bar code label on the back of the Skype for Business phone or on the outside of the box).
 - b) Create per-phone <MAC>.cfg files by using the MAC-Oriented CFG file from the distribution as templates.
 - c) Edit the parameters in the file as desired.
2. Create new common configuration files by performing the following steps:
 - a) Create <y0000000000xx>.cfg files by using the Common CFG file from the distribution as templates.
 - b) Edit the parameters in the file as desired.
3. Copy configuration files to the home directory of the provisioning server.
4. Reboot Skype for Business phones to trigger the auto provisioning process.

Skype for Business phones discover the provisioning server address, and then download the configuration files from the provisioning server.

For more information on configuration files, refer to [Configuration Files](#) on page 94. For protecting against unauthorized access, you can encrypt configuration files. For more information on encrypting configuration files, refer to [Encrypting Configuration Files](#) on page 344.

During the auto provisioning process, the Skype for Business phone supports the following methods to discover the provisioning server address:

- **DHCP:** DHCP option can be used to provide the address or URL of the provisioning server to Skype for Business phones. When the Skype for Business phone requests an IP address using the DHCP protocol, the resulting response may contain option 66 or the custom option (if configured) that contains the provisioning server address.
- **Static:** You can manually configure the server address via phone user interface or web user interface.

For more information on the above methods, refer to

[Yealink_Skype_for_Business_HD_IP_Phones_Auto_Provisioning_Guide](#).

Upgrading Firmware

Yealink supports three methods to upgrade phone firmware:

- **Upgrade firmware via web user interface:** Download firmware in ROM format, and upload it to the Skype for Business phone via web user interface. This method can deploy small number of phones.
- **Upgrade firmware from provisioning server:** Download firmware in ROM format, and use centralized provisioning method to upgrade the firmware. This method requires setting up a provisioning server, and uses configuration files to provision the Skype for Business phone.
- **Upgrade firmware from Skype for Business Server:** Download firmware in CAB file format, and place the firmware on Skype for Business Server to provision the Skype for Business phone.

The following table lists the associated and latest firmware name for each Skype for Business phone model (X is replaced by the actual firmware version).

Phone Model	Associated Firmware Name	Firmware Name(.rom)	Firmware Name(.cab)
T48G	35.x.x.x.rom	35.8.1.65.rom	Yealink_ver_35.8.1.65.cab
T46G	28.x.x.x.rom	28.8.1.65.rom	Yealink_ver_28.8.1.65.cab
T42G/T41P	29.x.x.x.rom	29.8.1.65.rom	Yealink_ver_29.8.1.65.cab
T40P	54.x.x.x.rom	54.8.1.65.rom	Yealink_ver_54.8.1.65.cab

Note

You can download the latest firmware online:

<http://support.yealink.com/documentFront/forwardToDocumentFrontDisplayPage>.

Do not unplug the network and power cables when the Skype for Business phone is upgrading firmware.


Upgrading Firmware via Web User Interface

To manually upgrade firmware via web user interface, you need to store firmware to your local system in advance.

To upgrade firmware manually via web user interface:

1. Click on **Settings->Upgrade**.
2. Click **Browse** to locate the required firmware from your local system.
3. Click **Upgrade**.

A dialog box pops up to prompt "Firmware of the Skype for Business phone will be updated. It will take 5 minutes to complete. Please don't power off!".



4. Click **OK** to confirm the upgrade.

Note

Do not close and refresh the browser when the Skype for Business phone is upgrading firmware via web user interface.

Upgrading Firmware from the Provisioning Server

Phones support using FTP, TFTP, HTTP and HTTPS protocols to download configuration files and firmware from the provisioning server, and then upgrade firmware automatically.

Phones can download firmware stored on the provisioning server in one of two ways:

- Check for configuration files and then download firmware during startup.
- Automatically check for configuration files and then download firmware at a fixed interval or specific time.

Method of checking for configuration files is configurable.

Procedure

Configuration changes can be performed using the configuration files or locally.

Configuration	<y0000000000xx>.cfg	Configure the way for the Skype for Business phone to check for configuration
----------------------	---------------------	---

File		files. Parameters: auto_provision.power_on auto_provision.repeat.enable auto_provision.repeat.minutes auto_provision.weekly.enable auto_provision.weekly.begin_time auto_provision.weekly.end_time auto_provision.weekly.dayofweek
		Specify the access URL of firmware. Parameter: firmware.url
		Configure the phone to be reset to factory after an upgrade. Parameter: auto_provision.reset_factory.enable
Local	Web User Interface	Configure the way for the Skype for Business phone to check for configuration files. Navigate to: http://<phoneIPAddress>/servlet?p=settings-autop&q=load

Details of Configuration Parameters:

Parameters	Permitted Values	Default
auto_provision.power_on	0 or 1	1
Description: Triggers the power on feature to on or off. 0 -Off 1 -On If it is set to 1 (On), the Skype for Business phone will perform an auto provisioning process when powered on. Web User Interface: Settings->Auto Provision->Power On Phone User Interface:		

Parameters	Permitted Values	Default
None		
auto_provision.repeat.enable	0 or 1	0
<p>Description: Triggers the repeatedly feature to on or off.</p> <p>0-Off 1-On</p> <p>If it is set to 1 (On), the Skype for Business phone will perform an auto provisioning process repeatedly.</p> <p>Web User Interface: Settings->Auto Provision->Repeatedly</p> <p>Phone User Interface: None</p>		
auto_provision.repeat.minutes	Integer from 1 to 43200	1440
<p>Description: Configures the interval (in minutes) for the Skype for Business phone to perform an auto provisioning process repeatedly.</p> <p>Note: It works only if the value of the parameter "auto_provision.repeat.enable" is set to 1 (On).</p> <p>Web User Interface: Settings->Auto Provision->Interval(Minutes)</p> <p>Phone User Interface: None</p>		
auto_provision.weekly.enable	0 or 1	0
<p>Description: Triggers the weekly feature to on or off.</p> <p>0-Off 1-On</p> <p>If it is set to 1 (On), the Skype for Business phone will perform an auto provisioning process weekly.</p> <p>Web User Interface: Settings->Auto Provision->Weekly</p>		

Parameters	Permitted Values	Default
Phone User Interface: None		
auto_provision.weekly.begin_time	Time from 00:00 to 23:59	00:00
Description: Configures the begin time of the day for the Skype for Business phone to perform an auto provisioning process weekly. Note: It works only if the value of the parameter "auto_provision.weekly.enable" is set to 1 (On). Web User Interface: Settings->Auto Provision->Time Phone User Interface: None		
auto_provision.weekly.end_time	Time from 00:00 to 23:59	00:00
Description: Configures the end time of the day for the Skype for Business phone to perform an auto provisioning process weekly. Note: It works only if the value of the parameter "auto_provision.weekly.enable" is set to 1 (On). Web User Interface: Settings->Auto Provision->Time Phone User Interface: None		
auto_provision.weekly.dayofweek	0, 1, 2, 3, 4, 5, 6 or a combination of these digits	0123456
Description: Configures the days of the week for the Skype for Business phone to perform an auto provisioning process weekly. 0 -Sunday 1 -Monday 2 -Tuesday 3 -Wednesday 4 -Thursday		

Parameters	Permitted Values	Default
5-Friday 6-Saturday Example: auto_provision.weekly.dayofweek = 01 It means the Skype for Business phone will perform an auto provisioning process every Sunday and Monday. Note: It works only if the value of the parameter "auto_provision.weekly.enable" is set to 1 (On). Web User Interface: Settings->Auto Provision->Day of Week Phone User Interface: None		
firmware.url	URL within 511 characters	Blank
Description: Configures the access URL of the firmware file. Example: firmware.url = http://192.168.1.20/28.8.1.65.rom Note: If you change this parameter, the Skype for Business phone will reboot to make the change take effect. Web User Interface: Settings->Upgrade->Select and Upgrade Firmware Phone User Interface: None		
auto_provision.reset_factory.enable	0 or 1	0
Description: Enables or disables the IP phone to be reset to factory. 0-Disabled 1-Enabled Note: You can reset your phone to factory using this parameter once only.		

To configure the way for the Skype for Business phone to check for configuration files via web user interface:

1. Click on **Settings->Auto Provision.**

2. Make the desired change.

The screenshot shows the Yealink T46G Settings page. The 'Settings' tab is selected, and the 'Auto Provision' section is active. The left sidebar lists various settings categories: Preference, Time&Date, Upgrade, Auto Provision (selected), Configuration, Dial Plan, Voice, Tones, Phone Lock, Location, EXP Module, and BToE. The main content area displays the 'Auto Provision' settings. A 'NOTE' box on the right states: 'Auto Provision: The auto provision parameters for administrator. You can click here to get more guides.'

Setting	Value
PNP Active	<input checked="" type="radio"/> On <input type="radio"/> Off
DHCP Active	<input checked="" type="radio"/> On <input type="radio"/> Off
Custom Option(128~254)	160,161
DHCP Option Value	MS-UC-Client
Server URL	
User Name	
Password	*****
Common AES Key	*****
MAC-Oriented AES Key	*****
Zero Active	Disabled
Wait Time(0~100s)	5
Power On	<input checked="" type="radio"/> On <input type="radio"/> Off
Repeatedly	<input type="radio"/> On <input checked="" type="radio"/> Off
Interval(Minutes)	1440
Weekly	<input type="radio"/> On <input checked="" type="radio"/> Off
Time	00 : 00 -- 00 : 00
Day of Week	<input checked="" type="checkbox"/> Sunday <input checked="" type="checkbox"/> Monday <input checked="" type="checkbox"/> Tuesday <input checked="" type="checkbox"/> Wednesday <input checked="" type="checkbox"/> Thursday <input checked="" type="checkbox"/> Friday <input checked="" type="checkbox"/> Saturday

Buttons: Autoprovision Now

3. Click **Confirm** to accept the change.

When the "Power On" is set to **On**, the Skype for Business phone will check configuration files stored on the provisioning server during startup and then will download firmware from the server.

Updating Phone Firmware from Skype for Business Server

You can update firmware of T48G/T46G/T42G/T41P and T40P phones from Skype for Business Server. There are two ways to update firmware from Skype for Business Server:

- Automatic Update
- Manual Update

Before updating firmware from Skype for Business Server, you must upload the update package (*.CAB) to your Skype for Business Update Server in advance. For more information, refer to [Updating Phone Firmware from Microsoft Skype for Business Server](#).

Automatic Update

When the phone has been signed in, it will update firmware automatically in following situations:

Reboot

When the phone connects to the network and is powered on, it automatically checks if an update is available on Skype for Business Server. If there is an update available on Skype for Business Server, the phone will automatically update firmware.

Regular Update When a User Signs in

If the phone is powered on, and a user signs in, the phone automatically checks if an update is available on Skype for Business Server when the auto update timer (24 hours) expires. If there is an update available on Skype for Business Server, the phone will automatically update firmware.

Note

The Skype for Business phone will not perform an update check when a user signs in/out. It only performs an update check when the auto update timer (24 hours) expires. The timer will be cleared when the phone reboots or a user signs in/out.

If no user signs into the phone or there is no update available on Skype for Business Server, the Skype for Business phone will not update firmware automatically when the timer expires.

Update Checking Time

Update checking time defines a period of time for Skype for Business phone to automatically check a firmware update on Skype for Business Server.

Procedure

Update checking time can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure update checking time. Parameters: sfb.update_time
		Configure the phone to automatically upgrade the phone firmware. Parameters: features.device_update_auto.enable
Local	Web User Interface	Configure update checking time. Navigate to: <a href="http://<phoneIPAddress>/servlet?p=features-general&q=load">http://<phoneIPAddress>/servlet?p=features-general&q=load

Details of Configuration Parameters:

Parameters	Permitted Values	Default
sfb.update_time	Integer from 1 to 48	24
<p>Description:</p> <p>Configures the auto timer (in hours) for the Skype for Business phone to automatically check if there is a firmware update available on Skype for Business Server.</p> <p>If it is set to 24, the Skype for Business phone will check if a firmware update is available on the Skype for Business Server every 24 hours.</p> <p>Note: If you change this parameter, the Skype for Business phone will reboot to make the change take effect.</p> <p>Web User Interface:</p> <p>Features->General Information->Update Checking Time</p> <p>Phone User Interface:</p> <p>None</p>		
features.device_update_auto.enable	0 or 1	1
<p>Description:</p> <p>Configure the phone to automatically upgrade the phone firmware when the auto timer expires.</p> <p>0-Disabled</p> <p>1-Enabled</p> <p>Note: Make sure the phone has been signed in and a firmware is available on the Skype for Business Server.</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p> <p>None</p>		

To configure update checking time via web user interface:

1. Click on **Features->General Information**.

2. Enter the desired value in the **Update Checking Time** field.

The screenshot shows the Yealink T46G web interface. The 'Features' tab is selected, and the 'General Information' section is active. The 'Update Checking Time' field is highlighted with a red box and set to 24. The interface includes a sidebar with navigation options like General Information, Audio, Remote Control, Bluetooth, and LED. The main area lists various settings such as Call Waiting, Key As Send, Hotline Number, and others. A 'NOTE' section on the right provides additional information about Call Waiting and Key As Send.

A dialog box pops up to prompt that settings will take effect after a reboot.

3. Click **Confirm** to accept the change.

Manual Update

You can initiate an update immediately, just power off the Skype for Business phone and power on it again. The phone will boot up, check for updates and apply the updates. You can also trigger an update manually via phone user interface.

To trigger an update manually via phone user interface:

1. Press **Menu**-> **Advanced** (default password: admin) -> **Firmware Update**.
2. Press the **Update** soft key.

The LCD screen prompts "Update Now?".



3. Press the **OK** soft key to confirm the update.

If there is no update available on Skype for Business Server, the LCD screen prompts "The firmware is the latest".



Configuring Basic Features

This chapter provides information for making configuration changes for the following basic features:

- [Signing into Skype for Business](#)
- [Remembering Password](#)
- [Signing Out of Skype for Business](#)
- [Updating Status Automatically](#)
- [Always On Line](#)
- [Power Indicator LED](#)
- [Contrast](#)
- [Backlight](#)
- [Bluetooth](#)
- [Time and Date](#)
- [Language](#)
- [Key As Send](#)
- [Dial Plan](#)
- [Hotline](#)
- [Contact Management](#)
- [Call Log](#)
- [Dial Search Delay](#)
- [Live Dialpad](#)
- [Call Waiting](#)
- [Auto Answer](#)
- [Busy Tone Delay](#)
- [Return Code When Refuse](#)
- [Early Media](#)
- [180 Ring Workaround](#)
- [Call Hold](#)
- [Call Forward](#)
- [Team-Call Group](#)
- [Response Group](#)
- [Allow Trans Exist Call](#)

- [Call Number Filter](#)
- [Allow Mute](#)
- [Voice Mail without PIN](#)
- [E911](#)
- [Boss-Admin Feature](#)
- [Calendar](#)
- [BToE](#)
- [EXP40 Expansion Module](#)

Signing into Skype for Business

Skype for Business users are authenticated against Microsoft Active Directory Domain Service. The following four sign-in methods are available.

- **User Sign-in:** This method uses the user's credentials (sign-in address, user name, and password) to sign into Skype for Business Server. This sign-in method is applicable to Onprem account and Online account.
- **PIN Authentication:** This method uses the user's phone number (or extension) and personal identification number (PIN) to sign into Skype for Business Server. This sign-in method is only applicable to Onprem account.
- **Web Sign-in:** This method uses the unique website shown on the phone to sign in. This sign-in method is only applicable to Online account.
- **Sign in via PC:** when your phone is paired with your computer using Better Together over Ethernet (BToE), use the Skype for Business client to sign in. This sign-in method is applicable to Onprem account and Online account.

Note

If the phone reboots after successful login, the login credentials from the previous Sign-In will be cached. User can sign in successfully without reentering the credentials.

User Sign-in

You can sign into Microsoft Skype for Business on your phone with your login credentials, which includes your address, username, and password. Your system administrator provides you with your login credentials.

Procedure

User sign-in method can be configured using the configuration files or locally.

Configuration File	<MAC>.cfg	Configure user sign-in method. Parameters: features.user_sign_in.enable account.sign_in.server_address account.sign_in.user_name account.sign_in.password
Local	Web User Interface	Configure user sign-in method. Navigate to: http://<phoneIPAddress>/servlet? p=account-register-lync&q=load &acc=0
	Phone User Interface	Configure user sign-in method.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
features.user_sign_in.enable	0 or 1	1
Description: Enables or disables the user to sign into the phone using User Sign-in method. 0 -Disabled 1 -Enabled Web User Interface: None Phone User Interface: None		
account.sign_in.server_address	SIP URI	Blank
Description: Configures the sign-in address for the user sign-in method. The value format is username@domain.com. Example: account.sign_in.server_address= 2216@yealinkuc.com Web User Interface:		

Parameters	Permitted Values	Default
Account->Register->Login address Phone User Interface: Sign in->User Sign-in->Address		
account.sign_in.user_name	String within 128 characters	Blank
Description: Configures the user name for the user sign-in method. The value format is username@domain.com or username@domain, domain.com\username or domain\username. Example: account.sign_in.user_name= 2216@yealinkuc.com Web User Interface: Account->Register->Register Name Phone User Interface: Sign in->User Sign-in->UserName		
account.sign_in.password	String within 99 characters	Blank
Description: Configures the password for the user sign-in method. Web User Interface: Account->Register->Password Phone User Interface: Sign in->User Sign-in->Password		

To sign into the Skype for Business Server using user sign-in method via web user interface:

1. Click on **Account->Register**.
2. Select **User Sign in** from the pull-down list of **Mode**.
3. Enter your Skype for Business user's sign-in address (e.g., 2216@yealinkuc.com) in the **Login address** field.
4. Enter your Skype for Business user name (e.g., 2216@yealinkuc.com) in the **Register Name** field.

- Enter the sign-in password in the **Password** field.

The screenshot shows the Yealink T46G web interface. The 'Account' tab is selected. Under the 'Mode' dropdown, 'User Sign in' is chosen. The 'Register Status' is set to 'Disabled'. The 'Login address' and 'Register Name' fields are both filled with '2216@yealinkuc.com'. The 'Password' field is masked with dots. There are 'Sign In', 'Sign Out', and 'Cancel' buttons at the bottom. A 'NOTE' box on the right explains the fields: 'Login address' is provided by the operator login address, 'Register Name' is provided by the operator register name, and 'Password' is provided by the operator Password. A link to get more guides is also present.

- Click **Sign In** to accept the change.

To sign into the Skype for Business Server using user sign-in method via phone user interface:

- Press the **Sign in** soft key.
- Press **◀** or **▶** or the **Switch** soft key to select **User Sign-in**.
- Enter your Skype for Business user's sign-in address (e.g., 2216@yealinkuc.com) in the **Address** field.
- Enter your Skype for Business user name (e.g., 2216@yealinkuc.com) in the **UserName** field.
- Enter the sign-in password in the **Password** field.

The screenshot shows the 'Sign in' screen on a phone's user interface. The 'Sign in' dropdown is set to 'User Sign-in'. The 'Address' field is filled with '2216@yealinkuc.com'. The 'UserName' field is filled with '2216@yealinkuc.com'. The 'Password' field is masked with dots. At the bottom, there are 'Back', 'abc', 'Delete', and 'Sign in' soft keys.

- Press the **Sign in** soft key.

PIN Authentication

You can sign into Skype for Business on your phone with your PIN Authentication credentials. Your system administrator provides you with your PIN Authentication credentials.

Procedure

PIN Authentication can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure PIN Authentication method. Parameter: features.pin_authentication.enable
	<MAC>.cfg	Configure PIN Authentication method. Parameter: account.sign_in.pin_number
		Configures the PIN for the PIN Authentication. Parameter: account.sign_in.pin_password
Local	Web User Interface	Configure PIN Authentication method. Navigate to: <a href="http://<phoneIPAddress>/servlet?p=account-register-lync&q=load&acc=0">http://<phoneIPAddress>/servlet?p=account-register-lync&q=load&acc=0
		Configure the certificate address of Skype for Business Server. Navigate to: <a href="http://<phoneIPAddress>/servlet?p=features-general&q=load">http://<phoneIPAddress>/servlet?p=features-general&q=load
	Phone User Interface	Configure PIN Authentication.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
features.pin_authentication.enable	0 or 1	1
Description: Enables or disables the user to sign into the phone using PIN Authentication method. 0 -Disabled 1 -Enabled		

Parameters	Permitted Values	Default
Web User Interface: None Phone User Interface: None		
account.sign_in.pin_number	String within 128 characters	Blank
Description: Configures the Skype for Business phone's extension for the PIN Authentication method. Web User Interface: Account->Register->Extension Phone User Interface: Sign in->PIN Authentication->Extension		
account.sign_in.pin_password	String within 99 characters	Blank
Description: Configures the PIN for the PIN Authentication method. Web User Interface: Account->Register->Pin Phone User Interface: Sign in->PIN Authentication->PIN		

To sign into the Skype for Business Server using PIN Authentication method via web user interface:

1. Click on **Account->Register**.
2. Select **Pin Authentication** from the pull-down list of **Mode**.
3. Enter your Skype for Business user's phone number or extension (e.g., 2216) in the **Extension** field.

4. Enter your personal identification number (e.g., user2216) in the **Pin** field.

The screenshot shows the 'Account' tab in the Yealink T46G web interface. The 'Mode' is set to 'Pin Authentication'. The 'Pin' field is filled with '2216'. The 'Sign In' button is highlighted. A 'NOTE' section on the right provides information about login address, register name, and password.

5. Click **Sign In** to accept the change.

If there is no DHCP Server in your environment, you may fail to sign in phone using PIN Authentication method, you can manually configure the certificate address of Skype for Business Server to make the phone sign in successfully.

To manually configure the certificate address of Skype for Business Server via web user interface:

1. Click on **Features->General Information**.
2. Enter the certificate address of Skype for Business Server in the **SFB Cert Service URL** field.

The screenshot shows the 'Features' tab in the Yealink T46G web interface, specifically the 'General Information' section. The 'SFB Cert Service URL' field is highlighted with a red box and contains the value 'https://xmpool.yealinkuc.co'. The 'Confirm' button is highlighted.

3. Click **Confirm** to accept the change.

To sign into Skype for Business Server using PIN Authentication method via phone user interface:

1. Press the **Sign in** soft key.
2. Press ◀ or ▶, or the **Switch** soft key to select **PIN Authentication**.
3. Enter your phone number or extension (e.g., 2216) in the **Extension** field.
4. Enter your PIN in the **PIN** field.

5. Press the **Sign in** soft key.

Web Sign-in

You can sign into your Skype for Business Online account using the Web Sign-In method, which allows you to sign into the phone with your Skype for Business Online account using a web browser. Your system administrator provides you with your login credentials.

Procedure

Web sign-in can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the Server URL for device pairing. Parameter: features.device_pairing.url
		Configure web sign-in method. Parameter: features.device_pairing_for_online.enable
Local	Web User Interface	Configure web sign-in method. Navigate to: http://<phoneIPAddress>/servlet?p=account-register-lync&q=load&acc=0
	Phone User Interface	Configure web sign-in method.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
features.device_pairing_for_online.enable	0 or 1	1
Description: Enables or disables the user to sign into the phone using web sign-in method. 0 -Disabled 1 -Enabled Web User Interface: Features->General Information->Web Sign in Phone User Interface: None		
features.device_pairing.url	URL within 512characters	https://bootstrap.pinauth.services.skypeforbusiness.com /
Configures the Server URL for device pairing, so that you can sign into the phone using web sign-in method. Example: features.device_pairing.url= https://bootstrap.pinauth.services.skypeforbusiness.com/		

To configure web sign-in via web user interface:

1. Click on **Features->General Information**.
2. Select the desired value from the pull-down list of **Web Sign in**.
 - If it is enabled, you can sign into the Skype for Business Server using web sign-in method.

- If it is disabled, you cannot sign into the Skype for Business Server using web sign-in method.

The screenshot shows the Yealink T46G web interface with the 'Features' tab selected. The 'General Information' section is expanded, showing various settings. The 'Web Sign in' setting is highlighted with a red box and is set to 'Enabled'. Other settings include 'Call Waiting' (Enabled), 'Key As Send' (#), 'Hotline Number' (empty), 'Hotline Delay(0~10s)' (4), 'Busy Tone Delay (Seconds)' (0), 'Return code when refuse' (603 (Decline)), 'Diversion/History-Info' (Disabled), 'Auto-Logout Time(1~1000min)' (5), 'Call Number Filter' (empty), 'Voice Mail Tone' (Enabled), 'DHCP Hostname' (SIP-T46G), 'E911 Location Tip' (Enabled), 'Update Checking Time' (24), 'Use DHCP Option 120' (Disabled), 'SFB Cert Service URL' (empty), 'Enable SFB Automation' (Disabled), 'SFB Inactive Time' (5), 'SFB Away Time' (5), 'Remember Password' (Disabled), and 'History Record Contacts Avatar' (Enabled). A 'NOTE' section on the right explains 'Call Waiting' and 'Key As Send'.

3. Click **Confirm** to accept the change.


To sign into Skype for Business Server using Web Sign-in method via phone user interface:

1. Press the **Sign in** soft key.
2. Press ◀, ▶ or the **Switch** soft key to select **Web Sign-in**.


The screenshot shows the phone's 'Sign in' screen. The 'Sign in:' dropdown is set to 'Web Sign-in'. The screen prompts the user to click on 'Sign in' to get the pairing code and URL. At the bottom, there are three soft keys: 'Back', 'Switch', and 'Sign in'.

3. Press the **Sign in** soft key.

The screen will show the pairing code and URL.




4. Enter the URL (e.g., <http://aka.ms/sphone>) into your web browser.
5. On the Skype for Business Authentication website, enter your email address (e.g., zhangdx@example.com) in the **Email address** field.




6. Click **Verify email** to check the validity of the email address.

The sign-in screen will appear if the email address is valid.




7. Enter your Online account and password.
8. (Optional) Check the **Keep me signed in** checkbox, so that you don't need to enter a password next time.
9. Click **Sign in**.
10. Enter the pairing code generated on the phone (e.g., GN7GUR3BK) into the web browser.



The screenshot shows a 'Device Login' window. At the top, it says 'Device Login'. Below that, it prompts the user to 'Enter the code that you received from the application on your device'. A text input field contains the code 'GN7GUR3BK'. Below the input field, it says 'Yealink Skype for Business Certified Phone' and 'Application publisher:'. A note below that says 'Click cancel if you received this code from a different application.' At the bottom, there are two buttons: 'Continue' (blue) and 'Cancel' (grey).

11. Click **Continue**.



The screenshot shows an account selection screen for 'Yealink Skype for Business Certified Phone'. It displays a user profile for 'zhangdaxi' with the email 'zhangdx@studunipaacid.onmicroso...' and the status 'Signed in'. Below the profile, there is a blue circle with a white plus sign and the text 'Use another account'.

12. Click the account to sign in.

A confirmation message is displayed when your phone successfully signs into Skype for Business.

Signing in via PC

When your phone and your computer are paired using Better Together over Ethernet (BToE), you can sign into your phone using the Skype for Business client on your computer. For more information, refer to [BToE](#) on page 250.

Remembering Password

You can enable the remember password feature, so that a **Remember Password** option will appear at the phone login screen.

(User Sign-in method)

(PIN Authentication method)

Remember password feature is disabled by default, and it is configurable via web user interface only.

Procedure

Remember password can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the remember password feature. Parameters: features.remember_password.enable
Local	Web User Interface	Configure the remember password

		feature. Navigate to: <a href="http://<phoneIPAddress>/servlet?p=features-general&q=load">http://<phoneIPAddress>/servlet?p=features-general&q=load
--	--	--

Details of Configuration Parameters:

Parameters	Permitted Values	Default
features.remember_password.enable	0 or 1	0
Description: Enables or disables a Remember Password option to appear at the phone login screen. 0 -Disabled 1 -Enabled If it is set to 1 (Enabled), a Remember Password option will appear at the phone login screen. Web User Interface: Features->General Information->Remember Password		

To configure remember password feature via web user interface:

1. Click on **Features->General Information**.

2. Select **Enabled** from the pull-down list of **Remember Password**.

The screenshot shows the Yealink T46G web interface with the 'Features' tab selected. The 'General Information' section is expanded, showing various settings. The 'Remember Password' option is highlighted with a red box and is set to 'Enabled'. Other settings include 'Call Waiting' (Enabled), 'Key As Send' (#), 'Hotline Number' (empty), 'Hotline Delay(0~10s)' (4), 'Busy Tone Delay (Seconds)' (0), 'Return code when refuse' (603 (Decline)), 'Diversion/History-Info' (Disabled), 'Auto-Logout Time(1~1000min)' (5), 'Call Number Filter' (empty), 'Voice Mail Tone' (Enabled), 'DHCP Hostname' (SIP-T46G), 'E911 Location Tip' (Enabled), 'Update Checking Time' (24), 'Use DHCP Option 120' (Disabled), 'SFB Cert. Service URL' (empty), 'Enable SFB Automation' (Disabled), 'SFB Inactive Time' (5), 'SFB Away Time' (5), 'Web Sign in' (Enabled), and 'History Record Contacts Avatar' (Enabled). A 'NOTE' section on the right provides information about 'Call Waiting' and 'Key As Send'.

3. Click **Confirm** to accept the change.
- A dialog box pops up to prompt you that this configuration will take effect after a reboot.
4. Click **OK** to reboot the phone.

Signing Out of Skype for Business

Procedure

Sign-out can be configured locally.

Local	Web User Interface	Sign out of Skype for Business Server. Navigate to: <code>http://<phoneIPAddress>/servlet?p=account-register-lync&q=load&acc=0</code>
	Phone User Interface	Sign out of Skype for Business Server.

To sign out of Skype for Business Server via web user interface:

1. Click on **Account**->**Register**.

The screenshot shows the Yealink T46G web interface. The top navigation bar includes 'Status', 'Account', 'Network', 'Features', 'Settings', 'Directory', and 'Security'. The 'Account' tab is selected, and the 'Register' sub-tab is active. The 'Mode' dropdown is set to 'User Sign in'. The 'Register Status' is 'Registered'. The 'Login address' and 'Register Name' fields both contain '2216@yealinkuc.com'. The 'Password' field is masked with dots. The 'Sign In' and 'Sign Out' buttons are at the bottom, with 'Sign Out' highlighted by a red rectangle. A 'NOTE' section on the right provides instructions for login, register name, and password.

2. Click **Sign Out** to accept the change.

To sign out of Skype for Business Server via phone user interface:

1. Press the **Status** soft key.
2. Press or to select **Sign Out**.

The phone signs out of Skype for Business Server.

After you sign out of Skype for Business Server, the account-related features (calling, viewing Skype for Business contacts, calendar, etc.) are not available. However, you can still use other phone features.

Updating Status Automatically

The Skype for Business Server helps you keep your presence information up-to-date by monitoring idle time of your phone. Phone status will be Inactive when your phone has been idle for the designated time. Phone status will change from Inactive to Away after another designated time.

Procedure

Updating status automatically can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configures the inactive time (in minutes) of the Skype for Business phone. Parameters: sfb.presence.inactive_time sfb.presence.away_time
Local	Web User Interface	Configures the inactive time (in minutes) of the Skype for Business phone. Navigate to: <a href="http://<phoneIPAddress>/servlet?p=features-general&q=load">http://<phoneIPAddress>/servlet?p=features-general&q=load

Details of Configuration Parameters:

Parameters	Permitted Values	Default
sfb.presence.inactive_time	Integer from 5 to 360	5
<p>Description:</p> <p>Configures the inactive time (in minutes) of the Skype for Business phone, after which the phone will change its status to Inactive automatically.</p> <p>Example:</p> <p>If it is set to 5, the Skype for Business phone will change its status to Inactive automatically when inactive time reaches 5 minutes.</p> <p>Note: If you change this parameter, the Skype for Business phone will reboot to make the change take effect.</p> <p>Web User Interface:</p> <p>Features->General Information->SFB Away Time</p> <p>Phone User Interface:</p> <p>None</p>		
sfb.presence.away_time	Integer from 5 to 360	5
<p>Description:</p> <p>Configures the inactive time (in minutes) of the Skype for Business phone, after which the phone will change its status from Inactive to Away automatically.</p> <p>Example:</p> <p>If it is set to 5, the Skype for Business phone whose status is Inactive will change to Away automatically after 5 minutes.</p> <p>Note: If you change this parameter, the Skype for Business phone will reboot to make the change take effect.</p> <p>Web User Interface:</p> <p>Features->General Information->SFB Away Time</p> <p>Phone User Interface:</p> <p>None</p>		

To configure the automatic status updating time via web user interface:

1. Click on **Features->General Information**.
2. Enter the desired time in the **SFB Inactive Time** field.

3. Enter the desired time in the **SFB Away Time** field.

The screenshot shows the Yealink T46G web interface. The 'Features' tab is selected. Under the 'General Information' section, the 'SFB Inactive Time' and 'SFB Away Time' fields are highlighted with a red box. Both fields are set to 5. The 'SFB Away Time' field is the one mentioned in step 3. Other fields like 'Call Waiting', 'Key As Send', 'Hotline Number', 'Hotline Delay', 'Busy Tone Delay', 'Return code when refuse', 'Diversion/History-Info', 'Auto-Logout Time', 'Call Number Filter', 'Voice Mail Tone', 'DHCP Hostname', 'E911 Location Tip', 'Update Checking Time', 'Use DHCP Option 120', 'SFB Cert. Service URL', 'Enable SFB Automation', 'Web Sign in', 'Remember Password', and 'History Record Contacts Avatar' are also visible.

4. Click **Confirm** to accept the change.

Always On Line

Always on line feature allow Skype for Business phones to maintain the current status until you manually change it. For example, the current status of the Skype for Business phone is Available, if the always online feature is enabled, then the Skype for Business phone status will stay Available until you manually change it.

Procedure

Always on line can be configured using the configuration files or locally.


Configuration File	<y0000000000xx>.cfg	Configure always on line. Parameter: sfb.always_online.enable
Local	Web User Interface	Configure always on line. Navigate to: http://<phoneIPAddress>/servlet?p=account-basic&q=load&acc=0

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
sfb.always_online.enable	0 or 1	0
<p>Description:</p> <p>Enables or disables the Skype for Business phone to maintain current status until you manually change it.</p> <p>0-Disabled 1-Enabled</p> <p>Note: If your phone status is DND before dialing an emergency number, then the Skype for Business phone status will be changed to available after the emergency call even if the value of this parameter is set to 1 (Enabled).</p> <p>Web User Interface:</p> <p>Account->Basic->Always On Line</p> <p>Phone User Interface:</p> <p>Menu->Basic->Always Online</p>		

To configure always on line via web user interface:

1. Click on **Account->Basic**.
2. Select the desired value from the pull-down list of **Always On Line**.



3. Click **Confirm** to accept the change.

To configure always on line via phone user interface:

1. Press **Menu->Basic->Always Online**.
2. Press **◀** or **▶**, or the **Switch** soft key to select the desired value from the **Always Online** field.
3. Press the **Save** soft key to accept the change.

Power Indicator LED

Power indicator LED indicates power status and phone status.

There are six configuration options for power indicator LED:

Common Power Light On

Common Power Light On allows the power indicator LED to be turned on.

Ring Power Light Flash

Ring Power Light Flash allows the power indicator LED to flash when the Skype for Business phone receives an incoming call.

Voice Mail Power Light Flash

Voice Mail Power Light Flash allows the power indicator LED to flash when the Skype for Business phone receives a voice mail.

Mute Power Light On

Mute Power Light On allows the power indicator LED to flash when a call is mute.

Hold/Held Power Light On

Hold/Held Power Light On allows the power indicator LED to flash when a call is placed on hold or is held.

Talk/Dial Power Light On

Talk/Dial Power Light On allows the power indicator LED to be turned on when the Skype for Business phone is busy.

Procedure

Power indicator LED can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	<p>Configure the power indicator LED.</p> <p>Parameters:</p> <p>phone_setting.common_power_led_enable</p> <p>phone_setting.ring_power_led_flash_enable</p> <p>phone_setting.mail_power_led_flash_enable</p> <p>phone_setting.mute_power_led_flash_enable</p> <p>phone_setting.hold_and_held_power_led_flash_enable</p> <p>phone_setting.talk_and_dial_power_led_enable</p>
---------------------------	---------------------	---

Local	Web User Interface	Configure the power indicator LED. Navigate to: <a href="http://<phoneIPAddress>/servlet?p=features-powerled&q=load">http://<phoneIPAddress>/servlet?p=features-powerled&q=load
--------------	--------------------	--


Details of Configuration Parameters:

Parameters	Permitted Values	Default
phone_setting.common_power_led_enable	0 or 1	0
Description: Enables or disables the power indicator LED to be turned on. 0 -Disabled (power indicator LED is off) 1 -Enabled (power indicator LED is solid red) Web User Interface: Features->LED->Common Power Light On Phone User Interface: None		
phone_setting.ring_power_led_flash_enable	0 or 1	1
Description: Enables or disables the power indicator LED to flash when the Skype for Business phone receives an incoming call. 0 -Disabled (power indicator LED does not flash) 1 -Enabled (power indicator LED fast flashes (300ms) red) Web User Interface: Features->LED->Ring Power Light Flash Phone User Interface: None		
phone_setting.mail_power_led_flash_enable	0 or 1	0
Description: Enables or disables the power indicator LED to flash when the Skype for Business phone receives a voice mail. 0 -Disabled (power indicator LED does not flash) 1 -Enabled (power indicator LED slow flashes (1000ms) red) Web User Interface:		

Parameters	Permitted Values	Default
Features->LED->Voice Mail Power Light Flash Phone User Interface: None		
phone_setting.mute_power_led_flash_enable	0 or 1	0
Description: Enables or disables the power indicator LED to flash when a call is mute. 0 -Disabled (power indicator LED does not flash) 1 -Enabled (power indicator LED fast flashes (300ms) red) Web User Interface: Features->LED->Mute Power Light On Phone User Interface: None		
phone_setting.hold_and_held_power_led_flash_enable	0 or 1	0
Description: Enables or disables the power indicator LED to flash when a call is placed on hold or is held. 0 -Disabled (power indicator LED does not flash) 1 -Enabled (power indicator LED fast flashes (500ms) red) Web User Interface: Features->LED->Hold/Held Power Light On Phone User Interface: None		
phone_setting.talk_and_dial_power_led_enable	0 or 1	0
Description: Enables or disables the power indicator LED to be turned on when the Skype for Business phone is busy. 0 -Disabled (power indicator LED is off) 1 -Enabled (power indicator LED is solid red) Web User Interface: Features->LED->Talk/Dial Power Light On Phone User Interface: None		

To configure the power Indicator LED via web user interface:

1. Click on **Features**->**LED**.
2. Select the desired value from the pull-down list of **Common Power Light On**.
3. Select the desired value from the pull-down list of **Ring Power Light Flash**.
4. Select the desired value from the pull-down list of **Voice Mail Power Light Flash**.
5. Select the desired value from the pull-down list of **Mute Power Light Flash**.
6. Select the desired value from the pull-down list of **Hold/Held Power Light Flash**.
7. Select the desired value from the pull-down list of **Talk/Dial Power Light On**.



8. Click **Confirm** to accept the change.

Contrast

Contrast determines the readability of the texts displayed on the LCD screen. Adjusting the contrast to a comfortable level can optimize the screen viewing experience. When configured properly, contrast allows users to read the LCD's display with minimal eyestrain. You can configure the LCD's contrast of T40P and EXP40 connected to T48G/T46G Skype for Business phones. Make sure the expansion module has been connected to the Skype for Business phone before adjustment. Contrast is not applicable to T42G/T41P Skype for Business phones.

Procedure

Contrast can be configured using the configuration files or locally.



Configuration File	<y0000000000xx>.cfg	Configure the contrast of the LCD screen. Parameter: phone_setting.contrast
Local	Web User Interface	Configure the contrast of the LCD screen. Navigate to: <a href="http://<phoneIPAddress>/servlet?p">http://<phoneIPAddress>/servlet?p

		=settings-preference&q=load
	Phone User Interface	Configure the contrast of the LCD screen.

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
phone_setting.contrast	Integer from 1 to 10	6
<p>Description:</p> <p>Configures the contrast of the LCD screen.</p> <p>For T48G/T46G Skype for Business phones, it configures the LCD's contrast of the connected EXP40 only.</p> <p>For T40P Skype for Business phones, it configures the LCD's contrast of the Skype for Business phone.</p> <p>Note: We recommend that you set the contrast of the LCD screen to 6 as a more comfortable level. It is not applicable to T42G/T41P Skype for Business phones.</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p> <p>Menu->Basic->Display->Contrast</p>		

To configure the contrast via phone user interface:

1. Press **Menu->Basic->Display->Contrast**.
If EXP40 is not connected to the phone, the Contrast Setting screen displays "No EXP".
2. Press  or , or the **Switch** soft key to increase or decrease the intensity of contrast.
The default contrast level is "6".
3. Press the **Save** soft key to accept the change.

Backlight

Backlight determines the brightness of the LCD screen display, allowing users to read easily in dark environments. Backlight time specifies the delay time to change the intensity of the LCD screen when the Skype for Business phone is inactive. Backlight turns off quickly if a short backlight time is configured, this may not give users enough time to read messages. Backlight time is applicable to T48G/T46G/T42G/T41P/T40P Skype for Business phones and EXP40 connected to T48G/T46G Skype for Business phones.

Backlight Active Level is used to adjust the backlight intensity of the LCD screen when the phone is active. Backlight Inactive Level is used to adjust the backlight intensity of the LCD screen when the phone is inactive. Backlight Active Level is applicable to T48G/T46G Skype for Business phones and the connected EXP40. Backlight Inactive Level is only applicable to T48G and T46G Skype for Business phones.

Note

Backlight time is configurable on Skype for Business Server only.

Before you adjust the LCD's backlight of expansion module, make sure the expansion module has been connected to the Skype for Business phone.

The following table lists available methods and configuration options to configure the backlight of phone models.

Phone Model (and the connected expansion module)	Configuration Methods	Configuration Options
T48G/T46G	Configuration Files Web User Interface Phone User Interface	Backlight Inactive Level
T48G(EXP40)/T46G (EXP40)	Configuration Files Web User Interface Phone User Interface	Backlight Active Level

Procedure

Backlight can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the backlight of the LCD screen. Parameters: phone_setting.active_backlight_level phone_setting.inactive_backlight_level
Local	Web User Interface	Configure the backlight of the LCD screen. Navigate to: <a href="http://<phoneIPAddress>/servlet?p=settings-preference&q=load">http://<phoneIPAddress>/servlet?p=settings-preference&q=load
	Phone User Interface	Configure the backlight of the LCD screen.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
phone_setting.active_backlight_level	Integer from 1 to 10	10

Description:

Configures the intensity of the LCD screen when the phone is active.

10 is the highest intensity.

For T48G/T46G Skype for Business phones, it configures the LCD's intensity of the Skype for Business phone and the connected EXP40.

Note: It is applicable to T48G/T46G Skype for Business phones and the connected EXP40.

Web User Interface:

Settings->Preference->Backlight Active Level

Phone User Interface:

Menu->Basic->Display->Backlight->Backlight Active Level

phone_setting.inactive_backlight_level

0 or 1

1

Description:

Configures the intensity of the LCD screen when the Skype for Business phone is inactive.

0-Off

1-Low

Note: It is only applicable to T48G and T46G Skype for Business phones.

Web User Interface:


Settings->Preference->Backlight Inactive Level

Phone User Interface:

Menu->Basic->Display->Backlight->Inactive Level





To configure the backlight via web user interface:

1. Click on **Settings->Preference**.
2. Select the desired value from the pull-down list of **Backlight Inactive Level**.
3. Select the desired value from the pull-down list of **Backlight Active Level**.



4. Click **Confirm** to accept the change.

To configure the backlight via phone user interface:

1. Press **Menu->Basic->Display->Backlight**.
2. Press  or , or the **Switch** soft key to select the desired level from the **Backlight Active Level** field.
3. Press  or , or the **Switch** soft key to select the desired value from the **Inactive Level** field.
4. Press the **Save** soft key to accept the change.

Bluetooth

Bluetooth enables low-bandwidth wireless connections within a range of 10 meters (32 feet). The best performance is in the 1 to 2 meters (3 to 6 feet) range. You can activate/deactivate the Bluetooth mode and then pair and connect the Bluetooth headset with your phone. For more information, refer to the [Yalink phone-specific user guide](#). It is only applicable to T48G/T46G Skype for Business phones.

You can personalize the Bluetooth device name for the Skype for Business phone. The pre-configured Bluetooth device name will display in scanning list of other devices. It is helpful for the other Bluetooth devices to identify and pair with your Skype for Business phone.

Note

To use this feature on T48G/T46G Skype for Business phones, make sure the Bluetooth USB dongle is properly connected to the USB port on the back of the phone.

Procedure

Bluetooth mode can be configured using the configuration files or locally.

Configuration File	<y000000000xx>.cfg	Configure Bluetooth mode. Parameter: features.bluetooth_enable
		Configure the Bluetooth device name. Parameter: features.bluetooth_adapter_name
Local	Web User Interface	Configure Bluetooth mode. Navigate to: For T48G/T46G Skype for Business phones: http://<phoneIPAddress>/servlet?p=features-bluetooth&q=load
	Phone User Interface	Configure Bluetooth mode.

		Configure the Bluetooth device name.
--	--	--------------------------------------


Details of the Configuration Parameter:

Parameter	Permitted Values	Default
features.bluetooth_enable	0 or 1	0
Description: Triggers Bluetooth mode to on or off. 0 -Off 1 -On Note: It is only applicable to T48G/T46G Skype for Business phones. Web User Interface: Features->Bluetooth->Bluetooth Active Phone User Interface: Menu->Basic->Bluetooth->Bluetooth		
features.bluetooth_adapter_name	String within 64 characters	Refer to the following content
Description: Configures the Bluetooth device name. For T48G Skype for Business phones: The default value is Yealink-T48G. For T46G Skype for Business phones: The default value is Yealink-T46G. Note: It works only if the value of the parameter "features.bluetooth_enable" is set to 1 (On). It is only applicable to T48G/T46G Skype for Business phones. Web User Interface: None Phone User Interface: Menu->Basic->Bluetooth->Bluetooth (On)->Edit My Device Information->Device Name		

To active the Bluetooth mode via web user interface:

1. Click on **Features->Bluetooth**.

2. Select the desired value from the pull-down list of **Bluetooth Active**.



3. Click **Confirm** to accept the change.

To active the Bluetooth mode via phone user interface:

1. Press **Menu->Basic->Bluetooth**.
2. Press **Left Arrow** or **Right Arrow**, or the **Switch** soft key to select **On** from the **Bluetooth** field.
3. Press the **Save** soft key to accept the change.

To edit device information via phone user interface:

1. Press **Menu->Basic->Bluetooth**.
2. Press **Left Arrow** or **Right Arrow**, or the **Switch** soft key to select **On** from the **Bluetooth** field.
3. Press the **Save** soft key to accept the change.
4. Select **Edit My Device Information** and then press the **Enter** soft key.

The LCD screen displays the device name and MAC address. The MAC address cannot be edited.

5. Enter the desired name in the **Device Name** field.
6. Press the **Save** soft key to accept the change or the **Back** soft key to cancel.

Time and Date

Phones maintain a local clock and calendar. Time and date are displayed on the idle screen of phones.

The following table lists available configuration methods for time and date.

Option	Configuration Methods
NTP time server	Configuration Files Web User Interface Phone User Interface
Time Zone	Configuration Files Web User Interface Phone User Interface

Option	Configuration Methods
Time	Web User Interface Phone User Interface
Time Format	Configuration Files Web User Interface Phone User Interface
Date	Web User Interface Phone User Interface
Date Format	Configuration Files Web User Interface Phone User Interface
Daylight Saving Time	Configuration Files Web User Interface

NTP Time Server

A time server is a computer server that reads the actual time from a reference clock and distributes this information to the clients in a network. The Network Time Protocol (NTP) is the most widely used protocol that distributes and synchronizes time in the network.

The phones synchronize the time and date automatically from the NTP time server by default. The NTP time server address can be offered by the DHCP server or configured manually. NTP by DHCP Priority feature can configure the priority for the phone to use the NTP time server address offered by the DHCP server or configured manually.

Time Zone

A time zone is a region on Earth that has a uniform standard time. It is convenient for areas in close commercial or other communication to keep the same time. When configuring the phone to obtain the time and date from the NTP time server, you must set the time zone.

Procedure

NTP time server and time zone can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the NTP server. Parameters: phone_setting.hide_ntp_server.enable
---------------------------	---------------------	---

Configuration File	<MAC>.cfg	Configure NTP by DHCP priority feature and DHCP time feature. Parameters: local_time.manual_ntp_srv_prior local_time.dhcp_time
		Configure the NTP server, time zone. Parameters: local_time.ntp_server1 local_time.ntp_server2 local_time.interval local_time.time_zone local_time.time_zone_name
Local	Web User Interface	Configure NTP by DHCP priority feature and DHCP time feature. Configure the NTP server, time zone. Navigate to: http://<phoneIPAddress>/servlet?p=settings-datetime&q=load
	Phone User Interface	Configure DHCP time feature. Configure the NTP server and time zone.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
local_time.manual_ntp_srv_prior	0 or 1	0
Description: Configures the priority for the Skype for Business phone to use the NTP server address offered by the DHCP server. 0 -High (use the NTP server address offered by the DHCP server preferentially) 1 -Low (use the NTP server address configured manually preferentially) Web User Interface: Settings->Time & Date->NTP by DHCP Priority Phone User Interface: None		

Parameters	Permitted Values	Default
local_time.dhcp_time	0 or 1	0
<p>Description:</p> <p>Enables or disables the Skype for Business phone to update time with the offset time offered by the DHCP server.</p> <p>0-Disabled</p> <p>1-Enabled</p> <p>Note: It is only available to offset from GMT 0.</p> <p>Web User Interface:</p> <p>Settings->Time & Date->DHCP Time</p> <p>Phone User Interface:</p> <p>Menu->Basic->Date & Time->DHCP Time</p>		
phone_setting.hide_ntp_server.enable	0 or 1	0
<p>Description:</p> <p>It enables or disables the phone to hide NTP Server configurations on the LCD screen.</p> <p>0-Disabled</p> <p>1-Enabled</p> <p>If it is set to 1 (Enabled), the NTP Server configurations on the LCD screen will be hidden, so that you cannot configure NTP Server address manually.</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p> <p>None</p>		
local_time.ntp_server1	IP Address or Domain Name	cn.pool.ntp.org
<p>Description:</p> <p>Configures the IP address or the domain name of the NTP server 1.</p> <p>Example:</p> <p>local_time.ntp_server1 = 192.168.0.5</p> <p>Web User Interface:</p> <p>Settings->Time & Date->Primary Server</p> <p>Phone User Interface:</p> <p>Menu->Basic->Date & Time->General->SNTP Settings->NTP Server1</p>		

Parameters	Permitted Values	Default
local_time.ntp_server2	IP Address or Domain Name	cn.pool.ntp.org
<p>Description: Configures the IP address or the domain name of the NTP server 2.</p> <p>If the NTP server 1 is not configured or cannot be accessed, the Skype for Business phone will request the time and date from the NTP server 2.</p> <p>Example: local_time.ntp_server2 = 192.168.0.6</p> <p>Web User Interface: Settings->Time & Date->Secondary Server</p> <p>Phone User Interface: Menu->Basic->Date & Time->General->SNTP Settings->NTP Server2</p>		
local_time.interval	Integer from 15 to 86400	1000
<p>Description: Configures the interval (in seconds) to update time and date from the NTP server.</p> <p>Example: local_time.interval = 1000</p> <p>Web User Interface: Settings->Time & Date->Synchronism (15~86400s)</p> <p>Phone User Interface: None</p>		
local_time.time_zone	-11 to +14	+8
<p>Description: Configures the time zone.</p> <p>Example: local_time.time_zone = +8</p> <p>For more available time zones, refer to Appendix B: Time Zones on page 382.</p> <p>Web User Interface: Settings->Time & Date->Time Zone</p> <p>Phone User Interface: Menu->Basic->Date & Time->General->SNTP Settings->Time Zone</p>		
local_time.time_zone_name	String within 32 characters	China(Beijing)

Parameters	Permitted Values	Default
<p>Description:</p> <p>Configures the time zone name.</p> <p>The available time zone names depend on the time zone configured by the parameter "local_time.time_zone". For more information on the available time zone names for each time zone, refer to Appendix B: Time Zones on page 382.</p> <p>Example:</p> <p>local_time.time_zone_name = China(Beijing)</p> <p>Note: It works only if the value of the parameter "local_time.summer_time" is set to 2 (Automatic) and the parameter "local_time.time_zone" should be configured in advance.</p> <p>Web User Interface:</p> <p>Settings->Time & Date->Location</p> <p>Phone User Interface:</p> <p>Menu->Basic->Date & Time->General->SNTP Settings->Location</p>		

To configure NTP by DHCP priority feature via web user interface:

1. Click on **Settings->Time & Date**.
2. Select the desired value from the pull-down list of **NTP by DHCP Priority**.

The screenshot shows the Yealink T46G web interface. The 'Settings' tab is active, and the 'Time & Date' sub-tab is selected. The 'NTP By DHCP Priority' dropdown menu is highlighted with a red rectangle and is currently set to 'High'. Other visible settings include 'Time Zone' set to '+8 China, Singapore, Australia, Russia', 'Daylight Saving Time' set to 'Automatic', 'Location' set to 'China(Beijing)', and 'Fixed Type' set to 'DST By Date'. The 'NTP Server' section shows 'Primary Server' as 'time.windows.com' and 'Secondary Server' as 'time.nist.gov'. The 'Manual Time' dropdown is set to 'Disabled'. The 'Time Format' is 'Hour 24' and the 'Date Format' is 'WWW MMM DD'. A 'NOTE' box on the right states: 'Time Zone: Choose the time zone you are in. NTP Server: The server which is used to synchronize the clock of the phone. You can click here to get more guides.'

3. Click **Confirm** to accept the change.

To configure the NTP server, time zone via web user interface:

1. Click on **Settings->Time & Date**.
2. Select **Disabled** from the pull-down list of **Manual Time**.
3. Select the desired time zone from the pull-down list of **Time Zone**.

4. Select the desired location from the pull-down list of **Location**.
5. Enter the domain name or IP address in the **Primary Server** and **Secondary Server** field respectively.
6. Enter the desired time interval in the **Synchronism (15~86400s)** field.

7. Click **Confirm** to accept the change.

To configure the SNTP settings via phone user interface:

1. Press **Menu->Basic->Date & Time->General->SNTP Settings**.
2. Press **◀** or **▶** or the **Switch** soft key to select the time zone that applies to your area from the **Time Zone** field.
The default time zone is "GMT+8".
3. Enter the domain name or IP address of SNTP server in the **NTP Server1** and **NTP Server2** field respectively.
4. Press **◀** or **▶** or the **Switch** soft key to select automatic, enabled and disabled from the **Daylight Saving** field.
5. Press **◀** or **▶** or the **Switch** soft key to select the desired location from the **Location** field.
6. Press the **Save** soft key to accept the change.

Time and Date Settings

You can set the time and date manually when phones cannot obtain the time and date from the NTP time server. The time and date display can use one of several different formats.

Procedure

Time and date can be configured using the configuration files or locally.

Configuration File	<MAC>.cfg	<p>Configure the time and date manually.</p> <p>Parameter:</p> <p>local_time.manual_time_enable</p> <p>Configure the time and date formats.</p> <p>Parameters:</p> <p>local_time.time_format</p> <p>local_time.date_format</p>
Local	Web User Interface	<p>Configure the time and date manually.</p> <p>Configure the time and date formats.</p> <p>Navigate to:</p> <p>http://<phoneIPAddress>/servlet?p=settings-datetime&q=load</p>
	Phone User Interface	<p>Configure the time and date manually.</p> <p>Configure the time and date formats.</p>

Details of Configuration Parameters:

Parameters	Permitted Values	Default
local_time.manual_time_enable	0 or 1	0
<p>Description:</p> <p>Enables or disables the Skype for Business phone to obtain time and date from manual settings.</p> <p>0-Disabled (obtain time and date from NTP server)</p> <p>1-Enabled (obtain time and date from manual settings)</p> <p>Web User Interface:</p> <p>Settings->Time & Date->Manual Time</p> <p>Phone User Interface:</p> <p>None</p>		
local_time.time_format	0 or 1	1
<p>Description:</p>		

Parameters	Permitted Values	Default
<p>Configures the time format.</p> <p>0-Hour 12</p> <p>1-Hour 24</p> <p>If it is set to 0 (Hour 12), the time will be displayed in 12-hour format with AM or PM specified.</p> <p>If it is set to 1 (Hour 24), the time will be displayed in 24-hour format (e.g., 2:00 PM displays as 14:00).</p> <p>Web User Interface:</p> <p>Settings->Time & Date->Time Format</p> <p>Phone User Interface:</p> <p>Menu->Basic->Date & Time->Time & Date Format->Time Format</p>		
local_time.date_format	0, 1, 2, 3, 4, 5 or 6	0
<p>Description:</p> <p>Configures the date format.</p> <p>Valid values are:</p> <p>0-WWW MMM DD</p> <p>1-DD-MMM-YY</p> <p>2-YYYY-MM-DD</p> <p>3-DD/MM/YYYY</p> <p>4-MM/DD/YY</p> <p>5-DD MMM YYYY</p> <p>6-WWW DD MMM</p> <p>Note: "WWW" represents the abbreviation of the week, "DD" represents a two-digit day, "MMM" represents the first three letters of the month, "YYYY" represents a four-digit year, and "YY" represents a two-digit year.</p> <p>Web User Interface:</p> <p>Settings->Time & Date->Date Format</p> <p>Phone User Interface:</p> <p>Menu->Basic->Date & Time->Time & Date Format->Date Format</p>		

To configure the time and date manually via web user interface:

1. Click on **Settings->Time & Date**.
2. Select **Enabled** from the pull-down list of **Manual Time**.

3. Enter the time and date in the corresponding fields.

The screenshot shows the 'Time&Date' configuration page in the Yealink T466 web interface. The left sidebar lists various settings categories, with 'Time&Date' selected. The main content area displays several configuration options. A red rectangular box highlights the 'Manual Time' section, which includes fields for 'Date' (Year: 2016, Month: 4, Day: 21) and 'Time' (Hour: 10, Minute: 35, Second: 19). Below these fields are 'Time Format' (set to 'Hour 24') and 'Date Format' (set to 'WWW MMM DD'). At the bottom of the configuration area are 'Confirm' and 'Cancel' buttons. On the right side, there is a 'NOTE' section with information about 'Time Zone' and 'NTP Server'.

4. Click **Confirm** to accept the change.



To configure the time and date format via web user interface:

1. Click on **Settings->Time & Date**.
2. Select the desired value from the pull-down list of **Time Format**.
3. Select the desired value from the pull-down list of **Date Format**.

This screenshot shows the 'Time&Date' configuration page, similar to the previous one but with more options visible. The 'Time Format' and 'Date Format' fields are highlighted with a red rectangular box. 'Time Format' is set to 'Hour 24' and 'Date Format' is set to 'WWW MMM DD'. Other visible settings include 'Time Zone' (set to '+8 China, Singapore, Australia, Russia'), 'Daylight Saving Time' (set to 'Automatic'), and 'Location' (set to 'China(Beijing)'). The 'Manual Time' section is now set to 'Disabled'. 'Confirm' and 'Cancel' buttons are at the bottom.

4. Click **Confirm** to accept the change.





To configure the date and time manually via phone user interface:

1. Press **Menu->Basic->Date & Time->General->Manual Settings**.
2. Enter the specific date and time or press  or  to edit specific date and time in the corresponding fields.

3. Press **Save** to accept the change.

The time and date displayed on the LCD screen will change accordingly.

To configure the time and date format via phone user interface:

1. Press **Menu** -> **Basic**-> **Date &Time** -> **Time & Date Format**.
2. Press  or , or the **Switch** soft key to select the desired date format from the **Date Format** field.
3. Press  or , or the **Switch** soft key to select the desired time format (**12 Hour** or **24 Hour**) from the **Time Format** field.
4. Press the **Save** soft key to accept the change or the **Back** soft key to cancel.

Daylight Saving Time

Daylight Saving Time (DST) is the practice of temporary advancing clocks during the summer time so that evenings have more daylight and mornings have less. Typically, clocks are adjusted forward one hour at the start of spring and backward in autumn. Many countries have used the DST at various times, details vary by location. By default, the DST is set to Automatic, so it can be adjusted automatically from the current time zone configuration. You can configure DST for the desired area as required.

Procedure

Daylight saving time can be configured using the configuration files or locally.

Configuration File	<MAC>.cfg	Configure DST. Parameters: local_time.summer_time local_time.dst_time_type local_time.start_time local_time.end_time local_time.offset_time
Local	Web User Interface	Configure DST. Navigate to: <a href="http://<phoneIPAddress>/servlet?parameters=settings-datetetime&q=load">http://<phoneIPAddress>/servlet?parameters=settings-datetetime&q=load

Details of Configuration Parameters:

Parameters	Permitted Values	Default
local_time.summer_time	0, 1 or 2	2

Parameters	Permitted Values	Default
Description: Configures Daylight Saving Time (DST) feature. 0 -Disabled 1 -Enabled 2 -Automatic Web User Interface: Settings->Time & Date->Daylight Saving Time Phone User Interface: Menu->Basic->Date & Time->General->SNTP Settings->Daylight Saving		
local_time.dst_time_type	0 or 1	0
Description: Configures the DST time type. 0 -DST By Date 1 -DST By Week Note: It works only if the value of the parameter "local_time.summer_time" is set to 1 (Enabled). Web User Interface: Settings->Time & Date->Fixed Type Phone User Interface: None		
local_time.start_time	Time	1/1/0
Description: Configures the start time of the DST. Value formats are: <ul style="list-style-type: none"> Month/Day/Hour (for DST By Date) Month/Day of Week Last in Month/Day of Week/Hour of Day (for DST By Week) If "local_time.dst_time_type" is set to 0 (DST By Date), use the mapping: Month: 1=January, 2=February,..., 12=December Day: 1=the first day in a month,..., 31= the last day in a month Hour: 0=0am, 1=1am,..., 23=11pm If "local_time.dst_time_type" is set to 1 (DST By Week), use the mapping: Month: 1=January, 2=February,..., 12=December		

Parameters	Permitted Values	Default
<p>Day of Week Last in Month: 1=the first week in a month,..., 5=the last week in a month</p> <p>Day of Week: 1=Monday, 2=Tuesday,..., 7=Sunday</p> <p>Hour of Day: 0=0am, 1=1am,..., 23=11pm</p> <p>Note: It works only if the value of the parameter "local_time.summer_time" is set to 1 (Enabled).</p> <p>Web User Interface: Settings->Time & Date->Start Date</p> <p>Phone User Interface: None</p>		
local_time.end_time	Time	12/31/23
<p>Description: Configures the end time of the DST.</p> <p>Value formats are:</p> <ul style="list-style-type: none"> Month/Day/Hour (for DST By Date) Month/Day of Week Last in Month/Day of Week/Hour of Day (for DST By Week) <p>If "local_time.dst_time_type" is set to 0 (DST By Date), use the mapping:</p> <p>Month: 1=January, 2=February,..., 12=December</p> <p>Day: 1=the first day in a month,..., 31= the last day in a month</p> <p>Hour: 0=0am, 1=1am,..., 23=11pm</p> <p>If "local_time.dst_time_type" is set to 1 (DST By Week), use the mapping:</p> <p>Month: 1=January, 2=February,..., 12=December</p> <p>Day of Week Last in Month: 1=the first week in a month,..., 5=the last week in a month</p> <p>Day of Week: 1=Monday, 2=Tuesday,..., 7=Sunday</p> <p>Hour of Day: 0=0am, 1=1am,..., 23=11pm</p> <p>Note: It works only if the value of the parameter "local_time.summer_time" is set to 1 (Enabled).</p> <p>Web User Interface: Settings->Time & Date->End Date</p> <p>Phone User Interface: None</p>		
local_time.offset_time	Integer from -300 to 300	Blank
<p>Description: Configures the offset time (in minutes) of DST.</p>		

Parameters	Permitted Values	Default
<p>Note: It works only if the value of the parameter "local_time.summer_time" is set to 1 (Enabled).</p> <p>Web User Interface: Settings->Time & Date->Offset(minutes)</p> <p>Phone User Interface: None</p>		

To configure the DST via web user interface:

1. Click on **Settings->Time & Date**.
2. Select **Disabled** from the pull-down list of **Manual Time**.
3. Select the desired time zone from the pull-down list of **Time Zone**.
4. Enter the domain name or IP address in the **Primary Server** and **Secondary Server** field respectively.
5. Enter the desired time interval in the **Synchronism (15~86400s)** field.
6. Mark the **Enabled** radio box in the **Daylight Saving Time** field.
 - Mark the **DST by Date** radio box in the **Fixed Type** field.
 - Enter the start time in the **Start Date** field.
 - Enter the end time in the **End Date** field.

The screenshot shows the Yealink T46G web interface with the 'Settings' tab selected. The 'Time&Date' section is active. The 'Daylight Saving Time' section is highlighted with a red box, showing 'Fixed Type' set to 'DST By Date'. The 'Start Date' is set to Month 1, Day 1, Hour 1, and the 'End Date' is set to Month 12, Day 12, Hour 12. Other settings include 'Time Zone' set to '+8 China, Singapore, Australia, Russia', 'Offset(minutes)' set to 0, 'NTP By DHCP Priority' set to High, 'Primary Server' set to time.windows.com, 'Secondary Server' set to time.nist.gov, 'Synchronism (15~86400s)' set to 1000, 'Manual Time' set to Disabled, and 'Date Format' set to WWW MMM DD.

- Mark the **DST by Week** radio box in the **Fixed Type** field.

Select the desired values of DST Start Month, DST Start Week of Month, DST Start Day of Week, Start Hour of Day; DST Stop Month, DST Stop Week of Month, DST Stop Day of Week and End Hour of Day from the pull-down lists.

7. Enter the desired offset time in the **Offset(minutes)** field.
8. Click **Confirm** to accept the change.

Customizing an AutoDST Template File

The time zone and corresponding DST pre-configurations exist in the AutoDST file. If the DST is set to Automatic, the Skype for Business phone obtains the DST configuration from the AutoDST file. You can customize the AutoDST file if required. The AutoDST file allows you to add or modify time zone and DST settings for your area each year.

Before customizing, you need to obtain the AutoDST file. You can ask the distributor or Yealink FAE for DST template. You can also obtain the DST template online:

<http://support.yealink.com/documentFront/forwardToDocumentFrontDisplayPage>. For more information on obtaining the template file, refer to [Obtaining Configuration Files/Resource Files](#) on page 96.

The following table lists description of each element in the template file:

Element	Type	Values	Description
DSTData	required	no	File root element
DST	required	no	Time Zone item's root element
szTime	required	[+/-][X]:[Y], X=0~14, Y=0~59	Time Zone
szZone	required	String (if the content is more than one city, it is the best to keep their daylight saving time the same)	Time Zone name

Element	Type	Values	Description
iType	optional	0/1 0: DST By Date 1: DST By Week	DST time type (This item is needed if you want to configure DST.)
szStart	optional	Month/Day/Hour (for iType=0) Month: 1~12 Day: 1~31 Hour: 0 (midnight)~23 Month/Week of Month/Day of Week/Hour of Day (for iType=1) Month: 1~12 Week of Month: 1~5 (the last week) Day of Week: 1~7 Hour of Day: 0 (midnight)~23	Start time of the DST
szEnd	optional	Same as szStart	End time of the DST
szOffset	optional	Integer from -300 to 300	The offset time (in minutes) of DST

When customizing an AutoDST file, learn the following:

- <DSTData> indicates the start of a template and </DSTData> indicates the end of a template.
- Add or modify time zone and DST settings between <DSTData> and </DSTData>.
- The display order of time zone is corresponding to the szTime order specified in the AutoDST.xml file.
- If the start time of DST is greater than the end time, the valid time of DST is from the start time of this year to the end time of the next year.

Customizing an AutoDST file:

1. Open the AutoDST file using an ASCII editor.
2. Add or modify time zone and DST settings as you want in the AutoDST file.

Example 1:

To modify the DST settings for the existing time zone "+5 Pakistan(Islamabad)" and add DST settings for the existing time zone "+5:30 India(Calcutta)".

The screenshot shows the AutoDST.xml file with several entries. Two entries are highlighted with red boxes and annotations:

- The entry for "Pakistan (Islamabad)" is highlighted, and a red box with the text "Modify it:" points to its `szStart` and `szEnd` values, which are being changed from "4/15/0" to "10/1/7/2" and "11/1/0" to "4/1/7/3" respectively.
- The entry for "India (Calcutta)" is highlighted, and a red box with the text "Add DST" points to its `szStart` and `szEnd` values, which are being changed from "9/5/7/3" to "4/1/7/2" and "4/1/7/2" to "4/1/7/2" respectively.

Example 2:

Add a new time zone (+6 Paradise) with daylight saving time 30 minutes.

The screenshot shows the AutoDST.xml file with a new entry added: "+6 Paradise". This entry is highlighted with a red box and an arrow pointing to it. The entry is: `<DST szTime="+6" szZone="Paradise" iType="1" szStart="3/5/7/2" szEnd="10/5/7/3" szOffset="30"/>`. The file also shows other time zones like Afghanistan, Kazakhstan, Kyrgyzstan, Pakistan, Russia, India, Nepal, Myanmar, Thailand, China, Singapore, Australia, and Japan.

3. Save this file and place it to the provisioning server (e.g., 192.168.1.100).
4. Specify the access URL of the AutoDST file in the configuration files.

Procedure

The access URL of the AutoDST file can be specified using the configuration files.

Configuration File	<MAC>.cfg	Specify the access URL of the AutoDST file. Parameters: auto_dst.url
---------------------------	-----------	---

Details of Configuration Parameters:

Parameters	Permitted Values	Default
auto_dst.url	URL within 511 characters	Blank
<p>Description: Configures the access URL of the AutoDST file (AutoDST.xml).</p> <p>Example: auto_dst.url = tftp://192.168.1.100/AutoDST.xml</p> <p>During the auto provisioning process, the Skype for Business phone connects to the provisioning server "192.168.1.100", and downloads the AutoDST file "AutoDST.xml". After update, you will find a new time zone "Paradise" and updated DST of "Pakistan (Islamabad)" and "India (Calcutta)" via web user interface: Settings->Time & Date->Time Zone.</p> <p>Note: It works only if the value of the parameter "local_time.summer_time" is set to 2 (Automatic).</p> <p>Web User Interface: None</p> <p>Phone User Interface: None</p>		

Language

Skype for Business phones support multiple languages. Languages used on the phone user interface and web user interface can be specified respectively as required.

The following table lists languages supported by the phone user interface and the web user interface.

Phone/Web User Interface
English
Chinese Simplified (not applicable to phone user interface of T40P Skype for Business phones)
Chinese Traditional (not applicable to phone user interface of T40P Skype for Business phones)
French
German
Italian

Phone/Web User Interface
Polish
Portuguese
Spanish
Turkish
Korean (not applicable to phone user interface of T40P Skype for Business phones)
Russian

Loading Language Packs

Languages available for selection depend on language packs currently loaded to the Skype for Business phone. You can customize the translation of the existing language on the phone user interface or web user interface. You can also make new languages (not included in the available language list) available for use on the phone user interface and web user interface by loading language packs to the Skype for Business phone. Language packs can only be loaded using configuration files.

You can ask the distributor or Yealink FAE for language packs. You can also obtain the language packs online:

<http://support.yealink.com/documentFront/forwardToDocumentFrontDisplayPage>. For more information on obtaining the language packs, refer to [Obtaining Configuration Files/Resource Files](#) on page 96.

Note

To modify translation of an existing language, do not rename the language file.

The new added language must be supported by the font library on the Skype for Business phone. If the characters in the custom language file are not supported by the Skype for Business phone, the phone will display "?" instead.

Customizing a Language for Phone User Interface

The following table lists the available languages and associated language packs for the phone user interface:

Available Language	Associated Language Pack
English	000.GUI.English.lang
Chinese Simplified	001.GUI.Chinese_S.lang
Chinese Traditional	002.GUI.Chinese_T.lang
French	003.GUI.French.lang
German	004.GUI.German.lang

Available Language	Associated Language Pack
Italian	005.GUI.Italian.lang
Polish	006.GUI.Polish.lang
Portuguese	007.GUI.Portuguese.lang
Spanish	008.GUI.Spanish.lang
Turkish	009.GUI.Turkish.lang
Korean	010.GUI.Korean.lang
Russian	011.GUI.Russian.lang

When adding a new language pack for the phone user interface, the language pack must be formatted as "X.GUI.name.lang" (X starts from 012, "name" is replaced with the language name). If the language name is the same as the existing one, the existing language pack will be overridden by the new uploaded one. We recommend that the filename of the new language pack should not be the same as the existing one.

To customize a language file:

1. Open the desired language template file (e.g., 000.GUI.English.lang) using an ASCII editor.
2. Modify the characters within the double quotation marks on the right of the equal sign. Don't modify the translation item on the left of the equal sign.

The following shows a portion of the language pack "000.GUI.English.lang" for the phone user interface (take T46G Skype for Business phones for example):

```

000.GUI.English.lang x
1 [ Lang ]
2
3 "Conference"="Conference"
4 "or # as send"="Key as send"
5 "(Empty)"="(Empty)"
6 "12 Hour"="12 Hour"
7 "120s"="120s"
8 "15s"="15s"
9 "1800s"="1800s"
10 "24 Hour"="24 Hour"
11 "300s"="300s"
12 "30s"="30s"
13 "600s"="600s"
14 "60s"="60s"
15 "802.1x Mode"="802.1x Mode"
16 "802.1x Settings"="802.1x Settings"

```

3. Save the language file and place it to the provisioning server (e.g., 192.168.10.25).
4. Specify the access URL of the phone user interface language pack in the configuration files.

If you want to add a new custom language (e.g., Guilan) to your Skype for Business phone (e.g., T46G), prepare the language file named as "012.GUI.Guilan.lang" for downloading. After update, you will find a new language selection "Guilan" on the phone user interface:

Menu->Basic->Language.

Procedure

Loading language pack can only be performed using the configuration files.

Configuration File	<y0000000000xx>.cfg	Specify the access URL of the phone user interface language pack. Parameter: gui_lang.url
		Delete custom LCD language packs of the phone user interface. Parameter: gui_lang.delete

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
gui_lang.url	URL within 511 characters	Blank
<p>Description: Configures the access URL of the custom LCD language pack for the phone user interface.</p> <p>Example: gui_lang.url = http://192.168.10.25/000.GUI.English.lang</p> <p>During the auto provisioning process, the Skype for Business phone connects to the HTTP provisioning server "192.168.10.25", and downloads the language pack "000.GUI.English.lang". The English language translation will be changed accordingly if you have modified the language template file.</p> <p>If you want to download multiple language packs to the Skype for Business phone simultaneously, you can configure as following: gui_lang.url = http://192.168.10.25/000.GUI.English.lang gui_lang.url = http://192.168.10.25/001.GUI.Chinese_S.lang</p> <p>Web User Interface: None</p> <p>Phone User Interface: None</p>		
gui_lang.delete	http://localhost/all or http://localhost/Y.GUI.name.lang	Blank

Parameter	Permitted Values	Default
<p>Description:</p> <p>Deletes the specified or all custom LCD language packs of the phone user interface.</p> <p>Example:</p> <p>Delete all custom language packs of the phone user interface:</p> <pre>gui_lang.delete = http://localhost/all</pre> <p>Delete a custom language pack of the phone user interface (e.g., 001.GUI.Chinese_S.lang):</p> <pre>gui_lang.delete = http://localhost/001.GUI.Chinese_S.lang</pre> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p> <p>None</p>		

Customizing a Language for Web User Interface

The following table lists available languages and associated language packs for the web user interface:


Available Language	Associated Language Pack
English	1.English.js
Chinese Simplified	2.Chinese_S.js
Chinese Traditional	3.Chinese_T.js
French	4.French.js
German	5.German.js
Italian	6.Italian.js
Polish	7.Polish.js
Portuguese	8.Portuguese.js
Spanish	9.Spanish.js
Turkish	10.Turkish.js
Korean	11.Korean.js
Russian	12.Russian.js

When adding a new language pack for the web user interface, the language pack must be formatted as "Y.name.js" (Y starts from 13, "name" is replaced with the language name). If the language name is the same as the existing one, the existing language file will be overridden by the new uploaded one. We recommend that the name of the new language file should not be the same as the existing languages.

To customize a language file:

1. Open the desired language template file (e.g., 1.English.js) using an ASCII editor.
2. Modify the characters within the double quotation marks on the right of the colon. Don't modify the translation item on the left of the colon.

The following shows a portion of the language pack "1.English.js" for the web user interface (take T46G Skype for Business phones for example):



3. Save the language file and place it to the provisioning server (e.g., 192.168.10.25).
4. Specify the access URL of the web user interface language pack in the configuration files.

If you want to add a new language (e.g., Wuilan) to Skype for Business phones, prepare the language file named as "13.Wuilan.js" for downloading. After update, you will find a new language selection "Wuilan" on the web user interface: **Settings->Preference->Language**.

Procedure

Loading language pack can only be performed using the configuration files.

Configuration File	<y0000000000xx>.cfg	Specify the access URL of the custom language pack for web user interface. Parameter: wui_lang.url
		Delete custom language packs of the web user interface. Parameter: wui_lang.delete

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
wui_lang.url	URL within 511 characters	Blank
<p>Description:</p> <p>Configures the access URL of the custom language pack for the web user interface.</p> <p>Example:</p> <p>wui_lang.url = http://192.168.10.25/1.English.js</p> <p>During the auto provisioning process, the Skype for Business phone connects to the HTTP provisioning server "192.168.10.25", and downloads the language pack "1.English.js". The English language translation will be changed accordingly if you have modified the language template file.</p> <p>If you want to download multiple language packs to the web user interface simultaneously, you can configure as following:</p> <p>wui_lang.url = http://192.168.10.25/1.English.js</p> <p>wui_lang.url = http://192.168.10.25/11.Russian.js</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p> <p>None</p>		
wui_lang.delete	http://localhost/all or http://localhost/Y.name.js	Blank
<p>Description:</p> <p>Delete the specified or all custom web language packs of the web user interface.</p> <p>Example:</p> <p>Delete all custom language packs of the web user interface:</p> <p>wui_lang.delete = http://localhost/all</p> <p>Delete a custom language pack of the web user interface (e.g., 11.Russian.js):</p> <p>wui_lang.delete = http://localhost/11.Russian.js</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p> <p>None</p>		

Specifying the Language to Use

The default language used on the phone user interface is English. If the language of your web browser is not supported by the Skype for Business phone, the web user interface will use English by default. You can specify the languages for the phone user interface and web user interface respectively.

Procedure

Specify the language for the phone user interface or the web user interface using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Specify the languages for the phone user interface and the web user interface. Parameters: lang.gui lang.wui
Local	Web User Interface	Specify the language for the web user interface. Navigate to: http://<phoneIPAddress>/servlet?parameters=settings-preference&q=load
	Phone User Interface	Specify the language for the phone user interface.


Details of Configuration Parameters:

Parameters	Permitted Values	Default
lang.gui	Refer to the following content	English
<p>Description: Configures the language used on the phone user interface.</p> <p>Permitted Values: English, Chinese Simplified, Chinese Traditional, French, German, Italian, Polish, Portuguese, Spanish, Turkish, Korean, Russian or the custom language name.</p> <p>Example: lang.gui = English</p> <p>If you want to use the custom language (e.g., Guilan) for the Skype for Business phone, configure the parameter "lang.gui = Guilan".</p> <p>Note: Korean, Chinese Simplified and Chinese Traditional are not applicable to phone user</p>		

Parameters	Permitted Values	Default
<p>interface of T40P Skype for Business phones.</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p> <p>Menu->Basic->Language</p>		
lang.wui	Refer to the following content	English
<p>Description:</p> <p>Configures the language used on the web user interface.</p> <p>Permitted Values:</p> <p>English, Chinese Simplified, Chinese Traditional, French, German, Italian, Polish, Portuguese, Spanish, Turkish, Korean, Russian or the custom language name.</p> <p>Example:</p> <p>lang.wui = English</p> <p>If the language of your browser is not supported by the Skype for Business phone, the web user interface will use English by default.</p> <p>Web User Interface:</p> <p>Settings->Preference->Language</p> <p>Phone User Interface:</p> <p>None</p>		

To specify the language for the web user interface via web user interface:



1. Click on **Settings->Preference**.
2. Select the desired language from the pull-down list of **Language**.



3. Click **Confirm** to accept the change.

To specify the language for the phone user interface via phone user interface:

1. Press **Menu->Basic->Language**.

2. Press  or  to select the desired language.
3. Press the **Save** soft key to accept the change.

Key As Send

Key as send allows assigning the pound key ("#") or asterisk key ("*") as the send key.

Send tone allows the phone to play a key tone when a user presses the send key. Key tone allows the phone to play a key tone when a user presses any key. Send tone works only if key tone is enabled.

Procedure

Key as send can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure a send key. Parameter: features.key_as_send
		Configure a send tone. Parameter: features.send_key_tone
		Configure a key tone. Parameter: features.key_tone
		Configure send pound key. Parameter: features.send_pound_key
Local	Web User Interface	Configure a send key. Configure send pound key. Navigate to: <a href="http://<phoneIPAddress>/servlet?parameters=features-general&q=load">http://<phoneIPAddress>/servlet?parameters=features-general&q=load
		Configure a send tone or key tone. Navigate to: <a href="http://<phoneIPAddress>/servlet?parameters=features-audio&q=load">http://<phoneIPAddress>/servlet?parameters=features-audio&q=load
	Phone User Interface	Configure a send key. Configure a key tone.


Details of Configuration Parameters:

Parameters	Permitted Values	Default
features.key_as_send	0, 1 or 2	1
<p>Description: Configures the "#" or "*" key as the send key.</p> <p>0-Disabled 1-# key 2-* key</p> <p>If it is set to 0 (Disabled), neither "#" nor "*" can be used as the send key. If it is set to 1 (# key), the pound key is used as the send key. If it is set to 2 (* key), the asterisk key is used as the send key.</p> <p>Web User Interface: Features->General Information->Key As Send</p> <p>Phone User Interface: Menu->Features->Key as send</p>		
features.key_tone	0 or 1	1
<p>Description: Enables or disables the Skype for Business phone to play a key tone when a user presses any key on your phone keypad.</p> <p>0-Disabled 1-Enabled</p> <p>If it is set to 1 (Enabled), the Skype for Business phone will play a key tone when a user presses any key on your phone keypad.</p> <p>Web User Interface: Features->Audio->Key Tone</p> <p>Phone User Interface: Menu-> Basic->Sounds->Key Tone</p>		
features.send_key_tone	0 or 1	1
<p>Description: Enables or disables the Skype for Business phone to play a key tone when a user presses a send key.</p> <p>0-Disabled 1-Enabled</p>		

Parameters	Permitted Values	Default
<p>If it is set to 1 (Enabled), the Skype for Business phone will play a key tone when a user presses a send key.</p> <p>Note: It works only if the value of the parameter "features.key_tone" is set to 1 (Enabled).</p> <p>Web User Interface:</p> <p>Features->Audio->Send Sound</p> <p>Phone User Interface:</p> <p>None</p>		
features.send_pound_key	0 or 1	0
<p>Description:</p> <p>Enables or disables the Skype for Business phone not to send any pound key when pressing double #.</p> <p>0-Disabled (Send one pound key by pressing double #)</p> <p>1-Enabled (Do not send any pound key when pressing double #)</p> <p>Note: It works only if the value of the parameter "features.key_as_send" is set to 1 (Enabled).</p> <p>Web User Interface:</p> <p>Features->General Information->Send Pound Key</p> <p>Phone User Interface:</p> <p>None</p>		

To configure a send key via web user interface:

1. Click on **Features->General Information**.
2. Select the desired value from the pull-down list of **Key As Send**.



3. Click **Confirm** to accept the change.

To configure a send tone and key tone via web user interface:

1. Click on **Features->Audio**.
2. Select the desired value from the pull-down list of **Key Tone**.
3. Select the desired value from the pull-down list of **Send Sound**.

The screenshot shows the 'Audio Settings' page in the Yealink T46G web interface. The 'Features' tab is selected, and the 'Audio' sub-tab is active. The 'Key Tone' and 'Send Sound' dropdown menus are highlighted with red boxes. The 'Key Tone' is set to 'Enabled' and 'Send Sound' is set to 'Enabled'. Other settings include 'Call Waiting Tone' (Enabled), 'Pre Dial Tone' (Disabled), 'Redial Tone' (empty), 'Ringer Device for Headset' (Use Speaker), and 'BToE as Audio Device (VDI support)' (Disabled). A 'Confirm' button is at the bottom.

4. Click **Confirm** to accept the change.



To configure send pound key via web user interface:

1. Click on **Features->General Information**.
2. Select the desired value from the pull-down list of **Send Pound Key**.



The screenshot shows the 'General Information' page in the Yealink T46G web interface. The 'Features' tab is selected, and the 'General Information' sub-tab is active. The 'Send Pound Key' dropdown menu is highlighted with a red box. The 'Send Pound Key' is set to 'Disabled'. Other settings include 'Call Waiting' (Enabled), 'Key As Send' (#), 'Busy Tone Delay (Seconds)' (0), 'Return code when refuse' (603 (Decline)), 'Time-Out for Dial-Now Rule' (1), 'Fwd International' (Enabled), 'Diversion/History-Info' (Disabled), 'Auto-Logout Time(1~1000min)' (5), 'Call Number Filter' (empty), 'Voice Mail Tone' (Enabled), 'DHCP Hostname' (SIP-T46G), 'E911 Location Tip' (Enabled), 'Update Checking Time' (24), 'Use DHCP Option 120' (Disabled), 'SFB Cert Service URL' (empty), 'Enable SFB Automation' (Disabled), 'SFB Inactive Time' (5), 'SFB Away Time' (5), 'Web Sign in' (Enabled), 'Remember Password' (Disabled), and 'History Record Contacts Avatar' (Enabled). A 'Confirm' button is at the bottom.

3. Click **Confirm** to accept the change.

To configure a send key via phone user interface:

1. Press **Menu->Features->Key as Send**.
2. Press  or , or the **Switch** soft key to select # or * from the **Key as Send** field, or select **Disabled** to disable this feature.
3. Press the **Save** soft key to accept the change.

To configure a key tone via web user interface:

1. Press **Menu->Basic->Sounds->Key Tone**.
2. Press  or , or the **Switch** soft key to select the desired value from the **Key Tone** field.
3. Press the **Save** soft key to accept the change.

Dial Plan

Dial plan is a string of characters that governs the way for phones to process the inputs received from the phone's keypads. You can use regular expression to define dial plan.

Regular expression, often called a pattern, is an expression that specifies a set of strings. A regular expression provides a concise and flexible means to "match" (specify and recognize) strings of text, such as particular characters, words, or patterns of characters. Regular expression is used by many text editors, utilities, and programming languages to search and manipulate text based on patterns.

Regular expression can be used to define Skype for Business phone dial plan. Dial plan is a string of characters that governs the way for Skype for Business phones to process the inputs received from the Skype for Business phone's keypads. The Skype for Business phone can receive dial plan through in-band provisioning.

You need to know the following basic regular expression syntax when creating dial plan:

.	The dot "." can be used as a placeholder or multiple placeholders for any string. Example: "12." would match "123", "1234", "12345", "12abc", etc.
x	The "x" can be used as a placeholder for any character. Example: "12x" would match "121", "122", "123", "12a", etc.
-	The dash "-" can be used to match a range of characters within the brackets. Example: "[5-7]" would match the number "5", "6" or "7".
,	The comma "," can be used as a separator within the bracket. Example: "[2,5,8]" would match the number "2", "5" or "8".

[]	The square bracket "[]" can be used as a placeholder for a single character which matches any of a set of characters. Example: "91[5-7]1234" would match "91 5 1234", "91 6 1234", "91 7 1234".
()	The parenthesis "(")" can be used to group together patterns, for instance, to logically combine two or more patterns. Example: "([1-9])([2-7])3" would match " 923 ", " 153 ", " 673 ", etc.
\$	The "\$" followed by the sequence number of a parenthesis means the characters placed in the parenthesis. The sequence number stands for the corresponding parenthesis. Example: A replace rule configuration, Prefix: "001(xxx)45(xx)", Replace: "9001\$145\$2". When you dial out "0012354599" on your phone, the Skype for Business phone will replace the number with "9001 2354599 ". "\$1" means 3 digits in the first parenthesis, that is, "235". "\$2" means 2 digits in the second parenthesis, that is, "99".

Dial-now

Dial-now is a string used to match numbers entered by the user. When entered numbers match the predefined dial-now rule, the Skype for Business phone will automatically dial out the numbers without pressing the send key. Skype for Business phones support up to 100 dial-now rules, which can be created either one by one or in batch using a dial-now rule template. For more information on how to customize a dial-now template, refer to [Customizing Dial-now Template File](#) on page 173.

Time Out for Dial Now Rule

The Skype for Business phone will automatically dial out the entered number, which matches the dial now rule, after a specified period of time.

Procedure

Dial-now rule can be created using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Create the dial-now rule for the Skype for Business phone. Parameters: dialplan.dialnow.rule.X
		Configure the delay time for the dial-now rule. Parameters: phone_setting.dialnow_delay
Local	Web User Interface	Create the dial-now rule for the

		Skype for Business phone. Navigate to: <a href="http://<phoneIPAddress>/servlet?parameters=settings-dialnow&q=load">http://<phoneIPAddress>/servlet?parameters=settings-dialnow&q=load
		Configure the delay time for the dial-now rule. Navigate to: <a href="http://<phoneIPAddress>/servlet?parameters=features-general&q=load">http://<phoneIPAddress>/servlet?parameters=features-general&q=load

Details of Configuration Parameters:

Parameters	Permitted Values	Default
dialplan.dialnow.rule.X (X ranges from 1 to 100)	String within 511 characters	Blank
Description: Configures the dial-now rule (the string used to match the numbers entered by the user). When entered numbers match the predefined dial-now rule, the Skype for Business phone will automatically dial out the numbers without pressing the send key. Example: dialplan.dialnow.rule.1 = 123 Web User Interface: Settings->Dial Plan->Dial-now->Rule Phone User Interface: None		
phone_setting.dialnow_delay	Integer from 0 to 14	1
Description: Configures the delay time (in seconds) for the dial-now rule. When entered numbers match the predefined dial-now rule, the Skype for Business phone will automatically dial out the entered number after the designated delay time. Web User Interface: Features->General Information->Time-Out for Dial-Now Rule Phone User Interface: None		

To create a dial-now rule via web user interface:

1. Click on **Settings->Dial Plan->Dial-now**.
2. Enter the desired value in the **Rule** field.

The screenshot shows the 'Dial-now' configuration page in the Yealink T46G web interface. The 'Rule' field is highlighted with a red box and contains the text 'Rule 1xxx'. The page includes a sidebar with navigation options like Preference, Time&Date, Upgrade, Auto Provision, Configuration, Dial Plan, Voice, Tones, Phone Lock, Location, EXP Module, and BToE. The main content area shows a table with 10 rows for dial-now rules, each with an index and a checkbox. A 'NOTE' section on the right provides additional guidance.

3. Click **Add** to add the dial-now rule.

To configure the delay time for the dial-now rule via web user interface:

1. Click on **Features->General Information**.
2. Enter the desired time within 0-14 (in seconds) in the **Time-Out for Dial-Now Rule** field.

The screenshot shows the 'General Information' configuration page in the Yealink T46G web interface. The 'Time-Out for Dial-Now Rule' field is highlighted with a red box and contains the value '1'. The page includes a sidebar with navigation options like General Information, Audio, Remote Control, Bluetooth, and LED. The main content area shows various configuration options for features like Call Waiting, Key As Send, Hotline Number, Hotline Delay, Busy Tone Delay, Return code when refuse, Time-Out for Dial-Now Rule, Dial Search Delay, 180 Ring Workaround, Save Call Log, Suppress DTMF Display, Suppress DTMF Display Delay, Play Local DTMF Tone, DTMF Repetition, and Multicast Codec. A 'NOTE' section on the right provides additional guidance.

3. Click **Confirm** to accept the change.

Customizing Dial-now Template File

The dial-now template helps with the creation of multiple dial-now rules. After setup, place the dial-now template to the provisioning server and specify the access URL in the configuration

files.

You can ask the distributor or Yealink FAE for dial-now template. You can also obtain the dial-now template online:

<http://support.yealink.com/documentFront/forwardToDocumentFrontDisplayPage>. For more information on obtaining the dial-now template, refer to [Obtaining Configuration Files/Resource Files](#) on page 96.

When editing a dial-now template, learn the following:

- <DialNow> indicates the start of a template and </DialNow> indicates the end of a template.
- When specifying the line for the dial-now rule, the valid value is 0 or 1. No matter you leave it blank or set it to 0 or 1, the dial-now rule will all be applied to account 1.
- At most 100 rules can be added to the Skype for Business phone.

The expression syntax in the dial-now rule template is the same as that introduced in the section [Dial Plan](#) on page 170.

To customize a dial-now template:

1. Open the template file using an ASCII editor.
2. Create dial-now rules between <DialNow> and </DialNow>.


For example:

```
<data DialNowRule="99" LineID="1" />
```

Where:

DialNowRule="" specifies the dial-now rule.

LineID="" specifies the desired line for this rule. When you leave it blank or enter 0 or enter 1, this dial-now rule will all apply to account 1.



```
<?xml version="1.0" encoding="UTF-8"?>
<DialNow>
  <data DialNowRule="11" LineID="1" />
  <data DialNowRule="22" LineID="" />
  <data DialNowRule="*xx" LineID="1" />
  <data DialNowRule="#xx" LineID="1" />
  <data DialNowRule="000" LineID="1" />
  <data DialNowRule="106" LineID="1" />
  <data DialNowRule="101" LineID="1" />
  <data DialNowRule="11xx" LineID="1" />
  <data DialNowRule="12[23]x" LineID="1" />
  <data DialNowRule="124xx" LineID="1" />
  <data DialNowRule="1251xx" LineID="1" />
  <data DialNowRule="1[38]xxxxxxx" LineID="1" />
  <data DialNowRule="13[1-9]xxx" LineID="1" />
  <data DialNowRule="1345xxxx" LineID="1" />
  <data DialNowRule="0[2-9]xxxxxxx" LineID="1" />
  <data DialNowRule="2xxx" LineID="1" />
  <data DialNowRule="[3-9]xxxxxxx" LineID="1" />
  <data DialNowRule="99" LineID="1" />
</DialNow>
```

If you want to change the dial-now rule, specify the values within double quotes.

3. Save the change and place this file to the provisioning server.
4. Specify the access URL of the dial-now template.

Procedure

Specify the access URL of the dial-now template using configuration files.

Configuration File	<y0000000000xx>.cfg	Configure the access URL of the dial-now template. Parameter: dialplan_dialnow.url
---------------------------	---------------------	---

Details of Configuration Parameters:

Parameters	Permitted Values	Default
dialplan_dialnow.url	URL within 511 characters	Blank
Description: Configures the access URL of the dial-now rule template file. Example: dialplan_dialnow.url = http://192.168.10.25/dialnow.xml During the auto provisioning process, the Skype for Business phone connects to the provisioning server "192.168.10.25", and downloads the dial-now rule file "dialnow.xml". Web User Interface: None Phone User Interface: None		

Hotline

Hotline, sometimes referred to as hot dialing, is a point-to-point communication link in which a call is automatically directed to the preset hotline number. The phone automatically dials out the hotline number using the first available line after a specified time interval when you lift the handset, press the Speakerphone key or the line key. phones only support one hotline number.

Procedure

Hotline can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the hotline number. Parameter: features.hotline_number
---------------------------	---------------------	---

		Specify the time (in seconds) the Skype for Business phone waits before automatically dialing out the hotline number. Parameter: features.hotline_delay
Local	Web User Interface	Configure the hotline number. Specify the time (in seconds) the Skype for Business phone waits before automatically dial out the hotline number. Navigate to: <a href="http://<phoneIPAddress>/servlet?p=features-general&q=load">http://<phoneIPAddress>/servlet?p=features-general&q=load
	Phone User Interface	Configure the hotline number. Specify the time (in seconds) the Skype for Business phone waits before automatically dialing out the hotline number.

Details of Configuration Parameters:

Parameter	Permitted Values	Default
features.hotline_number	String within 32 characters	Blank
Description: Configures the hotline number that the Skype for Business phone automatically dials out when you lift the handset, press the Speakerphone/off-hook key or the line key. Leaving it blank disables hotline feature. Example: features.hotline_number = 1234 Web User Interface: Features->General Information->Hotline Number Phone User Interface: Menu->Features->Hotline->Hot Number		
features.hotline_delay	Integer from 0 to 10	4
Description:		

Parameter	Permitted Values	Default
<p>Configures the waiting time (in seconds) for the Skype for Business phone to automatically dial out the hotline number.</p> <p>If it is set to 0 (0s), the Skype for Business phone will immediately dial out the preconfigured hotline number when you lift the handset, press the Speakerphone/off-hook key or press the line key.</p> <p>If it is set to a value greater than 0, the Skype for Business phone will wait the designated seconds before dialing out the predefined hotline number when you lift the handset, press the Speakerphone/off-hook key or press the line key.</p> <p>Note: Line key is not applicable to T48G Skype for Business phones.</p> <p>Web User Interface:</p> <p>Features->General Information->Hotline Delay(0~10s)</p> <p>Phone User Interface:</p> <p>Menu->Features->Hotline->HotLine Delay</p>		

To configure hotline via web user interface:

1. Click on **Features->General Information**.
2. Enter the hotline number in the **Hotline Number** field.
3. Enter the delay time in the **Hotline Delay(0~10s)** field.

The screenshot shows the Yealink T466 web interface. The 'Features' tab is selected, and the 'General Information' sub-tab is active. The 'Hotline Number' field contains '1234' and the 'Hotline Delay(0~10s)' field contains '4'. These fields are highlighted with a red rectangle. Other settings like 'Call Waiting' (Enabled), 'Key As Send' (#), 'Busy Tone Delay' (0), 'Return code when refuse' (603), 'Time-Out for Dial-Now Rule' (1), 'Dial Search Delay' (1), '180 Ring Workaround' (Disabled), 'Save Call Log' (Enabled), 'Suppress DTMF Display' (Disabled), 'Suppress DTMF Display Delay' (Disabled), 'Play Local DTMF Tone' (Enabled), and 'DTMF Repetition' (3) are also visible. A 'NOTE' section on the right provides additional information about 'Call Waiting' and 'Key As Send'.

4. Click **Confirm** to accept the change.

To configure hotline via phone user interface:

1. Press **Menu->Features->Hot Line**.
2. Enter the hotline number in the **Hot Number** field.
3. Enter the waiting time (in seconds) in the **Hotline Delay** field.
4. Press the **Save** soft key to accept the change.

Contact Management

Your phone can display local contacts, Skype for Business contacts and Outlook contacts.

Users can access directory lists by pressing the **Directory** or **Dir** soft key when the Skype for Business phone is idle.

Skype for Business Directory


The Skype for Business directory on your phone displays all Skype for Business contacts on your Skype for Business client. You can view Skype for Business contacts information on the Skype for Business phone, but you cannot add, edit or delete Skype for Business contacts on the Skype for Business phone.

To add contacts via Skype for Business client:

1. Enter a few continuous characters of the contact name or continuous numbers of the contact number in the Search field.

The contacts whose name or phone number matches the characters entered will appear in your contacts list.

2. Right click the contact, and then click **Add to Contacts List**.




3. Select the desired group.

The contact is added to the selected group.

To view Skype for Business contacts via phone user interface:

1. Press the **Directory** soft key.



2. Select the desired group (e.g., Favorites, Delegates, Bosses or Other Contacts) of Skype for Business directory and then press the **Enter** soft key.


Skype for Business Favorites

You can add your Skype for Business contacts as favorites via your Skype for Business client only.

To add contacts as favorites via Skype for Business client:

1. Right click a contact.

2. Click **Add to Favorites**.



You can view the Skype for Business favorites in the Skype for Business directory or on the idle screen.

To view Skype for Business favorites in the Skype for Business directory:


1. Press **Directory-> Favorites**.

Directory		
1. Local Directory(9)		
2. Favorites(10)		
3. Bosses(1)		
4. Delegates(1)		
5. Other Contacts(2)		
Back	Search	Enter

In addition, Skype for Business favorites of T48G/T46G/T42G/T41P Skype for Business phones are also displayed on the idle screen by default. Skype for Business favorites of T40P Skype for Business phones are displayed in the Skype for Business directory only.

To view the Skype for Business favorites on the idle screen (take T46G as an example):

1. By default, Skype for Business favorites are displayed behind the local favorites on the idle screen.



Monitoring Status Changes using Line Key LED Indicator

The line key LEDs on your phone can monitor Skype for Business favorites for status changes on the phone. For example, you can view the line key LED on the phone to monitor the status of a friend's line (busy or idle). The line key LED illuminates solid red when the friend's line is busy.

Procedure

Line key LED indicator can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the line key LED indicator. Parameter: phone_setting.line_key_led.enable
Local	Web User Interface	Configure the line key LED indicator. Navigate to: <a href="http://<phoneIPAddress>/servlet?p=features-powered&q=load">http://<phoneIPAddress>/servlet?p=features-powered&q=load


Details of Configuration Parameters:

Parameter	Permitted Values	Default
phone_setting.line_key_led.enable	0 or 1	1
Description: Enables or disables the line key LED indicators on the phone to monitor the status of the Skype for Business favorites. 0 -Disabled 1 -Enabled If it is set to 0 (Disabled), the line key LED indicators corresponding to your Skype for		

Parameter	Permitted Values	Default
<p>Business favorites are off.</p> <p>If it is set to 0 (Enabled), the line key LED indicators vary depending on the status of your Skype for Business favorites.</p> <p>Note: It is only applicable to T46G/T42G/T41P Skype for Business phones.</p> <p>Web User Interface:</p> <p>Features->LED-> Line Key Led Light On</p> <p>Phone User Interface:</p> <p>None</p>		

To configure the line key LED indicator via web user interface:

1. Click on **Features->LED**.
2. Select the desired value from the pull-down list of **Line Key Led Light On**.



3. Click **Confirm** to accept the change.

Line key LED indicator on your phone (when configured as Skype for Business favorites)

LED Status	Description
Solid green	The Skype for Business favorite is available.
Solid red	<p>The Skype for Business favorite is busy.</p> <p>The Skype for Business favorite is Do Not Disturb.</p> <p>The call of your Skype for Business favorite is parked.</p> <p>The call of your Skype for Business favorite is placed on hold.</p> <p>The held call of your Skype for Business favorite is resumed.</p> <p>The Skype for Business favorite is in a conference.</p>
Solid yellow	<p>The Skype for Business favorite is right back.</p> <p>The Skype for Business favorite is off work.</p>

LED Status	Description
	The Skype for Business favorite is away.
Off	The Skype for Business favorite is unknown. The Skype for Business favorite is offline. Your phone is locked.

Local Directory

Yealink Skype for Business phones also maintain a local directory. The T48G/T46G/T42G/T41P Skype for Business phones can store up to 1000 contacts. The T40P Skype for Business phones can store up to 100 contacts. When adding a contact to the local directory, in addition to name and phone numbers, you can also specify the ring tone and group for the contact. Contacts can be added either one by one or in batch using a local contact file. Yealink Skype for Business phones support both *.xml and *.csv format contact files, but only support *.xml format download for local contact file.

Customizing a Local Contact File

You can add contacts one by one on the phone directly. You can also add multiple contacts at a time and/or share contacts between phones using the local contact template file. After setup, place the template file to the provisioning server and specify the access URL of the template file in the configuration files. The existing local contacts on the phones will be overridden by the downloaded local contacts.

You can ask the distributor or Yealink FAE for local contact template. You can also obtain the local contact template online:

<http://support.yealink.com/documentFront/forwardToDocumentFrontDisplayPage>.

For more information on obtaining the local contact file, refer to [Obtaining Configuration Files/Resource Files](#) on page 96.

The following table lists meaning of each variable in the local contact template file:

Element	Values	Description
root_group	no	Group list's root element.
group	no	Group's root element.
display_name	All Contacts Favoritelist	An element of group. Group name.
root_contact	no	Contact list's root element.
contact	no	Contact's root element.
display_name	String	An element of contact. Contact name. Note: This value cannot be blank or duplicated.
office_number	String	Office number of the contact.

Element	Values	Description
mobile_number	String	Mobile number of the contact.
other_number	String	Other number of the contact.
address	String	Contact's address.
line	Valid Value: -1 or 0 - -1 stands for Auto (the first registered line) - 0 stands for line1	Since the Skype for Business phones only support 1 account, so no matter -1 or 0 is selected, the contact will all be added to account 1.
ring	Format of the value: System ring tone: - Auto - Resource:Silent.wav - Resource:Splash.wav - Resource:RingN.wav (integer N ranges from 1 to 8) Custom ring tone: Custom:Name.wav	An element of contact. Contact ring tone.
email	String	Contact's email address.
title	String	Contact's title.
priority	For T48G Skype for Business phones: 0~32. For T46G Skype for Business phones: 0~27. For T42G/T41P/T40P Skype for Business phones: 0~15.	It is only applicable to local favorites. Favorites display consecutively, according to their priority. The favorite with the lowest number displays first.
group_id_name	Valid Value: All Contacts, Favoritelist	Group name of a contact.

The following shows the procedure of customizing a local contact file for Skype for Business phones:

To customize a local contact file:

1. Open the template file using an ASCII editor.
2. For each contact that you want to add, add the following string to the file. Each starts on a separate line:

```
<contact display_name="" office_number="" mobile_number="" other_number=""
address="" line="" ring="" email="" title="" priority="" group_id_name="" />
```

- Specify the values within double quotes.

For example:

```
<contact display_name="Yealink" office_number="123" mobile_number="234"
other_number="345" address="china" line="-1" ring="Auto" email="456@yealink.com"
title="manager" priority="0" group_id_name="All Contacts" />
```

```
<root_group>
  <group display_name="All Contacts" />
  <group display_name="Favoritelist" />
  <group />
</root_group>
<root_contact>
  <contact display_name="Yealink" office_number="123" mobile_number="234" other_number="345" address="china"
line="-1" ring="Auto" email="456@yealink.com" title="manager" priority="0" group_id_name="All Contacts" />
</root_contact>
```

- Save the change and place this file to the provisioning server.
- Specify the access URL of the custom local contact template in the configuration files.

For example:

```
local_contact.data.url = tftp://192.168.10.25/contact.xml
```

During the auto provisioning process, the Skype for Business phone connects to the provisioning server "192.168.10.25", and downloads the contact file "contact.xml".

Procedure

Local directory can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Specify the access URL of the local contact file (*.xml). Parameter: local_contact.data.url
Local	Web User Interface	Add a new contact to the local directory. To import or export the local contact file. Navigate to: <a href="http://<phoneIPAddress>/servlet?parameters=contactsbasic&q=load&num=1&group=">http://<phoneIPAddress>/servlet?parameters=contactsbasic&q=load&num=1&group=
	Phone User Interface	Add a new contact to the local directory.

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
local_contact.data.url	URL within 511 characters	Blank

Parameter	Permitted Values	Default
<p>Description:</p> <p>Configures the access URL of the local contact file (*.xml).</p> <p>Example:</p> <p>local_contact.data.url = http://192.168.10.25/contact.xml</p> <p>Web User Interface:</p> <p>Directory->Local Directory->Import Local Contact File</p> <p>Phone User Interface:</p> <p>None</p>		

To add a contact to the local directory via web user interface:

1. Click on **Directory->Local Directory**.
2. In the **Contacts** block, enter name, work number, mobile number, home numbers, email, address and title in the corresponding fields.
3. Select the desired ring tone from the pull-down list of **Ring Tone**.
4. Select **All Contacts** from the pull-down list of **Ring Tone**.


The screenshot displays the Yealink T46G web interface. The top navigation bar includes tabs for Status, Account, Network, Features, Settings, Directory, and Security. The 'Directory' tab is active, showing a 'Local Directory' section with a table of contacts. Below the table, the 'Contacts' form is highlighted with a red box. The form contains the following fields: Name (Yealink), Work Number (1234), Mobile Number (1213), Home Number (1234), Email (2299@yealinkuc.com), Address (Wanghai Road), Title (Manager), Ring Tone (Auto), and Group (All Contacts). To the right of the form is the 'Import Local Contact File' section, which shows 'No file selected' for both XML and CSV formats. A 'NOTE' box on the right side of the page states: 'contactsbasic-note. You can click here to get more guides.'

5. Click **Add** to add the contact.

To import an XML contact list file via web user interface:

1. Click on **Directory->Local Directory**.

- Click **Browse** to locate a contact list file (the file format must be *.xml) from your local system.




- Click **Import XML** to import the contact list.
The web user interface prompts "The original contact will be covered, Continue?".
- Click **OK** to complete importing the contact list.

To import a CSV contact list file via web user interface:

- Click on **Directory**->**Local Directory**.

- Click **Browse** to locate a contact list file (the file format must be *.csv) from your local system.



- (Optional.) Check the **Show Title** checkbox.


It will prevent importing the title of the contact information which is located in the first line of the CSV file.

- Click **Import CSV** to import the contact list.
- (Optional.) Mark the **On** radio box in the **Delete Old Contacts** field.

It will delete all existing contacts while importing the contact list.

- Select the contact information you want to import into the local directory from the pull-down list of **Index**.

At least one item should be selected to be imported into the local directory.



- Click **Import** to complete importing the contact list.

To export a contact list via web user interface:

- Click on **Directory->Local Directory**.
- Click **Export XML** (or **Export CSV**).
- Click **Save** to save the contact list to your local system.

To add a contact to the local directory via phone user interface:

1. Press **Directory**->**Local Directory**->**All Contacts**.
2. Press the **Add** soft key.
3. Enter name, address, work number, mobile number, home number, title and email in the corresponding fields.

4. Press ◀ or ▶, or the **Switch** soft key to select the desired ring tone from the **Ring** field.
5. Press the **Save** soft key to accept the change.

Note

If the contact name already exists in the directory, the LCD screen will prompt "Contact name existed!".


Local Favorites

You can add local contacts as favorites on the Skype for Business phone. You can also reorder your favorites by assigning the contact a different index number.

To add a local favorite via web user interface:

1. Click on **Directory**->**Local Directory**.
2. In the **Contacts** block, enter the contact name, office, mobile, other numbers, Email, address and title in the corresponding fields.
3. Select the desired ring tone from the pull-down list of **Ring Tone**.
4. Select the **Favorites** group from the pull-down list of **Group**.
5. Enter the index number in the **Favorite Index** fields.

Favorites display consecutively, according to their index numbers. The contact with the lowest number displays first.



- Click **Add** to add the contact.

To add a local favorite via phone user interface:

- Press **Directory**->**Local Directory**->**Favorites**.
- Press **Add** soft key.
- Enter the contact name, address, work number, mobile number, home number, title and email in the corresponding fields.

Add Contact	
1. Name:	<input type="text"/>
2. Address:	<input type="text"/>
3. Work Number:	<input type="text"/>
4. Mobile Number:	<input type="text"/>
5. Home Number:	<input type="text"/>
<div>Back Abc Delete Save</div>	

- Press or , or the **Switch** soft key to select the desired ring tone from the **Ring** field.
- Press or , or the **Switch** soft key to select the index number from the **Index** field.
The contact with the lowest priority number displays first. For more information on the number of priority, refer to [priority](#) on page 184.
- Press the **Save** soft key to accept the change.


Managing Local Favorites


Local favorites and Skype for Business favorites of T48G/T46G/T42G/T41P Skype for Business phones are displayed on the idle screen. By default, local favorites are displayed before the Skype for Business favorites.



You can configure whether to display local favorites on the idle screen and configure the display order of the local favorites. This feature is not applicable to T40P Skype for Business phones.

For example: Alex, John, Martin and Mike are your local favorites, 2224-cgc, 2228, 80045 and William are your Skype for Business favorites.


For T48G:


Local favorite is indicated by an  icon. The following figure shows a sample Favorites list.



When the number of favorite contacts is more than 8, the page switch keys will appear on the right side of the Favorites screen. You can tap  or  to turn pages to view other favorites.

For T46G:

Local favorite is indicated by an  icon. The following figure shows a sample Favorites list.




When the number of favorite contacts is more than 9, the line key located in the bottom right corner of the screen will be used to turn pages. Press it to view other favorites.

For T42G/T41P:

Local favorite is indicated by an ★ icon. The following figure shows a sample Favorites list.



When the number of favorite contacts is more than 5, the line key located in the bottom right corner of the screen will be used to turn pages. Press it to view other favorites.



Note Only Skype for Business favorites have presence status.

Procedure

Local favorites can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	<p>Configure whether to display local favorites on the idle screen.</p> <p>Parameter:</p> <p>sfb.local_favorite.enable</p> <p>Configure the display order of the local favorites on the idle screen.</p> <p>Parameter:</p> <p>sfb.local_favorite.sort</p>
Local	Web User Interface	<p>Configure whether to display local favorites on the idle screen.</p> <p>Configure the display order of the local favorites on the idle screen.</p> <p>Navigate to:</p> <p><a href="http://<phoneIPAddress>/servlet?p=contacts-settings&q=load">http://<phoneIPAddress>/servlet?p=contacts-settings&q=load</p>

Details of the Configuration Parameter:


Parameter	Permitted Values	Default
sfb.local_favorite.enable	0 or 1	1
<p>Description:</p> <p>Enables or disables the Skype for Business phone to display local favorites on the idle screen.</p> <p>0-Disabled 1-Enabled</p> <p>If it is set to 0 (Disabled), only Skype for Business favorites are displayed on the idle screen.</p> <p>Note: It is only applicable to T48G/T46G/T42G/T41P Skype for Business phones.</p> <p>Web User Interface:</p> <p>Directory->Settings->Local Favorite</p> <p>Phone User Interface:</p> <p>None</p>		
Parameter	Permitted Values	Default
sfb.local_favorite.sort	1 or 2	1
<p>Description:</p> <p>Configures the order of the local favorites on the idle screen.</p> <p>1-Preferential 2-General</p> <p>If it is set to 1 (Preferential), the local favorites will be displayed before the Skype for Business favorites on the idle screen.</p> <p>If it is set to 2 (General), the local favorites will be displayed after the Skype for Business favorites on the idle screen.</p> <p>Note: It works only if the value of the parameter "sfb.local_favorite.enable" is set to 1 (Enabled). And it is only applicable to T48G/T46G/T42G/T41P Skype for Business phones.</p> <p>Web User Interface:</p> <p>Directory->Settings->Local Favorite</p> <p>Phone User Interface:</p> <p>None</p>		

To configure the display order of local favorites via web user interface:

1. Click on **Directory>Settings**.
2. Select the desired value from the pull-down list of **Local Favorite**.

3. Depending on your selection:

- If **Disabled** is selected, only Skype for Business favorites are displayed on the idle screen.
- If **Preferential** is selected, local favorites will be displayed before the Skype for Business favorites on the idle screen.
- If **General** is selected, the local favorites will be displayed after the Skype for Business favorites on the idle screen.



4. Click **Confirm** to accept the change.

Outlook Contacts

Skype for Business Server and Exchange Server are integrated. You can add Outlook contacts on the Microsoft Outlook software. You can view and search Outlook contacts on your Skype for Business phones.

Procedure

Outlook contacts can be configured using the configuration files only.

Configuration File	<y0000000000xx>.cfg	Configures the number of Outlook contacts that can be displayed when you perform a search. Parameter: phone_setting.search_outlook_contacts.return_number
		Configures the phone to synchronize outlook contacts from the Microsoft Exchange Server. Parameter: exchange.outlook_contact_sync.enable
		Configures the interval (in minutes) for the phone to automatically check if any outlook contacts update available on Microsoft Exchange Server. Parameter: phone_setting.outlook_contacts.update_time

		<p>Configures the phone to display a directory called Outlook Contacts.</p> <p>Parameter: exchange.outlook_contact.enable</p>
		<p>Configure the maximum outlook contacts that can be downloaded from the Microsoft Exchange Server.</p> <p>Parameter: exchange.outlook_contact.request_number</p>

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
phone_setting.search_outlook_contacts.return_number	20	Refer to the following content
<p>Description: It configures the number of results searched from the Outlook Directory when you perform a search.</p> <p>Web User Interface: None</p> <p>Phone User Interface: None</p>		
exchange.outlook_contact_sync.enable	0 or 1	Refer to the following content
<p>Description: It enables or disables the phone to synchronize outlook contacts from the Exchange Server.</p> <p>0-Disabled 1-Enabled</p> <p>For T48G/T46G/T42G/T41P: The default value is 1;</p> <p>For T40P: The default value is 0;</p> <p>Note: If you change this parameter, the Skype for Business phone will reboot to make the change take effect.</p> <p>Web User Interface: None</p> <p>Phone User Interface:</p>		


Parameter	Permitted Values	Default
None		
phone_setting.outlook_contacts.update_time	Integer from 0 to 100	10
<p>Description:</p> <p>It configures the interval (in minutes) for the phone to automatically check if any outlook contacts update available on Microsoft Exchange Server.</p> <p>If it is set to 10 (in minutes), the phone will check if any outlook contact update available on the Microsoft Exchange Server every 10 minutes. If an update is available, the phone will download the outlook contacts.</p> <p>Note: If you change this parameter, the Skype for Business phone will reboot to make the change take effect.</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p> <p>None</p>		
exchange.outlook_contact.enable	0 or 1	0
<p>Description:</p> <p>It enables or disables the phone to display a directory called Outlook Contacts. This directory will include your Outlook contacts.</p> <p>0-Disabled</p> <p>1-Enabled</p> <p>Note: It is only applicable to T48G Skype for Business phones.</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p> <p>None</p>		
exchange.outlook_contact.request_number	Integer from 1 to 5000	100
<p>Description:</p> <p>Configures the maximum outlook contacts that can be downloaded from the Exchange Server.</p> <p>For T48G/T46G:</p> <p>The maximum value is 500.</p>		

Parameter	Permitted Values	Default
<p>For T42G/T41P:</p> <p>The maximum value is 300.</p> <p>For T40P:</p> <p>The maximum value is 100.</p> <p>Note: If you change this parameter, the Skype for Business phone will reboot to make the change take effect.</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p> <p>None</p>		


Adding Outlook Contacts

To add an Outlook contact via Microsoft Outlook software:

1. Click **People** at the bottom of the screen.



2. Click **HOME**->**New Contacts**.



3. Enter a name and any other information that you want to include for the contact.
4. If you want to immediately create another contact, click **Save & New** (this way, you don't have to start over for each contact). After you have added new contacts, click **Save & Close**.

Searching Outlook Contacts

To search Outlook contacts via phone user interface:

1. On the pre-dialing screen, enter the first few continuous characters of the Outlook contact name or number. The phone performs an Intelligent search (e.g., press the digit key 2 to search the letters "2, a, b and c").

The entries whose name or phone number matches the characters entered will appear on

the LCD screen. The search results are from your Skype for Business contacts, local contacts and Microsoft Outlook contacts.


Viewing Outlook Contacts


If you have configured the T48G Skype for Business phones to display a directory named **Outlook Contacts** using parameter "exchange.outlook_contact.enable", the **Outlook Contacts** directory will include your Outlook contacts.

Note

Outlook Contacts directory is not applicable to T46G/T42G/T41P/T40P Skype for Business phones.

To view Outlook contacts in T48G Skype for Business phone's directory:

1. Tap  -> **Outlook Contacts**.



Call Log

Save Call Log

Skype for Business phones record and maintain phone events to a call log, also known as a call list. The call log contains call information such as remote party identification, time and date of the call, and call duration. It can be used to redial previous outgoing calls and return incoming calls.

Skype for Business phones maintain a local call log. Call log consists of four lists: Missed Calls, Placed Calls, Received Calls, and Forwarded Calls (Forwarded Calls are not applicable to T48G Skype for Business phones). Each call log list supports up to 100 entries. To store call information, you must enable save call log feature in advance. You can access the call history information via phone user interface only.

Procedure

Call log can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure call log feature. Parameter: features.save_call_history
Local	Web User Interface	Configure call log feature. Navigate to: http://<phoneIPAddress>/servlet?p=features-general&q=load
	Phone User Interface	Configure call log feature.

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
features.save_call_history	0 or 1	1
Description: Enables or disables the Skype for Business phone to save the call log. 0 -Disabled 1 -Enabled If it is set to 0 (Disabled), the Skype for Business phone cannot save the missed calls, placed calls, received calls and the forwarded calls in the call log lists. Web User Interface: Features->General Information->Save Call Log Phone User Interface: Menu->Features->History Setting->History Record		

To save call log feature via web user interface:

1. Click on **Features->General Information**.

2. Select the desired value from the pull-down list of **Save Call Log**.

The screenshot shows the Yealink T466 web interface with the 'Features' tab selected. In the 'General Information' section, the 'Save Call Log' option is set to 'Enabled' and is highlighted with a red box. Other settings include 'Call Waiting' (Enabled), 'Key As Send' (#), 'Hotline Number' (1234), 'Hotline Delay' (4s), 'Busy Tone Delay' (0s), 'Return code when refuse' (603), 'Time-Out for Dial-Now Rule' (1s), 'Dial Search Delay' (1s), '180 Ring Workaround' (Disabled), 'Suppress DTMF Display' (Disabled), 'Suppress DTMF Display Delay' (Disabled), 'Play Local DTMF Tone' (Enabled), and 'DTMF Repetition' (3).

3. Click **Confirm** to accept the change.

To configure call log feature via phone user interface:

1. Press **Menu->Features->History Setting**.
2. Press **Left** or **Right** arrow, or the **Switch** soft key to select the desired value from the **History Record** field.
3. Press the **Save** soft key to accept the change.

User or administrator can access call logs by downloading them to the local system for diagnosis purpose.

To export the call logs via web user interface:


1. Click on **Settings->Configuration**.
2. Click **Export** to open file download window, and then save the file to your local system.

The screenshot shows the Yealink T466 web interface with the 'Settings' tab selected. In the 'Configuration' section, the 'Export Call Log' button is highlighted with a red box. Other settings include 'Export or Import Configuration' (Browse... No file selected.), 'Pcap Feature' (Start, Stop, Export), 'Export System Log' (Local, Server), and 'System Log Level' (3).

To view the call logs on your local system:

1. Open the folder where you save the call logs.
2. Double-click the call logs file that is in .xml format.

The following figure shows a portion of a call logs file:



Missed Call Log

Missed call log allows the Skype for Business phone to display the number of missed calls with an indicator icon on the idle screen, and to log missed calls in the Missed Calls list when the Skype for Business phone misses calls. Once the user accesses the Missed Calls list, the prompt message and indicator icon on the idle screen disappear.

Procedure

Missed call log can be configured using the configuration files or locally.

Configuration File	<MAC>.cfg	Configure missed call log feature. Parameter: account.1.missed_callog
Local	Web User Interface	Configure missed call log feature. Navigate to: <a href="http://<phoneIPAddress>/servlet?p=account-basic&q=load&acc=0">http://<phoneIPAddress>/servlet?p=account-basic&q=load&acc=0


Details of the Configuration Parameter:

Parameter	Permitted Values	Default
account.1.missed_callog	0 or 1	1
Description: Enables or disables the Skype for Business phone to indicate and record missed calls for the account. 0 -Disabled 1 -Enabled		

Parameter	Permitted Values	Default
<p>If it is set to 0 (Disabled), the Skype for Business phone does not display indicator on the idle screen and log the missed call in the Missed Calls list when missed calls.</p> <p>If it is set to 1 (Enabled), the Skype for Business phone displays a message on the idle screen and logs the missed call in the Missed Calls list when missed calls.</p> <p>Note: It works only if the value of the parameter “features.save_call_history” is set to 1 (Enabled).</p> <p>Web User Interface:</p> <p>Account->Basic->Missed Call Log</p> <p>Phone User Interface:</p> <p>None</p>		

To configure missed call log via web user interface:

1. Click on **Account->Basic**.
2. Select the desired value from the pull-down list of **Missed Call Log**.



3. Click **Confirm** to accept the change.

History Record Contacts Avatar

History record contacts avatar allows the history record to display the contact avatars.

Procedure

History record contacts avatar can be configured using the configuration files or locally.

Configuration File	<MAC>.cfg	<p>Configure the History record contacts avatar.</p> <p>Parameter:</p> <p>features.call_history_contacts_avator.enable</p>
Local	Web User Interface	Configure the History record contacts

		avatar. Navigate to: <a href="http://<phoneIPAddress>/servlet?p=features-general&q=load">http://<phoneIPAddress>/servlet?p=features-general&q=load
--	--	---

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
features.call_history_contacts_avator.enable	0 or 1	1
Description: Enables or disables the history record to display the contact avatars. 0 -Disabled 1 -Enabled If it is set to 0 (Disabled), the history records do not display contact avatars. If it is set to 1 (Enabled), the history records display contact avatars. Note: It is only applicable to T48G and T46G Skype for Business phones. Web User Interface: Features->General Information->History Record Contacts Avatar Phone User Interface: Menu->Features->History Setting->Contacts Avatar		

To configure contacts avatar feature via web user interface:

1. Click on **Features->General Information**.

2. Select the desired value from the pull-down list of **History Record Contacts Avatar**.

The screenshot shows the Yealink T46G web interface. The 'Features' tab is selected. Under 'General Information', the 'History Record Contacts Avatar' is set to 'Enabled'. A red box highlights this setting. On the right, a 'NOTE' section contains the following text:

Call Waiting
This call feature allows your phone to accept other incoming calls during the conversation.

Key As Send
Select * or # as the send key.

You can click here to get more guides.

3. Click **Confirm** to accept the change.

To configure contacts avatar feature via phone user interface:

1. Press **Menu->Features->History Setting**.
2. Press or , or the **Switch** soft key to select the desired value from the **Contacts Avatar** field.
3. Press the **Save** soft key to accept the change.

Dial Search Delay

Dial search delay defines a period of delay time before the Skype for Business phones automatically displays the search results. It is applicable only when searching contacts on the dialing screen.

Procedure

Dial search delay can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure dial search delay feature. Parameter: sfb.search_delay_time
---------------------------	---------------------	--


Local	Web User Interface	Configure dial search delay feature. Navigate to: <a href="http://<phoneIPAddress>/servlet?p=features-general&q=load">http://<phoneIPAddress>/servlet?p=features-general&q=load
--------------	--------------------	--

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
sfb.search_delay_time	Integer from 1 to 10	1
<p>Description:</p> <p>Configures the delay time (in seconds) for the Skype for Business phone to automatically display the search results on the dialing screen.</p> <p>Example:</p> <p>sfb.search_delay_time = 1</p> <p>Web User Interface:</p> <p>Features->General Information->Dial Search Delay</p> <p>Phone User Interface:</p> <p>None</p>		

To configure dial search delay via web user interface:

1. Click on **Features->General Information**.
2. Select the desired value from the pull-down list of **Dial Search Delay**.



3. Click **Confirm** to accept the change.

Live Dialpad

Live dialpad allows Skype for Business phones to automatically dial out the entered phone number after a specified period of time.

Procedure

Live dialpad can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure live dialpad. Parameters: phone_setting.predial_autodial phone_setting.inter_digit_time
Local	Web User Interface	Configure live dialpad. Navigate to: <a href="http://<phoneIPAddress>/servlet?parameters=settings-preference&q=load">http://<phoneIPAddress>/servlet?parameters=settings-preference&q=load


Details of Configuration Parameters:

Parameters	Permitted Values	Default
phone_setting.predial_autodial	0 or 1	0
Description: Enables or disables live dialpad feature. 0 -Disabled 1 -Enabled If it is set to 1 (Enabled), the Skype for Business phone will automatically dial out the entered phone number on the dialing screen without pressing a send key. Web User Interface: Settings->Preference->Live Dialpad Phone User Interface: None		
phone_setting.inter_digit_time	Integer from 1 to 14	8
Description: Configures the delay time (in seconds) for the Skype for Business phone to automatically dial out the entered digits without pressing a send key. Note: It works only if the value of the parameter "phone_setting.predial_autodial" is set to 1 (Enabled).		

Parameters	Permitted Values	Default
Web User Interface:		
None		
Phone User Interface:		
None		

To configure live dialpad via web user interface:

1. Click on **Settings->Preference**.
2. Select the desired value from the pull-down list of **Live Dialpad**.



3. Click **Confirm** to accept the change.

Call Waiting

Call waiting allows Skype for Business phones to receive a new incoming call when there is already an active call. The new incoming call is presented to the user visually on the LCD screen. Call waiting tone allows the Skype for Business phone to play a short tone, to remind the user audibly of a new incoming call during conversation. Call waiting tone works only if call waiting is enabled. You can customize call waiting tone or select specialized tone sets (vary from country to country) for your Skype for Business phone. For more information, refer to [Tones](#) on page 287.

Procedure

Call waiting and call waiting tone can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure call waiting and call waiting tone. Parameters: call_waiting.enable call_waiting.tone
Local	Web User Interface	Configure call waiting.

		Navigate to: <a href="http://<phoneIPAddress>/servlet?parameters=features-general&q=load">http://<phoneIPAddress>/servlet?parameters=features-general&q=load
		Configure call waiting tone. Navigate to: <a href="http://<phoneIPAddress>/servlet?parameters=features-audio&q=load">http://<phoneIPAddress>/servlet?parameters=features-audio&q=load
	Phone User Interface	Configure call waiting and call waiting tone.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
call_waiting.enable	0 or 1	1
Description: Enables or disables call waiting feature. 0 -Disabled 1 -Enabled If it is set to 0 (Disabled), a new incoming call is automatically rejected by the Skype for Business phone with a busy message while during a call. If it is set to 1 (Enabled), the LCD screen will present a new incoming call while during a call. Web User Interface: Features->General Information->Call Waiting Phone User Interface: Menu->Features->Call Waiting->Call Waiting		
call_waiting.tone	0 or 1	1
Description: Enables or disables the Skype for Business phone to play the call waiting tone when the Skype for Business phone receives an incoming call during a call. 0 -Disabled 1 -Enabled If it is set to 1 (Enabled), the Skype for Business phone will perform an audible indicator when receiving a new incoming call during a call. Note: It works only if the value of the parameter "call_waiting.enable" is set to 1 (Enabled). Web User Interface: Features->Audio->Call Waiting Tone		

Parameters	Permitted Values	Default
Phone User Interface: Menu->Features->Call Waiting->Play Tone		

To configure call waiting via web user interface:

1. Click on **Features->General Information**.
2. Select the desired value from the pull-down list of **Call Waiting**.

The screenshot shows the Yealink T46G web interface. The 'Features' tab is selected, and the 'General Information' sub-tab is active. A red box highlights the 'Call Waiting' dropdown menu, which is currently set to 'Enabled'. Other settings visible include 'Key As Send' (set to '#'), 'Hotline Number' (1234), 'Hotline Delay' (4), 'Busy Tone Delay' (0), 'Return code when refuse' (603), 'Time-Out for Dial-Now Rule' (1), 'Dial Search Delay' (1), '180 Ring Workaround' (Disabled), 'Save Call Log' (Enabled), 'Suppress DTMF Display' (Disabled), 'Suppress DTMF Display Delay' (Disabled), 'Play Local DTMF Tone' (Enabled), and 'DTMF Repetition' (3). A 'NOTE' section on the right explains the 'Call Waiting' feature and the 'Key As Send' options.

3. Click **Confirm** to accept the change.

To configure call waiting tone via web user interface:

1. Click on **Features->Audio**.
2. Select the desired value from the pull-down list of **Call Waiting Tone**.



The screenshot shows the Yealink T46G web interface. The 'Features' tab is selected, and the 'Audio' sub-tab is active. A red box highlights the 'Call Waiting Tone' dropdown menu, which is currently set to 'Enabled'. Other settings visible include 'Key Tone' (Enabled), 'Pre Dial Tone' (Disabled), 'Send Sound' (Enabled), 'Redial Tone' (empty), 'Ringer Device for Headset' (Use Speaker), and 'BToE as Audio Device (VDI support)' (Disabled). A 'NOTE' section on the right explains the 'Audio' parameters for the administrator. At the bottom, there are 'Confirm' and 'Cancel' buttons.

3. Click **Confirm** to accept the change.

To configure call waiting and call waiting tone via phone user interface:

1. Press **Menu->Features->Call Waiting**.
2. Press or , or the **Switch** soft key to select the desired value from the **Call**

Waiting field.

3. Press  or  , or the **Switch** soft key to select the desired value from the **Play Tone** field.
4. Press the **Save** soft key to accept the change.

Auto Answer

Auto answer allows Skype for Business phones to automatically answer an incoming call. Skype for Business phones will not automatically answer the incoming call during a call even if auto answer is enabled. Auto answer is configurable on a per-line basis. Auto-Answer delay defines a period of delay time before the Skype for Business phone automatically answers incoming calls.

Procedure

Auto answer can be configured using the configuration files or locally.

Configuration File	<MAC>.cfg	Configure auto answer. Parameter: account.1.auto_answer
	<y0000000000xx>.cfg	Specify a period of delay time for auto answer. Parameter: features.auto_answer_delay
Local	Web User Interface	Configure auto answer. Navigate to: <a href="http://<phoneIPAddress>/servlet?p=account-basic&q=load&acc=0">http://<phoneIPAddress>/servlet?p=account-basic&q=load&acc=0 Specify a period of delay time for auto answer. Navigate to: <a href="http://<phoneIPAddress>/servlet?p=features-general&q=load">http://<phoneIPAddress>/servlet?p=features-general&q=load


Details of Configuration Parameters:

Parameters	Permitted Values	Default
account.1.auto_answer	0 or 1	0
Description: Enables or disables auto answer feature for the account.		

Parameters	Permitted Values	Default
0-Disabled 1-Enabled If it is set to 1 (Enabled), the Skype for Business phone can automatically answer an incoming call. Note: The Skype for Business phone cannot automatically answer the incoming call during a call even if auto answer is enabled. Web User Interface: Account->Basic->Auto Answer Phone User Interface: Menu->Features->Auto Answer->Line 1->Auto Answer		
features.auto_answer_delay	Integer from 1 to 4	1
Description: Configures the delay time (in seconds) before the Skype for Business phone automatically answers an incoming call. Web User Interface: Features->General Information->Auto-Answer Delay(1~4s) Phone User Interface: None		

To configure auto answer via web user interface:

1. Click on **Account->Basic**.
2. Select the desired value from the pull-down list of **Auto Answer**.



3. Click **Confirm** to accept the change.

To configure a period of delay time for auto answer via web user interface:

1. Click on **Features->General Information**.

- Enter the desired time in the **Auto-Answer Delay(1~4s)** field.

The screenshot shows the Yealink T46G web interface. The 'Features' tab is selected, and the 'General Information' section is expanded. The 'Auto-Answer Delay(1~4s)' field is highlighted with a red box and contains the value '1'. The interface includes a sidebar with 'General Information', 'Audio', 'Remote Control', 'Bluetooth', and 'LED'. The top navigation bar has tabs for 'Status', 'Account', 'Network', 'Features', 'Settings', 'Directory', and 'Security'. A 'NOTE' section on the right explains 'Call Waiting' and 'Key As Send'.

- Click **Confirm** to accept the change.

To configure auto answer via phone user interface:

- Press **Menu->Features->Auto Answer->Line 1-> Auto Answer**.
- Press **◀** or **▶**, or the **Switch** soft key to select the desired value from the **Auto Answer** field.
- Press the **Save** soft key to accept the change.

Busy Tone Delay

Busy tone is audible to the other party, indicating that the call connection has been broken when one party releases a call. Busy tone delay can define a period of time during which the busy tone is audible.

Procedure

Busy tone delay can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure busy tone delay. Parameter: features.busy_tone_delay
Local	Web User Interface	Configure busy tone delay. Navigate to: http://<phoneIPAddress>/servlet?p


		=features-general&q=load
--	--	--------------------------

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
features.busy_tone_delay	0, 3 or 5	0
<p>Description:</p> <p>Configures the duration time (in seconds) for the busy tone.</p> <p>When one party releases the call, a busy tone is audible to the other party indicating that the call connection breaks.</p> <p>0-0s</p> <p>3-3s</p> <p>5-5s</p> <p>If it is set to 3 (3s), a busy tone is audible for 3 seconds on the Skype for Business phone.</p> <p>Web User Interface:</p> <p>Features->General Information->Busy Tone Delay (Seconds)</p> <p>Phone User Interface:</p> <p>None</p>		

To configure busy tone delay via web user interface:

1. Click on **Features->General Information**.
2. Select the desired value from the pull-down list of **Busy Tone Delay (Seconds)**.



3. Click **Confirm** to accept the change.

Return Code When Refuse

Return code when refuse defines the return code and reason of the SIP response message for the refused call. The caller's phone LCD screen displays the reason according to the received return code. Available return codes and reasons are:

- 404 (Not Found)
- 480 (Temporarily Not Available)
- 486 (Busy Here)
- 603 (Decline)

Procedure

Return code for refused call can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Specify the return code and the reason of the SIP response message when refusing a call. Parameter: features.normal_refuse_code
Local	Web User Interface	Specify the return code and the reason of the SIP response message when refusing a call. Navigate to: <a href="http://<phoneIPAddress>/servlet?p=features-general&q=load">http://<phoneIPAddress>/servlet?p=features-general&q=load


Details of the Configuration Parameter:

Parameter	Permitted Values	Default
features.normal_refuse_code	404, 480, 486 or 603	603
Description: Configures a return code and reason of SIP response messages when the Skype for Business phone rejects an incoming call. A specific reason is displayed on the caller's phone LCD screen. 404 -Not Found 480 -Temporarily Not Available 486 -Busy Here 603 -Decline If it is set to 486 (Busy Here), the caller's phone LCD screen will display the message "Busy		

Parameter	Permitted Values	Default
Here" when the callee rejects the incoming call.		
Web User Interface:		
Features->General Information->Return Code When Refuse		
Phone User Interface:		
None		

To specify the return code and the reason when refusing a call via web user interface:

1. Click on **Features->General Information**.
2. Select the desired value from the pull-down list of **Return Code When Refuse**.



3. Click **Confirm** to accept the change.

Early Media

Early media refers to media (e.g., audio and video) played to the caller before a SIP call is actually established. Current implementation supports early media through the 183 message. When the caller receives a 183 message with SDP before the call is established, a media channel is established. This channel is used to provide the early media stream for the caller.

180 Ring Workaround

180 ring workaround defines whether to deal with the 180 message received after the 183 message. When the caller receives a 183 message, it suppresses any local ringback tone and begins to play the media received. 180 ring workaround allows Skype for Business phones to resume and play the local ringback tone upon a subsequent 180 message received.

Procedure

180 ring workaround can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure 180 ring workaround. Parameter: phone_setting.is_deal180
Local	Web User Interface	Configure 180 ring workaround. Navigate to: http://<phoneIPAddress>/servlet?p =features-general&q=load

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
phone_setting.is_deal180	0 or 1	0
Description: Enables or disables the Skype for Business phone to deal with the 180 SIP message received after the 183 SIP message. 0 -Disabled 1 -Enabled If it is set to 1 (Enabled), the Skype for Business phone will resume and play the local ringback tone upon a subsequent 180 message received. Web User Interface: Features->General Information->180 Ring Workaround Phone User Interface: None		

To configure 180 ring workaround via web user interface:

1. Click on **Features->General Information**.

- Select the desired value from the pull-down list of **180 Ring Workaround**.

The screenshot shows the Yealink T466 web interface. The 'Features' tab is selected. In the 'General Information' section, the '180 Ring Workaround' dropdown menu is highlighted with a red box, showing 'Disabled' as the selected option. The interface includes a sidebar with 'General Information', 'Audio', 'Remote Control', 'Bluetooth', and 'LED'. The main area lists various features like Call Waiting, Key As Send, Hotline Number, and 180 Ring Workaround. A 'NOTE' section on the right explains the 'Call Waiting' and 'Key As Send' features.

- Click **Confirm** to accept the change.

Call Hold

Call hold provides a service of placing an active call on hold. The purpose of call hold is to pause activity on the existing call so that you can use the phone for another task (e.g., to place or receive another call).

When a call is placed on hold, the phones send an INVITE request with HOLD SDP to request remote parties to stop sending media and to inform them that they are being held. Phones support two call hold methods, one is [RFC 3264](#), which sets the "a" (media attribute) in the SDP to sendonly, recvonly or inactive (e.g., a=sendonly). The other is [RFC 2543](#), which sets the "c" (connection addresses for the media streams) in the SDP to zero (e.g., c=0.0.0.0).

Call hold tone allows phones to play a warning tone at regular intervals when there is a call on hold. The warning tone is played through the speakerphone.

Procedure

Call hold can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the call hold tone and call hold tone delay. Parameters: features.play_hold_tone.enable features.play_hold_tone.delay
Local	Web User Interface	Configure the call hold tone and call hold tone delay. Navigate to: <a href="http://<phoneIPAddress>/servlet?p">http://<phoneIPAddress>/servlet?p

		=features-general&q=load
--	--	--------------------------

Details of Configuration Parameters:

Parameters	Permitted Values	Default
features.play_hold_tone.enable	0 or 1	1
Description: Enables or disables the Skype for Business phone to play a warning tone when there is a call on hold. 0 -Disabled 1 -Enabled Web User Interface: Features->General Information->Play Hold Tone Phone User Interface: None		
features.play_hold_tone.delay	Integer from 3 to 3600	30
Description: Configures the interval (in seconds) at which the Skype for Business phone play a warning tone when there is a call on hold. If it is set to 30 (30s), the Skype for Business phone will play a warning tone every 30 seconds when there is a call on hold. Note: It works only if the value of the parameter "features.play_hold_tone.enable" is set to 1 (Enabled). Web User Interface: Features->General Information->Play Hold Tone Delay Phone User Interface: None		

To configure call hold tone and call hold tone delay via web user interface:

1. Click on **Features->General Information**.
2. Select the desired value from the pull-down list of **Play Hold Tone**.

3. Enter the desired time in the **Play Hold Tone Delay** field.

The screenshot shows the Yealink T46G web interface. The 'Features' tab is selected, and the 'General Information' section is expanded. The 'Play Hold Tone' and 'Play Hold Tone Delay' fields are highlighted with a red box. The 'Play Hold Tone' is set to 'Enabled' and 'Play Hold Tone Delay' is set to '30'. A 'NOTE' section on the right explains 'Call Waiting' and 'Key As Send'.

4. Click **Confirm** to accept the change.

Music on Hold

Music on Hold (MoH) is the business practice of playing recorded music to fill the silence that would be heard by the party who has been placed on hold. When a call is placed on hold, the Skype for Business phone will play built-in ring tone to the held party.

Procedure

Music on hold can be configured using the configuration file only.

Configuration File	<y0000000000xx>.cfg	Configure the music on hold feature. Parameter: sfb.music_on_hold.enable
---------------------------	---------------------	---

Details of the Configuration Parameter:

Parameters	Permitted Values	Default
sfb.music_on_hold.enable	0 or 1	0
Description:		

Parameters	Permitted Values	Default
<p>Enables or disables the Music on Hold feature when placing an active call on hold.</p> <p>0-Disabled</p> <p>1-Enabled</p> <p>If it is set to 1 (Enabled), the Skype for Business phone will play music to the held party when placing an active call on hold.</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p> <p>None</p>		

Call Forward

Call forward allows users to redirect an incoming call to a third party or voicemail box. Skype for Business phones redirect an incoming INVITE message by responding with a 303 Moved See Other message, which contains a Contact header with a new URI that should be tried. Three types of call forward:

- **Forward to Voice Mail:** incoming calls are forwarded to voice mailbox.
- **Forward Calls to Number or Contact:** incoming calls are forwarded to the preset number.
- **Simultaneously Ring:** the preset number will ring simultaneously when you receive an incoming call.

Diversion/History-Info

Skype for Business phones support the redirected call information sent by the SIP server with Diversion header, per draft-levy-sip-diversion-08, or History-info header, per RFC 4244. The Diversion/History-info header is used to inform the Skype for Business phone of a call's history. For example, when a phone has been set to enable call forward, the Diversion/History-info header allows the receiving phone to indicate who the call was from, and from which phone number it was forwarded.

Forward International

Forward international allows users to forward an incoming call to an international telephone number (the prefix is 00). This feature is enabled by default.

Procedure

Call forward can be configured using the configuration files or locally.

Procedure

Call forward can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure diversion/history-info feature. Parameter: features.fwd_diversion_enable
		Configure forward international. Parameter: forward.international.enable
Local	Web User Interface	Configure diversion/history-info feature. Configure forward international. Navigate to: http://<phoneIPAddress>/servlet?p=features-general&q=load
	Phone User Interface	Configure call forward. Configure forward international.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
features.fwd_diversion_enable	0 or 1	1
Description: Enables or disables the Skype for Business phone to present the diversion information when an incoming call is forwarded to your Skype for Business phone. 0 -Disabled 1 -Enabled Web User Interface: Features->General Information->Diversion/History-Info Phone User Interface: None		
forward.international.enable	0 or 1	1

Parameters	Permitted Values	Default
<p>Description:</p> <p>Enables or disables the Skype for Business phone to forward incoming calls to international numbers (the prefix is 00).</p> <p>0-Disabled</p> <p>1-Enabled</p> <p>Web User Interface:</p> <p>Features->General Information->Fwd International</p> <p>Phone User Interface:</p> <p>Menu-> Advanced (default password: admin)->FWD International->FWD International</p>		

To configure Diversion/History-Info feature via web user interface:

1. Click on **Features->General Information**.
2. Select the desired value from the pull-down list of **Diversion/History-Info**.

The screenshot shows the Yealink T46G web interface. The 'Features' tab is selected, and the 'General Information' sub-tab is active. The 'Diversion/History-Info' dropdown menu is highlighted with a red box and set to 'Enabled'. Other settings include Call Waiting (Enabled), Key As Send (#), Hotline Number, Hotline Delay (0~10s), Busy Tone Delay (Seconds), Return code when refuse (603 (Decline)), Auto-Logout Time (1~1000min), Call Number Filter, Voice Mail Tone (Enabled), DHCP Hostname (SIP-T46G), E911 Location Tip (Enabled), Update Checking Time (24), Use DHCP Option 120 (Disabled), SFB Cert Service URL, Enable SFB Automation (Disabled), SFB Inactive Time (5), SFB Away Time (5), Web Sign in (Enabled), Remember Password (Disabled), and History Record Contacts Avatar (Enabled). A 'NOTE' section on the right explains 'Call Waiting' and 'Key As Send'.

3. Click **Confirm** to accept the change.

To configure forward international via web user interface:

1. Click on **Features->General Information**.

- Select the desired value from the pull-down list of **Fwd International**.



The screenshot shows the Yealink T46G web interface. The 'Features' tab is selected. In the 'General Information' section, the 'Fwd International' option is highlighted with a red box. The interface includes a sidebar with 'General Information', 'Audio', 'Remote Control', 'Bluetooth', and 'LED'. The main area lists various features like Call Waiting, Key As Send, Hotline Number, and Fwd International, each with a pull-down menu and a help icon. A 'NOTE' section on the right provides additional information about 'Call Waiting' and 'Key As Send'.

- Click **Confirm** to accept the change.

To enable call forward via phone user interface:

- Press **Menu->Features->Call Forward**.
- Press **▲** or **▼** to select the desired forwarding type.
- Depending on your selection:
 - If you select **Forward to Voice Mail**, and press the **Save** soft key.
The prompting message "Forward to Voice Mail" appears on the LCD screen.
 - If you select **Forward Calls to Number or Contact**, and then press the **Enter** soft key:
 - Enter the desired number in the **Forward to** field.
 - Press the **Save** soft key to accept the change.
The prompting message "Call Forwarding On" appears on the LCD screen.
 - If you select **Simultaneously Ring**, and then press the **Enter** soft key:
 - Enter the desired number in the **Simultaneously Ring** field.
 - Press the **Save** soft key to accept the change.
The prompting message "Simultaneously Ring On" appears on the LCD screen.

To configure forward international via phone user interface:

1. Press **Menu**-> **Advanced** (default password: admin) -> **FWD International**.
2. Press  or , or the **Switch** soft key to select the desired value from the **FWD International** field.
3. Press the **Save** soft key to accept the change.


Team-Call Group


A team-call group is a team of people who can answer your work calls. You can add or remove members, and select when they can answer calls for you. Team-call group can be configured via Skype for Business client only.

For example, you have a team of people working on the same project or tasks. If one of your team members is away from his desk and his phone rings, anyone in the team-call group can answer the call for him. As soon as a team member picks up the phone, the other phones stop ringing.


Setting up Team-call Group

To set up team-call group using Skype for Business client:

1. Open Skype for Business client.
2. Sign into Skype for Business client.
3. Click the  button, and then click **Call Forwarding Settings**.
4. Mark the radio box in **Simultaneously ring** field.
5. Select **My Team-Call Group** from the pull-down list of **Simultaneously ring**.



6. In the **Team-Call Group** dialog box, click **Add** to choose team-call group members.
7. Click the **Ring your team-call group after this many seconds** pull-down list to determine when your team-call group members' phones ring.



8. Click **OK**.
9. Click **OK** in the **My Team-Call Group** dialog box.
10. Click **OK** in the **Options** dialog box.

Simultaneous ringing is enabled for all assigned team-call members. If your line receives an incoming call, other phones in the team-call group will ring too.

Team-Call Ringtone

Team-call ring tone feature allows the phone to play a distinct ringtone when receiving a team-call.

Procedure

Team-call ring tone can be configured using the configuration files or locally.



Configuration File	<y0000000000xx>.cfg	Configure a ring tone for the team-call. Parameter: phone_setting.team_call_ring.enable phone_setting.team_call_ring_type
Local	Phone User Interface	Configure a ring tone for the team-call.

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
phone_setting.team_call_ring.enable	0 or 1	1

Parameter	Permitted Values	Default
<p>Description:</p> <p>Enables or disables the phone to play a distinct ringtone for team-call.</p> <p>0-Disabled</p> <p>1-Enabled</p> <p>If it is set to 0 (Disabled), incoming calls to team-call group will use the phone's ring tone. The phone's ring tone is configured by the parameter "phone_setting.ring_type".</p> <p>If it is set to 1 (Enabled), you can set a distinct ringtones for team-call.</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p> <p>None</p>		
phone_setting.team_call_ring_type	Refer to the following content	Ring1.wav
<p>Description:</p> <p>Configures a ring tone for the team-call.</p> <p>Permitted Values:</p> <p>Ring1.wav, Ring2.wav, Ring3.wav, Ring4.wav, Ring5.wav, Ring6.wav, Ring7.wav, Ring8.wav, Silent.wav, Splash.wav or custom ring tone name (e.g., Customring.wav).</p> <p>Example:</p> <p>To configure a phone built-in ring tone (e.g., Ring1.wav):</p> <p>phone_setting.team_call_ring_type = Ring1.wav</p> <p>To configure a custom ring tone (e.g., Customring.wav):</p> <p>phone_setting.team_call_ring_type = Customring.wav</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p> <p>Menu->Basic->Sounds->Ring Tones->Team-call</p>		

To set a ringtone for the team-call via phone user interface:

1. Press **Menu->Basic->Sounds->Ring Tones->Team-call**.
2. Press  or  to select a ring tone.
3. Press the **Save** soft key to accept the change.

Response Group

If you sign into the phone using Onprem account, you can use response groups feature. Current Online environment does not support this feature.

If your organization has groups of people who answer and manage certain types of calls, such as for customer service, an internal help desk, or general telephone support for a department, you can deploy the Response Group application to manage these types of calls. The Response Group application routes and queues incoming calls to designated persons, who are known as agents. You can increase the use of telephone support services and reduce the overhead of running these services by using response groups.

When a caller calls a response group, the call is routed to an agent based on a hunt group or the caller's answers to interactive voice response (IVR) questions.

If no agents are available, the call is held in a queue until an agent is available. While in the queue, the caller hears music until an available agent accepts the call. If the queue is full, or if the call times out while in the queue, the caller might hear a message and then is either disconnected or transferred to a different destination, such as a different phone number or voicemail.

The Response Group application uses standard response group routing methods to route the call to the next available agent. The system administrator can configure the routing methods of response group on the Skype for Business Server.

The routing methods of response group are as follows:

- **Longest idle** method: The call is routed to the agent who has the longest idle time.
If the agent is unavailable, the call goes into the next agent who has the longest idle time until the call is answered.
- **Parallel** method: The call is routed to all idle agents.
All idle agents are called at the same time for every incoming call.
- **Round robin** method: The call is routed to the agent ordered by agent list circularly.
If the agent is unavailable, the call goes into the next agent ordered by agents list circularly until the call is answered or the agent list end.
- **Serial** method: The call is routed to the agent ordered by agents list orderly.
If the agent is unavailable, the call goes into the next agent ordered by agents list orderly until the call is answered.
- **Attendant** method: The call is routed to the agents who sign into Skype for Business Server or response group.
All agents are called at the same time for every incoming call, regardless of their current presence.

Response Group Ringtone

Response group ring tone feature allows the phone to play a distinct ringtone when receiving a response group call.

Procedure

Response group ring tone can be configured using the configuration files or locally.



Configuration File	<y0000000000xx>.cfg	Configure a ring tone for the response group calls. Parameter: phone_setting.rsg_call_ring.enable phone_setting.rsg_call_ring_type
Local	Phone User Interface	Configure a ring tone for the response group calls.

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
phone_setting.rsg_call_ring.enable	0 or 1	1
Description: Enables or disables the phone play a distinct ringtone for response group calls. 0 -Disabled 1 -Enabled If it is set to 0 (Disabled), incoming calls to response group will use the phone's ring tone. The phone's ring tone is configured by the parameter "phone_setting.ring_type". If it is set to 1 (Enabled), you can set a distinct ringtones for response group calls. Web User Interface: None Phone User Interface: None		
phone_setting.rsg_call_ring_type	Refer to the following content	Ring1.wav
Description: Configures a ring tone for response group calls. Permitted Values: Ring1.wav, Ring2.wav, Ring3.wav, Ring4.wav, Ring5.wav, Ring6.wav, Ring7.wav, Ring8.wav,		

Parameter	Permitted Values	Default
<p>Silent.wav, Splash.wav or custom ring tone name (e.g., Customring.wav).</p> <p>Example:</p> <p>To configure a phone built-in ring tone (e.g., Ring6.wav): phone_setting.rsg_call_ring_type = Ring6.wav</p> <p>To configure a custom ring tone (e.g., Customring.wav): phone_setting.rsg_call_ring_type = Customring.wav</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p> <p>Menu->Basic->Sounds->Ring Tones->Response Group</p>		


To set a ringtone for the response group via phone user interface:

1. Press **Menu->Basic->Sounds->Ring Tones->Response Group**.
2. Press  or  to select a ring tone.
3. Press the **Save** soft key to accept the change.

Allow Trans Exist Call

Allow trans exist call feature allows users to select transfer-to party's call during multiple calls. It is convenient to transfer the active call to another existing call. It is not applicable to T48G/T46G Skype for Business phones.

For example, party A (2216) has two calls on line 1, one with party B (2227) and the other with party C (2529). If party A transfers the call with party B by pressing the **Tran** soft key, a "Transfer to" screen will display on the phone. In this case, party A can select to transfer the call to a new party or party C (2529).



Procedure

Allow trans exist call can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure allow trans exist call. Parameters: transfer.multi_call_trans_enable
Local	Web User Interface	Configure allow trans exist call.

		Navigate to: <a href="http://<phoneIPAddress>/servlet?p=features-general&q=load">http://<phoneIPAddress>/servlet?p=features-general&q=load
--	--	--

Details of Configuration Parameters:

Parameters	Permitted Values	Default
transfer.multi_call_trans_enable	0 or 1	1
<p>Description:</p> <p>Enables or disables the Skype for Business phone to select transfer-to party's call (a new call or another existing call) during multiple calls when user presses the Tran soft key.</p> <p>0-Disabled 1-Enabled</p> <p>If it is set to 1 (Enabled), the user can select to transfer the active call to a new call or another existing call during multiple calls when the user presses the Tran soft key.</p> <p>If it is set to 0 (Disabled), the user can transfer the active call to a new call during multiple calls when the user presses the Tran soft key.</p> <p>Note: It is not applicable to T48G/T46G Skype for Business phones.</p> <p>Web User Interface:</p> <p>Features->General Information->Allow Trans Exist Call</p> <p>Phone User Interface:</p> <p>None</p>		

To configure allow trans exist call via web user interface (take T42G Skype for Business phones for example):

1. Click on **Features->General Information**.

2. Select the desired value from the pull-down list of **Allow Trans Exist Call**.

The screenshot shows the Yealink T42G web interface with the 'Features' tab selected. The 'General Information' section contains various settings. The 'Allow Trans Exist Call' option is highlighted with a red box and is set to 'Enabled'. Other settings include 'Call Waiting' (Enabled), 'Key As Send' (#), 'Hotline Number' (empty), 'Hotline Delay(0~10s)' (4), 'Busy Tone Delay (Seconds)' (0), 'Auto-Logout Time(1~1000min)' (5), 'Call Number Filter' (empty), 'Voice Mail Tone' (Enabled), 'DHCP Hostname' (SIP-T41P), 'E911 Location Tip' (Enabled), 'Update Checking Time' (24), 'Use DHCP Option 120' (Disabled), 'SFB Cert Service URL' (empty), 'Enable SFB Automation' (Disabled), 'SFB Inactive Time' (5), 'SFB Away Time' (5), 'Web Sign in' (Enabled), 'Remember Password' (Disabled), and 'History Record Contacts Avatar' (Enabled). A 'NOTE' section on the right provides information about 'Call Waiting' and 'Key As Send'.

3. Click **Confirm** to accept the change.

Call Number Filter

Call number filter feature allows Skype for Business phone to automatically filter designated characters when dialing.

Procedure

Call number filter can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the characters that the Skype for Business phone filters when dialing. Parameters: features.call_num_filter
Local	Web User Interface	Configure the characters that the Skype for Business phone filters when dialing. Navigate to: http://<phoneIPAddress>/servlet?p=features-general&q=load

Details of Configuration Parameters:

Parameters	Permitted Values	Default
features.call_num_filter	String within 99 characters	Blank
<p>Description:</p> <p>Configures the characters that the Skype for Business phone filters when dialing.</p> <p>If the dialed number contains configured characters, the Skype for Business phone will automatically filter these characters when dialing.</p> <p>Example:</p> <p>features.call_num_filter = ,-</p> <p>If you dial 3-61, the phone will filter the character -, and then dial out 361.</p> <p>Note: If it is left blank, the Skype for Business phone will not automatically filter any characters when dialing. If you want to filter just a space, you have to set the value to " ," (a space first followed by a comma).</p> <p>Web User Interface:</p> <p>Features->General Information->Call Number Filter</p> <p>Phone User Interface:</p> <p>None</p>		

To configure the characters the Skype for Business phone will filter via web user interface:

1. Click on **Features->General Information**.

- Enter the desired character in the **Call Number Filter** field.

The screenshot shows the Yealink T46G web interface. The 'Features' tab is selected. In the 'General Information' section, the 'Call Number Filter' field is highlighted with a red box. The field contains a single character, possibly a comma or a period. To the right of the field is a help icon. The sidebar on the left lists various settings categories: General Information, Audio, Remote Control, Bluetooth, and LED. The main content area lists various features with their current status and a help icon for each. A 'NOTE' section on the right provides additional information about 'Call Waiting' and 'Key As Send'.

- Click **Confirm** to accept the change.

Allow Mute

You can mute the microphone of the active audio device during an active call, and then the other party cannot hear you. If allow mute feature is disabled, you cannot mute an active call.

Procedure

Allow mute can be configured using the configuration files or locally.


Configuration File	<y0000000000xx>.cfg	Configure allow mute feature. Parameters: features.allow_mute
Local	Web User Interface	Configure allow mute feature. Navigate to: <a href="http://<phoneIPAddress>/servlet?p=features-general&q=load">http://<phoneIPAddress>/servlet?p=features-general&q=load

Details of Configuration Parameters:

Parameters	Permitted Values	Default
features.allow_mute	0 or 1	1
<p>Description:</p> <p>Enables or disables the Skype for Business phone to mute an active call.</p> <p>0-Disabled</p> <p>1-Enabled</p> <p>Web User Interface:</p> <p>Features->General Information->Allow Mute</p> <p>Phone User Interface:</p> <p>None</p>		

To configure allow mute via web user interface:

1. Click on **Features->General Information**.
2. Select the desired value from the pull-down list of **Allow Mute**.



3. Click **Confirm** to accept the change.

Voice Mail without PIN

Generally, users have to enter a PIN before they access the voice mail box. If voice mail without PIN feature is enabled, users can access voice mail box without entering PIN. It is especially

useful for users who often access mailbox from the Skype for Business phone in a secure office.

Procedure

Voice mail without PIN can be configured using the configuration files.

Configuration File	<y0000000000xx>.cfg	Configure voice mail without PIN. Parameters: account.1.voice_mail.skin_pin.enable
---------------------------	---------------------	---

Details of Configuration Parameters:

Parameters	Permitted Values	Default
account.1.voice_mail.skin_pin.enable	0 or 1	0
Description: Enables or disables the Skype for Business phone to access voice mail box without entering PIN. 0 -Disabled 1 -Enabled Web User Interface: None Phone User Interface: None		

E911

E911 (Enhanced 911) is a location technology that enables the called party to identify the geographical location of the calling party. For example, if a caller makes an emergency call to E911, the feature extracts the caller's information for the police department to immediately identify the caller's location. For more information, refer to <https://technet.microsoft.com/en-us/library/dn951423.aspx>.

The phone sends the following attributes to LIS to get back the location information:

1. MAC address
2. IP address
3. Subnet
4. SIP URI
5. Chassis ID / Port ID of L2 switch (This information is obtained using LLDP)

During in-band provisioning, the following have been sent from the Frontend server to the Skype for Business phone.

1. LIS URI
2. Enhanced Emergency Enabled
3. Location Required
4. Emergency Dial String
5. Emergency Dial Mask
6. Secondary Location Source
7. Notify URI
8. Conf URI
9. Conf Mode

Sample:

```
ms-subnet: 192.168.1.0.  
<provisionGroup name="locationPolicy" >  
  <propertyEntryList >  
    <property name="EnhancedEmergencyServicesEnabled" >true</property>  
    <property name="LocationPolicyTagID" >user-tagid</property>  
    <property name="LocationRequired" >yes</property>  
    <property name="UseLocationForE911Only" >true</property>  
    <property name="EmergencyDialString" >910086</property>  
    <property name="EmergencyDialMask" >911;912</property>  
  </propertyEntryList>  
  <property name="NotificationUri" >sip:7000@yealinkuc.com,sip:80040@yealinkuc.com</property>  
  <property name="ConferenceMode" >oneway</property>  
</provisionGroup>
```

When user dials an emergency number, the location of the user set in phone and the phone number are sent out as a part of INVITE message.

Sample:

```
INVITE sip:+119@bor-ee.com;user=phone SIP/2.0  
<location-info>  
  <civicAddress xmlns="urn:ietf:params:xml:ns:pidf:geopriv10:civicAddr">  
    <PC>361008</PC>  
    <country>CN</country>  
    <STS />  
    <PRD />  
    <HNS />  
    <POD />  
    <HNO />  
    <RD>Wanghailu</RD>  
    <A3>Xiamen</A3>  
    <A1>Fujian</A1>  
    <NAM />  
    <LOC>63</LOC>  
  </civicAddress>
```


```
</location-info>
```

Note

If user's presence status is DND before dialing an emergency number, it will reset to Available from DND when a 911 number is dialed.

E911 Location Tip

The network administrator configures geographical location on Skype for Business Server for users. After user signs in, the geographical location is downloaded via in-band provisioning. If geographical location is not provisioned by the server and the LocationRequired property of in-band LocationPolicy is set to 'yes' or 'disclaimer' on the Skype for Business Server, a popup opens in the phone's LCD enabling users to either ignore the notification or edit the location information.



Procedure

E911 location tip can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure E911 location tip. Parameters: sfb.E911_location_tip
Local	Web User Interface	Configure E911 location tip. Navigate to: <a href="http://<phoneIPAddress>/servlet?p=features-general&q=load">http://<phoneIPAddress>/servlet?p=features-general&q=load

Details of Configuration Parameters:

Parameters	Permitted Values	Default
sfb.E911_location_tip	0 or 1	1

Parameters	Permitted Values	Default
<p>Description:</p> <p>Enables or disables the idle screen to display the notification "Location is not set" when the location of the Skype for Business phone is not set.</p> <p>0-Disabled 1-Enabled</p> <p>Web User Interface:</p> <p>Features->General Information->E911 Location Tip</p> <p>Phone User Interface:</p> <p>None</p>		

To configure E911 location tip via web user interface:

1. Click on **Features->General Information**.
2. Select the desired value from the pull-down list of **E911 Location Tip**.

The screenshot displays the Yealink T46G web interface. The 'Features' tab is selected, and the 'General Information' sub-tab is active. The 'E911 Location Tip' setting is highlighted with a red box and is currently set to 'Enabled'. Other settings visible include 'Call Waiting' (Enabled), 'Key As Send' (#), 'Hotline Number' (empty), 'Hotline Delay (0~10s)' (4), 'Busy Tone Delay (Seconds)' (0), 'Return code when refuse' (603 (Decline)), 'Diversion/History-Info' (Enabled), 'Auto-Logout Time(1~1000min)' (5), 'Call Number Filter' (empty), 'Voice Mail Tone' (Enabled), 'DHCP Hostname' (SIP-T46G), 'Update Checking Time' (24), 'Use DHCP Option 120' (Disabled), 'SFB Cert Service URL' (empty), 'Enable SFB Automation' (Disabled), 'SFB Inactive Time' (5), 'SFB Away Time' (5), 'Web Sign in' (Enabled), 'Remember Password' (Disabled), and 'History Record Contacts Avatar' (Enabled). A 'NOTE' section on the right provides additional information about the 'Call Waiting' and 'Key As Send' features.


3. Click **Confirm** to accept the change.


Boss-Admin Feature

The boss-admin feature, which is also called boss-delegate feature, enables a "boss" phone and delegates' phones to ring simultaneously when a user calls the boss. When one party answers the call, the other phone will stop ringing. A boss can assign delegates and delegates can manage calls on behalf of the boss's line. For more information, refer to [Yealink phone-specific user guide](#).


Assigning Delegates

To assign delegates using Skype for Business client:

1. Open Skype for Business client.
2. Sign into Skype for Business client as the person who wants to assign a delegate.
3. Click the  button, and then click **Call Forwarding Settings**.
4. Mark the radio box in **Simultaneously ring** field.
5. Select **My Delegates** from the pull-down list of **Simultaneously ring**.



6. In the **Delegates** dialog box, click **Add**. Each delegate must be a Skype for Business contact.
7. Click the **Ring your delegates after this many seconds** pull-down list to determine when your delegates' phones ring.



8. Click **OK**.
9. Click **OK** in the **Delegates** dialog box.
10. Click **OK** in the **Options** dialog box.

The boss's phone is able to accept the response (200 OK) to initial SUBSCRIBE and the response contains the current list of provisioned delegates and indication (in <flags>) that delegate ringing is currently enabled.

For example, when a user calls the boss (extension: 2227), the boss's line and his delegates (2216 and 2529) will ring simultaneously.


```
<flags name="clientflags" value="delegate_ring forward_audio_app_invites"> </flags>
<list name=" delegates "> <target uri="sip:2529@yealinkuc.com"> </target> <target
uri="sip:2216@yealinkuc.com"> </target> </list>
```

Removing Delegates


To remove a delegate from Skype for Business client:

1. Open Skype for Business client.
2. Sign into Skype for Business client as the person who wants to remove a delegate.
Make sure **My Delegates** option is not selected in either the **Simultaneously ring** or **Forward my calls to** list.

3. Click **Edit my delegate members**.



4. Check the checkbox of the delegate you want to remove.



5. Click **Remove**.
6. Click **OK** in the **Delegates** dialog box.
7. Click **OK** in the **Options** dialog box.

For example, if the boss removes the delegate whose extension is 2216, then the Skype for Business phone is able to accept a Notification of modified delegate list and the NOTIFY contains a list of current provisioned delegate:

```
<list name="delegates"> <target uri="sip:2529@yealinkuc.com"> </target>
```

Boss-Line Ringtone

As a delegate, you can set a distinct ringtone for your assigned bosses' lines. When you receive incoming calls from your assigned bosses or your assigned bosses receives incoming calls, your phone will play this ringtone.

Procedure





Boss-line ringtone can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure a distinct ringtone for assigned bosses' lines. Parameter: phone_setting.boss_line_ring.enable
Local	Phone User Interface	Configure a distinct ringtone for assigned bosses' lines.

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
phone_setting.boss_line_ring.enable	0 or 1	1
<p>Description:</p> <p>Enables or disables the delegate to set a distinct ringtone for assigned bosses' lines.</p> <p>0-Disabled</p> <p>1-Enabled</p> <p>If it is set to 0 (Disabled), ringtone for assigned bosses' lines will use the phone's ringtone. The phone's ringtone is configured by the parameter "phone_setting.ring_type".</p> <p>If it is set to 1 (Enabled), the delegate can set a distinct ringtone for assigned bosses' lines. When delegate receives incoming calls from assigned bosses or assigned bosses receive incoming calls, delegate's phone will play the distinct ringtone.</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p> <p>None</p>		

To set a ringtone for assigned bosses' lines via phone user interface:

1. Press **Menu->Basic->Sounds->Ring Tones->Boss Line**.
2. Press  or  to select a boss.
3. Press  or  to select a ring tone.
4. Press the **Save** soft key to accept the change.

Delegates-call Ringtone

As a boss, you can set a distinct ringtone for incoming calls from your assigned delegates' lines.

Procedure





Delegates-call ringtone can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure a distinct ringtone for incoming calls from the assigned delegates' lines. Parameter: phone_setting.delegates_call_ring.enable
Local	Phone User Interface	Configure a distinct ringtone for incoming calls from the assigned delegates' lines.

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
phone_setting.delegates_call_ring.enable	0 or 1	1
<p>Description:</p> <p>Enables or disables the boss to set a distinct ringtone for incoming calls from the assigned delegates' lines.</p> <p>0-Disabled 1-Enabled</p> <p>If it is set to 0 (Disabled), incoming calls from the assigned delegates' lines will use the phone's ringtone. The phone's ringtone is configured by the parameter "phone_setting.ring_type".</p> <p>If it is set to 1 (Enabled), the boss can set a distinct ringtone for incoming calls from the assigned delegates' lines.</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p> <p>None</p>		

To set a ringtone for the assigned delegates' lines via phone user interface:

1. Press **Menu**->**Basic**->**Sounds**->**Ring Tones**->**Delegates-call**.
2. Press  or  to select a delegate.
3. Press  or  to select a ring tone.
4. Press the **Save** soft key to accept the change.


Calendar

Yeastar Yealink Skype for Business phones integrates with the Microsoft Exchange calendar feature. If your phone is configured to connect to the Microsoft Exchange Server, and the Microsoft® Outlook® application is installed at your site, you can view Skype conference, appointment, meeting and event, or join the Skype conference in your Microsoft Outlook application from your phone.


Setting up a Skype Conference in Outlook

To set up a Skype conference in outlook:

1. Open Outlook and go to your calendar.



2. Click **HOME**->**New Skype Meeting**.



3. In the **To** box, enter the email addresses of your invitees.
4. Enter a subject, location, and then select the start and end time.
5. Enter the content about the Skype conference.
6. Click **Send**.

A Skype conference reminder will display on the phone screen of organizer and invitees 15 minutes before the Skype conference starts.


Note

If you change the Skype conference content (e.g., location, subject, time) via outlook after you have sent the invitation, the phone will update the Skype conference content.


Setting up an Appointment in Outlook

To set up an appointment in outlook:

1. Open Outlook and go to your calendar.



2. Click **Home->New Items->More Items->Recurring Appointment**.



3. Enter the appointment time.
4. Click **OK**.
5. Enter a subject, location and the appointment content.
6. Click **Save & Close**.

A reminder will display on the phone screen 15 minutes before the appointment starts.


Setting up a Meeting in Outlook

To set up a meeting in outlook:

1. Open Outlook and go to your calendar.



- Click **Home->New Items->More Items->Recurring Meeting**.



- Enter the meeting time.
- Click **OK**.
- In the **To** box, enter the email addresses of your invitees.
- Enter a subject, location and the meeting content.
- Click **Send**.

A reminder will display on the phone screen of organizer and invitees 15 minutes before the meeting starts.


Setting up an Event in Outlook

To set up an event in outlook:

- Open Outlook and go to your calendar.



- Click **Home->New Items->More Items->Recurring Event**.



- Enter the event time.
- Click **OK**.
- Enter a subject, location and the event content.
- Click **Save & Close**.

A reminder will display on the phone screen 15 minutes before the event starts.

Using the Calendar

To use the calendar feature on your phone, you must sign into the phone using [User Sign-in](#) or [Web Sign-in](#) method. So the phones can display the Microsoft Exchange calendar which gives you quick access to Skype conference, appointment, meeting and event.

Procedure

Calendar can be configured using the configuration files only.

Configuration File	<y0000000000xx>.cfg	Configure calendar feature. Parameters: sfb.calendar.enable
		Configures the interval (in seconds) for the phone to automatically check if any calendars update available on Microsoft Exchange Server. Parameters:

		phone_setting.calendar.update_time
--	--	------------------------------------

Details of Configuration Parameters:

Parameters	Permitted Values	Default
sfb.calendar.enable	0 or 1	1
Description: Enables or disables the calendar feature. 0 -Disabled 1 -Enabled If it is set to 1 (Enabled), user can use calendar feature on the Skype for Business phone. If it is set to 0 (Disabled), user cannot use calendar feature on the Skype for Business phone. Web User Interface: None Phone User Interface: Menu->Calendar		
phone_setting.calendar.update_time	Integer from 0 to 1000	300
Description: It configures the interval (in seconds) for the phone to automatically check if any calendars update available on Microsoft Exchange Server. If it is set to 300 (in seconds) , the phone will check if any calendar update available on the Microsoft Exchange Server every 300 seconds. If an update is available, the phone will download the calendars. Web User Interface: None Phone User Interface: Menu->Calendar		


Viewing the Calendar

You can view all schedules via the calendar on your phone.

To view the calendar via phone user interface:

1. Press **Menu->Calendar**.

The calendar displays the schedules of today by default.




No.	Name	Description
1	Month view	Shows all the days which have schedules in the selected month.
2	Day view	Shows all schedules of the selected day, including the subject, start and end time.
3	Schedule view	Shows the details of the selected schedule, including the subject, participants, organizer, start and end time, location and content.

2. Press the **Back** soft key to return to the pervious screen.

Working with Schedule Reminders


If you have a schedule, a reminder pop-up is displayed 15 minutes before it starts. The reminder shows the main information of the schedule, including subject and the rest time.

If you receive a reminder of an appointment, meeting or event, you can:




- Press the **Ignore** soft key to permanently remove the reminder from the screen and stop all future reminders for this schedule.
- Press the **Snooze** soft key to temporarily remove the reminder from the screen, until the next schedule reminder. The reminder will appear every 5 minutes and also appear 1 minute before the schedule starts.
- Press the **Detail** soft key to view specific information.

If you receive a reminder of a Skype conference, you can:



- Press the **Ignore** soft key to permanently remove the reminder from the screen and stop all future reminders for the Skype conference.
- Press the **Snooze** soft key to temporarily remove the reminder from the screen, until the next schedule reminder. The reminder will appear every 5 minutes before the Skype conference starts. The phone will pop up the reminder before 15 minutes, 10 minutes, 5 minutes and 1 minute before Skype conference.
- Press the **Detail** soft key to view specific information about the Skype conference, including the Skype conference's subject, participants, organizer, start and end time, location and content.
- Press the **Join** soft key to join the Skype conference.

Note

You can press  on the phone to ignore all reminders.

When receives a Skype conference reminder during a call, you can press the **Join** soft key to join the Skype conference directly. Current call will be held and you can resume it after the Skype conference.

For more information on how to use the calendar feature, refer to the [Yealink phone-specific user guide](#).

BToE

Better Together over Ethernet (BToE) feature on Yealink Skype for Business phones enables you to control call activity from your phones and your computer using your Skype for Business client. You can also use BToE to sign into your phone using your Skype for Business credentials. In order to use BToE, you need to download and install the Yealink BToE Connector application.

Procedure

BToE can be configured using the configuration files.

Configuration File	<y0000000000xx>.cfg	Configure BToE feature. Parameters: sip.btoe.enable features.sign_in_via_btoe.enable
		Configures the BToE pairing mode. Parameters: sip.btoe.pairing_mode
Local	Web User Interface	Configure BToE feature. Configures the BToE pairing mode. Navigate to: http://<phoneIPAddress>/servlet?p=settings-btoe&q=load
	Phone User Interface	Configure BToE feature. Configures the BToE pairing mode.

Details of Configuration Parameters:


Parameters	Permitted Values	Default
sip.btoe.enable	0 or 1	1
Description: Enables or disables the BToE (Better Together over Ethernet) feature. 0 -Disabled 1 -Enabled If it is set to 1 (Enabled), BToE is enabled on the phone. Your phone can pair with Skype for Business Client. If it is set to 0 (Disabled), BToE is disabled on the phone. Your phone cannot pair with Skype for Business Client. Web User Interface: Settings->BToE->BToE Phone User Interface: Menu->Features->BToE->BToE		
features.sign_in_via_btoe.enable	0 or 1	1

Parameters	Permitted Values	Default
<p>Description:</p> <p>Enables or disables the user to sign into the phone via PC.</p> <p>0-Disabled</p> <p>1-Enabled</p> <p>Note: It works only if the value of the parameter "sip.btoe.enable" is set to 1 (Enabled). If it is set to 1 (Enabled), make sure your phone has paired with the Skype for Business client using BToE software, so that you can sign into the phone via PC.</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p> <p>None</p>		
sip.btoe.pairing_mode	0 or 1	0
<p>Description:</p> <p>Configures the BToE pairing mode.</p> <p>If it is set to 0 (Auto), you can pair your phone and PC without a pairing code.</p> <p>If it is set to 1 (Manual), your phone will generate a pairing code when pairing with Skype for Business client. You need to enter the pairing code on your BToE software to manually to pair your phone and Skype for Business client.</p> <p>Note: It works only if the value of the parameter "sip.btoe.enable" is set to 1 (Enabled).</p> <p>Web User Interface:</p> <p>Settings->BToE->BToE pairing Mode</p> <p>Phone User Interface:</p> <p>Menu->Features->BToE->BToE Pairing Mode</p>		

To configure BToE feature via web user interface:

1. Click on **Settings->BToE**.
2. Select the desired value from the pull-down list of **BToE**.

3. Select the desired generation from the pull-down list of **BToE Pairing Mode**.



4. Click **Confirm** to accept the change.

To configure BToE feature via phone user interface:

1. Press **Menu-> Features-> BToE**.
2. Press or , or the **Switch** soft key to select **Enabled** from the **BToE** field.
3. Press or , or the **Switch** soft key to select the desired pairing mode from the **BToE Pairing Mode** field.

The default value is **Auto**.

BToE		
1. BToE:	Enabled	< >
2. BToE Pairing Status:	Unpaired(Not signed in)	
3. BToE Pairing Mode:	Auto	< >
Back	Switch	Save

4. Press the **Save** soft key to accept the change or the **Back** soft key to cancel.

To use the BToE feature and sign in:

1. Download and install the Yealink BToE Connector application to your computer.
2. Sign into the Skype for Business client.
3. Enable BToE and pair your phone with your computer. For more information on how to pair, refer to [Better Together over Ethernet](#) chapter in [Yealink phone-specific user guide](#).

When no user signs into the phone, a logon dialog will pop up on the Skype for Business client on your computer to prompt you to enter the password.

4. Enter your password and sign in.

Now you will sign into your phone with the same account on your client. You can manage calls on your phone using the Skype for Business client.

EXP40 Expansion Module

The Yealink EXP40 expansion module is an ideal choice for receptionists, administrative assistants, call center agents, power-users, and executives who need to handle large call volumes on a daily basis.

Assigning Contacts to EXP40

You can connect an EXP40 expansion module to T48G/T46G Skype for Business phones only. When your T48G/T46G is registered with a Skype for Business account, you can assign contacts to EXP keys on your EXP40 expansion module, so that you can quickly call contact by pressing the corresponding EXP key.

You can also monitor your Skype for Business contacts' presence status from your expansion module. For more information on contact's presence, refer to [Reading Icons](#) on page 17.

To use EXP40 expansion modules, connect the Ext jack of the Skype for Business phone and the Ext in jack of the expansion module using one supplied cord. If you need to connect multiple expansion modules, connect the Ext out jack of the previous expansion module and the Ext in jack of the next expansion module using another supplied cord.

Each EXP40 expansion module provides you with 20 EXP keys and 2 display pages, supporting a total of 40 EXP keys that you can set up as contacts. You can connect up to 6 EXP40 expansion modules to your phone to support a maximum of 240 EXP keys per phone.

Procedure


EXP40 expansion module can be configured locally.

Locally	Web User Interface	Configure the desired contact group to be displayed on the EXP40 expansion module. Navigate to: <code>http://<phoneIPAddress>/servlet?p=settings-expmodule&q=load</code>
	Phone user Interface	Configure the desired contact group to be displayed on the EXP40 expansion module.

To assign contact group to the EXP40 expansion module via web user interface:

1. Click on **Settings->EXP Module**.

2. Select the desired contact group from the pull-down list of **ModuleX** (X ranges from 1 to 6 depending on the amount of the connected EXP40).




3. Click **Confirm** to accept the change.

The selected contact group will be displayed on the selected expansion module.

To assign contact group to the EXP40 expansion module via phone user interface:

1. Press **Menu->Basic->Exp Module**.
2. Press **◀** or **▶**, or the **Switch** soft key to select the desired contact group from the **ModuleX** field (X ranges from 1 to 6 depending on the amount of the connected EXP40).



3. Press the **Save** soft key to accept the change.

The selected contact group will be displayed on the selected expansion module.

Monitoring Status Changes using EXP Key LED Indicator

EXP40 can display local contacts or Skype for Business contacts, but you can only use EXP40 to monitor Skype for Business contacts for status changes. For example, you can assign a Skype for Business contact to the EXP40 to monitor the status of his line (busy or idle). The EXP key LED indicator illuminates solid red when his line is busy.

Procedure

EXP key LED indicator can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the EXP key LED indicator. Parameter: phone_setting.exp40_led.enable
Local	Web User Interface	Configure the EXP key indicator LED. Navigate to: http://<phoneIPAddress>/servlet?p=features-poweredled&q=load

Details of Configuration Parameters:

Parameter	Permitted Values	Default
phone_setting.exp40_led.enable	0 or 1	1
<p>Description:</p> <p>Enables or disables the EXP key indicator LED on the expansion module to monitor the status of the Skype for Business contacts.</p> <p>0-Disabled 1-Enabled</p> <p>If it is set to 0 (Disabled), the EXP key LED indicators corresponding to your Skype for Business contacts are off.</p> <p>If it is set to 0 (Enabled), the EXP key LED indicators vary depending on the status of your Skype for Business contacts.</p> <p>Note: It is only applicable to T48G/T46G Skype for Business phones.</p> <p>Web User Interface:</p> <p>Features->LED->Exp Led Light On</p> <p>Phone User Interface:</p> <p>None</p>		

To configure the EXP key LED indicators via web user interface:

1. Click on **Features->LED**.

- Select the desired value from the pull-down list of **Exp Led Light On**.

The screenshot shows the Yealink T466 web interface. The 'Features' tab is selected, and the 'LED' sub-tab is active. Under the 'Power LED' section, several options are listed with pull-down menus: Common Power Light On (Disabled), Ring Power Light Flash (Enabled), Voice Mail Power Light Flash (Enabled), Mute Power Light On (Disabled), Hold/Held Power Light On (Disabled), and Talk/Dial Power Light On (Disabled). Under the 'Indicator LED' section, 'Line Key Led Light On' is set to 'Enabled', and 'Exp Led Light On' is also set to 'Enabled' and highlighted with a red rectangular box. A 'Confirm' button is at the bottom left, and a 'Cancel' button is at the bottom right. A 'NOTE' box on the right states: 'Power LED Power LED Setting. You can click here to get more guides.'

- Click **Confirm** to accept the change.

The EXP key LED indicators on the EXP40 expansion module:

LED Status	Description
Solid green	The Skype for Business contact is available.
Solid red	<p>The Skype for Business contact is busy.</p> <p>The Skype for Business contact is Do Not Disturb.</p> <p>The call of your Skype for Business contact is parked.</p> <p>The call of your Skype for Business contact is placed on hold.</p> <p>The held call of your Skype for Business contact is resumed.</p> <p>The Skype for Business contact is in a Skype for Business conference.</p>
Solid yellow	<p>The Skype for Business contact is right back.</p> <p>The Skype for Business contact is off work.</p> <p>The Skype for Business contact is away.</p>
Stay the original LED status	<p>The Skype for Business contact is placing a call.</p> <p>The Skype for Business contact is receiving a call.</p> <p>The parked call of your Skype for Business contact is retrieved.</p>
Off	<p>The Skype for Business contact is unknown.</p> <p>The Skype for Business contact is offline.</p> <p>Your phone is locked.</p>

Configuring Advanced Features

This chapter provides information for making configuration changes for the following advanced features:

- [Multicast Paging](#)
- [Action URI](#)
- [Quality of Experience](#)

Multicast Paging

Multicast paging allows Skype for Business phones to send/receive Real-time Transport Protocol (RTP) streams to/from the pre-configured multicast address(es) without involving SIP signaling. Up to 10 listening multicast addresses can be specified on the Skype for Business phone.

Sending RTP Stream

Users can send an RTP stream without involving SIP signaling by pressing a **Paging** soft key. A multicast address (IP: Port) should be assigned to the multicast paging key, which is defined to transmit RTP stream to a group of designated Skype for Business phones. When the Skype for Business phone sends the RTP stream to a pre-configured multicast address, each Skype for Business phone preconfigured to listen to the multicast address can receive the RTP stream. When the originator stops sending the RTP stream, the subscribers stop receiving it.

Procedure

Configuration changes can be performed using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Specify a multicast codec for the Skype for Business phone to send the RTP stream. Parameter: multicast.codec
		Configure the multicast IP address and port number for a paging list key. Parameter: multicast.paging_address.X.ip_address

		<p>Configure the multicast paging group name for a paging list key.</p> <p>Parameter:</p> <p>multicast.paging_address.X.label</p>
Local	Web User Interface	<p>Specify a multicast codec for the Skype for Business phone to send the RTP stream.</p> <p>Navigate to:</p> <p>http://<phoneIPAddress>/servlet?p=features-general&q=load</p>
		<p>Configure the multicast IP address and port number for a paging list key.</p> <p>Configure the multicast paging group name for a paging list key.</p> <p>Navigate to:</p> <p>http://<phoneIPAddress>/servlet?p=contacts-multicastIP&q=load</p>
	Phone User Interface	<p>Configure the multicast IP address and port number for a paging list key.</p> <p>Configure the multicast paging group name for a paging list key.</p>

Details of the Configuration Parameter:

Parameters	Permitted Values	Default
multicast.codec	PCMU, PCMA, G729, G722	G722
<p>Description:</p> <p>Configures the codec of multicast paging.</p> <p>Example:</p> <p>multicast.codec = G722</p> <p>Web User Interface:</p> <p>Features->General Information->Multicast Codec</p> <p>Phone User Interface:</p> <p>None</p>		
multicast.paging_address.X.ip_address	String	Blank

Parameters	Permitted Values	Default
(X ranges from 1 to 10)		
<p>Description:</p> <p>Configures the IP address and port number of the multicast paging group in the paging list.</p> <p>It will be displayed on the LCD screen when placing the multicast paging call.</p> <p>Example:</p> <p>multicast.paging_address.1.ip_address = 224.5.6.20:10008 multicast.paging_address.2.ip_address = 224.1.6.25:1001</p> <p>Note: The valid multicast IP addresses range from 224.0.0.0 to 239.255.255.255.</p> <p>Web User Interface:</p> <p>Directory->Multicast IP->Paging List->Paging Address</p> <p>Phone User Interface:</p> <p>Menu->Features->Paging List->Option->Edit->Address</p>		
multicast.paging_address.X.label (X ranges from 1 to 10)	String	Blank
<p>Description:</p> <p>Configures the name of the multicast paging group to be displayed in the paging list.</p> <p>It will be displayed on the LCD screen when placing the multicast paging calls.</p> <p>Example:</p> <p>multicast.paging_address.1.label = Product multicast.paging_address.2.label = Sales</p> <p>Web User Interface:</p> <p>Directory->Multicast IP->Paging List->Label</p> <p>Phone User Interface:</p> <p>Menu->Features->Paging List->Option->Edit->Label</p>		

To configure a codec for multicast paging via web user interface:

1. Click on **Features->General Information**.

2. Select the desired codec from the pull-down list of **Multicast Codec**.

The screenshot shows the Yealink T46G web interface with the 'Features' tab selected. The 'General Information' section is expanded, and the 'Multicast Codec' is set to 'G722'. A red box highlights the 'Multicast Codec' dropdown menu.

Feature	Value
Call Waiting	Enabled
Key As Send	#
Hotline Number	
Hotline Delay(0~10s)	4
Busy Tone Delay (Seconds)	0
Return code when refuse	603 (Decline)
Time-Out for Dial-Now Rule	1
Dial Search Delay	1
180 Ring Workaround	Disabled
Save Call Log	Enabled
Suppress DTMF Display	Disabled
Suppress DTMF Display Delay	Disabled
Play Local DTMF Tone	Enabled
DTMF Repetition	3
Multicast Codec	G722

3. Click **Confirm** to accept the change.

To configure two sending multicast addresses via web user interface:

1. Click on **Directory->Multicast IP**.
2. Enter the sending multicast address and port number in the **Paging Address** field.
3. Enter the label in the **Label** field.

The label will appear on the LCD screen when sending the RTP multicast.



The screenshot shows the Yealink T46G web interface with the 'Directory' tab selected. The 'Multicast IP' settings are configured. The 'Paging List' table shows two entries: 'Product' and 'Sales'.

Index	Paging Address	Label
1	224.5.6.20:10008	Product
2	224.5.6.20:10001	Sales
3		
4		
5		
6		
7		
8		
9		
10		

4. Click **Confirm** to accept the change.

To configure paging list via phone user interface:

1. Press **Menu->Features->Paging List**.

2. Press  or  to select a desired paging group.
3. The default tag is Empty if it is not configured before.

Paging List		
1. (Empty)		↑ ↓
2. (Empty)		
3. (Empty)		
4. (Empty)		
5. (Empty)		
Back	Option	Paging

4. Press the **Option** soft key, and then press the **Edit** soft key.
5. Enter the multicast IP address and port number (e.g., 224.5.6.20:10008) in the **Address** field.
6. The valid multicast IP addresses range from 224.0.0.0 to 239.255.255.255.

Edit Paging Address	
1. Number:	1
2. Address:	224.5.6.20:10008
3. Label:	
Back	123
Delete	Save

7. Enter the group name in the **Label** field.
8. Press the **Save** soft key to accept the change.
9. Repeat steps 2 to 6, you can add more paging groups.

For T40P Skype for Business phones, the third line key will change to be a paging list key automatically. When the phone is idle, you can press the paging list key to access the paging list.

For T46G/T42G/T41P Skype for Business phones, the second line key will change to be a paging list key automatically. When the phone is idle, you can press the paging list key to access the paging list.

For T48G Skype for Business phones: when the phone is idle, you can tap ...
-> **Features**-> **Paging list** to access the paging list.

Receiving RTP Stream

Skype for Business phones can receive an RTP stream from the pre-configured multicast address(es) without involving SIP signaling, and can handle the incoming multicast paging calls

differently depending on the configurations of Paging Barge and Paging Priority Active.

Paging Barge

This parameter defines the priority of the voice call in progress, and decides how the Skype for Business phone handles the incoming multicast paging calls when there is already a voice call in progress. If the value of the parameter is configured as disabled, all incoming multicast paging calls will be automatically ignored. If the value of the parameter is the priority value, the incoming multicast paging calls with higher or equal priority are automatically answered and the ones with lower priority are ignored.

Paging Priority Active

This parameter decides how the Skype for Business phone handles the incoming multicast paging calls when there is already a multicast paging call in progress. If the value of the parameter is configured as disabled, the Skype for Business phone will automatically ignore all incoming multicast paging calls. If the value of the parameter is configured as enabled, an incoming multicast paging call with higher priority or equal is automatically answered, and the one with lower priority is ignored.

Procedure

Configuration changes can be performed using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the listening multicast address. Parameters: multicast.listen_address.X.ip_address multicast.listen_address.X.label
		Configure Paging Barge and Paging Priority Active features. Parameters: multicast.receive_priority.enable multicast.receive_priority.priority
Local	Web User Interface	Configure the listening multicast address. Configure Paging Barge and Paging Priority Active features. Navigate to: <a href="http://<phoneIPAddress>/servlet?p=contacts-multicastIP&q=load">http://<phoneIPAddress>/servlet?p=contacts-multicastIP&q=load

Details of Configuration Parameters:

Parameters	Permitted Values	Default
multicast.listen_address.X.ip_address (X ranges from 1 to 10)	IP address: port	Blank
Description: Configures the multicast address and port number that the Skype for Business phone listens to. Example: multicast.listen_address.1.ip_address = 224.5.6.20:10008 Note: The valid multicast IP addresses range from 224.0.0.0 to 239.255.255.255. Web User Interface: Directory->Multicast IP->Multicast Listening->Listening Address Phone User Interface: None		
multicast.listen_address.X.label (X ranges from 1 to 10)	String within 99 characters	Blank
Description: (Optional.) Configures the label to be displayed on the LCD screen when receiving the multicast paging calls. Example: multicast.listen_address.1.label = Paging1 Web User Interface: Directory->Multicast IP->Multicast Listening->Label Phone User Interface: None		
multicast.receive_priority.enable	0 or 1	1
Description: Enables or disables the Skype for Business phone to handle the incoming multicast paging calls when there is an active multicast paging call on the Skype for Business phone. 0-Disabled 1-Enabled If it is set to 0 (Disabled), the Skype for Business phone will ignore the incoming multicast paging calls when there is an active multicast paging call on the Skype for Business phone. If it is set to 1 (Enabled), the Skype for Business phone will receive the incoming multicast paging call with a higher or equal priority and ignore that with a lower priority.		

Parameters	Permitted Values	Default
Web User Interface: Directory->Multicast IP->Paging Priority Active Phone User Interface: None		
multicast.receive_priority.priority	Integer from 0 to 10	10
Description: Configures the priority of the voice call (a normal phone call rather than a multicast paging call) in progress. 1 is the highest priority, 10 is the lowest priority. 0 -Disabled 1 -1 2 -2 3 -3 4 -4 5 -5 6 -6 7 -7 8 -8 9 -9 10 -10 If it is set to 0 (Disabled), all incoming multicast paging calls will be automatically ignored when a voice call is in progress. If it is not set to 0 (Disabled), the Skype for Business phone will receive the incoming multicast paging call with a higher or same priority than this value and ignore that with a lower priority than this value when a voice call is in progress. Web User Interface: Directory->Multicast IP->Paging Barge Phone User Interface: None		

To configure a listening multicast address via web user interface:

1. Click on **Directory->Multicast IP**.
2. Enter the listening multicast address and port number in the **Listening Address** field.
1 is the highest priority and 10 is the lowest priority.

3. Enter the label in the **Label** field.

The label will appear on the LCD screen when receiving the RTP multicast.

The screenshot shows the Yealink T46G web interface. The 'Directory' tab is selected, and the 'Multicast Listening' section is active. The 'Paging Barge' is set to '10' and 'Paging Priority Active' is set to 'Enabled'. A table lists 10 IP addresses with their corresponding listening addresses and labels. The first entry, IP Address 1, has a listening address of 224.5.6.20:10008 and a label of 'Test', which is highlighted with a red box. The 'priority' column shows values from 1 to 10.

IP Address	Listening Address	Label	priority
1 IP Address	224.5.6.20:10008	Test	1
2 IP Address			2
3 IP Address			3
4 IP Address			4
5 IP Address			5
6 IP Address			6
7 IP Address			7
8 IP Address			8
9 IP Address			9
10 IP Address			10

4. Click **Confirm** to accept the change.

To configure paging barge and paging priority active features via web user interface:

1. Click on **Directory**->**Multicast IP**.
2. Select the desired value from the pull-down list of **Paging Barge**.
3. Select the desired value from the pull-down list of **Paging Priority Active**.

The screenshot shows the Yealink T23G web interface. The 'Directory' tab is selected, and the 'Multicast Listening' section is active. The 'Paging Barge' is set to '10' and 'Paging Priority Active' is set to 'Enabled', both highlighted with a red box. A table lists 10 IP addresses with their corresponding listening addresses and labels. The first entry, IP Address 1, has a listening address of 224.5.6.20:10003 and a label of 'Manager'. The 'priority' column shows values from 1 to 10.

IP Address	Listening Address	Label	priority
1 IP Address	224.5.6.20:10003	Manager	1
2 IP Address			2
3 IP Address			3
4 IP Address			4
5 IP Address			5
6 IP Address			6
7 IP Address			7
8 IP Address			8
9 IP Address			9
10 IP Address			10

4. Click **Confirm** to accept the change.

Action URI

HTTP/HTTPS GET Request

Action URI allows Skype for Business phones to interact with web server application by receiving and handling an HTTP or HTTPS GET request. When receiving a GET request, the Skype for Business phone will perform the specified action and respond with a 200 OK message. A GET request may contain variable named as "key" and variable value, which are separated by "=". The valid URI format is: *http(s)://<phoneIPAddress>/servlet?key=variable value*. For example: *http://10.3.20.10/servlet?key=OK*.

Configuring Trusted IP Address for Action URI

For security reasons, phones do not handle HTTP/HTTPS GET requests by default. You need to specify the trusted IP address for action URI. When the phone receives a GET request from the trusted IP address for the first time, the LCD screen prompts the message "Allow Remote Control?". Press the **OK** soft key on the phone to allow remote control. You can specify one or more trusted IP addresses on the phone, or configure the phone to receive and handle the URI from any IP address.

You can use action URI feature to capture the Skype for Business phone's current screen. For more information, refer to [Capturing the Current Screen of the Phone](#) on page 270.

Procedure

Specify the trusted IP address for action URI using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the Skype for Business phone to receive the action URI requests. Parameter: features.action_uri.enable
		Specify the trusted IP address(es) for sending the action URI to the Skype for Business phone. Parameter: features.action_uri_limit_ip
Local	Web User Interface	Specify the trusted IP address(es) for sending the action URI to the Skype for Business phone. Navigate to: http://<phoneIPAddress>/servlet?p=features-remotecontrol&q=load


Details of the Configuration Parameter:

Parameter	Permitted Values	Default
features.action_uri.enable	0 or 1	0
<p>Description: Enables or disables the Skype for Business phone to receive the action URI requests.</p> <p>0-Disabled 1-Enabled</p> <p>Web User Interface: None</p> <p>Phone User Interface: None</p>		
features.action_uri_limit_ip	IP address or any	Blank
<p>Description: Configures the IP address of the server from which the Skype for Business phone receives the action URI requests.</p> <p>For discontinuous IP addresses, multiple IP addresses are separated by commas.</p> <p>For continuous IP addresses, the format likes *.*.* and the "*" stands for the values 0~255.</p> <p>For example: 10.10.*.* stands for the IP addresses that range from 10.10.0.0 to 10.10.255.255.</p> <p>If left blank, the Skype for Business phone will reject any HTTP GET request.</p> <p>If it is set to "any", the Skype for Business phone will accept and handle HTTP GET requests from any IP address.</p> <p>Example: features.action_uri_limit_ip = any</p> <p>Note: It works only if the value of the parameter "features.action_uri.enable" is set to 1 (Enabled).</p> <p>Web User Interface: Features->Remote Control->Action URI allow IP List</p> <p>Phone User Interface: None</p>		

To configure the trusted IP address(es) for action URI via web user interface:

1. Click on **Features->Remote Control**.
2. Enter the IP address or any in the **Action URI allow IP List** field.

Multiple IP addresses are separated by commas. If you enter “any” in this field, the Skype for Business phone can receive and handle GET requests from any IP address. If you leave the field blank, the Skype for Business phone cannot receive or handle any HTTP GET request.



3. Click **Confirm** to accept the change.

Capturing the Current Screen of the Phone

You can capture the screen display of the Skype for Business phone using the action URI. Skype for Business phones support handling an HTTP or HTTPS GET request. The URI format is `http(s)://<phoneIPAddress>/screencapture`. The captured picture can be saved as a BMP or JPEG file.

You can also use the URI “`http(s)://<phoneIPAddress>/screencapture/download`” to capture the screen display first, and then download the image (which is saved as a JPG file and named with the Skype for Business phone model and the capture time) to the local system. Before capturing the Skype for Business phone’s current screen, ensure that the IP address of the PC is included in the trusted IP address for Action URI on the Skype for Business phone.

When you capture the screen display, the Skype for Business phone may prompt you to enter the user name and password of the administrator if web browser does not remember the user name and password for web user interface login.

Note


Skype for Business phones also support capturing the screen display using the old URI “`http://<phoneIPAddress>/servlet?command=screenshot`”.

To capture the current screen of the Skype for Business phone:

1. Enter request URI (e.g., `http://10.2.20.126/screencapture`) in the browser's address bar and press the Enter key on the keyboard.
2. Do one of the following:
 - If it is the first time you capture the phone’s current screen using the computer, the browser will display “Remote control forbidden”, and the LCD screen will prompt the message “Allow remote control?”.

Press the OK soft key on the Skype for Business phone to allow remote control. The phone will return to the previous screen. Refresh the web page.

The browser will display an image showing the Skype for Business phone's current screen. You can save the image to your local system.



- Else, the browser will display an image showing the Skype for Business phone's current screen directly. You can save the image to your local system.

Note Frequent capture may affect the Skype for Business phone performance. Yealink recommend you to capture the phone screen display within a minimum interval of 4 seconds.

Quality of Experience

Quality of Experience (QoE) metrics track the quality of audio calls made in your organization, including such things as the number of network packets lost, background noise, and the amount of "jitter" (differences in packet delay).

The phone calculates QoE metrics and then sends them to a server for monitoring and diagnostics purposes.

The phone will send QoE metrics every 30 seconds during a call or once a call ends (the call should last at least 5 seconds).

Procedure

QoE can be configured using the configuration files only.

Configuration File	<y0000000000xx>.cfg	Configure the QoE feature. Parameters: features.report_qoe.when_bad_quality.enable
---------------------------	---------------------	---

Details of Configuration Parameters:

Parameters	Permitted Values	Default
features.report_qoe.when_bad_quality.enable	0 or 1	1
Description: Enables or disables the phone to send Quality of Experience (QoE) metrics to a server for monitoring and diagnostics purposes when voice quality on phone calls is poor. 0 -Disabled 1 -Enabled Web User Interface: None Phone User Interface: None		

In QoE Metrics, the following formation will be reported:

Fields	Element	Attribute
VQReportEvent	VQSessionReport	
	VQSessionIntervalReport	
VQSessionReport		
	Endpoint	SessionId
	DialogInfo	
	MediaLine	
VQSessionReport:Endpoint		
		xmlns
		xmlns:v2
		xmlns:v3
		Name
		v2:OS
		v2:CPUName
		v2:CPUNumberOfCores
		v2:CPUProcessorSpeed
		v2:VirtualizationFlag
VQSessionReport:DialogInfo		
	DialogCategory	CallId
	CorrelationID	FromTag
	FromURI	ToTag
	ToURI	Start
	Caller	End
	LocalContactURI	

Fields	Element	Attribute
	RemoteContactURI	
	LocalUserAgent	
	RemoteUserAgent	
	RemotePAI	
	v2:MediationServerBypassFlag	
	v2:TrunkingPeer	
	v2:RegisteredInside	
	CallId	
	FromTag	
	ToTag	
	Start	
	End	
VQSessionReport:MediaLine		
	Description	xmlns
	InboundStream	xmlns:v2
	OutboundStream	xmlns:v3
		Label
MediaLine:Description	Connectivity	
	Security	
	Offerer	
	Transport	
	NetworkConnectivityInfo	
	LocalAddr	
	RemoteAddr	
	CaptureDev	
	RenderDev	
	ReflexiveLocalIPAddress	
	v3:ReflexiveLocalIPAddresses	
	v3:MidCallReport	
Description:Connectivity	Ice	
	IceWarningFlags	
	RelayAddress	
Connectivity:RelayAddress	IPAddr	
	Port	
Description:NetworkConnectivityInfo	NetworkConnection	
	VPN	
	LinkSpeed	
	v3:NetworkConnectionDetails	

Fields	Element	Attribute
Description:LocalAddr	IPAddr	
	Port	
	SubnetMask	
	v2:MACAddr	
Description:RemoteAddr	IPAddr	
	Port	
	SubnetMask	
Description:CaptureDev	Name	
	Driver	
Description:RenderDev	Name	
	Driver	
Description:ReflexiveLocalIP Address	IPAddr	
	Port	
MediaLine:InboundStream	Network	ID
	Payload	
	QualityEstimates	
InboundStream:Network	Jitter	
	PacketLoss	
	BurstGapLoss	
	Delay	
	Utilization	
Network:Jitter	InterArrival	
	InterArrivalSD	
	InterArrivalMax	
Network:PacketLoss	LossRate	
	LossRateMax	
Network:Delay	RelativeOneWay	
Delay:RelativeOneWay	Average	
	Max	
	BurstGapLoss	
RelativeOneWay:BurstGapLoss	BurstDensity	
	BurstDuration	
	GapDensity	
	GapDuration	
Network:Utilization	Packets	
InboundStream:Payload:Audio	PayloadType	
	PayloadDescription	
	SampleRate	
	Signal	

Fields	Element	Attribute
	v4:JitterBufferSizeAvg	
	v4:JitterBufferSizeMax	
	v4:JitterBufferSizeMin	
	v4:NetworkJitterAvg	
	v4:NetworkJitterMax	
	v4:NetworkJitterMin	
Audio:Signal	SignalLevel	
	NoiseLevel	
	SpeakerGlitchRate	
	v2:InitialSignalLevelRMS	
	v2:RxAvgAGCGain	
	v3:RecvSignalLevelCh1	
	v3:RecvNoiseLevelCh1	
	v4:RenderSignalLevel	
	v4:RenderNoiseLevel	
	v4:RenderLoopbackSignalLevel	
QualityEstimates:Audio	RecvListenMOS	
	RecvListenMOSMin	
	RecvListenMOSAlg	
	NetworkMOS	
Audio:NetworkMOS	OverallAvg	
	OverallMin	
	DegradationAvg	
	DegradationMax	
MediaLine:OutboundStream	Network	ID
	Payload	
	QualityEstimates	
OutboundStream:Network	Jitter	
	PacketLoss	
	Delay	
	Utilization	
Network:Jitter	InterArrival	
	InterArrivalMax	
Network:PacketLoss	LossRate	
	LossRateMax	
Network:Delay	RoundTrip	
Network:Utilization	Packets	
	BandwidthEst	
OutboundStream:Payload:Audio	PayloadType	
	PayloadDescription	

Fields	Element	Attribute
	SampleRate	
	Signal	
Audio:Signal	SignalLevel	
	NoiseLevel	
	MicGlitchRate	
	EchoPercentMicIn	
	EchoPercentSend	
	SendSignalLevelCh1	
	SendNoiseLevelCh1	
OutboundStream:QualityEstimates:Audio	SendListenMOS	
	SendListenMOSMin	
	SendListenMOSA1g	

You can log into the QoE Monitoring Server to view intuitive QoE information.


Configuring Audio Features

This chapter provides information for making configuration changes for the following audio features:

- [Pre Dial Tone](#)
- [Phone Ring Tones](#)
- [Private Line Tones](#)
- [Redial Tone](#)
- [Tones](#)
- [Voice Mail Tone](#)
- [Headset Prior](#)
- [Ringer Device for Headset](#)
- [Dual Headset](#)
- [Sending Volume](#)
- [Audio Codecs](#)
- [Acoustic Clarity Technology](#)
- [DTMF](#)

Pre Dial Tone

Pre dial tone allows Skype for Business phones to play key tone in following situations:

- Enter phone numbers without picking up the handset (applicable to T48G/T46G/T42G/T41P/T40P Skype for Business phones).
- Tap  (**Search** icon) to enter the pre-dialing screen, and then enter phone numbers without picking up the handset (only applicable to T48G Skype for Business phones).


Procedure

Pre dial tone can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure pre dial tone feature. Parameters: sfb.pre_dial_tone.enable
Local	Web User Interface	Configure pre dial tone feature. Navigate to: http://<phoneIPAddress>/servlet?p


=features-audio&q=load

Details of Configuration Parameters:

Parameters	Permitted Values	Default
sfb.pre_dial_tone.enable	0 or 1	0
<p>Description:</p> <p>Enables or disables the Skype for Business phones to play key tone in following situations:</p> <p>For T48G/T46G/T42G/T41P/T40P Skype for Business phones:</p> <p>Enter phone numbers without picking up the handset.</p> <p>For T48G Skype for Business phones:</p> <p>Tap  (Search icon) to enter the pre-dialing screen, and then enter phone numbers without picking up the handset.</p> <p>Web User Interface:</p> <p>Features->Audio->Pre Dial Tone</p> <p>Phone User Interface:</p> <p>None</p>		

To configure pre dial tone via web user interface:

1. Click on **Features->Audio**.
2. Select the desired value from the pull-down list of **Pre Dial Tone**.



3. Click **Confirm** to accept the change.

Phone Ring Tones

Phone ring tones are used to indicate incoming calls acoustically. Users can select a built-in system ring tone or a custom ring tone for the phone or account. To set the custom ring tones, you need to upload the custom ring tones to the phone in advance.

The ring tone format must meet the following:

Skype for Business phone Model	Format	Single File Size	Total File Size
T48G/T46G	.wav	<=8MB	<=20MB
T42G/T41P/T40P	.wav	<=100KB	<=100KB

Note

The ring tone file format must be *.wav.

Procedure

Ring tones can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure a ring tone for the Skype for Business phone. Parameter: phone_setting.ring_type
		Specify the access URL of the custom ring tone. Parameter: phone_setting.ringtonurl
		Delete all custom ring tone files. Parameter: ringtone.delete
	<MAC>.cfg	Configure a ring tone on a per-line basis. Parameters: account.1.ringtone.ring_type
Local	Web User Interface	Upload the custom ring tones. Navigate to: http://<phoneIPAddress>/servle t?p=settings-preference&q=load
		Configure a ring tone for the Skype for Business phone. Navigate to: http://<phoneIPAddress>/servle t?p=settings-preference&q=load

		<p>Configure a ring tone on a per-line basis.</p> <p>Navigate to:</p> <p><a href="http://<phoneIPAddress>/servlet?p=account-basic&q=load&acc=0">http://<phoneIPAddress>/servlet?p=account-basic&q=load&acc=0</p>
	Phone User Interface	<p>Configure a ring tone for the Skype for Business phone.</p> <p>Configure a ring tone for the account.</p>

Details of the Configuration Parameter:


Parameters	Permitted Values	Default
phone_setting.ring_type	Refer to the following content	Ring1.wav
<p>Description:</p> <p>Configures a ring tone for the Skype for Business phone.</p> <p>Permitted Values:</p> <p>Ring1.wav, Ring2.wav, Ring3.wav, Ring4.wav, Ring5.wav, Ring6.wav, Ring7.wav, Ring8.wav, Silent.wav, Splash.wav or custom ring tone name (e.g., Customring.wav).</p> <p>Example:</p> <p>To configure a phone built-in ring tone (e.g., Ring1.wav):</p> <p>phone_setting.ring_type = Ring1.wav</p> <p>To configure a custom ring tone (e.g., Customring.wav):</p> <p>phone_setting.ring_type = Customring.wav</p> <p>Web User Interface:</p> <p>Settings->Preference->Ring Type</p> <p>Phone User Interface:</p> <p>Menu->Basic->Sounds->Ring Tones->Normal Ringtone</p>		
account.1.ringtone.ring_type	Refer to the following content	Common
<p>Description:</p> <p>Configures a ring tone for the account 1.</p> <p>Example:</p> <p>account.1.ringtone.ring_type = Ring3.wav</p> <p>It means configuring Ring3.wav for the account.</p>		

Parameters	Permitted Values	Default
<p>account.1.ringtone.ring_type = Common</p> <p>It means the account will use the ring tone selected for the Skype for Business phone configured by the parameter "phone_setting.ring_type".</p> <p>Permitted Values:</p> <p>Common, Ring1.wav, Ring2.wav, Ring3.wav, Ring4.wav, Ring5.wav, Ring6.wav, Ring7.wav, Ring8.wav, Silent.wav, Splash.wav or custom ring tone name (e.g., Customring.wav).</p> <p>Web User Interface:</p> <p>Account->Basic->Ring Type</p> <p>Phone User Interface:</p> <p>None</p>		
phone_setting.ringtone.url	URL within 511 characters	Blank
<p>Description:</p> <p>Configures the access URL of the custom ring tone file.</p> <p>Example:</p> <p>phone_setting.ringtone.url = tftp://192.168.1.100/Customring.wav</p> <p>Web User Interface:</p> <p>Settings->Preference->Upload Ringtone</p> <p>Phone User Interface:</p> <p>None</p>		
ringtone.delete	http://localhost/all	Blank
<p>Description:</p> <p>Deletes all custom ring tone files.</p> <p>Example:</p> <p>ringtone.delete = http://localhost/all</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p> <p>None</p>		

To upload a custom ring tone via web user interface:

1. Click on **Settings->Preference**.
2. In the **Upload Ringtone** field, click **Browse** to locate a ring tone file (the file format must be *.wav) from your local system.


- Click **Upload** to upload the file.



The custom ring tone appears in the pull-down list of **Ring Type**.

To change the ring tone for the Skype for Business phone via web user interface:


- Click on **Settings->Preference**.
- Select the desired ring tone from the pull-down list of **Ring Type**.



- Click **Confirm** to accept the change.



To change the ring tone for the account via web user interface:

- Click on **Account->Basic**.
- Select the desired ring tone from the pull-down list of **Ring Type**.



- Click **Confirm** to accept the change.

To select a ring tone for the phone via phone user interface:

1. Press **Menu->Basic->Sounds->Ring Tones->Normal Ringtone**.
2. Press  or  to select the desired ring tone.
3. Press the **Save** soft key to accept the change.

Muting the Ringtone

If you do not want to be disturbed by the phone ringtone, you can choose to mute the ringtone when you set account status to Busy (in a call) or Do Not Disturb.

Procedure

Muting the ringtone can be configured using the configuration files only.

Configuration File	<y0000000000xx>.cfg	Configure the phone to mute the ringtone. Parameters: phone_setting.soundsmin.busy_enable phone_setting.soundsmin.dnd_enable
---------------------------	---------------------	--

Details of Configuration Parameters:

Parameters	Permitted Values	Default
phone_setting.soundsmin.busy_enable	0 or 1	0
Description: Enables or disables the IP phone to mute the ringtone when account status is busy (in a call). 0 -Disabled 1 -Enabled If it is set to 1 (Enabled), the IP phone does not play a ringtone for incoming calls when account status is busy (in a call). If it is set to 0 (Disabled), the IP phone plays a ringtone for incoming calls when account status is busy (in a call). Web User Interface: None Phone User Interface: None		
phone_setting.soundsmin.dnd_enable	0 or 1	0
Description: Enables or disables the IP phone to mute the ringtone when account status is Do not		

Disturb.

0-Disabled

1-Enabled

If it is set to 1 (Enabled), the IP phone does not play a ringtone for incoming calls from work group when account status is Do not Disturb.

If it is set to 0 (Disabled), the IP phone plays a ringtone for incoming calls from work group when account status is Do not Disturb.

Web User Interface:

None

Phone User Interface:

None

Private Line Tones

The Skype for Business Server allows the system administrator to give user a second, private telephone line in addition to their primary telephone line. Private lines are often assigned to bosses who want an unlisted telephone number at which they can be reached directly.

When the boss receives a private call, the private line will bypass call delegation and only boss's phone rings. Private line can be configured via Skype for Business Server only.

Private line tones feature allows the phone to play a distinct ring tone when receiving a private call.

Procedure

Private line tones can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure a ring tone for the private line. Parameter: phone_setting.private_line_ring.enable phone_setting.private_line_ring_type
Local	Web User Interface	Configure a ring tone for the private line. Navigate to: <a href="http://<phoneIPAddress>/servlet?p=settings-preference&q=load">http://<phoneIPAddress>/servlet?p=settings-preference&q=load
	Phone User Interface	Configure a ring tone for the private line.

Details of the Configuration Parameter:


Parameter	Permitted Values	Default
-----------	------------------	---------

Parameter	Permitted Values	Default
phone_setting.private_line_ring.enable	0 or 1	1
<p>Description:</p> <p>Enables or disables the IP phone to set a distinct ring tone for the private line.</p> <p>0-Disabled</p> <p>1-Enabled</p> <p>If it is set to 0 (Disabled), private call will use the phone's ring tone. The phone's ring tone is configured by the parameter "phone_setting.ring_type".</p> <p>If it is set to 1 (Enabled), a distinct ring tone can be assigned to the private line.</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p> <p>None</p>		
phone_setting.private_line_ring_type	Refer to the following content	Ring6.wav
<p>Description:</p> <p>Configures a ring tone for the private line.</p> <p>Permitted Values:</p> <p>Ring1.wav, Ring2.wav, Ring3.wav, Ring4.wav, Ring5.wav, Ring6.wav, Ring7.wav, Ring8.wav, Silent.wav, Splash.wav or custom ring tone name (e.g., Customring.wav).</p> <p>Example:</p> <p>To configure a phone built-in ring tone (e.g., Ring6.wav):</p> <p>phone_setting.private_line_ring_type = Ring6.wav</p> <p>To configure a custom ring tone (e.g., Customring.wav):</p> <p>phone_setting.private_line_ring_type = Customring.wav</p> <p>Web User Interface:</p> <p>Settings->Preference->Private line ring</p> <p>Phone User Interface:</p> <p>Menu->Basic->Sounds->Ring Tones->Private Line Tones</p>		

To change the ring tone for the private line via web user interface:

1. Click on **Settings->Preference**.

2. Select the desired ring tone from the pull-down list of **Private line ring**.



3. Click **Confirm** to accept the change.

To select a ring tone for the private line via phone user interface:

1. Press **Menu->Basic->Sounds->Ring Tones->Private Line Tones**.
2. Press or to select the desired ring tone.
3. Press the **Save** soft key to accept the change.

Redial Tone

Redial tone allows Skype for Business phones to continue to play the dial tone after inputting the preset numbers on the pre-dialing screen.

Procedure

Redial tone can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure redial tone feature. Parameters: features.redial_tone
Local	Web User Interface	Configure redial tone feature. Navigate to: http://<phoneIPAddress>/servlet?p=features-audio&q=load


Details of Configuration Parameters:

Parameters	Permitted Values	Default
features.redial_tone	Integer within 6 digits	Blank
Description:		

Parameters	Permitted Values	Default
<p>Configures the Skype for Business phone to continue to play the dial tone after inputting the preset numbers on the pre-dialing screen.</p> <p>Example:</p> <p>features.redial_tone = 125</p> <p>The Skype for Business phone will continue to play the dial tone after inputting "125" on the pre-dialing screen.</p> <p>If it is left blank, the Skype for Business phone will not play the dial tone after inputting numbers on the pre-dialing screen.</p> <p>Web User Interface:</p> <p>Features->Audio->Redial Tone</p> <p>Phone User Interface:</p> <p>None</p>		

To configure redial tone via web user interface:

1. Click on **Features->Audio**.
2. Enter the desired value in the **Redial Tone** field.



3. Click **Confirm** to accept the change.

Tones

When receiving a message, the Skype for Business phone will play a warning tone. You can customize tones or select specialized tone sets (vary from country to country) to indicate different conditions of the Skype for Business phone. The default tones used on Skype for Business phones are the US tone sets. Available tone sets for Skype for Business phones:

- Australia
- Austria
- Brazil
- Belgium

- Chile
- China
- Czech
- Czech ETSI
- Denmark
- Finland
- France
- Germany
- Great Britain
- Greece
- Hungary
- Lithuania
- India
- Italy
- Japan
- Mexico
- New Zealand
- Netherlands
- Norway
- Portugal
- Spain
- Switzerland
- Sweden
- Russia
- United States

Configured tones can be heard on Skype for Business phones for the following conditions.

Condition	Description
Dial	When in the pre-dialing interface
Ring Back	Ring-back tone
Busy	When the callee is busy
Congestion	When the network is congested
Call Waiting	Call waiting tone (For more information on call waiting, refer to Call Waiting)
Dial Recall	When receiving a call back
Info	When receiving a special message

Condition	Description
Stutter	When receiving a voice mail
Auto Answer	When automatically answering a call (For more information on auto answer, refer to Auto Answer)

Procedure

Tones can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	<p>Configure the tones for the Skype for Business phone.</p> <p>Parameters:</p> <p>voice.tone.country voice.tone.dial voice.tone.ring voice.tone.busy voice.tone.congestion voice.tone.callwaiting voice.tone.dialrecall voice.tone.info voice.tone.stutter voice.tone.autoanswer</p>
Local	Web User Interface	<p>Configure the tones for the Skype for Business phone.</p> <p>Navigate to:</p> <p>http://<phoneIPAddress>/servlet?p=settings-tones&q=load</p>

Details of Configuration Parameters:

Parameters	Permitted Values	Default
voice.tone.country	Refer to the following content	Custom
<p>Description:</p> <p>Configures the country tone for the Skype for Business phone.</p> <p>Permitted Values:</p> <p>Custom, Australia, Austria, Brazil, Belgium, Chile, China, Czech, Czech ETSI, Denmark, Finland, France, Germany, Great Britain, Greece, Hungary, Lithuania, India, Italy, Japan, Mexico, New Zealand, Netherlands, Norway, Portugal, Spain, Switzerland, Sweden, Russia, United States.</p>		

Parameters	Permitted Values	Default
Example: voice.tone.country = Custom Web User Interface: Settings->Tones->Select Country Phone User Interface: None		
voice.tone.dial	String	Blank
Description: Customizes the dial tone. tonelist = element[,element] [,element]... Where element = [!] Freq1 [+ Freq2][+ Freq3][+ Freq4] / Duration Freq : the frequency of the tone (ranges from 200 to 4000Hz). If it is set to 0Hz, it means the tone is not played. For T40P: A tone is comprised of at most two different frequencies. For T48G/T46G/T42G/T41P: A tone is comprised of at most four different frequencies. Duration : the duration (in milliseconds) of the dial tone, ranges from 0 to 30000ms. You can configure at most eight different tones for one condition, and separate them by commas. (e.g., 250/200,0/1000,200+300/500,200+500+800+1500/1000). If you want the Skype for Business phone to play tones once, add an exclamation mark "!" before tones (e.g., !250/200,0/1000,200+300/500,200+500+800+1500/1000). Note: It works only if the value of the parameter "voice.tone.country" is set to Custom. Web User Interface: Settings->Tones->Dial Phone User Interface: None		
voice.tone.ring	String	Blank
Description: Customizes the ringback tone. The value format is Freq/Duration. For more information on the value format, refer to the parameter "voice.tone.dial".		

Parameters	Permitted Values	Default
<p>Note: It works only if the value of the parameter "voice.tone.country" is set to Custom.</p> <p>Web User Interface: Settings->Tones->Ring Back</p> <p>Phone User Interface: None</p>		
voice.tone.busy	String	Blank
<p>Description: Customizes the tone when the callee is busy.</p> <p>The value format is Freq/Duration. For more information on the value format, refer to the parameter "voice.tone.dial".</p> <p>Note: It works only if the value of the parameter "voice.tone.country" is set to Custom.</p> <p>Web User Interface: Settings->Tones->Busy</p> <p>Phone User Interface: None</p>		
voice.tone.congestion	String	Blank
<p>Description: Customizes the tone when the network is congested.</p> <p>The value format is Freq/Duration. For more information on the value format, refer to the parameter "voice.tone.dial".</p> <p>Note: It works only if the value of the parameter "voice.tone.country" is set to Custom.</p> <p>Web User Interface: Settings->Tones->Congestion</p> <p>Phone User Interface: None</p>		
voice.tone.callwaiting	String	Blank
<p>Description: Customizes the call waiting tone.</p> <p>The value format is Freq/Duration. For more information on the value format, refer to the parameter "voice.tone.dial".</p> <p>Note: It works only if the value of the parameter "voice.tone.country" is set to Custom.</p> <p>Web User Interface:</p>		

Parameters	Permitted Values	Default
Settings->Tones->Call Waiting Phone User Interface: None		
voice.tone.dialrecall	String	Blank
Description: Customizes the call back tone. The value format is Freq/Duration. For more information on the value format, refer to the parameter "voice.tone.dial". Note: It works only if the value of the parameter "voice.tone.country" is set to Custom. Web User Interface: Settings->Tones->Dial Recall Phone User Interface: None		
voice.tone.info	String	Blank
Description: Customizes the info tone. The phone will play the info tone with the special information, for example, the number you are calling is not in service. The value format is Freq/Duration. For more information on the value format, refer to the parameter "voice.tone.dial". Note: It works only if the value of the parameter "voice.tone.country" is set to Custom. Web User Interface: Settings->Tones->Info Phone User Interface: None		
voice.tone.stutter	String	Blank
Description: Customizes the tone when the Skype for Business phone receives a voice mail. The value format is Freq/Duration. For more information on the value format, refer to the parameter "voice.tone.dial". Note: It works only if the value of the parameter "voice.tone.country" is set to Custom. Web User Interface: Settings->Tones->Stutter		

Parameters	Permitted Values	Default
Phone User Interface: None		
voice.tone.autoanswer	String	Blank
Description: Customizes the warning tone for auto answer. The value format is Freq/Duration. For more information on the value format, refer to the parameter "voice.tone.dial". Note: It works only if the value of the parameter "voice.tone.country" is set to Custom. Web User Interface: Settings->Tones->Auto Answer Phone User Interface: None		

To configure tones via web user interface:

1. Click on **Settings->Tones**.
2. Select the desired value from the pull-down list of **Select Country**.

If you select **Custom**, you can customize a tone for each condition of the Skype for Business phone.

3. Click **Confirm** to accept the change.

Voice Mail Tone

Voice mail tone feature allows the Skype for Business phone to play a warning tone when receiving a new voice mail. You can customize the warning tone or select specialized tone sets (vary from country to country) for your Skype for Business phone. For more information, refer to

Voice Mail Tone on page 293.

Procedure

Voice mail tone can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure whether to play a warning tone when the Skype for Business phone receives a new voice mail. Parameters: features.voice_mail_tone_enable
Local	Web User Interface	Configure whether to play a warning tone when the Skype for Business phone receives a new voice mail. Navigate to: http://<phoneIPAddress>/servlet?p=features-general&q=load

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
features.voice_mail_tone_enable	0 or 1	1
Description: Enables or disables the Skype for Business phone to play a warning tone when it receives a new voice mail. 0 -Disabled 1 -Enabled Web User Interface: Features->General Information->Voice Mail Tone Phone User Interface: None		

To configure voice mail tone via web user interface:

1. Click on **Features->General Information**.

2. Select the desired value from the pull-down list of **Voice Mail Tone**.

The screenshot shows the Yealink T46G web interface. The 'Features' tab is selected. In the 'General Information' section, the 'Voice Mail Tone' dropdown menu is highlighted with a red box and set to 'Enabled'. The interface includes a sidebar with 'General Information', 'Audio', 'Remote Control', 'Bluetooth', and 'LED'. The main area lists various settings like Call Waiting, Key As Send, Hotline Number, etc. A 'NOTE' section on the right provides additional information about 'Call Waiting' and 'Key As Send'.

3. Click **Confirm** to accept the change.

Headset Prior

Headset prior allows users to use headset preferentially if a headset is physically connected to the Skype for Business phone. This feature is especially useful for permanent or full-time headset users.

Procedure

Headset prior can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure headset prior. Parameter: features.headset_prior
Local	Web User Interface	Configure headset prior. Navigate to: http://<phoneIPAddress>/servlet?p=features-general&q=load

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
features.headset_prior	0 or 1	0
<p>Description:</p> <p>Enables or disables headset prior feature. You need to press the HEADSET key to activate the headset mode in advance.</p> <p>0-Disabled</p> <p>1-Enabled</p> <p>If it is set to 1 (Enabled), the headset mode will not be deactivated until the user presses the HEADSET key again.</p> <p>If it is set to 0 (Disabled), the headset mode can be deactivated by pressing the speakerphone key or the HEADSET key except the HANDSET key.</p> <p>Web User Interface:</p> <p>Features->General Information->Headset Prior</p> <p>Phone User Interface:</p> <p>None</p>		

To configure headset prior via web user interface:

1. Click on **Features->General Information**.

2. Select the desired value from the pull-down list of **Headset Prior**.

The screenshot shows the Yealink T46G web interface. The 'Features' tab is selected. In the 'General Information' section, the 'Headset Prior' setting is highlighted with a red box and is set to 'Enabled'. The interface includes a sidebar with 'General Information', 'Audio', 'Remote Control', 'Bluetooth', and 'LED'. The main area lists various features like Call Waiting, Key As Send, Hotline Number, etc. A 'NOTE' section on the right provides additional information about Call Waiting and Key As Send.

3. Click **Confirm** to accept the change.

Ringer Device for Headset

The Skype for Business phones support either or both speaker and headset ringer devices. Ringer Device for Headset feature allows users to configure which ringer device to be used when receiving an incoming call. For example, if the ringer device is set to Headset, ring tone will be played through your headset.

If the ringer device is set to Headset or Headset&Speaker, the headset should be connected to the Skype for Business phone and the headset mode also should be activated in advance. You can press the HEADSET key to activate the headset mode. For more information, refer to the [Yealink phone-specific user guide](#).

Procedure

Ringer device for headset can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the ringer device for the Skype for Business phone. Parameters: features.ringer_device.is_use_headset
Local	Web User Interface	Configure the ringer device for the Skype for Business phone.


		Navigate to: <a href="http://<phoneIPAddress>/servlet?p=features-audio&q=load">http://<phoneIPAddress>/servlet?p=features-audio&q=load
--	--	--

Details of Configuration Parameters:

Parameters	Permitted Values	Default
features.ringer_device.is_use_headset	0, 1 or 2	0
<p>Description:</p> <p>Configures the ringer device for the Skype for Business phone.</p> <p>0-Use Speaker 1-Use Headset 2-Use Headset & Speaker</p> <p>If the ringer device is set to Headset or Headset&Speaker, the headset should be connected to the Skype for Business phone and the headset mode also should be activated in advance.</p> <p>Web User Interface:</p> <p>Features->Audio->Ringer Device for Headset</p> <p>Phone User Interface:</p> <p>None</p>		

To configure ringer device for headset via web user interface:

1. Click on **Features->Audio**.
2. Select the desired value from the pull-down list of **Ringer Device for Headset**.



3. Click **Confirm** to accept the change.

Dual Headset

Dual headset allows users to use two headsets on one Skype for Business phone. To use this feature, users need to physically connect two headsets to the headset and handset jacks respectively. Once the Skype for Business phone connects to a call, the user with the headset connected to the headset jack has full-duplex capabilities, while the user with the headset connected to the handset jack is only able to listen.

Procedure

Dual headset can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure dual headset. Parameter: features.headset_training
Local	Web User Interface	Configure dual headset. Navigate to: http://<phoneIPAddress>/servlet?p=features-general&q=load

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
features.headset_training	0 or 1	0
<p>Description: Enables or disables dual headset feature.</p> <p>0-Disabled 1-Enabled</p> <p>If it is set to 1 (Enabled), users can use two headsets on one phone. When the Skype for Business phone joins in a call, the users with the headset connected to the headset jack have a full-duplex conversation, while the users with the headset connected to the handset jack are only allowed to listen to.</p> <p>Web User Interface: Features->General Information->Dual-Headset</p> <p>Phone User Interface: None</p>		

To configure dual headset via web user interface:

1. Click on **Features->General Information**.

2. Select the desired value from the pull-down list of **Dual-Headset**.

The screenshot shows the Yealink T46G configuration interface. The 'Features' tab is selected, and the 'General Information' sub-tab is active. A list of settings is displayed, including 'Call Waiting', 'Key As Send', 'Hotline Number', 'Hotline Delay(0~10s)', 'Busy Tone Delay (Seconds)', 'Return code when refuse', 'Time-Out for Dial-Now Rule', 'Dial Search Delay', '180 Ring Workaround', 'Save Call Log', 'Suppress DTMF Display', 'Suppress DTMF Display Delay', 'Play Local DTMF Tone', 'DTMF Repetition', 'Multicast Codec', 'Play Hold Tone', 'Play Hold Tone Delay', 'Allow Mute', 'Dual-Headset', 'Auto-Answer Delay(1~4s)', 'Headset Prior', and 'DTMF Replace Tran'. The 'Dual-Headset' setting is highlighted with a red box, and its value is 'Enabled'. A 'NOTE' section on the right provides additional information about 'Call Waiting' and 'Key As Send'.

3. Click **Confirm** to accept the change.

Sending Volume

Sending volume allows user to adjust the sending volume of currently engaged audio devices (handset, speakerphone or headset) when the phone is in use.

Procedure

Sending volume can be configured using the configuration files only.

Configuration File	<y0000000000xx>.cfg	Configure the sending volume of the speaker. Parameter: voice.handfree_send
		Configure the sending volume of the handset. Parameter: voice.handset_send

		Configure the sending volume of the headset. Parameter: voice.headset_send
--	--	---

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
voice.handfree_send	Integer from -50 to 50	0
Description: Configures the sending volume of the speaker. Note: We recommend that you modify this parameter cautiously. An unreasonable value may render the voice quality bad. If you change this parameter, the Skype for Business phone will reboot to make the change take effect. Web User Interface: None Phone User Interface: None		
voice.handset_send	Integer from -50 to 50	0
Description: Configures the sending volume of the handset. Note: We recommend that you modify this parameter cautiously. An unreasonable value may render the voice quality bad. If you change this parameter, the Skype for Business phone will reboot to make the change take effect. Web User Interface: None Phone User Interface: None		
voice.headset_send	Integer from -50 to 50	0
Description: Configures the sending volume of the headset. Note: We recommend that you modify this parameter cautiously. An unreasonable value may render the voice quality bad. If you change this parameter, the Skype for Business phone will reboot to make the change take effect.		

Parameter	Permitted Values	Default
Web User Interface: None Phone User Interface: None		

Audio Codecs

CODEC is an abbreviation of COMpress-DECompress, capable of coding or decoding a digital data stream or signal by implementing an algorithm. The object of the algorithm is to represent the high-fidelity audio signal with minimum number of bits while retaining the quality. This can effectively reduce the frame size and the bandwidth required for audio transmission.

The audio codec that the Skype for Business phone uses to establish a call should be supported by the SIP server. When placing a call, the Skype for Business phone will offer the enabled audio codec list to the server and then use the audio codec negotiated with the called party according to the priority.

The following table lists the audio codecs supported by each phone model:

Skype for Business phone	Supported Audio Codecs	Default Audio Codecs
T48G/T46G/T42G/T41P	G722, PCMA, PCMU, G729, G726-16, G726-24, G726-32, G726-40, iLBC, G723_53, G723_63	G722, PCMA, PCMU, G729
T40P	G722, PCMA, PCMU, G729, G726-16, G726-24, G726-32, G726-40, iLBC	G722, PCMA, PCMU, G729

The following table summarizes the supported audio codecs on Skype for Business phones:

Codec	Algorithm	Reference	Bit Rate	Sample Rate	Packetization Time
G722	G.722	RFC 3551	64 Kbps	16 Ksps	20ms
PCMA	G.711 a-law	RFC 3551	64 Kbps	8 Ksps	20ms
PCMU	G.711 u-law	RFC 3551	64 Kbps	8 Ksps	20ms
G729	G.729	RFC 3551	8 Kbps	8 Ksps	20ms
G726-16	G.726	RFC 3551	16 Kbps	8 Ksps	20ms
G726-24	G.726	RFC 3551	24 Kbps	8 Ksps	20ms
G726-32	G.726	RFC 3551	32 Kbps	8 Ksps	20ms

Codec	Algorithm	Reference	Bit Rate	Sample Rate	Packetization Time
G726-40	G.726	RFC 3551	40 Kbps	8 Ksps	20ms
G723_53/ G723_63	G.723.1	RFC 3551	5.3kbps 6.3kbps	8 Ksps	30ms
iLBC	iLBC	RFC 3952	15.2 Kbps 13.33 Kbps	8 Ksps	20ms 30ms

Packetization Time

Ptime (Packetization Time) is a measurement of the duration (in milliseconds) of the audio data in each RTP packet sent to the destination, and defines how much network bandwidth is used for the RTP stream transfer. Before establishing a conversation, codec and ptime are negotiated through SIP signaling. The valid values of ptime range from 10 to 60, in increments of 10 milliseconds. The default ptime is 20ms. You can also disable the ptime negotiation.

Codecs and priorities of these codecs are configurable on a per-line basis. The attribute "rtpmap" is used to define a mapping from RTP payload codes to a codec, clock rate and other encoding parameters.

The corresponding attributes of the codec are listed as follows:

Codec	Configuration Methods	Priority	RTPmap
G722	Configuration Files Web User Interface	1	9
PCMU	Configuration Files Web User Interface	2	0
PCMA	Configuration Files Web User Interface	3	8
G729	Configuration Files Web User Interface	4	18
G723_53	Configuration Files Web User Interface	0	4
G723_63	Configuration Files Web User Interface	0	4
G726-16	Configuration Files Web User Interface	0	103
G726-24	Configuration Files Web User Interface	0	104

Codec	Configuration Methods	Priority	RTPmap
G726-32	Configuration Files Web User Interface	0	102
G726-40	Configuration Files Web User Interface	0	105
iLBC	Configuration Files Web User Interface	0	106

Procedure

Configuration changes can be performed using the configuration files or locally.

Configuration File	<MAC>.cfg	Configure the codecs to use on a per-line basis. Parameters: account.1.codec.Y.enable account.1.codec.Y.payload_type
		Configure the priority and rtpmap for the enabled codec. Parameters: account.1.codec.Y.priority account.1.codec.Y.rtpmap
Local	Web User Interface	Configure the codecs to use on a per-line basis. Configure the priority for the enabled codec. Navigate to: <a href="http://<phoneIPAddress>/servlet?p=account-codec&q=load&acc=0">http://<phoneIPAddress>/servlet?p=account-codec&q=load&acc=0

Details of Configuration Parameters:

Parameters	Permitted Values	Default
account.1.codec.Y.enable (Y ranges from 1 to 11)	0 or 1	Refer to the following content
Description: Enables or disables the specified codec for the account. 0 -Disabled		


Parameters	Permitted Values	Default
<p>1-Enabled</p> <p>Default:</p> <p>For T48G/T46G/T42G/T41P:</p> <p>When Y=1, the default value is 1; When Y=2, the default value is 1; When Y=3, the default value is 0; When Y=4, the default value is 0; When Y=5, the default value is 1; When Y=6, the default value is 1; When Y=7, the default value is 0; When Y=8, the default value is 0; When Y=9, the default value is 0; When Y=10, the default value is 0; When Y=11, the default value is 0;</p> <p>For T40P:</p> <p>When Y=1, the default value is 1; When Y=2, the default value is 1; When Y=3, the default value is 1; When Y=4, the default value is 1; When Y=5, the default value is 0; When Y=6, the default value is 0; When Y=7, the default value is 0; When Y=8, the default value is 0; When Y=9, the default value is 0;</p> <p>Example:</p> <p>account.1.codec.1.enable = 1</p> <p>It means that the codec PCMU is enabled on the account.</p> <p>Web User Interface:</p> <p>Account->Codec</p> <p>Phone User Interface:</p> <p>None</p>		
account.1.codec.Y.payload_type (Y ranges from 1 to 11)	Refer to the following content	Refer to the following content
Description:		

Parameters	Permitted Values	Default
<p>Configures the codec for the account.</p> <p>Permitted Values:</p> <p>G722, PCMU, PCMA, G729, G726-16, G726-24, G726-32, G726-40, iLBC, G723_53, G723_63</p> <p>For T48G/T46G/T42G/T41P:</p> <p>When Y=1, the default value is PCMU;</p> <p>When Y=2, the default value is PCMA;</p> <p>When Y=3, the default value is G723_53;</p> <p>When Y=4, the default value is G723_63;</p> <p>When Y=5, the default value is G729;</p> <p>When Y=6, the default value is G722;</p> <p>When Y=7, the default value is iLBC;</p> <p>When Y=8, the default value is G726-16;</p> <p>When Y=9, the default value is G726-24;</p> <p>When Y=10, the default value is G726-32;</p> <p>When Y=11, the default value is G726-40;</p> <p>For T40P:</p> <p>When Y=1, the default value is PCMU;</p> <p>When Y=2, the default value is PCMA;</p> <p>When Y=3, the default value is G729;</p> <p>When Y=4, the default value is G722;</p> <p>When Y=5, the default value is iLBC;</p> <p>When Y=6, the default value is G726-16;</p> <p>When Y=7, the default value is G726-24;</p> <p>When Y=8, the default value is G726-32;</p> <p>When Y=9, the default value is G726-40;</p> <p>Example:</p> <p>account.1.codec.1.payload_type = PCMU</p> <p>Web User Interface:</p> <p>Account->Codec</p> <p>Phone User Interface:</p> <p>None</p>		
account.1.codec.Y.priority (Y ranges from 1 to 11)	Integer from 0 to 12	Refer to the following content
Description:		

Parameters	Permitted Values	Default
<p>Configures the priority of the enabled codec for the account.</p> <p>For T48G/T46G/T42G/T41P:</p> <p>When Y=1, the default value is 2; When Y=2, the default value is 3; When Y=3, the default value is 0; When Y=4, the default value is 0; When Y=5, the default value is 4; When Y=6, the default value is 1; When Y=7, the default value is 0; When Y=8, the default value is 0; When Y=9, the default value is 0; When Y=10, the default value is 0; When Y=11, the default value is 0;</p> <p>For T40P:</p> <p>When Y=1, the default value is 2; When Y=2, the default value is 3; When Y=3, the default value is 4; When Y=4, the default value is 1; When Y=5, the default value is 0; When Y=6, the default value is 0; When Y=7, the default value is 0; When Y=8, the default value is 0; When Y=9, the default value is 0;</p> <p>Example:</p> <p>account.1.codec.1.priority = 2</p> <p>Web User Interface:</p> <p>Account->Codec</p> <p>Phone User Interface:</p> <p>None</p>		
account.1.codec.Y.rtpmap (Y ranges from 1 to 11)	Integer from 0 to 127	Refer to the following content
<p>Description:</p> <p>Configures the rtpmap of the audio codec for the account.</p> <p>For T48G/T46G/T42G/T41P:</p>		



Parameters	Permitted Values	Default
<p>When Y=1, the default value is 0;</p> <p>When Y=2, the default value is 8;</p> <p>When Y=3, the default value is 4;</p> <p>When Y=4, the default value is 4;</p> <p>When Y=5, the default value is 18;</p> <p>When Y=6, the default value is 9;</p> <p>When Y=7, the default value is 106;</p> <p>When Y=8, the default value is 103;</p> <p>When Y=9, the default value is 104;</p> <p>When Y=10, the default value is 102;</p> <p>When Y=11, the default value is 105;</p> <p>For T40P:</p> <p>When Y=1, the default value is 0;</p> <p>When Y=2, the default value is 8;</p> <p>When Y=3, the default value is 18;</p> <p>When Y=4, the default value is 9;</p> <p>When Y=5, the default value is 106;</p> <p>When Y=6, the default value is 103;</p> <p>When Y=7, the default value is 104;</p> <p>When Y=8, the default value is 102;</p> <p>When Y=9, the default value is 105;</p> <p>Example:</p> <p>account.1.codec.1.rtpmap = 0</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p> <p>None</p>		


To configure the codecs to use and adjust the priority of the enabled codecs on a per-line basis via web user interface:

1. Click on **Account->Codec**.
2. Select the desired account from the pull-down list of **Account**.
3. Select the desired codec from the **Disable Codecs** column and then click .

The selected codec appears in the **Enable Codecs** column.
4. Repeat the step 4 to add more codecs to the **Enable Codecs** column.
5. To remove the codec from the **Enable Codecs** column, select the desired codec and then

click .

- To adjust the priority of codecs, select the desired codec and then click  or .



- Click **Confirm** to accept the change.

Acoustic Clarity Technology

Acoustic Echo Cancellation

Acoustic Echo Cancellation (AEC) is used to reduce acoustic echo from a voice call to provide natural full-duplex communication patterns. It also increases the capacity achieved through silence suppression by preventing echo from traveling across a network. Skype for Business phones employ advanced AEC for hands-free operation. AEC is not normally required for calls via the handset. In certain situation, where echo is experienced by the remote party, AEC may be used to reduce/avoid echo when the user uses the handset.

Note Utilizing acoustic echo cancellation will introduce a small delay increase into audio path which might cause a lower voice quality.

Procedure

AEC can be configured using the configuration files or locally.


Configuration File	<y0000000000xx>.cfg	Configure AEC. Parameter: voice.echo_cancellation
Local	Web User Interface	Configure AEC. Navigate to: http://<phoneIPAddress>/servlet?p=settings-voice&q=load

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
voice.echo_cancellation	0 or 1	1
<p>Description: Enables or disables AEC (Acoustic Echo Canceller) feature on the Skype for Business phone.</p> <p>0-Disabled 1-Enabled</p> <p>Web User Interface: Settings->Voice->Echo Cancellation->ECHO</p> <p>Phone User Interface: None</p>		

To configure AEC via web user interface:

1. Click on **Settings->Voice**.
2. Select the desired value from the pull-down list of **ECHO**.



3. Click **Confirm** to accept the change.

Background Noise Suppression (BNS)

Background noise suppression (BNS) is designed primarily for hands-free operation and reduces background noise to enhance communication in noisy environments.

Automatic Gain Control (AGC)

Automatic Gain Control (AGC) is applicable to hands-free operation and is used to keep audio output at nearly a constant level by adjusting the gain of signals in certain circumstances. This increases the effective user-phone radius and helps with the intelligibility of soft-talkers.

Voice Activity Detection (VAD)

Voice Activity Detection (VAD) is used in speech processing to detect the presence or absence of human speech. When detecting period of "silence", VAD replaces that silence efficiently with special packets that indicate silence is occurring. It can facilitate speech processing, and deactivate some processes during non-speech section of an audio session. VAD can avoid unnecessary coding or transmission of silence packets in VoIP applications, saving on computation and network bandwidth.

Procedure

VAD can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure VAD. Parameter: voice.vad
Local	Web User Interface	Configure VAD. Navigate to: http://<phoneIPAddress>/servlet?p=settings-voice&q=load

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
voice.vad	0 or 1	0
Description: Enables or disables VAD (Voice Activity Detection) feature on the Skype for Business phone. 0 -Disabled 1 -Enabled Web User Interface: Settings->Voice->Echo Cancellation->VAD Phone User Interface: None		

To configure VAD via web user interface:

1. Click on **Settings->Voice**.

2. Select the desired value from the pull-down list of **VAD**.

The screenshot shows the Yealink T46G web interface. The 'Settings' tab is selected. Under 'Echo Cancellation', the 'VAD' dropdown menu is highlighted with a red box, showing 'Disabled' as the selected option. Other settings include 'ECHO' (Enabled), 'CNG' (Enabled), and 'JITTER BUFFER' (Adaptive). The 'JITTER BUFFER' section also shows 'Type' (Adaptive), 'Min Delay' (60), 'Max Delay' (240), and 'Normal' (120). A 'NOTE' section on the right explains VAD and CNG.

3. Click **Confirm** to accept the change.

Comfort Noise Generation (CNG)

Comfort Noise Generation (CNG) is used to generate background noise for voice communications during periods of silence in a conversation. It is a part of the silence suppression or VAD handling for VoIP technology. CNG, in conjunction with VAD algorithms, quickly responds when periods of silence occur and inserts artificial noise until voice activity resumes. The insertion of artificial noise gives the illusion of a constant transmission stream, so that background sound is consistent throughout the call and the listener does not think the line has released. The purpose of VAD and CNG is to maintain an acceptable perceived QoS while simultaneously keeping transmission costs and bandwidth usage as low as possible.

Note

VAD is used to send CN packets when phone detect a "silence" period; CNG is used to generate comfortable noise when phone receives CN packets from the other side.

For example, A is talking with B.

A: VAD=1, CNG=1

B: VAD=0, CNG=1

If A mutes the call, since VAD=1, A will send CN packets to B. When receiving CN packets, B will generate comfortable noise.

If B mutes the call, since VAD=0, B will not send CN packets to A. So even if CNG=1 (B), A will not hear comfortable noise.

Procedure

CNG can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure CNG. Parameter: voice.cng
---------------------------	---------------------	--


Local	Web User Interface	Configure CNG. Navigate to: <a href="http://<phoneIPAddress>/servlet?p=settings-voice&q=load">http://<phoneIPAddress>/servlet?p=settings-voice&q=load
--------------	--------------------	--

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
voice.cng	0 or 1	1
Description: Enables or disables CNG (Comfortable Noise Generation) feature on the Skype for Business phone. 0 -Disabled 1 -Enabled Web User Interface: Settings->Voice->Echo Cancellation->CNG Phone User Interface: None		

To configure CNG via web user interface:

1. Click on **Settings->Voice**.
2. Select the desired value from the pull-down list of **CNG**.



3. Click **Confirm** to accept the change.

Jitter Buffer

Jitter buffer is a shared data area where voice packets can be collected, stored, and sent to the voice processor in even intervals. Jitter is a term indicating variations in packet arrival time, which can occur because of network congestion, timing drift or route changes. The jitter buffer, located at the receiving end of the voice connection, intentionally delays the arriving packets so that the end user experiences a clear connection with very little sound distortion. phones support two types of jitter buffers: fixed and adaptive. A fixed jitter buffer adds the fixed delay to voice packets. You can configure the delay time for the static jitter buffer on phones. An adaptive jitter buffer is capable of adapting the changes in the network's delay. The range of the delay time for the dynamic jitter buffer added to packets can be also configured on phones.

Procedure

Jitter buffer can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the mode of jitter buffer and the delay time for jitter buffer. Parameters: voice.jib.adaptive voice.jib.min voice.jib.max voice.jib.normal
Local	Web User Interface	Configure the mode of jitter buffer and the delay time for jitter buffer. Navigate to: <a href="http://<phoneIPAddress>/servlet?p=settings-voice&q=load">http://<phoneIPAddress>/servlet?p=settings-voice&q=load

Details of Configuration Parameters:

Parameters	Permitted Values	Default
voice.jib.adaptive	0 or 1	1
Description: Configures the type of jitter buffer. 0 -Fixed 1 -Adaptive		

Parameters	Permitted Values	Default
Web User Interface: Settings->Voice->JITTER BUFFER->Type Phone User Interface: None		
voice.jib.min	Integer from 0 to 400	60
Description: Configures the minimum delay time (in milliseconds) of jitter buffer. Note: It works only if the value of the parameter "voice.jib.adaptive" is set to 1 (Adaptive). Web User Interface: Settings->Voice->JITTER BUFFER->Min Delay Phone User Interface: None		
voice.jib.max	Integer from 0 to 400	240
Description: Configures the maximum delay time (in milliseconds) of jitter buffer. Note: It works only if the value of the parameter "voice.jib.adaptive" is set to 1 (Adaptive). Web User Interface: Settings->Voice->JITTER BUFFER->Max Delay Phone User Interface: None		
voice.jib.normal	Integer from 0 to 400	120
Description: Configures the normal delay time (in milliseconds) of jitter buffer. Note: It works only if the value of the parameter "voice.jib.adaptive" is set to 0 (Fixed). Web User Interface: Settings->Voice->JITTER BUFFER->Normal Phone User Interface: None		

To configure Jitter Buffer via web user interface:

1. Click on **Settings->Voice**.
2. Mark the desired radio box in the **Type** field.

3. Enter the minimum delay time for adaptive jitter buffer in the **Min Delay** field.
The valid value ranges from 0 to 300.
4. Enter the maximum delay time for adaptive jitter buffer in the **Max Delay** field.
The valid value ranges from 0 to 300.
5. Enter the fixed delay time for fixed jitter buffer in the **Normal** field.
The valid value ranges from 0 to 300.

The screenshot shows the Yealink T46G Settings page. The 'JITTER BUFFER' section is highlighted with a red box. It contains the following settings:

- Type: ☒ Adaptive ☐ Fixed
- Min Delay: 60
- Max Delay: 240
- Normal: 120

The 'Echo Cancellation' section shows the following settings:

- ECHO: Enabled
- VAD: Disabled
- CNG: Enabled

A 'NOTE' section on the right provides additional information:

- VAD** (Voice Activity Detection): Voice Activity Detection.
- CNG** (Comfort Noise Generation): Comfort Noise Generation.
- JITTER BUFFER**: It is a shared data area where voice packets can be collected, stored, and sent to the voice processor in evenly.

6. Click **Confirm** to accept the change.

DTMF

DTMF (Dual Tone Multi-frequency), better known as touch-tone, is used for telecommunication signaling over analog telephone lines in the voice-frequency band. DTMF is the signal sent from the phone to the network, which is generated when pressing the phone's keypad during a call. Each key pressed on the phone generates one sinusoidal tone of two frequencies. One is generated from a high frequency group and the other from a low frequency group.

The DTMF keypad is laid out in a 4×4 matrix, with each row representing a low frequency, and each column representing a high frequency. Pressing a digit key (such as '1') will generate a sinusoidal tone for each of two frequencies (697 and 1209 hertz (Hz)).

DTMF Keypad Frequencies:

	1209 Hz	1336 Hz	1477 Hz	1633 Hz
697 Hz	1	2	3	A
770 Hz	4	5	6	B
852 Hz	7	8	9	C
941 Hz	*	0	#	D

Methods of Transmitting DTMF Digit

RFC 2833

DTMF digits are transmitted using the RTP Event packets that are sent along with the voice path. These packets use RFC 2833 format and must have a payload type that matches what the other end is listening for. The payload type for RTP Event packets is configurable. The default payload type for RTP Event packets is 101 and the payload type is configurable. The Skype for Business phones use the configured value to negotiate with the other end during call establishment.

The RTP Event packet contains 4 bytes. The 4 bytes are distributed over several fields denoted as Event, End bit, R-bit, Volume and Duration. If the End bit is set to 1, the packet contains the end of the DTMF event. You can configure the sending times of the end RTP Event packet.

Procedure

Configuration changes can be performed using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the number of times for the Skype for Business phone to send the end RTP Event packet. Parameter: features.dtmf.repetition
Local	Web User Interface	Configure the number of times for the Skype for Business phone to send the end RTP Event packet. Navigate to: <a href="http://<phoneIPAddress>/servlet?parameters=features-general&q=load">http://<phoneIPAddress>/servlet?parameters=features-general&q=load

Details of Configuration Parameters:

Parameters	Permitted Values	Default
features.dtmf.repetition	1, 2 or 3	3
Description: Configures the repetition times for the Skype for Business phone to send the end RTP Event packet during an active call. Web User Interface: Features->General Information->DTMF Repetition Phone User Interface: None		

To configure the number of times to send the end RTP Event packet via web user interface:

1. Click on **Features->General Information**.
2. Select the desired value (1-3) from the pull-down list of **DTMF Repetition**.

The screenshot shows the Yealink T46G web interface. The 'Features' tab is selected, and the 'General Information' sub-tab is active. A list of settings is displayed, including 'Call Waiting', 'Key As Send', 'Hotline Number', 'Hotline Delay(0~10s)', 'Busy Tone Delay (Seconds)', 'Return code when refuse', 'Time-Out for Dial-Now Rule', 'Dial Search Delay', '180 Ring Workaround', 'Save Call Log', 'Suppress DTMF Display', 'Suppress DTMF Display Delay', 'Play Local DTMF Tone', 'DTMF Repetition', 'Multicast Codec', 'Play Hold Tone', 'Play Hold Tone Delay', 'Allow Mute', 'Dual-Headset', 'Auto-Answer Delay(1~4s)', and 'Headset Prior'. The 'DTMF Repetition' dropdown menu is highlighted with a red box and set to '3'. A 'NOTE' section on the right provides information about 'Call Waiting' and 'Key As Send'.

3. Click **Confirm** to accept the change.

Suppress DTMF Display

Suppress DTMF display allows Skype for Business phones to suppress the display of DTMF digits during an active call. DTMF digits are displayed as "*" on the LCD screen. Suppress DTMF display delay defines whether to display the DTMF digits for a short period of time before displaying as "*".

Procedure

Configuration changes can be performed using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure suppress DTMF display and suppress DTMF display delay. Parameters: features.dtmf.hide features.dtmf.hide_delay
Local	Web User Interface	Configure suppress DTMF display and suppress DTMF display delay.

		Navigate to: <a href="http://<phoneIPAddress>/servlet?p=features-general&q=load">http://<phoneIPAddress>/servlet?p=features-general&q=load
--	--	--

Details of Configuration Parameters:

Parameters	Permitted Values	Default
features.dtmf.hide	0 or 1	0
Description: Enables or disables the Skype for Business phone to suppress the display of DTMF digits during an active call. 0 -Disabled 1 -Enabled If it is set to 1 (Enabled), the DTMF digits are displayed as asterisks. Web User Interface: Features->General Information->Suppress DTMF Display Phone User Interface: None		
features.dtmf.hide_delay	0 or 1	0
Description: Enables or disables the Skype for Business phone to display the DTMF digits for a short period before displaying asterisks during an active call. 0 -Disabled 1 -Enabled Note: It works only if the value of the parameter "features.dtmf.hide" is set to 1 (Enabled). Web User Interface: Features->General Information->Suppress DTMF Display Delay Phone User Interface: None		

To configure suppress DTMF display and suppress DTMF display delay via web user interface:

1. Click on **Features->General Information**.
2. Select the desired value from the pull-down list of **Suppress DTMF Display**.

3. Select the desired value from the pull-down list of **Suppress DTMF Display Delay**.

The screenshot shows the Yealink T46G web interface. The 'Features' tab is selected, and the 'General Information' section is expanded. The 'Suppress DTMF Display Delay' dropdown menu is highlighted with a red box, showing 'Disabled' as the selected option. Other settings visible include 'Call Waiting' (Enabled), 'Key As Send' (#), 'Hotline Number' (empty), 'Hotline Delay(0~10s)' (4), 'Busy Tone Delay (Seconds)' (0), 'Return code when refuse' (603 (Decline)), 'Time-Out for Dial-Now Rule' (1), 'Dial Search Delay' (1), '180 Ring Workaround' (Disabled), 'Save Call Log' (Enabled), 'Suppress DTMF Display' (Disabled), 'Play Local DTMF Tone' (Enabled), 'DTMF Repetition' (3), 'Multicast Codec' (G722), 'Play Hold Tone' (Enabled), 'Play Hold Tone Delay' (30), 'Allow Mute' (Enabled), 'Dual-Headset' (Disabled), 'Auto-Answer Delay(1~4s)' (1), and 'Headset Prior' (Disabled). A 'NOTE' section on the right provides additional information about 'Call Waiting' and 'Key As Send'.

4. Click **Confirm** to accept the change.

Transfer via DTMF

Call transfer is implemented via DTMF on some traditional servers. The Skype for Business phone sends specified DTMF digits to the server for transferring calls to third parties.

Procedure

Configuration changes can be performed using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure transfer via DTMF. Parameters: features.dtmf.replace_tran features.dtmf.transfer
Local	Web User Interface	Configure transfer via DTMF. Navigate to: http://<phoneIPAddress>/servlet? p=features-general&q=load

Details of Configuration Parameters:

Parameters	Permitted Values	Default
features.dtmf.replace_tran	0 or 1	0
<p>Description:</p> <p>Enables or disables the Skype for Business phone to send DTMF sequences for transfer function when pressing the Tran/Transfer soft key or TRANSFER key.</p> <p>0-Disabled 1-Enabled</p> <p>If it is set to 0 (Disabled), the Skype for Business phone will perform the transfer as normal when pressing the Tran/Transfer soft key or TRANSFER key during a call.</p> <p>If it is set to 1 (Enabled), the Skype for Business phone will transmit the designated DTMF digits to the server for performing call transfer when pressing the Tran/Transfer soft key or TRANSFER key during a call.</p> <p>Web User Interface:</p> <p>Features->General Information->DTMF Replace Tran</p> <p>Phone User Interface:</p> <p>None</p>		
features.dtmf.transfer	String within 32 characters	Blank
<p>Description:</p> <p>Configures the DTMF digits to be transmitted to perform call transfer. Valid values are: 0-9, *, # and A-D.</p> <p>Example:</p> <p>features.dtmf.transfer = 123</p> <p>Note: It works only if the value of the parameter "features.dtmf.replace_tran" is set to 1 (Enabled).</p> <p>Web User Interface:</p> <p>Features->General Information->Tran Send DTMF</p> <p>Phone User Interface:</p> <p>None</p>		

To configure transfer via DTMF via web user interface:

1. Click on **Features->General Information**.
2. Select the desired value from the pull-down list of **DTMF Replace Tran**.

3. Enter the specified DTMF digits in the **Tran Send DTMF** field.

The screenshot shows the Yealink T46G web interface with the 'Features' tab selected. The 'General Information' section is expanded, showing a list of settings. The 'Tran Send DTMF' field is highlighted with a red box and contains the value '123'. Other settings include Call Waiting (Enabled), Key As Send (#), Hotline Number (1234), Hotline Delay (0~10s) (4), Busy Tone Delay (Seconds) (0), Return code when refuse (603 (Decline)), Time-Out for Dial-Now Rule (1), Dial Search Delay (1), 180 Ring Workaround (Disabled), Save Call Log (Enabled), Suppress DTMF Display (Disabled), Suppress DTMF Display Delay (Disabled), Play Local DTMF Tone (Enabled), DTMF Repetition (3), Multicast Codec (G722), Play Hold Tone (Enabled), Play Hold Tone Delay (30), Allow Mute (Enabled), Dual-Headset (Disabled), Auto-Answer Delay(1~4s) (1), Headset Prior (Disabled), DTMF Replace Tran (Enabled), Tran Send DTMF (123), and Send Pound Key (Disabled). A 'NOTE' section on the right provides information about Call Waiting and Key As Send.

4. Click **Confirm** to accept the change.

Play Local DTMF Tone

Play local DTMF tone allows Skype for Business phones to play a local DTMF tone during an active call. If this feature is enabled, you can hear the DTMF tone when pressing the Skype for Business phone's keypad during a call.

Procedure

Configuration changes can be performed using the configuration files or locally.


Configuration File	<y0000000000xx>.cfg	Configure play local DTMF tone. Parameters: features.play_local_dtmf_tone_enable
Local	Web User Interface	Configure play local DTMF tone. Navigate to: http://<phoneIPAddress>/servlet?path=/features-general&q=load

Details of Configuration Parameters:

Parameters	Permitted Values	Default
features.play_local_dtmf_tone_enable	0 or 1	1
<p>Description:</p> <p>Enables or disables the Skype for Business phone to play a local DTMF tone during a call.</p> <p>0-Disabled</p> <p>1-Enabled</p> <p>If it is set to 1 (Enabled), you can hear the DTMF tone when pressing the Skype for Business phone's keypad during a call.</p> <p>Web User Interface:</p> <p>Features->General Information->Play Local DTMF Tone</p> <p>Phone User Interface:</p> <p>None</p>		

To configure play local DTMF tone via web user interface:

1. Click on **Features->General Information**.
2. Select the desired value from the pull-down list of **Play Local DTMF Tone**.



3. Click **Confirm** to accept the change.

Configuring Security Features

This chapter provides information for making configuration changes for the following security-related features:

- [Skype for Business Feature License](#)
- [User and Administrator Passwords](#)
- [Auto-Logout Time](#)
- [Phone Lock](#)
- [Account Lock](#)
- [Transport Layer Security](#)
- [Encrypting Configuration Files](#)

Skype for Business Feature License

By default, the Skype for Business phone has a built-in Skype for Business feature license, which allows user to use Yealink phones with Skype for Business features directly.

If users purchase Skype for Business phones which aren't running Skype for Business firmware, while the user wants to upgrade firmware to a Skype for Business firmware, then a Skype for Business feature license is needed to be uploaded to the Skype for Business phone after the update. Contact Yealink resellers to purchase the license.

Procedure

Skype for Business feature license can be configured using the configuration files or locally.


Configuration File	<y0000000000xx>.cfg	Specify the access URL of Skype for Business feature license. Parameter: lync_license_dat.url
Local	Web User Interface	Specify the access URL of Skype for Business feature license. Navigate to: http://<phoneIPAddress>/servlet?p=security-license&q=load

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
lync_license_dat.url	String within 99 characters	Blank
<p>Description: Configures the access URL of the Skype for Business feature license.</p> <p>Example: lync_license_dat.url = http://192.168.1.20/License_\$MAC.dat</p> <p>Example: The Skype for Business phones will replace the characters "\$MAC" with its MAC addresses during auto provisioning. For example, the MAC address of one T46G Skype for Business phone is 00156543EC97. When performing auto provisioning, the Skype for Business phone will request to download the License_00156543ec97.dat file from the provisioning server address "http://192.168.1.20".</p> <p>Web User Interface: Security->License</p> <p>Phone User Interface: None</p> <p>Note: If you change this parameter, the Skype for Business phone will reboot to make the change take effect.</p>		

To upload the Skype for Business feature license via web user interface:

1. Click on **Security->License**.
2. Click **Browse** to select the license from your local system.



3. Click **Upload** to upload the certificate.

You can view the Skype for Business Server license status via web user interface. For more information, refer to [Skype for Business Status](#) on page 352.

User and Administrator Passwords

Some menu options are protected by two privilege levels, user and administrator, each with its own password. When logging into the web user interface, you need to enter the user name and password to access various menu options. The default user password is "user" and the default administrator password is "admin".

For security reasons, the user or administrator should change the default user or administrator password as soon as possible. A user or an administrator can change the user password. The administrator password can only be changed by an administrator.

Advanced menu options are strictly used by administrators. Users can configure them only if they have administrator privileges.

Procedure

User or administrator password can be changed using the following methods.

Configuration File	<y0000000000xx>.cfg	Change the user or administrator password of the phone. Parameter: security.user_password
Local	Web User Interface	Change the user or administrator password of the phone. Navigate to: http://<phoneIPAddress>/servlet?password=security&q=load
	Phone User Interface	Change the administrator password of the phone.

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
static.security.user_password	String within 32 characters	user
Description: Configures the password of the user or administrator for phone's web user interface access. The phone uses "user" as the default user password and "admin" as the default administrator password. The valid value format is username:new password. Example: static.security.user_password = user:123 means setting the password of user (current user name is "user") to password 123.		

Parameter	Permitted Values	Default
<p>static.security.user_password = admin:456 means setting the password of administrator (current user name is "admin") to password 456.</p> <p>Note: Phones support ASCII characters 32-126(0x20-0x7E) in passwords. You can set the password to be empty via web user interface only.</p> <p>Web User Interface: Security->Password</p> <p>Phone User Interface: Menu->Advanced (default password: admin)->Set Password</p> <p>Note: You cannot change the user password via phone user interface.</p>		

To change the user or administrator password via web user interface:

1. Click on **Security->Password**.
2. Select the desired value (**user** or **admin**) from the pull-down list of **User Type**.
3. Enter new password in the **New Password** and **Confirm Password** fields.

Valid characters are ASCII characters 32-126(0x20-0x7E) except 58(3A).

4. Click **Confirm** to accept the change.

Note

If logging into the web user interface of the phone with the user credential, you need to enter the old user password in the **Old Password** field.

To change the administrator password via phone user interface:

1. Press **Menu-> Advanced** (default password: admin) ->**Set Password**.
2. Enter the current administrator password in the **Current PWD** field.
3. Enter new password in the **New PWD** field and **Confirm PWD** field.
Valid characters are ASCII characters 32-126(0x20-0x7E).
4. Press the **Save** soft key to accept the change.

Auto-Logout Time

Auto-logout time defines a specific period of time during which the Skype for Business phones will automatically log out if you have not performed any actions via web user interface. Once logging out, you must re-enter username and password for web access authentication.

Procedure

Auto-logout time can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure auto-logout time. Parameter: features.relog_offtime
Local	Web User Interface	Configure auto-logout time. Navigate to: http://<phoneIPAddress>/servlet?parameters=features-general&q=load

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
features.relog_offtime	Integer from 1 to 1000	5
Description: Configures the timeout interval (in minutes) for web access authentication. Example: features.relog_offtime = 5 If you log into the web user interface and leave it for 5 minutes, it will automatically log out. Note: If you change this parameter, the Skype for Business phone will reboot to make the change take effect. Web User Interface: Features->General Information->Auto-Logout Time(1~1000min) Phone User Interface: None		

To configure the auto-logout time via web user interface:

1. Click on **Features->General Information**.

- Enter the desired auto-logout time in **Auto-Logout Time(1~1000min)** field.

The screenshot shows the Yealink T46G web interface with the 'Features' tab selected. The 'General Information' section is expanded, and the 'Auto-Logout Time(1~1000min)' field is highlighted with a red box, showing a value of '5'. Other settings include 'Call Waiting' (Enabled), 'Key As Send' (#), 'Hotline Number' (empty), 'Hotline Delay(0~10s)' (4), 'Busy Tone Delay (Seconds)' (0), 'Return code when refuse' (603 (Decline)), 'Diversion/History-Info' (Enabled), 'Call Number Filter' (empty), 'Voice Mail Tone' (Enabled), 'DHCP Hostname' (SIP-T46G), 'E911 Location Tip' (Enabled), 'Update Checking Time' (24), 'Use DHCP Option 120' (Disabled), 'SFB Cert. Service URL' (empty), 'Enable SFB Automation' (Disabled), 'SFB Inactive Time' (5), 'SFB Away Time' (5), 'Web Sign in' (Enabled), 'Remember Password' (Disabled), and 'History Record Contacts Avatar' (Enabled). A 'NOTE' section on the right provides information about 'Call Waiting' and 'Key As Send'.

- Click **Confirm** to accept the change.

Phone Lock


If system administrator sets the policy "ucEnforcePinLock" = true on the Skype for Business Frontend Server, user can use phone lock feature to lock the Skype for Business phone to prevent it from unauthorized use. And the Skype for Business phone will prompt the user to configure an n-digit unlock PIN at the initial sign-in.

The screenshot shows the 'Unlock PIN Setting' dialog box. It has a blue header and a white body. The 'New PIN:' field is highlighted with a blue background and contains the text 'PIN's length must be from 6 to 15'. The 'Confirm PIN:' field is empty. At the bottom, there are three buttons: '123', 'Delete', and 'Save'.

The minimum PIN length is dictated in the policy information pushed during the in-band provisioning as a value in "<ucMinPinLength> </ucMinPinLength>", so the PIN length should be greater than or equal to the specified value. Once the Skype for Business phone is locked, a user

must enter the unlock PIN to unlock it.

Do one of the following to lock the Skype for Business phone:

- Long press  for two seconds to lock the phone immediately when the phone is idle.
- Press **Menu->Lock**.
- Press **Menu ->Basic->Phone Lock**. Select **Lock the phone**, and then press the **Lock** soft key.
- The phone will be locked automatically if when it has been inactive for the designated time. The time is specified in the ucTimeout policy on Skype for Business Frontend Server.

If you enable phone lock feature, available features are limited. They are described as below:

1. User is able to receive calls.
2. User is able to dial emergency numbers.
3. Whether the phone can make other outgoing calls depends on the value of **DisableHandsetOnLockedMachine** only.
 - When the parameter **DisableHandsetOnLockedMachine** is set to **True** on the Skype for Business Server, the locked phone cannot make other outgoing calls.
 - When the parameter **DisableHandsetOnLockedMachine** is set to **False** on the Skype for Business Server, the locked phone can place other outgoing calls.

By default the locked phone can only place an emergency call and cannot make other outgoing calls.
4. User cannot forward an incoming call to another user.
5. User cannot search the directory.
6. User cannot see favorite lists displayed on the screen.
7. User cannot access voicemail without first unlocking the phone or providing a voicemail PIN.

If the Skype for Business Server is configured not to lock the phone, the phone will not have the phone lock feature.

If the Skype for Business Server is configured to forcibly lock the phone, the phone lock feature will be enabled on the phone by default. User can also disable the phone lock feature as needed. The following introduces how to disable or enable the phone lock feature on the phone.

Procedure

Phone lock configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the phone lock feature. Parameter: sfb.phone_lock.enable
Local	Web User Interface	Configure the phone lock feature. Change the unlock PIN.

		Navigate to: http://<phoneIPAddress>/servlet?= =features-phonelock&q=load
	Phone User Interface	Configure the phone lock feature. Change the unlock PIN.


Details of Configuration Parameter:

Parameters	Permitted Values	Default
sfb.phone_lock.enable	0 or 1	0
<p>Description: Enables or disables the phone lock feature.</p> <p>0- Enabled 1- Disabled</p> <p>If it is set to 0 (Enabled), the Skype for Business phone will prompt the user to configure an n-digit unlock PIN at the initial sign-in.</p> <p>Web User Interface: Settings->Phone Lock</p> <p>Phone User Interface: Menu->Basic->Phone Lock- >Phone Lock->Lock the phone</p>		

To configure phone lock via web user interface:

1. Click on **Settings->Phone Lock**.
2. Select the desired value from the pull-down list of **Phone Lock**.
 - If it is enabled, users need to configure a unlock PIN after login.
 - If it is disabled, users do not need to configure a unlock PIN after login and the phone will not be locked.

3. Enter the unlock PIN in the **Phone Unlock PIN(6~15 Digit)** field.



4. Click **Confirm** to accept the change.

To configure phone lock via phone user interface:

1. Press **Menu-> Basic->Phone Lock->Phone Lock**.
2. Press or , or the **Switch** soft key to select the desired value from the **Lock the phone** field.
3. Press the **Save** soft key to accept the change.
The phone user interface prompts "Reboot now?".
4. Press **OK** soft key.

To change the phone Unlock PIN via phone user interface:

1. Press **Menu->Basic->Phone Lock->Change PIN**.
2. Enter the current unlock PIN in the **Current PIN** field.
3. Enter the new unlock PIN in the **New PIN** field.
4. Enter the new unlock PIN again in the **Confirm PIN** field.
5. Press the **Save** soft key to accept the change.

Account Lock

Account lock is used to lock the account on the Skype for Business phone. It can prevent your account being signed in or signed out randomly. If account lock feature is enabled, users are prompted for administrator password to sign in or sign out. This feature is especially useful for public area telephone users.

Procedure

Account lock can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure account lock. Parameters:
---------------------------	---------------------	---


		sfb.account_lock.enable
Local	Web User Interface	Configure account lock. Navigate to: http://<phoneIPAddress>/servlet?p=account-basic&q=load&acc=0
	Phone User Interface	Configure account lock.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
sfb.account_lock.enable	0 or 1	0
<p>Description:</p> <p>Enables or disables the Skype for Business phone to lock the account to prevent the account being signed in or signed out randomly.</p> <p>0-Disabled 1-Enabled</p> <p>If it is set to 1 (Enabled), the Skype for Business phone needs an administrator password to sign in or sign out.</p> <p>Web User Interface:</p> <p>Account->Basic->Account Lock</p> <p>Phone User Interface:</p> <p>Menu->Advanced (default password: admin)->Account Lock</p>		



To configure account lock feature via web user interface:

1. Click on **Account->Basic**.
2. Select the desired value from the pull-down list of **Account Lock**.



3. Click **Confirm** to accept the change.

To configure the account lock feature via phone user interface:

1. Press **Menu->Advanced** (default password: admin) -> **Account Lock**.
2. Press  or , or the **Switch** soft key to select **On** from the **Account Lock** field.
3. Press the **Save** soft key to accept the change.

Transport Layer Security

TLS is a commonly-used protocol for providing communications privacy and managing the security of message transmission, allowing Skype for Business phones to communicate with other remote parties and connect to the HTTPS URL for provisioning in a way that is designed to prevent eavesdropping and tampering.

TLS protocol is composed of two layers: TLS Record Protocol and TLS Handshake Protocol. The TLS Record Protocol completes the actual data transmission and ensures the integrity and privacy of the data. The TLS Handshake Protocol allows the server and client to authenticate each other and negotiate an encryption algorithm and cryptographic keys before data is exchanged.

The TLS protocol uses asymmetric encryption for authentication of key exchange, symmetric encryption for confidentiality, and message authentication codes for integrity.

- **Symmetric encryption:** For symmetric encryption, the encryption key and the corresponding decryption key can be told by each other. In most cases, the encryption key is the same as the decryption key.
- **Asymmetric encryption:** For asymmetric encryption, each user has a pair of cryptographic keys – a public encryption key and a private decryption key. The information encrypted by the public key can only be decrypted by the corresponding private key and vice versa. Usually, the receiver keeps its private key. The public key is known by the sender, so the sender sends the information encrypted by the known public key, and then the receiver uses the private key to decrypt it.


Skype for Business phones support TLS version 1.0. A cipher suite is a named combination of authentication, encryption, and message authentication code (MAC) algorithms used to negotiate the security settings for a network connection using the TLS/SSL network protocol.

Skype for Business phones support the following cipher suites:

- DHE-RSA-AES256-SHA
- DHE-DSS-AES256-SHA
- AES256-SHA
- EDH-RSA-DES-CBC3-SHA
- EDH-DSS-DES-CBC3-SHA
- DES-CBC3-SHA
- DHE-RSA-AES128-SHA
- DHE-DSS-AES128-SHA
- AES128-SHA

- IDEA-CBC-SHA
- DHE-DSS-RC4-SHA
- RC4-SHA
- RC4-MD5
- EXP1024-DHE-DSS-DES-CBC-SHA
- EXP1024-DES-CBC-SHA
- EDH-RSA-DES-CBC-SHA
- EDH-DSS-DES-CBC-SHA
- DES-CBC-SHA
- EXP1024-DHE-DSS-RC4-SHA
- EXP1024-RC4-SHA
- EXP1024-RC4-MD5
- EXP-EDH-RSA-DES-CBC-SHA
- EXP-EDH-DSS-DES-CBC-SHA
- EXP-DES-CBC-SHA
- EXP-RC4-MD5

The following figure illustrates the TLS messages exchanged between the Skype for Business phone and TLS server to establish an encrypted communication channel:



The image shows a Wireshark packet capture of a TLS handshake. The packet list on the left shows seven packets. The selected packet (No. 13) is expanded, showing the details of the TLS handshake. The details pane shows the following information:

No.	Time	Source	Destination	Protocol	Info
1	0.000000	192.168.3.86	192.168.0.230	SSLv3	Client Hello
2	0.021345	192.168.0.230	192.168.3.86	SSLv3	Server Hello, Certificate, Server Key Exchange, Server Hello Done
3	0.954947	192.168.3.86	192.168.0.230	SSLv3	Client Key Exchange, Change Cipher Spec, Encrypted Handshake Message
4	0.970099	192.168.0.230	192.168.3.86	SSLv3	Change Cipher Spec, Encrypted Handshake Message
5	1.012295	192.168.3.86	192.168.0.230	SSLv3	Application Data, Application Data
6	1.013562	192.168.0.230	192.168.3.86	SSLv3	Application Data
7	1.013667	192.168.0.230	192.168.3.86	SSLv3	Application Data

The details pane for the selected packet (No. 13) shows the following information:

- Frame 13: 652 bytes on wire (5216 bits), 652 bytes captured (5216 bits)
- Ethernet II, Src: Vmware_72:c9:2e (00:0c:29:72:c9:2e), Dst: Xiamenye_11:12:b7 (00:15:65:11:12:b7)
- Internet Protocol, Src: 192.168.0.230 (192.168.0.230), Dst: 192.168.3.86 (192.168.3.86)
- Transmission Control Protocol, Src Port: https (443), Dst Port: nmsserver (2244), Seq: 1482, Ack: 437, Len: 586
- Secure Socket Layer

Step1: Skype for Business phone sends "Client Hello" message proposing SSL options.

Step2: Server responds with "Server Hello" message selecting the SSL options, sends its public key information in "Server Key Exchange" message and concludes its part of the negotiation with "Server Hello Done" message.

Step3: Skype for Business phone sends session key information (encrypted by server's public key) in the "Client Key Exchange" message.

Step4: Server sends "Change Cipher Spec" message to activate the negotiated options for all future messages it will send.

Skype for Business phones can encrypt SIP with TLS, which is called SIPS. When TLS is enabled for an account, the SIP message of this account will be encrypted, and a lock icon appears on the LCD screen after the successful TLS negotiation.

Certificates

The Skype for Business phone can serve as a TLS client or a TLS server. The TLS requires the following security certificates to perform the TLS handshake:

- **Trusted Certificate:** When the Skype for Business phone requests a TLS connection with a server, the Skype for Business phone should verify the certificate sent by the server to decide whether it is trusted based on the trusted certificates list. The Skype for Business phone has 49 built-in trusted certificates. You can upload 10 custom certificates at most. The format of the trusted certificate files must be *.pem, *.cer, *.crt and *.der and the maximum file size is 5MB. For more information on 49 trusted certificates, refer to [Appendix C: Trusted Certificates](#) on page 384.
- **Server Certificate:** When clients request a TLS connection with the Skype for Business phone, the Skype for Business phone sends the server certificate to the clients for authentication. The Skype for Business phone has two types of built-in server certificates: a unique server certificate and a generic server certificate. You can only upload one server certificate to the Skype for Business phone. The old server certificate will be overridden by the new one. The format of the server certificate files must be *.pem and *.cer and the maximum file size is 5MB.
 - **A unique server certificate:** It is unique to a Skype for Business phone (based on the MAC address) and issued by the Yealink Certificate Authority (CA).
 - **A generic server certificate:** It issued by the Yealink Certificate Authority (CA). Only if no unique certificate exists, the Skype for Business phone may send a generic certificate for authentication.

The Skype for Business phone can authenticate the server certificate based on the trusted certificates list. The trusted certificates list and the server certificates list contain the default and custom certificates. You can specify the type of certificates the Skype for Business phone accepts: default certificates, custom certificates or all certificates.

Common Name Validation feature enables the Skype for Business phone to mandatorily validate the common name of the certificate sent by the connecting server. And Security verification rules are compliant with RFC 2818.

Note

In TLS feature, we use the terms trusted and server certificate. These are also known as CA and device certificates.

Resetting the Skype for Business phone to factory defaults will delete custom certificates by default. But this feature is configurable by the parameter "phone_setting.reserve_certs_enable" using the configuration files.

Procedure

Configuration changes can be performed using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure trusted certificates feature. Parameters: security.trust_certificates security.ca_cert security.cn_validation
		Configure server certificates feature. Parameters: security.dev_cert
		Upload the trusted certificates. Parameter: trusted_certificates.url
		Delete all uploaded trusted certificates. Parameter: trusted_certificates.delete
		Upload the server certificates. Parameter: server_certificates.url
		Delete all uploaded server certificates. Parameter: server_certificates.delete
		Configure the custom certificates. Parameter: phone_setting.reserve_certs_enable
Local	Web User Interface	Configure trusted certificates feature. Upload the trusted certificates. Navigate to: <a href="http://<phoneIPAddress>/servlet?p=trusted-cert&q=load">http://<phoneIPAddress>/servlet?p=trusted-cert&q=load
		Configure server certificates feature. Upload the server certificates. Navigate to: <a href="http://<phoneIPAddress>/servlet?p=server-cert&q=load">http://<phoneIPAddress>/servlet?p=server-cert&q=load

Details of Configuration Parameters:

Parameters	Permitted Values	Default
security.trust_certificates	0 or 1	0
<p>Description:</p> <p>Enables or disables the Skype for Business phone to only trust the server certificates in the Trusted Certificates list.</p> <p>0-Disabled 1-Enabled</p> <p>If it is set to 0 (Disabled), the Skype for Business phone will trust the server no matter whether the certificate sent by the server is valid or not.</p> <p>If it is set to 1 (Enabled), the Skype for Business phone will authenticate the server certificate based on the trusted certificates list. Only when the authentication succeeds, the Skype for Business phone will trust the server.</p> <p>Note: If you change this parameter, the Skype for Business phone will reboot to make the change take effect.</p> <p>Web User Interface:</p> <p>Security->Trusted Certificates->Only Accept Trusted Certificates</p> <p>Phone User Interface:</p> <p>None</p>		
security.ca_cert	0, 1 or 2	2
<p>Description:</p> <p>Configures the type of certificates in the Trusted Certificates list for the Skype for Business phone to authenticate for TLS connection.</p> <p>0-Default Certificates 1-Custom Certificates 2-All Certificates</p> <p>Note: If you change this parameter, the Skype for Business phone will reboot to make the change take effect.</p> <p>Web User Interface:</p> <p>Security->Trusted Certificates->CA Certificates</p> <p>Phone User Interface:</p> <p>None</p>		
security.cn_validation	0 or 1	0


Parameters	Permitted Values	Default
<p>Description:</p> <p>Enables or disables the Skype for Business phone to mandatorily validate the CommonName or SubjectAltName of the certificate sent by the server.</p> <p>0-Disabled 1-Enabled</p> <p>Note: If you change this parameter, the Skype for Business phone will reboot to make the change take effect.</p> <p>Web User Interface: Security->Trusted Certificates->Common Name Validation</p> <p>Phone User Interface: None</p>		
security.dev_cert	0 or 1	0
<p>Description:</p> <p>Configures the type of the device certificates for the Skype for Business phone to send for TLS authentication.</p> <p>0-Default Certificates 1-Custom Certificates</p> <p>Note: If you change this parameter, the Skype for Business phone will reboot to make the change take effect.</p> <p>Web User Interface: Security->Server Certificates->Device Certificates</p> <p>Phone User Interface: None</p>		
trusted_certificates.url	URL within 511 characters	Blank
<p>Description:</p> <p>Configures the access URL of the custom trusted certificate used to authenticate the connecting server.</p> <p>Example: trusted_certificates.url = http://192.168.1.20/tc.crt</p> <p>Note: The certificate you want to upload must be in *.pem, *.crt, *.cer or *.der format.</p> <p>Web User Interface: Security->Trusted Certificates->Load trusted certificates file</p>		

Parameters	Permitted Values	Default
Phone User Interface: None		
trusted_certificates.delete	http://localhost/all	Blank
Description: Deletes all uploaded trusted certificates. Example: trusted_certificates.delete = http://localhost/all Web User Interface: None Phone User Interface: None		
server_certificates.url	URL within 511 characters	Blank
Description: Configures the access URL of the certificate the Skype for Business phone sends for authentication. Example: server_certificates.url = http://192.168.1.20/ca.pem Note: The certificate you want to upload must be in *.pem or *.cer format. Web User Interface: Security->Server Certificates->Load server cer file Phone User Interface: None		
server_certificates.delete	http://localhost/all	Blank
Description: Deletes all uploaded server certificates. Example: server_certificates.delete = http://localhost/all Web User Interface: None Phone User Interface:		

Parameters	Permitted Values	Default
None		
phone_setting.reserve_certs_enable	0 or 1	0
<p>Description:</p> <p>Enables or disables the Skype for Business phone to reserve custom certificates after it is reset to factory defaults.</p> <p>0-Disabled 1-Enabled</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p> <p>None</p>		

To configure the trusted certificates via web user interface:

1. Click on **Security->Trusted Certificates**.
2. Select the desired values from the pull-down lists of **Only Accept Trusted Certificates**, **Common Name Validation** and **CA Certificates**.




3. Click **Confirm** to accept the change.

To upload a trusted certificate via web user interface:

1. Click on **Security->Trusted Certificates**.


- Click **Browse** to select the certificate (*.pem, *.crt, *.cer or *.der) from your local system.



- Click **Upload** to upload the certificate.

To configure the server certificates via web user interface:

- Click on **Security->Server Certificates**.
- Select the desired value from the pull-down list of **Device Certificates**.




- Click **Confirm** to accept the change.

To upload a server certificate via web user interface:

- Click on **Security->Server Certificates**.

- Click **Browse** to select the certificate (*.pem and *.cer) from your local system.



- Click **Upload** to upload the certificate.

A dialog box pops up to prompt "Success: The Server Certificate has been loaded! Rebooting, please wait...".

Encrypting Configuration Files

Encrypted configuration files can be downloaded from the provisioning server to protect against unauthorized access and tampering of sensitive information (e.g., login passwords, registration information). Yealink supplies a configuration encryption tool for encrypting configuration files. The encryption tool encrypts plaintext <y0000000000xx>.cfg and <MAC>.cfg files (one by one or in batch) using 16-character symmetric keys (the same or different keys for configuration files) and generates encrypted configuration files with the same file name as before. This tool also encrypts the plaintext 16-character symmetric keys using a fixed key, which is the same as the one built in the Skype for Business phone, and generates new files named as <xx_Security>.enc (xx indicates the name of the configuration file, for example, y000000000028_Security.enc for y000000000028.cfg file). This tool generates another new file named as Aeskey.txt to store the plaintext 16-character symmetric keys for each configuration file.

For a Microsoft Windows platform, you can use a Yealink-supplied encryption tool "Config_Encrypt_Tool.exe" to encrypt the <y0000000000xx>.cfg and <MAC>.cfg files respectively.

Note

Yealink also supplies a configuration encryption tool (yealinkencrypt) for Linux platform if required. For more information, refer to [Yealink Configuration Encryption Tool User Guide](#).

For security reasons, administrator should upload encrypted configuration files, <y0000000000xx_Security>.enc and/or <MAC_Security>.enc files to the root directory of the provisioning server. During auto provisioning, the Skype for Business phone requests to download <y0000000000xx>.cfg file first. If the downloaded configuration file is encrypted, the Skype for Business phone will request to download <y0000000000xx_Security>.enc file (if enabled) and decrypt it into the plaintext key (e.g., key2) using the built-in key (e.g., key1). Then the Skype for Business phone decrypts <y0000000000xx>.cfg file using key2. After decryption, the Skype for Business phone resolves configuration files and updates configuration settings onto the Skype for Business phone system.


The way the Skype for Business phone processes the <MAC>.cfg file is the same to that of the <y0000000000xx>.cfg file.

Procedure to Encrypt Configuration Files

To encrypt the <y0000000000xx>.cfg file:

1. Double click "Config_Encrypt_Tool.exe" to start the application tool.

The screenshot of the main page is shown as below:



When you start the application tool, a file folder named "Encrypted" is created automatically in the directory where the application tool is located.

2. Click **Browse** to locate configuration file(s) (e.g., y000000000028.cfg) from your local system in the **Select File(s)** field.

To select multiple configuration files, you can select the first file and then press and hold the **Ctrl** key and select the next files.

3. (Optional.) Click **Browse** to locate the target directory from your local system in the **Target Directory** field.

The tool uses the file folder "Encrypted" as the target directory by default.

4. (Optional.) Mark the desired radio box in the **AES Model** field.

If you mark the **Manual** radio box, you can enter an AES key in the **AES KEY** field or click **Re-Generate** to generate an AES key in the **AES KEY** field. The configuration file(s) will be encrypted using the AES key in the **AES KEY** field.

If you mark the **Auto Generate** radio box, the configuration file(s) will be encrypted using random AES key. The AES keys of configuration files are different.

Note


AES keys must be 16 characters and the supported characters contain: 0 ~ 9, A ~ Z, a ~ z and the following special characters are also supported: # \$ % * + , - . : = ? @ [] ^ _ { } ~.

5. Click **Encrypt** to encrypt the configuration file(s).



6. Click **OK**.

The target directory will be automatically opened. You can find the encrypted CFG file(s), encrypted key file(s) and an Aeskey.txt file storing plaintext AES key(s).



Procedure

AES keys can be configured using the configuration files.

Configuration File	<y0000000000xx>.cfg	Configure the decryption method. Parameter: auto_provision.aes_key_in_file
		Configure AES keys. Parameters: auto_provision.aes_key_16.com auto_provision.aes_key_16.mac
Local	Web User Interface	Configure AES keys. Navigate to: http://<phoneIPAddress>/servlet?p=s

		ettings-autop&q=load
	Phone User Interface	Configure AES keys.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
auto_provision.aes_key_in_file	0 or 1	0
<p>Description:</p> <p>Enables or disables the Skype for Business phone to decrypt configuration files using the encrypted AES keys.</p> <p>0-Disabled</p> <p>1-Enabled</p> <p>If it is set to 1 (Enabled), the Skype for Business phone will download <y0000000000xx_Security>.enc and <MAC_Security>.enc files during auto provisioning, and then decrypts these files into the plaintext keys (e.g., key2, key3) respectively using the phone built-in key (e.g., key1). The Skype for Business phone then decrypts the encrypted configuration files using corresponding key (e.g., key2, key3).</p> <p>If it is set to 0 (Disabled), the Skype for Business phone will decrypt the encrypted configuration files using plaintext AES keys configured on the Skype for Business phone.</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p> <p>None</p>		
auto_provision.aes_key_16.com	16 characters	Blank
<p>Description:</p> <p>Configures the plaintext AES key for decrypting the Common CFG file.</p> <p>The valid characters contain: 0 ~ 9, A ~ Z, a ~ z and the following special characters are also supported: # \$ % * + , - . : = ? @ [] ^ _ { } ~.</p> <p>Example:</p> <p>auto_provision.aes_key_16.com = 0123456789abcdef</p> <p>Web User Interface:</p> <p>Settings->Auto Provision->Common AES Key</p> <p>Phone User Interface:</p> <p>Menu->Advanced ->Set AES Key->Common</p>		

Parameters	Permitted Values	Default
auto_provision.aes_key_16.mac	16 characters	Blank
<p>Description:</p> <p>Configures the plaintext AES key for decrypting the MAC-Oriented CFG file.</p> <p>The valid characters contain: 0 ~ 9, A ~ Z, a ~ z and the following special characters are also supported: # \$ % * + , - . : = ? @ [] ^ _ { } ~.</p> <p>Example:</p> <p>auto_provision.aes_key_16.mac = 0123456789abmins</p> <p>Web User Interface:</p> <p>Settings->Auto Provision->MAC-Oriented AES Key</p> <p>Phone User Interface:</p> <p>Menu-> Advanced ->Set AES Key->MAC-Oriented</p>		

To configure AES keys via web user interface:

1. Click on **Settings->Auto Provision**.
2. Enter the values in the **Common AES Key** and **MAC-Oriented AES Key** fields.

AES keys must be 16 characters and the supported characters contain: 0-9, A-Z, a-z and the following special characters are also supported: # \$ % * + , - . : = ? @ [] ^ _ { } ~.

3. Click **Confirm** to accept the change.

To configure AES keys via phone user interface:

1. Press **Menu**->**Advanced** (default password: admin) ->**Set AES Key**.
2. Enter the values in the **Common** and **MAC-Oriented** fields.

AES keys must be 16 characters and the supported characters contain: 0-9, A-Z, a-z and the following special characters are also supported: # \$ % * + , - . : = ? @ [] ^ _ { } ~.

3. Press the **Save** soft key to accept the change.

Troubleshooting

This chapter provides an administrator with general information for troubleshooting some common problems that he (or she) may encounter while using Skype for Business phones.

Troubleshooting Methods

Skype for Business phones can provide feedback in a variety of forms such as log files, packets, status indicators and so on, which can help an administrator more easily find the system problem and fix it.

The following are helpful for better understanding and resolving the working status of the Skype for Business phone.

- [Memory Information](#)
- [Skype for Business Status](#)
- [Viewing Global Log Files](#)
- [Capturing Packets](#)
- [Enabling Watch Dog Feature](#)
- [Getting Information from Status Indicators](#)
- [Analyzing Configuration File](#)

Memory Information

You can understand phone process, memory occupancy and CPU utility via the web user interface.

Procedure


Memory information can be configured locally.

Local	Web User Interface	Configure memory information feature. Navigate to: <a href="http://<phoneIPAddress>/servlet?p=status-systeminfo&q=load">http://<phoneIPAddress>/servlet?p=status-systeminfo&q=load
--------------	--------------------	---

To configure memory information via web user interface:

1. Click on **Status->Memory Info**.

- Select the desired refresh interval from the pull-down list.
If **Disabled** is selected, the page will not be refreshed.



- Click **Refresh Now** to refresh the page and accept the change.

Skype for Business Status

You can troubleshoot phone issues by viewing the phone's SFB Status menu. The SFB Status menu includes a variety of information that can help you know the phone and account status.

Status	Display Name	Description
Phone Status	License Status	Indicates whether the Skype for Business feature license is imported to your phone. Values: <ul style="list-style-type: none"> Installed None
	Btoe Status	Indicates the BToE (Better Together over Ethernet) status. Value: <ul style="list-style-type: none"> Unpaired: Your phone and your Skype for Business client are not paired. Paired: Your phone and your Skype for Business client are paired but failing to sign in. Signed in: Your phone and your Skype for Business client are paired and sign in successfully.

Status	Display Name	Description
	CAP	Indicates whether the account you are using is a common area account. Value: <ul style="list-style-type: none"> TRUE False
Server Status	Update Server Url	Indicates the Updates Server URL.
	Edge Server	Indicates the Edge Server address.
	Voice Mail Uri	Indicates the Voice Mail URI of your account
	Email URI	Indicates the Email URI of your account
	ABS Url	Indicates the ABS (Address Book Server) URL
	LIS Url	Indicates the LIS URL for obtaining address information
	EWS Url	Indicates the URL of the Exchange server.
	STS URI	Indicates the URI of the Security token service.
	Focus Factory URI	Indicates the URI of the Focus Factory.
	Home Server URL	Indicates the URL of the Home server.
	MRAS URL	Indicates the URL of the Media Relay Authentication Service.
	CallPark Server URI	Indicates the CallPark Server URI.
Authentication info	User Type	Indicates the account type. Values: <ul style="list-style-type: none"> PIN: PIN authentication On-prem: On-premis account Managed: Online Managed Federated: Online federated
	SIP Authentication	Indicates the SIP authentication type. Values: <ul style="list-style-type: none"> NTLM TLS-DSK
	Sign-in Authentication Type	Indicates the Sign-in authentication type. Values: <ul style="list-style-type: none"> NTLM

Status	Display Name	Description
		<ul style="list-style-type: none"> • OAUTH • ORGID
	Exchange Authentication Type	<p>Indicates the Exchange authentication type.</p> <p>Values:</p> <ul style="list-style-type: none"> • NTLM • OAUTH • ORGID
UC Policy	Simultaneous ringing	Indicates whether the simultaneous ringing feature is enabled
	Call forwarding	Indicates whether the call forwarding feature is enabled
	Call Park	Indicates whether the call park feature is enabled
	Call transfer	Indicates whether the call transfer feature is enabled
	Delegation	Indicates whether the Delegation (assign a delegate or being assigned to be a delegate) feature is enabled.
	Teamcall	Indicates whether the Teamcall (your phone and your team-call group will ring simultaneously when you receive a call) feature is enabled
Data Number	Calendar Number	Indicates the total number of calendars downloaded from the server.
	Contact Number	Indicates the total number of your Skype for Business contacts.
	Calllog Number	Indicates the total number of call logs downloaded from the server.
	Visual Voicemail Number	Indicates the total number of voice mails downloaded from the server.

To view Skype for Business status via web user interface:

1. Click on **Status**->**SFB Status**.

The screenshot shows the Yealink T46G web interface. The top navigation bar includes tabs for Status, Account, Network, Features, Settings, Directory, and Security. The left sidebar shows a tree view with Status, SFB Status, and Memory Info. The main content area is titled 'SFB Status' and contains several sections:

- Phone Status:**
 - License Status: Installed
 - Btoe Status: Unpaired
 - CAP: False
- Server Status:**
 - Update Server Uri: https://xmpool.yealinkuc.com:443/RequestHandler/ucdevice.upxx
 - Edge Server: edgsrv.yealinkuc.com (IP: 192.168.6.60; Port: 3478)
 - Voice Mail Uri: sip:2227@yealinkuc.com;opaque=app:voicemail
 - Email URI: 2227@yealinkuc.com
 - ABS Uri: https://xmpool.yealinkuc.com:443/abs/handler
 - LIS Uri: https://xmpool.yealinkuc.com:443/locationinformation/liservice.svc
 - EWS Uri: https://exchange2013.yealinkuc.com/EWS/Exchange.asmx
 - STS URI: https://xmpool.yealinkuc.com:443/CertProv/CertProvisioningService.svc
 - Focus Factory URI: sip:2227@yealinkuc.com;gruu;opaque=app:conf:factory
 - Home Server URL: xmpool.yealinkuc.com (IP: 192.168.6.53; Port: 5061;transport = 2)
 - MRAS URL: sip:edgsrv.yealinkuc.com@yealinkuc.com;gruu;opaque=srv:MRAS_PB750R-r1Vj2XsnRaeVQAA
 - CallPark Server URI: sip:xmpool.yealinkuc.com@yealinkuc.com;gruu;opaque=srv:Microsoft.Rtc.Applications.Cps:gCBYhVrl20StPySmGJDAAA
- Authentication info:**
 - User Type: On-prem
 - SIP Authentication: TLS_DSK
 - Sign-in Authentication Type: NTLM
 - Exchange Authentication Type: None
- UC Policy:**
 - Simultaneous ringing: Enabled
 - Call forwarding: Enabled
 - Call Park: Enabled
 - Call transfer: Enabled
 - Delegation: Enabled
 - Teamcall: Enabled
- Data Number:**
 - Calendar Number: 33
 - Contact Number: 7
 - Callog Number: 199
 - Visual Voicemail Number: 49

On the right side, there is a 'NOTE' section with the text: 'status-lync-note' and a message: 'You can click here to get more guides.'

Viewing Global Log Files

If your Skype for Business phone encounters some problems, commonly the global log files are needed. You can export the global log files to a local system, a syslog server or the Skype for Business Server. You can also specify the severity level of the global log and module log to be reported. The default global log and module log are 3.

Log parameters are described below:

Module	Parameter	Description
Export System Log	Local	Export the global log files to a local system (e.g., PC).

Module	Parameter	Description
	Server	Export the global log files to a syslog server.
Global Log Level Setting	Global log Level	Specify the severity level of the global log.
	Max Log File Size	Specify the maximum size of the global log.
Module Log Level Settings	Register Log Level	Specify the severity level of the registration log.
	Subscribe Log Level	Specify the severity level of the subscription log.
	Call Log Level	Specify the severity level of the call log.
	Ice Log Level	Specify the severity level of the ICE log.
	Btoe Log Level	Specify the severity level of the BToE log.
	Exchange Log Level	Specify the severity level of the Exchange log.

Note

Global Log consists of Module logs. The severity level of the exported Module Log will not be greater than the Global Log Level. For example, if you set Global Log Level to 3 and set ICE log Level to 6, the exported ICE log Level will be 3.

In the configuration files, you can use the following parameters to configure global log settings:

- **syslog.log_level** -- Specify the global log level. The following lists the log level of events you can log:
 - 0:** system is unusable
 - 1:** action must be taken immediately
 - 2:** critical condition
 - 3:** error conditions
 - 4:** warning conditions
 - 5:** normal but significant condition
 - 6:** informational
- **syslog.mode** - Specify the global log to be exported to the syslog server or local system.
- **syslog.server** -- Specify the IP address or domain name of the syslog server to which the global log will be exported.

Configuring the Severity Level of the Log

Procedure

Severity level can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configures the detail level of global log to be exported. Parameters: syslog.log_level
Local	Web User Interface	Configure the severity level of the logs to be reported. Navigate to: <a href="http://<phoneIPAddress>/servlet?m=mod_data&p=settings-config&q=load">http://<phoneIPAddress>/servlet?m=mod_data&p=settings-config&q=load

Details of Configuration Parameters:

Parameters	Permitted Values	Default
syslog.log_level	Integer from 0 to 6	3
<p>Description: Configures the detail level of global log to be exported.</p> <p>0-system is unusable 1-action must be taken immediately 2-critical condition 3-error conditions 4-warning conditions 5-normal but significant condition 6-informational</p> <p>Note: If you change this parameter, the Skype for Business phone will reboot to make the change take effect.</p> <p>Web User Interface: Settings->Configuration->Global log Level</p> <p>Phone User Interface: None</p>		

To configure the severity level of the log via web user interface:

1. Click on **Settings->Configuration**.
2. Select the desired level from the pull-down list of corresponding log levels.

- Enter the desired maximum size of global log in the **Max Log File Size(1-3072KB)** field.

The screenshot shows the Yalink T466 web interface. The 'Settings' tab is selected, and the 'Configuration' sub-tab is active. A red box highlights the 'Global Log Level Setting' section. This section contains a dropdown for 'Global log Level' (set to 3) and a text input for 'Max Log File Size (1-3072KB)' (set to 3072). Below this is the 'Module Log Level Settings' section, which includes dropdowns for 'Register Log Level', 'Subscribe Log Level', 'Call Log Level', 'Ice Log Level', 'Btoe Log Level', and 'Exchange Log Level', all of which are set to 3. At the bottom of the form are buttons for 'Confirm', 'Reset Log Level to default', and 'Cancel'. A 'NOTE' box on the right states: 'Configuration: The configuration parameters for administrator. You can click here to get more guides.'

- Click **Confirm** to accept the change.

Resetting the Severity Level of the Log

High level may make some sensitive information accessible (e.g., password and dial number), we recommend that you reset the log level to 3 after providing the global log for troubleshooting purpose.

Procedure

Severity level can be reset locally.

Local	Web User Interface	Reset the severity level of all logs. Navigate to: <a href="http://<phoneIPAddress>/servlet?m=mod_data&p=settings-config&q=load">http://<phoneIPAddress>/servlet?m=mod_data&p=settings-config&q=load
--------------	--------------------	---

To reset severity level of all logs via web user interface:

- Click on **Settings->Configuration**.

2. Click **Reset Log Level To Default**.

All log level will reset to 3.

Exporting the Log File to the Local System

Procedure

Log setting can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the syslog mode. Parameters: syslog.mode
Local	Web User Interface	Configure the syslog mode. Navigate to: http://<phoneIPAddress>/servlet?m=mod_data&p=settings-config&q=load


Details of Configuration Parameters:

Parameters	Permitted Values	Default
syslog.mode	0 or 1	0
Description: Configures the Skype for Business phone to export log files to the local system or a syslog server.		

Parameters	Permitted Values	Default
0-Local 1-Server Note: If you change this parameter, the Skype for Business phone will reboot to make the change take effect. Web User Interface: Settings->Configuration->Export System Log Phone User Interface: None		

To export a log file to the local system via web user interface:

1. Click on **Settings->Configuration**.
2. Mark the **Local** radio box in the **Export System Log** field.
A dialog box pops up to prompt "Do you want to restart your machine". The configuration will take effect after a reboot.
3. Click **OK** to reboot the Yealink for Business phone.
4. Reproduce the issue (e.g., account registration).
5. Click **Export** to open file download window, and then save the file to your local system.



A log file "MAC address-sys.log" is successfully exported to your local system.

To view the log file on your local system:

1. Extract the combined log files to your local system.

- Open the folder you extracted to and identify the files you will view.

The following figure shows a portion of a <mac>.log (e.g., 0015659188F2.log) - an account registration:

```

Sep 24 00:53:35 sua [509]: DLG <6+info > [000] REGISTER sip:yealinkuc.com SIP/2.0'M
Sep 24 00:53:35 sua [509]: DLG <6+info > [000] Via: SIP/2.0/TLS 10.10.20.39:5061;port:branch=9bG4bE1839199345'M
Sep 24 00:53:35 sua [509]: DLG <6+info > [000] From: "2227" <sip:2227@yealinkuc.com>;tag=2513018937;msgid=00156574b16e00'M
Sep 24 00:53:35 sua [509]: DLG <6+info > [000] To: "2227" <sip:2227@yealinkuc.com>'M
Sep 24 00:53:35 sua [509]: DLG <6+info > [000] Call-ID: 0.2890835069'M
Sep 24 00:53:35 sua [509]: DLG <6+info > [000] CSeq: 5 REGISTER'M
Sep 24 00:53:35 sua [509]: DLG <6+info > [000] Contact: <sip:2227@10.10.20.39:5061;transport=TLS;line=b7052276b8e4e07>;sip.instance="urn:uuid:8c8c93be-e22a-539b-8ac9-c8
Sep 24 00:53:35 sua [509]: DLG <6+info > [000] Authorization: TLS-DSK realm="SIP Communications Service", response=DE3115A4F43E811D698865A49BBA1DEA218065, opaque="4696
Sep 24 00:53:35 sua [509]: DLG <6+info > [000] Allow: INVITE, INFO, PRACK, ACK, BYE, CANCEL, OPTIONS, NOTIFY, REGISTER, SUBSCRIBE, REFER, PUBLISH, UPDATE, MESSAGE'M
Sep 24 00:53:35 sua [509]: DLG <6+info > [000] Max-Forwards: 70'M
Sep 24 00:53:35 sua [509]: DLG <6+info > [000] User-Agent: UCCAPI/15.0.4707.1000 OC/15.0.4707.1000 (Skype for Business)'M
Sep 24 00:53:35 sua [509]: DLG <6+info > [000] X-keep-alives: UA:hop-hop=yes'M
Sep 24 00:53:35 sua [509]: DLG <6+info > [000] Allow-Events: talk,hold,conference,REFER,check-sym'M
Sep 24 00:53:35 sua [509]: DLG <6+info > [000] Supported: timer'M
Sep 24 00:53:35 sua [509]: DLG <6+info > [000] X-subnet: 10.10.20.0'M
Sep 24 00:53:35 sua [509]: DLG <6+info > [000] X-device-info: MAC=00:15:65:74:b1:6e; vendor=UCCAPI/15.0.4707.1000 OC/15.0.4707.1000 (Skype for Business); version=44.8.25
Sep 24 00:53:35 sua [509]: DLG <6+info > [000] X-event: registration'M
Sep 24 00:53:35 sua [509]: DLG <6+info > [000] Supported: path, gruu-10, adhoclist, marto-event-categories'M
Sep 24 00:53:35 sua [509]: DLG <6+info > [000] Supported: ma-user-services-state-notification'M
Sep 24 00:53:35 sua [509]: DLG <6+info > [000] Supported: ma-cluster-follower'M
Sep 24 00:53:35 sua [509]: DLG <6+info > [000] Supported: ma-bypass'M
Sep 24 00:53:35 sua [509]: DLG <6+info > [000] Expires: 0'M
Sep 24 00:53:35 sua [509]: DLG <6+info > [000] Content-Length: 0'M
Sep 24 00:53:35 sua [509]: DLG <6+info > [000] 'M
Sep 24 00:53:35 sua [509]: DLG <6+info > [000]
Sep 24 00:53:35 sua [509]: NET <5+notice> [000] =====>>> TLS socket 192.168.6.53:5061: send 1302 bytes
Sep 24 00:53:35 sua [509]: NET <5+notice> [000] free transaction resource 6_0_2890835069
Sep 24 00:53:35 sua [509]: FSM <6+info > [255] free nict resource
Sep 24 00:53:35 sua [509]: RET <5+notice> [255] <==== TLS socket 192.168.6.53:5061: read 934 bytes
Sep 24 00:53:35 sua [509]: SIP <6+info > [SIP] match line=2227 host:yealinkuc.com
Sep 24 00:53:35 sua [509]: DLG <5+notice> [000] Message rcv: (from src=192.168.6.53:5061 len=934)
Sep 24 00:53:35 sua [509]: DLG <6+info > [000]
Sep 24 00:53:35 sua [509]: DLG <6+info > [000] SIP/2.0 200 OK'M

```

Exporting the Log File to a Syslog Server

Procedure

Log setting can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the syslog mode.
		Parameters: syslog.mode
Local	Web User Interface	Configure the IP address or domain name of the syslog server where to export the log files.
		Parameters: syslog.server
Local	Web User Interface	Configure the syslog mode.
		Configure the IP address or domain name of the syslog server where to export the log files. Navigate to: <a href="http://<phoneIPAddress>/servlet?m=mod_data&p=settings-config&q=load">http://<phoneIPAddress>/servlet?m=mod_data&p=settings-config&q=load

Details of Configuration Parameters:

Parameters	Permitted Values	Default
syslog.mode	0 or 1	0


Parameters	Permitted Values	Default
<p>Description: Configures the Skype for Business phone to export log files to the local system or a syslog server.</p> <p>0-Local 1-Server</p> <p>Note: If you change this parameter, the Skype for Business phone will reboot to make the change take effect.</p> <p>Web User Interface: Settings->Configuration->Export System Log</p> <p>Phone User Interface: None</p>		
syslog.server	IP address or domain name	Blank
<p>Description: Configures the IP address or domain name of the syslog server when exporting log to the syslog server.</p> <p>Example: syslog.server = 192.168.1.100</p> <p>Note: It works only if the value of the parameter "syslog.mode" is set to 1 (Server). If you change this parameter, the Skype for Business phone will reboot to make the change take effect.</p> <p>Web User Interface: Settings->Configuration->Server Name</p> <p>Phone User Interface: None</p>		

To configure the Skype for Business phone to export the system log to a syslog server via web user interface:

1. Click on **Settings->Configuration**.
2. Mark the **Server** radio box in the **Export System Log** field.

- Enter the IP address or domain name of the syslog server in the **Server Name** field.

For example, the IP address of your syslog server is 192.168.1.100.



- Click **Confirm** to accept the change.

A dialog box pops up to prompt "Do you want to restart your machine?". The configuration will take effect after a reboot.

- Click **OK** to reboot the Skype for Business phone.

The system log will be exported successfully to the desired syslog server (192.168.1.100) after a reboot.

To view the log file on your syslog server:

You can view the system log file in the desired folder on the syslog server. The location of the folder may differ from the syslog server. For more information, refer to the network resources.

The following figure shows a portion of the system log:

```
Oct 19 09:00:45 sua [554]: DLG <+info > [000] Via: SIP/2.0/TLS 192.168.6.53:5061;branch=39d4b80CAB2A67.24044689A7E5A4DFD;branch=FALSE
Oct 19 09:00:45 sua [554]: DLG <+info > [000] Authentication-Info: TLS-DSR qop="auth", opaque="CC727F09", srand="FCC812C9", snum="11", rsauth="fa15b7ab469f09d47db1e97
Oct 19 09:00:45 sua [554]: DLG <+info > [000] Max-Forwards: 70
Oct 19 09:00:45 sua [554]: DLG <+info > [000] To: <esp1227@yealinkuc.com>;tag=468936962;epid=00156574b16e00
Oct 19 09:00:45 sua [554]: DLG <+info > [000] Content-Length: 6631
Oct 19 09:00:45 sua [554]: DLG <+info > [000] From: <esp1227@yealinkuc.com>;tag=9E3A0080
Oct 19 09:00:45 sua [554]: DLG <+info > [000] Call-ID: 0_4102263140
Oct 19 09:00:45 sua [554]: DLG <+info > [000] CSeq: 2 REINVITE
Oct 19 09:00:45 sua [554]: DLG <+info > [000] Require: eventlist
Oct 19 09:00:45 sua [554]: DLG <+info > [000] Content-Type: multipart/related; type="application/rlm+xml";start=resourceList; boundary="c79b776193274c4eab00314ff114c8d7
Oct 19 09:00:45 sua [554]: DLG <+info > [000] Event: presence
Oct 19 09:00:45 sua [554]: DLG <+info > [000]
Oct 19 09:00:45 sua [554]: FMK <+info > [-01] allocating transaction resource 14 0_4102263140
Oct 19 09:00:45 sua [554]: FMK <+info > [-01] allocating WIST context
Oct 19 09:00:45 sua [554]: FMK <+info > [000] missing a contact in invite!
Oct 19 09:00:45 sua [554]: SUA <+info > [000] ****eCore event:(0x0043)ECORE_SUBSCRIPTION_NOTIFY ****
Oct 19 09:00:45 sua [554]: SUB <+notice > [000] notify receive sub_type=12
Oct 19 09:00:45 sua [554]: APP <+info > [SIP] <IPC_ntfp:msg=0x0040211(262673), uparam=0, lparam=2, size=120
Oct 19 09:00:45 sua [554]: DLG <+info > [000] cb_niot_kill_transaction (id=14)
Oct 19 09:00:45 sua [554]: IDUI6 <+info > [000] Update_m_pionList: yVwedStatusList size(0).
Oct 19 09:00:45 sua [554]: IDUI6 <+info > [000] UpdateData :: UpdateData iRangeMask(4).
Oct 19 09:00:45 sua [554]: IDUI6 <+info > [000] Account is available[1], Lock is Loaded[1]
Oct 19 09:00:45 sua [554]: IDUI6 <+info > [000] UpdateSoftkey: eState(0).
Oct 19 09:00:45 sua [554]: IDUI6 <+info > [000] ChainModv:UpdateEnd() begin draw
Oct 19 09:00:45 sua [554]: IDUI6 <+info > [000] Show :: UpdateData(IRT_ALL).
Oct 19 09:00:45 sua [554]: IDUI6 <+info > [000] UpdateData :: UpdateData iRangeMask(255).
Oct 19 09:00:45 sua [554]: IDUI6 <+info > [000] Account is available[1], Lock is Loaded[1]
Oct 19 09:00:45 sua [554]: IDUI6 <+info > [000] UpdateSoftkey: eState(0).
Oct 19 09:00:45 sua [554]: IDUI6 <+info > [000] StateItem.m_nId(0). StateItem.m_strHint(), strNotifyText(), strNotifyIcon().
```

Exporting the Log File to the Skype for Business Server

You can upload system log to the Skype for Business Server via phone user interface only.

When performing a log upload, The HTTP POST sent from Skype for Business phone has following Headers:

UCDevice_Type: "with a value of "3PIP".

UCDevice_ID: containing a unique string identifying the phone.

The UCDevice_ID contains at minimum the following entries:

1. VendorName-phone manufacturer name
2. DeviceModel-phone model
3. Firmware version
4. MAC address

Sample:

UCDevice_ID: Yealink_SIP-T46G_28.8.1.65_00156574B1D6E\r\n
UCDevice_Type: 3PIP\r\n

To export a log file to the Skype for Business Server via phone user interface:

1. Press **Menu->Basic ->Log Upload**.

A dialog box pops up to prompt "Log Upload Success! ".

The log file can be found on the Skype for Business Server

at %ocsfilestore%\%domain%-WebServices-1\DeviceUpdateLogs\Cient.

Capturing Packets


You can capture packet in two ways: capturing the packets via web user interface or using the Ethernet software. You can analyze the packet captured for troubleshooting purpose.

Capturing the Packets via Web User Interface

To capture packets via web user interface:

1. Click on **Settings->Configuration**.
2. Click **Start** to start capturing signal traffic.
3. Reproduce the issue to get stack traces.
4. Click **Stop** to stop capturing.

5. Click **Export** to open the file download window, and then save the file to your local system.



Capture the Packets Using the Ethernet Software

Receiving data packets from the HUB

Connect the Internet port of the Skype for Business phone and the PC to the same HUB, and then use Sniffer, Ethereal or Wireshark software to capture the signal traffic.

Receiving data packets from PC port

Connect the Internet port of the Skype for Business phone to the Internet and the PC port of the Skype for Business phone to a PC. Before capturing the signal traffic, make sure the data packets can be received from the WAN (Internet) port to the PC (LAN) port.

Procedure

Span to PC Port can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure span to PC Port. Parameter: network.span_to_pc_port
Local	Web User Interface	Configure span to PC Port. Navigate to: http://<phoneIPAddress>/servlet?p=network-adv&q=load

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
network.span_to_pc_port	0 or 1	0
Description: Enables or disables the Skype for Business phone to span data packets received from the		

Parameter	Permitted Values	Default
<p>WAN (Internet) port to the PC (LAN) port.</p> <p>0-Disabled</p> <p>1-Enabled</p> <p>If it is set to 1 (Enabled), all data packets from WAN port can be received by PC port.</p> <p>Note: It works only if the value of the parameter "network.pc_port.enable" is set to 1 (Auto Negotiate). If you change this parameter, the Skype for Business phone will reboot to make the change take effect.</p> <p>Web User Interface:</p> <p>Network->Advanced->Span to PC->Span to PC Port</p> <p>Phone User Interface:</p> <p>None</p>		

To enable span to pc port via web user interface:

1. Click on **Network->Advanced**.
2. Select **Enabled** from the pull-down list of **Span to PC Port**.

The screenshot shows the Yealink T46G web interface. The top navigation bar includes 'Status', 'Account', 'Network', 'Features', 'Settings', 'Directory', and 'Security'. The 'Network' tab is selected, and the 'Advanced' sub-tab is active. On the left sidebar, 'Basic', 'PC Port', and 'Advanced' are listed. The main content area shows various network settings:

- LLDP**: Active (Enabled), Packet Interval (1~3600s) (60)
- CDP**: Active (Enabled), Packet Interval (1~3600s) (60)
- VLAN**: WAN Port (Active, Disabled), VID (1-4094) (1)
- 802.1x**: 802.1x Mode (Disabled), Identity, MDS Password, CA Certificates, Device Certificates
- Span to PC** (highlighted with a red box): Span to PC Port (Enabled)
- ICMPv6 Status**: Active (Enabled)

At the bottom, there are 'Confirm' and 'Cancel' buttons. A 'NOTE' section on the right explains VLAN and QoS.

3. Click **Confirm** to accept the change.
A dialog box pops up to prompt that settings will take effect after a reboot.
4. Click **OK** to reboot the Skype for Business phone.
Then you can use Sniffer, Ethereal or Wireshark software to capture the signal traffic.

Enabling Watch Dog Feature

The Skype for Business phone provides a troubleshooting feature called “Watch Dog”, which helps you monitor the Skype for Business phone status and provides the ability to get stack traces from the last time the Skype for Business phone failed. If Watch Dog feature is enabled, the Skype for Business phone will automatically reboot when it detects a fatal failure. This feature can be configured using the configuration files or via web user interface.

Procedure

Watch dog can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure watch dog feature. Parameter: watch_dog.enable
Local	Web User Interface	Configure watch dog feature. Navigate to: <a href="http://<phoneIPAddress>/servlet?p=settings-preference&q=load">http://<phoneIPAddress>/servlet?p=settings-preference&q=load


Details of the Configuration Parameter:

Parameter	Permitted Values	Default
watch_dog.enable	0 or 1	1
Description: Enables or disables Watch Dog feature. 0 -Disabled 1 -Enabled If it is set to 1 (Enabled), the Skype for Business phone will reboot automatically when the system is broken down. Web User Interface: Settings->Preference->Watch Dog Phone User Interface: None		

To configure watch dog feature via web user interface:

1. Click on **Settings->Preference**.

2. Select the desired value from the pull-down list of **Watch Dog**.



3. Click **Confirm** to accept the change.

Getting Information from Status Indicators

Status indicators may consist of the power LED, MESSAGE key LED, line key indicator, headset key indicator and the on-screen icon.

The following shows two examples of obtaining the Skype for Business phone information from status indicators on T46G Skype for Business phones:

- If a LINK failure of the Skype for Business phone is detected, a prompting message "Network unavailable" will appear on the LCD screen.
- If a voice mail is received, the power indicator LED slowly flashes red.
- If a Skype for Business favorite is during a call, the line key LED indicator is solid red.

Analyzing Configuration File

Wrong configurations may have an impact on your phone use. You can export BIN file to check the current configuration of the Skype for Business phone and troubleshoot if necessary. You can also import configuration files for a quick and easy configuration. The BIN file is an encrypted file. For more information on BIN file, contact your Yealink reseller.

Procedure

Configuration changes can be performed using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Specify the access URL for the custom configuration files. Parameter: configuration.url
Local	Web User Interface	Export or import the custom configuration files.


		Navigate to: <a href="http://<phoneIPAddress>/servlet?parameter=settings-config&q=load">http://<phoneIPAddress>/servlet?parameter=settings-config&q=load
--	--	--

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
configuration.url	URL within 511 characters	Blank
Description: Configures the access URL for the custom configuration files. Note: The file format of custom configuration file must be *.bin. Web User Interface: Settings->Configuration->Export or Import Configuration Phone User Interface: None		

To export configuration files via web user interface:


1. Click on **Settings->Configuration**.
2. In the **Export or Import Configuration** block, click **Export** to open the file download window, and then save the file to your local system.



To import a BIN configuration file via web user interface:

1. Click on **Settings->Configuration**.

2. In the **Export or Import Configuration** block, click **Browse** to locate a configuration file from your local system.



3. Click **Import** to import the configuration file.

Troubleshooting Solutions

This section describes solutions to common issues that may occur while using the Skype for Business phone. Upon encountering a scenario not listed in this section, contact your Yealink reseller for further support.

IP Address Issues

Why doesn't the Skype for Business phone get an IP address?

Do one of the following:

- Ensure that the Ethernet cable is plugged into the Internet port on the Skype for Business phone and the Ethernet cable is not loose.
- Ensure that the Ethernet cable is not damaged.
- Ensure that the IP address and related network parameters are set correctly.
- Ensure that your network switch or hub is operational.

How to solve the IP conflict problem?

Do one of the following:

- Reset another available IP address for the Skype for Business phone.
- Check network configuration via phone user interface at the path **Menu->Advanced->Network->WAN Port->IPv4** (or **IPv6**). If the Static IP is selected, select DHCP instead.

Time and Date Issues

Why doesn't the Skype for Business phone display time and date correctly?

Check if the Skype for Business phone is configured to obtain the time and date from the NTP server automatically. If your phone is unable to access the NTP server, configure the time and date manually.

Display Issues

Why is the LCD screen blank?

Do one of the following:

- Ensure that the Skype for Business phone is properly plugged into a functional AC outlet.
- Ensure that the Skype for Business phone is plugged into a socket controlled by a switch that is on.
- If the Skype for Business phone is plugged into a power strip, try plugging it directly into a wall outlet.
- If your phone is PoE powered, ensure that you are using a PoE-compliant switch or hub.

Directory Issues

What is the difference between a Skype for Business directory and a local directory?

The Skype for Business directory on your phone displays all Skype for Business contacts on your Skype for Business client. While a local directory is placed on the phone flash. When you sign into different Skype for Business phones using the same account, the phone will display the same Skype for Business contacts, while a local directory can only be used by a specific phone.

Audio Issues

How to increase or decrease the volume?

Press the volume key to increase or decrease the ringer volume when the Skype for Business phone is idle or ringing, or to adjust the volume of engaged audio device (handset, speakerphone or headset) when there is an active call in progress.

Why do I get poor sound quality during a call?

If you have poor sound quality/acoustics like intermittent voice, low volume, echo or other noises, the possible reasons could be:

- Users are seated too far out of recommended microphone range and sound faint, or are seated too close to sensitive microphones and cause echo.
- Intermittent voice is mainly caused by packet loss, due to network congestion, and jitter, due to message recombination of transmission or receiving equipment (e.g., timeout handling, retransmission mechanism, buffer under run).
- Noisy equipment, such as a PC or a fan, may cause voice interference. Turn off any noisy equipment.
- Line issues can also cause this problem; disconnect the old line and redial the call to ensure another line may provide better connection.

Why is there no sound when the other party picks up the call?

If the caller and receiver cannot hear anything - there is no sound at all when the other party picks up the call, the possible reason could be: the Skype for Business phone cannot send the real-time transport protocol (RTP) streams, in which audio data is transmitted, to the connected call.

Try to disable the 180 ring workaround feature. For more information, refer to [180 Ring Workaround](#) on page 215.

Why does the Skype for Business phone play the local ringback tone instead of media when placing a long distance number without plus 0?

Ensure that the 180 ring workaround feature is disabled. For more information, refer to [180 Ring Workaround](#) on page 215.

Bluetooth Issues

Why can't I connect the Bluetooth device with my phone all the time?

Try to delete the registration information of the Bluetooth device on both phone and Bluetooth device, and then pair and connect it again. Contact Yealink field application engineer and your Bluetooth device manufacturer for more information.

Why does the Bluetooth headset affect the phone's voice quality?

You may not experience the best voice quality if you use a Bluetooth headset while the 2.4 GHz band is enabled or while you are in an environment with many other Bluetooth devices. This possible loss in voice quality is due to inherent limitations with Bluetooth technology.

Firmware and Upgrading Issues


Why doesn't the Skype for Business phone upgrade firmware successfully?

Do one of the following:

- Ensure that the target firmware is not the same as the current firmware.
- Ensure that the target firmware is applicable to the Skype for Business phone model.
- Ensure that the current or the target firmware is not protected.
- Ensure that the power is on and the network is available in the process of upgrading.
- Ensure that the web browser is not closed or refreshed when upgrading firmware via web user interface.
- Ensure that the target firmware on the Skype for Business Server is available.

How can I verify the firmware generation and version of the Skype for Business phone?

Press the **OK** key when the Skype for Business phone is idle to check the firmware version. For example: 28.8.1.65.



	Item	Description
1	28	<p>A fixed number for each Skype for Business phone model.</p> <ul style="list-style-type: none"> • 35: T48G • 28: T46G • 29: T42G/T41P • 54: T40P
2	8	<p>Firmware generation.</p> <p>Note: The larger it is, the newer the firmware generation is.</p>
3	1	A fixed number.

	Item	Description
4	65	Firmware version. Note: With the same firmware generation, the larger it is, the newer the firmware version is.

Why doesn't the Skype for Business phone update the configuration?

Do one of the following:

- Ensure that the configuration is set correctly.
- Reboot the Skype for Business phone. Some configurations require a reboot to take effect.
- Ensure that the configuration is applicable to the Skype for Business phone model.
- The configuration may depend on support from a server.

Provisioning Issues

What is auto provisioning?

Auto provisioning refers to the update of Skype for Business phones, including update on configuration parameters, local phone book, firmware and so on. You can use auto provisioning on a single phone, but it makes more sense in mass deployment.

System Log Issues

Why cannot I export the system log to a syslog server?

Do one of the following:

- Ensure that the syslog server supports saving the syslog files exported from Skype for Business phone.
- Ensure that you have configured the syslog server address correctly via web user interface on your Skype for Business phone.
- Reboot the Skype for Business phone. The configurations require a reboot to take effect.

Resetting Issues

Generally, some common issues may occur while using the Skype for Business phone. You can reset your phone to factory configurations after you have tried all troubleshooting suggestions but do not solve the problem. Resetting the phone to factory configurations clears the flash parameters, removes log files, user data, and cached data, and resets the administrator password to admin. All custom settings will be overwritten after resetting.

You can reset the Skype for Business phone to default factory configurations. The default factory


configurations are the settings that reside on the Skype for Business phone after it has left the factory. For more information, refer to [How to reset the Skype for Business phone to default factory configurations?](#) on page 375.

How to reset the Skype for Business phone to default factory configurations?

To reset the Skype for Business phone via web user interface:

1. Click on **Settings**->**Upgrade**.
2. Click **Reset to Factory Setting** in the **Reset to Factory Setting** field.

The web user interface prompts the message "Do you want to reset to factory?".



3. Click **OK** to confirm the resetting.

The Skype for Business phone will be reset to factory successfully after startup.

Note

Reset of your phone may take a few minutes. Do not power off until the Skype for Business phone starts up successfully.

Rebooting Issues

How to reboot the Skype for Business phone via web/phone user interface?

You can reboot your Skype for Business phone via web/phone user interface.

To reboot the phone via phone user interface:

1. Press **Menu**->**Advanced** (default password: admin).
2. Press or to scroll to **Reboot**, and then press the **Enter** soft key.
3. Press **Reboot** soft key.


The LCD screen prompts "Reboot the phone?".

4. Press the **OK** soft key to reboot the phone.

The phone begins rebooting. Any reboot of the Skype for Business phone may take a few minutes.

To reboot the Skype for Business phone via web user interface:

1. Click on **Settings**->**Upgrade**.
2. Click **Reboot** to reboot the Skype for Business phone.



The phone begins rebooting. Any reboot of the Skype for Business phone may take a few minutes.

Protocols and Ports Issues

What communication protocols and ports do Yealink Skype for Business phones support?

Source Device	Source IP	Source Port	Destination Device	Destination IP	Destination Port (Listening port)	Protocol	Description of destination port
Skype for Business phones	IP address of Skype for Business phones	2~65535	Skype for Business phone or voice gateway	IP address of Skype for Business phone or voice gateway	Determined by destination device.	UDP	RTP protocol port, it is used to send or receive audio stream.
		1024~65535	SIP Server	IP address of SIP server	Determined by destination device.	UDP/TCP	SIP protocol port, it is used for signaling interaction with SIP server.
		1024~65535	File server	IP address of file server	Determined by destination device.	TCP	HTTP protocol port, it is used to download file.
		1024~65535	AA	IP address of AA	Determined by destination device.	TCP	HTTP protocol port, it is used for AA communication.
		68	DHCP Server	IP address of DHCP server	67	UDP	DHCP protocol port, it is used to obtain IP address from DHCP server.
		1024~65535	NTP Server	IP address of NTP server	123	UDP	NTP protocol port, it is used to synchronize time from NTP time server.
		1024~65535	Syslog Server	IP address of syslog server	514	UDP	Syslog protocol port, it is used for Skype for Business phones

Source Device	Source IP	Source Port	Destination Device	Destination IP	Destination Port (Listening port)	Protocol	Description of destination port
							to upload syslog information to syslog server.
PC	IP address of PC	Determined by the destination device.	Skype for Business phones	IP address of Skype for Business phones	1~65535	TCP	HTTP port (default value: 80)
					1~65535	TCP	HTTP port (default value: 443)
SIP Server	IP address of SIP Server				1024~65534	UDP/TCP	SIP protocol port, it is used for signaling interaction with SIP server.
Skype for Business phone of voice gateway	Skype for Business phone or voice gateway				2~65535	UDP	RTP protocol port, it is used by destination device to send or receive audio stream.

Password Issues

How to restore the administrator password?

Factory reset can restore the original password. All custom settings will be overwritten after reset.

Power and Startup Issues

What will happen if I connect both PoE cable and power adapter? Which has the higher priority?

Phones use the PoE preferentially.

Why does the phone have no power?

If no lights appear on the phone when it is powered up, do one of the following:

- Reboot your phone.
- Replace the power adapter.

Why is the LCD screen black?

If the power indicator LED is on, the keypad is usable but the LCD screen is black, please reboot your phone.


Other Issues

How do I find the basic information of the Skype for Business phone?

Press **Menu**-> **Status** when the Skype for Business phone is idle to check the basic information (e.g., IP address, MAC address and firmware version).

What is the difference between enabling and disabling the RFC 2543 Hold feature?

Capturing packets after you enable the RFC 2543 Hold feature. SDP media direction attributes (such as a=sendonly) per RFC 2543 is used in the INVITE message when placing a call on hold.



Filter: sip


No.	Time	Source	Destination	Protocol	Length	Info
54	2.018991	10.3.20.14	10.3.5.199	SIP/SDP	904	Request: INVITE sip:1021@10.3.5.199:5060, with session description
55	2.021424	10.3.5.199	10.3.20.14	SIP	314	Status: 100 Trying
56	2.034665	10.3.5.199	10.3.20.14	SIP	342	Status: 487 Request Cancelled
57	2.037965	10.3.20.14	10.3.5.199	SIP	305	Request: ACK sip:1010@10.3.5.199:5060
58	2.251601	10.3.5.199	10.3.20.14	SIP	547	Status: 180 Ringing
60	4.650231	10.3.5.199	10.3.20.14	SIP/SDP	746	Status: 200 OK, with session description
61	4.670808	10.3.20.14	10.3.20.4	SIP	405	Request: ACK sip:1021@10.3.20.4:5063
192	6.064543	10.3.5.199	10.3.20.14	SIP	342	Status: 487 Request Cancelled
193	6.067820	10.3.20.14	10.3.5.199	SIP	305	Request: ACK sip:1010@10.3.5.199:5060
263	6.733904	10.3.20.14	10.3.20.4	SIP/SDP	918	Request: INVITE sip:1021@10.3.20.4:5063, in-dialog, with session description
264	6.741332	10.3.20.4	10.3.20.14	SIP	336	Status: 100 Trying
267	6.790510	10.3.20.4	10.3.20.14	SIP/SDP	746	Status: 200 OK, with session description
269	6.803767	10.3.20.14	10.3.20.4	SIP	405	Request: ACK sip:1021@10.3.20.4:5063

Message Body

Session Description Protocol

- Session Description Protocol Version (v): 0
- Owner/Creator, Session Id (o): - 20037 20038 IN IP4 10.3.20.14
- Session Name (s): SDP data
- Connection Information (c): IN IP4 10.3.20.14
- Time Description, active time (t): 0 0
- Media Description, name and address (m): audio 11854 RTP/AVP 18 9 0 8 101
- Media Attribute (a): rtpmap:18 G729/8000
- Media Attribute (a): fmp:18 annexb=no
- Media Attribute (a): rtpmap:9 G722/8000
- Media Attribute (a): rtpmap:0 PCMU/8000
- Media Attribute (a): rtpmap:8 PCMA/8000
- Media Attribute (a): rtpmap:101 telephone-event/8000
- Media Attribute (a): fmp:101 0-15
- Media Attribute (a): pt=20
- Media Attribute (a): sendonly

Capturing packets after you disable the RFC 2543 Hold feature. SDP media connection address c=0.0.0.0 per RFC 3264 is used in the INVITE message when placing a call on hold.



Filter: sip

No.	Time	Source	Destination	Protocol	Length	Info
56	3.074205	10.3.20.14	10.3.5.199	SIP/SDP	904	Request: INVITE sip:1021@10.3.5.199:5060, with session description
57	3.076752	10.3.5.199	10.3.20.14	SIP	314	Status: 100 Trying
59	3.328526	10.3.5.199	10.3.20.14	SIP	546	Status: 180 Ringing
60	5.121648	10.3.5.199	10.3.20.14	SIP/SDP	745	Status: 200 OK, with session description
61	5.141647	10.3.20.14	10.3.20.4	SIP	403	Request: ACK sip:1021@10.3.20.4:5063
85	5.463380	10.3.20.9	224.0.0.175	SIP	544	Request: SUBSCRIBE sip:MAC001565770984@224.0.0.175
182	6.429073	10.3.20.14	10.3.20.4	SIP/SDP	914	Request: INVITE sip:1021@10.3.20.4:5063, in-dialog, with session description
184	6.439004	10.3.20.4	10.3.20.14	SIP	335	Status: 100 Trying
187	6.482474	10.3.20.4	10.3.20.14	SIP/SDP	743	Status: 200 OK, with session description
189	6.496305	10.3.20.14	10.3.20.4	SIP	404	Request: ACK sip:1021@10.3.20.4:5063

Message Header

Message Body

Session Description Protocol

- Session Description Protocol Version (v): 0
- Owner/Creator, Session Id (o): - 20038 20039 IN IP4 10.3.20.14
- Session Name (s): SDP data
- Connection Information (c): IN IP4 0.0.0.0
- Connection Network Type: IN
- Connection Address Type: IP4
- Connection Address: 0.0.0.0
- Time Description, active time (t): 0 0
- Media Description, name and address (m): audio 11856 RTP/AVP 18 9 0 8 101
- Media Attribute (a): rtpmap:18 G729/8000
- Media Attribute (a): fmp:18 annexb=no
- Media Attribute (a): rtpmap:9 G722/8000
- Media Attribute (a): rtpmap:0 PCMU/8000
- Media Attribute (a): rtpmap:8 PCMA/8000
- Media Attribute (a): rtpmap:101 telephone-event/8000
- Media Attribute (a): fmp:101 0-15
- Media Attribute (a): pt=20
- Media Attribute (a): inactive

For more information on RFC 2543 hold feature, refer to [Call Hold](#) on page 217. For more information on capturing packets, refer to [Capturing Packets](#) on page 364.

Appendix

Appendix A: Glossary

802.1x--an IEEE Standard for port-based Network Access Control (PNAC). It is a part of the IEEE 802.1 group of networking protocols. It provides an authentication mechanism to devices wishing to attach to a LAN or WLAN.

ACS (Auto Configuration server)--responsible for auto-configuration of the Central Processing Element (CPE).

Cryptographic Key--a piece of variable data that is fed as input into a cryptographic algorithm to perform operations such as encryption and decryption, or signing and verification.

DHCP (Dynamic Host Configuration Protocol)--built on a client-server model, where designated DHCP server hosts allocate network addresses and deliver configuration parameters to dynamically configured hosts.

DHCP Option--can be configured for specific values and enabled for assignment and distribution to DHCP clients based on server, scope, class or client-specific levels.

DNS (Domain Name System)--a hierarchical distributed naming system for PC, services, or any resource connected to the Internet or a private network.

EAP-MD5 (Extensible Authentication Protocol-Message Digest Algorithm 5)--only provides authentication of the EAP peer to the EAP server but not mutual authentication.

EAP-TLS (Extensible Authentication Protocol-Transport Layer Security) --provides for mutual authentication, integrity-protected cipher suite negotiation between two endpoints.

PEAP-MSCHAPv2 (Protected Extensible Authentication Protocol-Microsoft Challenge Handshake Authentication Protocol version 2) --provides for mutual authentication, but does not require a client certificate on the Skype for Business phone.

FAC (Feature Access Code)--special patterns of characters that are dialed from a phone keypad to invoke particular features.

HTTP (Hypertext Transfer Protocol)--used to request and transmit data on the World Wide Web.

HTTPS (Hypertext Transfer Protocol over Secure Socket Layer)--a widely-used communications protocol for secure communication over a network.

IEEE (Institute of Electrical and Electronics Engineers)--a non-profit professional association headquartered in New York City that is dedicated to advancing technological innovation and excellence.

LAN (Local Area Network)--used to interconnects network devices in a limited area such as a

home, school, PC laboratory, or office building.

MIB (Management Information Base)--a virtual database used for managing the entities in a communications network.

OID (Object Identifier)--assigned to an individual object within a MIB.

ROM (Read-only Memory)--a class of storage medium used in PC and other electronic devices.

RTP (Real-time Transport Protocol)--provides end-to-end service for real-time data.

TCP (Transmission Control Protocol)--a transport layer protocol used by applications that require guaranteed delivery.

UDP (User Datagram Protocol)--a protocol offers non-guaranteed datagram delivery.

URI (Uniform Resource Identifier)--a compact sequence of characters that identifies an abstract or physical resource.

URL (Uniform Resource Locator)--specifies the address of an Internet resource.

VLAN (Virtual LAN)-- a group of hosts with a common set of requirements, which communicate as if they were attached to the same broadcast domain, regardless of their physical location.

VoIP (Voice over Internet Protocol)--a family of technologies used for the delivery of voice communications and multimedia sessions over IP networks.

WLAN (Wireless Local Area Network)--a type of local area network that uses high-frequency radio waves rather than wires to communicate between nodes.

XML-RPC (Remote Procedure Call Protocol)--which uses XML to encode its calls and HTTP as a transport mechanism.

Appendix B: Time Zones

Time Zone	Time Zone Name
-11	Samoa
-10	United States-Hawaii-Aleutian, United States-Alaska-Aleutian
-9:30	French Polynesia
-9	United States-Alaska Time
-8	Canada(Vancouver,Whitehorse), Mexico(Tijuana,Mexicali), United States-Pacific Time
-7	Canada(Edmonton,Calgary), Mexico(Mazatlan,Chihuahua), United States-MST no DST, United States-Mountain Time
-6	Canada-Manitoba(Winnipeg), Chile(Easter Islands), Mexico(Mexico City,Acapulco), United States-Central Time
-5	Bahamas(Nassau), Canada(Montreal,Ottawa,Quebec), Cuba(Havana), United States-Eastern Time
-4:30	Venezuela(Caracas)

Time Zone	Time Zone Name
-4	Canada(Halifax,Saint John), Chile(Santiago), Paraguay(Asuncion), United Kingdom-Bermuda(Bermuda), United Kingdom(Falkland Islands), Trinidad&Tobago
-3:30	Canada-New Foundland(St.Johns)
-3	Argentina(Buenos Aires), Brazil(DST), Brazil(no DST), Denmark-Greenland(Nuuk)
-2:30	Newfoundland and Labrador
-2	Brazil(no DST)
-1	Portugal(Azores)
0	Denmark-Faroe Islands(Torshavn), GMT, Greenland, Ireland(Dublin), Morocco, Portugal(Lisboa,Porto,Funchal), Spain-Canary Islands(Las Palmas), United Kingdom(London)
+1	Albania(Tirane), Austria(Vienna), Belgium(Brussels), Caicos, Chad, Croatia(Zagreb), Czech Republic(Prague), Denmark(Kopenhagen), France(Paris), Germany(Berlin), Hungary(Budapest), Italy(Rome), Luxembourg(Luxembourg), Macedonia(Skopje), Namibia(Windhoek), Netherlands(Amsterdam), Spain(Madrid)
+2	Estonia(Tallinn), Finland(Helsinki), Gaza Strip(Gaza), Greece(Athens), Israel(Tel Aviv), Jordan(Amman), Latvia(Riga), Lebanon(Beirut), Moldova(Kishinev), Romania(Bucharest), Russia(Kaliningrad), Syria(Damascus), Turkey(Ankara), Ukraine(Kyiv, Odessa)
+3	East Africa Time, Iraq(Baghdad), Russia(Moscow)
+3:30	Iran(Teheran)
+4	Armenia(Yerevan), Azerbaijan(Baku), Georgia(Tbilisi), Abu Dhabi, Kazakhstan(Aktau), Russia(Samara)
+4:30	Afghanistan(Kabul)
+5	Kazakhstan(Aqtobe), Kyrgyzstan(Bishkek), Pakistan(Islamabad), Russia(Chelyabinsk)
+5:30	India(Calcutta)
+5:45	Nepal(Katmandu)
+6	Kazakhstan(Astana, Almaty), Russia(Novosibirsk,Omsk)
+6:30	Myanmar(Naypyitaw)
+7	Russia(Krasnoyarsk), Thailand(Bangkok)
+8	Australia(Perth), China(Beijing), Russia(Irkutsk, Ulan-Ude), Singapore(Singapore)
+8:45	Eucla
+9	Japan(Tokyo), Korea(Seoul), Russia(Yakutsk,Chita)
+9:30	Australia(Adelaide), Australia(Darwin)
+10	Australia(Brisbane), Australia(Hobart), Australia(Sydney,Melbourne,Canberra), Russia(Vladivostok)
+10:30	Australia(Lord Howe Islands)

Time Zone	Time Zone Name
+11	New Caledonia(Noumea), Russia(Srednekolymsk Time)
+11:30	Norfolk Island
+12	New Zealand(Wellington,Auckland), Russia(Kamchatka Time)
+12:45	New Zealand(Chatham Islands)
+13	Tonga(Nukualofa)
+13:30	Chatham Islands
+14	Kiribati

Appendix C: Trusted Certificates

Yealink Skype for Business phones trust the following CAs by default:

- DigiCert High Assurance EV Root CA
- Deutsche Telekom AG Root CA-2
- Equifax Secure Certificate Authority
- Equifax Secure eBusiness CA-1
- Equifax Secure Global eBusiness CA-1
- GeoTrust Global CA
- GeoTrust Global CA2
- GeoTrust Primary CA
- GeoTrust Primary CA G2 ECC
- GeoTrust Universal CA
- GeoTrust Universal CA2
- Thawte Personal Freemail CA
- Thawte Premium Server CA
- Thawte Primary Root CA - G1 (EV)
- Thawte Primary Root CA - G2 (ECC)
- Thawte Primary Root CA - G3 (SHA256)
- Thawte Server CA
- VeriSign Class 1 Public Primary Certification Authority
- VeriSign Class 1 Public Primary Certification Authority - G2
- VeriSign Class 1 Public Primary Certification Authority - G3
- VeriSign Class 2 Public Primary Certification Authority - G2
- VeriSign Class 2 Public Primary Certification Authority - G3
- VeriSign Class 3 Public Primary Certification Authority
- VeriSign Class 3 Public Primary Certification Authority - G2
- VeriSign Class 3 Public Primary Certification Authority - G3
- VeriSign Class 3 Public Primary Certification Authority - G4

- VeriSign Class 3 Public Primary Certification Authority - G5
- VeriSign Class 4 Public Primary Certification Authority - G2
- VeriSign Class 4 Public Primary Certification Authority - G3
- VeriSign Universal Root Certification Authority
- Microsoft_IT_SSL_SHA2.cer
- CNNIC_Root.cer
- baltimoreCyberTrust.cer
- UserTrust.cer
- AAA Certificate Services.cer
- DigiCert Assured ID Root CA.cer
- Entrust.net Certification Authority (2048).cer
- Entrust Root Certification Authority
- Entrust.net Secure Server Certification Authority
- GTE CyberTrust Global Root.cer
- Starfield Class 2 Certification Authority.cer
- AddTrust External CA Root
- Go Daddy Class 2 Certification Authority
- StartCom Certification Authority
- DST Root CA X3
- ISRG Root X1 (intermediate certificates: Let's Encrypt Authority X1 and Let's Encrypt Authority X2 are signed by the root certificate ISRG Root X1.)
- Baltimore CyberTrust Root
- AddTrust External CA Root
- Starfield Root Certificate Authority - G2

Note

Yealink endeavors to maintain a built-in list of most common used CA Certificates. Due to memory constraints, we cannot ensure a complete set of certificates. If you are using a certificate from a commercial Certificate Authority not in the list above, you can send a request to your local distributor. At this point, you can upload your particular CA certificate into your phone. For more information on uploading custom CA certificate, refer to [Transport Layer Security](#) on page 335.

Appendix D: SIP (Session Initiation Protocol)

This section describes how Yealink Skype for Business phones comply with the IETF definition of SIP as described in [RFC 3261](#).

This section contains compliance information in the following:

- [RFC and Internet Draft Support](#)
- [SIP Request](#)

- [SIP Header](#)
- [SIP Responses](#)
- [SIP Session Description Protocol \(SDP\) Usage](#)

RFC and Internet Draft Support

The following RFC's and Internet drafts are supported:

- RFC 1321—The MD5 Message-Digest Algorithm
- RFC 1889—RTP Media control
- RFC 2112—Multipart MIME
- RFC 2327—SDP: Session Description Protocol
- RFC 2387—The MIME Multipart/Related Content-type
- RFC 2543—SIP: Session Initiation Protocol
- RFC 2617—Http Authentication: Basic and Digest access authentication
- RFC 2782—A DNS RR for specifying the location of services (DNS SRV)
- RFC 2806—URLs for Telephone Calls
- RFC 2833—RTP Payload for DTMF Digits, Telephony Tones and Telephony Signals
- RFC 2915—The Naming Authority Pointer (NAPTR) DNS Resource Record
- RFC 2976—The SIP INFO Method
- RFC 3087—Control of Service Context using SIP Request-URI
- RFC 3261—SIP: Session Initiation Protocol (replacement for RFC 2543)
- RFC 3262—Reliability of Provisional Responses in the Session Initiation Protocol (SIP)
- RFC 3263—Session Initiation Protocol (SIP): Locating SIP Servers
- RFC 3264—An Offer/Answer Model with the Session Description Protocol (SDP)
- RFC 3265—Session Initiation Protocol (SIP) - Specific Event Notification
- RFC 3266—Support for IPv6 in Session Description Protocol (SDP)
- RFC 3310—HTTP Digest Authentication Using Authentication and Key Agreement (AKA)
- RFC 3311—The Session Initiation Protocol (SIP) UPDATE Method
- RFC 3312—Integration of Resource Management and SIP
- RFC 3313—Private SIP Extensions for Media Authorization
- RFC 3323—A Privacy Mechanism for the Session Initiation Protocol (SIP)
- RFC 3324—Requirements for Network Asserted Identity
- RFC 3325—SIP Asserted Identity
- RFC 3326—The Reason Header Field for the Session Initiation Protocol (SIP)
- RFC 3361—DHCP-for-IPv4 Option for SIP Servers
- RFC 3372—SIP for Telephones (SIP-T): Context and Architectures
- RFC 3398—ISUP to SIP Mapping

- RFC 3420–Internet Media Type message/sipfrag
- RFC 3428–Session Initiation Protocol (SIP) Extension for Instant Messaging
- RFC 3455–Private Header (P-Header) Extensions to the SIP for the 3GPP
- RFC 3486–Compressing the Session Initiation Protocol (SIP)
- RFC 3489–STUN - Simple Traversal of User Datagram Protocol (UDP) Through Network Address Translators (NATs)
- RFC 3515–The Session Initiation Protocol (SIP) Refer Method
- RFC 3550–RTP: Transport Protocol for Real-Time Applications
- RFC 3555–MIME Type Registration of RTP Payload Formats
- RFC 3581–An Extension to the SIP for Symmetric Response Routing
- RFC 3608–SIP Extension Header Field for Service Route Discovery During Registration
- RFC 3611–RTP Control Protocol Extended Reports (RTCP XR)
- RFC 3665–Session Initiation Protocol (SIP) Basic Call Flow Examples
- RFC 3666–SIP Public Switched Telephone Network (PSTN) Call Flows.
- RFC 3680–SIP Event Package for Registrations
- RFC 3702–Authentication, Authorization, and Accounting Requirements for the SIP
- RFC 3711–The Secure Real-time Transport Protocol (SRTP)
- RFC 3725–Best Current Practices for Third Party Call Control (3pcc) in the Session Initiation Protocol (SIP)
- RFC 3842–A Message Summary and Message Waiting Indication Event Package for the Session Initiation Protocol (SIP)
- RFC 3856–A Presence Event Package for Session Initiation Protocol (SIP)
- RFC 3863–Presence Information Data Format
- RFC 3890–A Transport Independent Bandwidth Modifier for the SDP
- RFC 3891–The Session Initiation Protocol (SIP) “Replaces” Header
- RFC 3892–The Session Initiation Protocol (SIP) Referred-By Mechanism
- RFC 3959–The Early Session Disposition Type for SIP
- RFC 3960–Early Media and Ringing Tone Generation in SIP
- RFC 3966–The tel URI for telephone number
- RFC 3968–IANA Registry for SIP Header Field
- RFC 3969–IANA Registry for SIP URI
- RFC 4028–Session Timers in the Session Initiation Protocol (SIP)
- RFC 4083–3GPP Release 5 Requirements on SIP
- RFC 4235–An INVITE-Initiated Dialog Event Package for the Session Initiation Protocol (SIP)
- RFC 4244–An Extension to the SIP for Request History Information
- RFC 4317–Session Description Protocol (SDP) Offer/Answer Examples
- RFC 4353–A Framework for Conferencing with the SIP

- RFC 4458–SIP URIs for Applications such as Voicemail and Interactive Voice Response (IVR)
- RFC 4475–Session Initiation Protocol (SIP) Torture
- RFC 4485–Guidelines for Authors of Extensions to the SIP
- RFC 4504–SIP Telephony Device Requirements and Configuration
- RFC 4566–SDP: Session Description Protocol.
- RFC 4568–Session Description Protocol (SDP) Security Descriptions for Media Streams
- RFC 4575–A SIP Event Package for Conference State
- RFC 4579–SIP Call Control - Conferencing for User Agents
- RFC 4583–Session Description Protocol (SDP) Format for Binary Floor Control Protocol (BFCP) Streams
- RFC 4662–A SIP Event Notification Extension for Resource Lists
- RFC 4730–Event Package for KPML
- RFC 5009–P-Early-Media Header
- RFC 5079–Rejecting Anonymous Requests in SIP
- RFC 5359–Session Initiation Protocol Service Examples
- RFC 5589–Session Initiation Protocol (SIP) Call Control - Transfer
- RFC 5630–The Use of the SIPS URI Scheme in SIP
- RFC 5806–Diversion Indication in SIP
- RFC 5954–Essential Correction for IPv6 ABNF and URI Comparison in RFC 3261
- RFC 6026–Correct Transaction Handling for 2xx Responses to SIP INVITE Requests
- RFC 6141–Re-INVITE and Target-Refresh Request Handling in SIP
- draft-ietf-sip-cc-transfer-05.txt–SIP Call Control - Transfer
- draft-anil-sipping-bla-02.txt–Implementing Bridged Line Appearances (BLA) Using Session Initiation Protocol (SIP)
- draft-anil-sipping-bla-03.txt–Implementing Bridged Line Appearances (BLA) Using Session Initiation Protocol (SIP)
- draft-ietf-sip-privacy-00.txt–SIP Extensions for Caller Identity and Privacy, November
- draft-ietf-sip-privacy-04.txt–SIP Extensions for Network-Asserted Caller Identity and Privacy within Trusted Networks
- draft-levy -sip-diversion-08.txt–Diversion Indication in SIP
- draft-ietf-sipping-cc-conferencing-03.txt–SIP Call Control - Conferencing for User Agents
- draft-ietf-sipping-cc-conferencing-05.txt–Connection Reuse in the Session Initiation Protocol (SIP)
- draft-ietf-sipping-rtcp-summary-02.txt–Session Initiation Protocol Package for Voice Quality Reporting Event
- draft-ietf-sip-connect-reuse-06.txt–Connection Reuse in the Session Initiation Protocol (SIP)

- draft-ietf-bliss-shared-appearances-15.txt–Shared Appearances of a Session Initiation Protocol (SIP) Address of Record (AOR)

To find the applicable Request for Comments (RFC) document, go to <http://www.ietf.org/rfc.html> and enter the RFC number.

SIP Request

The following SIP request messages are supported:

Method	Supported	Notes
REGISTER	Yes	
INVITE	Yes	Yealink Skype for Business phones support mid-call changes such as placing a call on hold as signaled by a new INVITE that contains an existing Call-ID.
ACK	Yes	
CANCEL	Yes	
BYE	Yes	
OPTIONS	Yes	
SUBSCRIBE	Yes	
NOTIFY	Yes	
REFER	Yes	
PRACK	Yes	
INFO	Yes	
MESSAGE	Yes	
UPDATE	Yes	
PUBLISH	Yes	

SIP Header

The following SIP request headers are supported:

Note

In the following table, a “Yes” in the Supported column means the header is sent and properly parsed.

Method	Supported	Notes
Accept	Yes	
Alert-Info	Yes	
Allow	Yes	
Allow-Events	Yes	
Authorization	Yes	
Call-ID	Yes	
Call-Info	Yes	
Contact	Yes	
Content-Length	Yes	
Content-Type	Yes	
CSeq	Yes	
Diversion	Yes	
History-Info	Yes	
Event	Yes	
Expires	Yes	
From	Yes	
Max-Forwards	Yes	
Min-SE	Yes	
P-Asserted-Identity	Yes	
P-Preferred-Identity	Yes	
Proxy-Authenticate	Yes	
Proxy-Authorization	Yes	
RAck	Yes	
Record-Route	Yes	

Method	Supported	Notes
Refer-To	Yes	
Referred-By	Yes	
Remote-Party-ID	Yes	
Replaces	Yes	
Require	Yes	
Route	Yes	
RSeq	Yes	
Session-Expires	Yes	
Subscription-State	Yes	
Supported	Yes	
To	Yes	
User-Agent	Yes	
Via	Yes	

SIP Responses

The following SIP responses are supported:

Note

In the following table, a “Yes” in the Supported column means the header is sent and properly parsed. The phone may not actually generate the response.

1xx Response—Information Responses

1xx Response	Supported	Notes
100 Trying	Yes	
180 Ringing	Yes	
181 Call Is Being Forwarded	Yes	
183 Session Progress	Yes	

2xx Response—Successful Responses

2xx Response	Supported	Notes
200 OK	Yes	
202 Accepted	Yes	In REFER transfer.

3xx Response—Redirection Responses

3xx Response	Supported	Notes
300 Multiple Choices	Yes	
301 Moved Permanently	Yes	
302 Moved Temporarily	Yes	

4xx Response—Request Failure Responses

4xx Response	Supported	Notes
400 Bad Request	Yes	
401 Unauthorized	Yes	
402 Payment Required	Yes	
403 Forbidden	Yes	
404 Not Found	Yes	
405 Method Not Allowed	Yes	
406 Not Acceptable	No	
407 Proxy Authentication Required	Yes	
408 Request Timeout	Yes	
409 Conflict	No	
410 Gone	No	
411 Length Required	No	
413 Request Entity Too Large	No	
414 Request-URI Too Long	Yes	
415 Unsupported Media Type	Yes	
416 Unsupported URI Scheme	No	
420 Bad Extension	No	

4xx Response	Supported	Notes
421 Extension Required	No	
423 Interval Too Brief	Yes	
480 Temporarily Unavailable	Yes	
481 Call/Transaction Does Not Exist	Yes	
482 Loop Detected	Yes	
483 Too Many Hops	No	
484 Address Incomplete	Yes	
485 Ambiguous	No	
486 Busy Here	Yes	
487 Request Terminated	Yes	
488 Not Acceptable Here	Yes	
491 Request Pending	No	
493 Undecipherable	No	

5xx Response—Server Failure Responses

5xx Response	Supported	Notes
500 Internal Server Error	Yes	
501 Not Implemented	Yes	
502 Bad Gateway	No	
503 Service Unavailable	No	
504 Gateway Timeout	No	
505 Version Not Supported	No	

6xx Response—Global Responses

6xx Response	Supported	Notes
600 Busy Everywhere	Yes	
603 Decline	Yes	
604 Does Not Exist Anywhere	No	
606 Not Acceptable	No	

SIP Session Description Protocol (SDP) Usage

SDP Headers	Supported
v–Protocol version	Yes
o–Owner/creator and session identifier	Yes
a–Media attribute	Yes
c–Connection information	Yes
m–Media name and transport address	Yes
s–Session name	Yes
t–Active time	Yes

Appendix E: SIP Call Flows

SIP uses six request methods:

INVITE–Indicates a user is being invited to participate in a call session.

ACK–Confirms that the client has received a final response to an INVITE request.

BYE–Terminates a call and can be sent by either the caller or the callee.

CANCEL–Cancels any pending searches but does not terminate a call that has already been accepted.

OPTIONS–Queries the capabilities of servers.

REGISTER–Registers the address listed in the To header field with a SIP server.

The following types of responses are used by SIP and generated by the Skype for Business phone or the SIP server:

SIP 1xx–Informational Responses

SIP 2xx–Successful Responses

SIP 3xx–Redirection Responses

SIP 4xx–Client Failure Responses

SIP 5xx–Server Failure Responses


SIP 6xx–Global Failure Responses

Successful Call Setup and Disconnect

The following figure illustrates the scenario of a successful call. In this scenario, the two end users are User A and User B. User A and User B are located at Yealink Skype for Business phones.

The call flow scenario is as follows:

1. User A calls User B.
2. User B answers the call.
3. User B hangs up.



Step	Action	Description
F1	INVITE—User A to Proxy Server	<p>User A sends a SIP INVITE message to a proxy server. The INVITE request is an invitation to User B to participate in a call session.</p> <p>In the INVITE request:</p> <ul style="list-style-type: none"> The IP address of User B is inserted in the Request-URI field. User A is identified as the call session initiator in the From field.

Step	Action	Description
		<ul style="list-style-type: none"> A unique numeric identifier is assigned to the call and is inserted in the Call-ID field. The transaction number within a single call leg is identified in the CSeq field. The media capability User A is ready to receive is specified. The port on which User B is prepared to receive the RTP data is specified.
F2	INVITE–Proxy Server to User B	The proxy server maps the SIP URI in the To field to User B. The proxy server sends the INVITE message to User B.
F3	100 Trying–User B to Proxy Server	User B sends a SIP 100 Trying response to the proxy server. The 100 Trying response indicates that the INVITE request has been received by User B.
F4	100 Trying–Proxy Server to User A	The proxy server forwards the SIP 100 Trying to User A to indicate that the INVITE request has been received by User B.
F5	180 Ringing–User B to Proxy Server	User B sends a SIP 180 Ringing response to the proxy server. The 180 Ringing response indicates that the User B is being alerted.
F6	180 Ringing–Proxy Server to User A	The proxy server forwards the 180 Ringing response to User A. User A hears the ring-back tone indicating that User B is being alerted.
F7	200 OK– User B to Proxy Server	User B sends a SIP 200 OK response to the proxy server. The 200 OK response notifies User A that the connection has been made.
F8	200OK–Proxy Server to User A	The proxy server forwards the 200 OK message to User A. The 200 OK response notifies User A that the connection has been made.
F9	ACK–User A to Proxy Server	User A sends a SIP ACK to the proxy server. The ACK confirms that User A has received the 200 OK response. The call session is now active.

Step	Action	Description
F10	ACK—Proxy Server to User B	The proxy server sends the SIP ACK to User B. The ACK confirms that the proxy server has received the 200 OK response. The call session is now active.
F11	BYE—User B to Proxy Server	User B terminates the call session by sending a SIP BYE request to the proxy server. The BYE request indicates that User B wants to release the call.
F12	BYE—Proxy Server to User A	The proxy server forwards the SIP BYE request to User A to notify that User B wants to release the call.
F13	200 OK—User A to Proxy Server	User A sends a SIP 200 OK response to the proxy server. The 200 OK response indicates that User A has received the BYE request. The call session is now terminated.
F14	200 OK—Proxy Server to User B	The proxy server forwards the SIP 200 OK response to User B to indicate that User A has received the BYE request. The call session is now terminated.


Unsuccessful Call Setup—Called User is Busy

The following figure illustrates the scenario of an unsuccessful call caused by the called user's being busy. In this scenario, the two end users are User A and User B. User A and User B are located at Yealink Skype for Business phones.

The call flow scenario is as follows:

1. User A calls User B.
2. User B is busy on the Skype for Business phone and unable or unwilling to take another call.

The call cannot be set up successfully.



Step	Action	Description
F1	INVITE—User A to Proxy Server	<p>User A sends the INVITE message to a proxy server. The INVITE request is an invitation to User B to participate in a call session.</p> <p>In the INVITE request:</p> <ul style="list-style-type: none"> The IP address of User B is inserted in the Request-URI field. User A is identified as the call session initiator in the From field. A unique numeric identifier is assigned to the call and is inserted in the Call-ID field. The transaction number within a single call leg is identified in the CSeq field. The media capability User A is ready to receive is specified. The port on which User B is prepared to receive the RTP data is specified.
F2	INVITE—Proxy Server to User B	The proxy server maps the SIP URI in the To field to User B. Proxy server forwards the INVITE message to User B.
F3	100 Trying—User B to Proxy Server	User B sends a SIP 100 Trying response to the proxy server. The 100 Trying response

Step	Action	Description
		indicates that the INVITE request has been received by User B.
F4	100 Trying—Proxy Server to User A	The proxy server forwards the SIP 100 Trying to User A to indicate that the INVITE request has already been received.
F5	486 Busy Here—User B to Proxy Server	User B sends a SIP 486 Busy Here response to the proxy server. The 486 Busy Here response is a client error response indicating that User B is successfully connected but User B is busy on the Skype for Business phone and unable or unwilling to take the call.
F6	486 Busy Here—Proxy Server to User A	The proxy server forwards the 486 Busy Here response to notify User A that User B is busy.
F7	ACK—User A to Proxy Server	User A sends a SIP ACK to the proxy server. The SIP ACK message indicates that User A has received the 486 Busy Here message.
F8	ACK—Proxy Server to User B	The proxy server forwards the SIP ACK to User B to indicate that the 486 Busy Here message has already been received.


Unsuccessful Call Setup—Called User Does Not Answer

The following figure illustrates the scenario of an unsuccessful call caused by the called user's no answering. In this scenario, the two end users are User A and User B. User A and User B are located at Yealink Skype for Business phones.

The call flow scenario is as follows:

1. User A calls User B.
2. User B does not answer the call.
3. User A hangs up.

The call cannot be set up successfully.



Step	Action	Description
F1	INVITE—User A to Proxy Server	<p>User A sends an INVITE message to a proxy server. The INVITE request is an invitation to User B to participate in a call session.</p> <p>In the INVITE request:</p> <ul style="list-style-type: none"> The IP address of User B is inserted in the Request-URI field. User A is identified as the call session initiator in the From field. A unique numeric identifier is assigned to the call and is inserted in the Call-ID field. The transaction number within a single call leg is identified in the CSeq field. The media capability User A is ready to receive is specified. The port on which User B is prepared to receive the RTP data is specified.
F2	INVITE—Proxy Server to User B	<p>The proxy server maps the SIP URI in the To field to User B. Proxy server forwards the INVITE message to User B.</p>


Step	Action	Description
F3	180 Ringing–User B to Proxy Server	User B sends a SIP 180 Ringing response to the proxy server. The 180 Ringing response indicates that the user is being alerted.
F4	180 Ringing–Proxy Server to User A	The proxy server forwards the 180 Ringing response to User A. User A hears the ring-back tone indicating that User B is being alerted.
F5	CANCEL–User A to Proxy Server	User A sends a SIP CANCEL request to the proxy server after not receiving an appropriate response within the time allocated in the INVITE request. The SIP CANCEL request indicates that User A wants to disconnect the call.
F6	CANCEL–Proxy Server to User B	The proxy server forwards the SIP CANCEL request to notify User B that User A wants to disconnect the call.
F7	200 OK–User B to Proxy Server	User B sends a SIP 200 OK response to the proxy server. The SIP 200 OK response indicates that User B has received the CANCEL request.
F8	200 OK–Proxy Server to User A	The proxy server forwards the SIP 200 OK response to notify User A that the CANCEL request has been processed successfully.

Successful Call Setup and Call Hold

The following figure illustrates a successful call setup and call hold. In this scenario, the two end users are User A and User B. User A and User B are located at Yealink Skype for Business phones.

The call flow scenario is as follows:

1. User A calls User B.
2. User B answers the call.

3. User A places User B on hold.

Step	Action	Description
F1	INVITE–User A to Proxy Server	<p>User A sends an INVITE message to a proxy server. The INVITE request is an invitation to User B to participate in a call session.</p> <p>In the INVITE request:</p> <ul style="list-style-type: none"> • The IP address of User B is inserted in the Request-URI field. • User A is identified as the call session initiator in the From field. • A unique numeric identifier is assigned to the call and is inserted in the Call-ID field. • The transaction number within a single call leg is identified in the CSeq field. • The media capability User A is ready to receive is specified. • The port on which User B is prepared to receive the RTP data is specified.
F2	INVITE–Proxy Server to User B	The proxy server maps the SIP URI in the To field to User B. The proxy server sends the INVITE message to User B.
F3	180 Ringing–User B to Proxy Server	User B sends a SIP 180 Ringing response to the proxy server. The 180 Ringing response indicates that the user is being alerted.
F4	180 Ringing–Proxy Server to User A	The proxy server forwards the 180 Ringing response to User A. User A hears the ring-back tone indicating that User B is being alerted.
F5	200 OK–User B to Proxy Server	User B sends a SIP 200 OK response to the proxy server. The 200 OK response notifies the proxy server that the connection has been made.
F6	200 OK–Proxy Server to User A	The proxy server forwards the 200 OK message to User A. The 200 OK response notifies User A that the connection has been made.
F7	ACK–User A to Proxy Server	User A sends a SIP ACK to the proxy server. The ACK confirms that User A has received the 200 OK response. The call session is

Step	Action	Description
		now active.
F8	ACK–Proxy Server to User B	The proxy server sends the SIP ACK to User B. The ACK confirms that the proxy server has received the 200 OK response. The call session is now active.
F9	INVITE–User A to Proxy Server	User A sends a mid-call INVITE request to the proxy server with new SDP session parameters, which are used to place the call on hold.
F10	INVITE–Proxy Server to User B	The proxy server forwards the mid-call INVITE message to User B.
F11	200 OK–User B to Proxy Server	User B sends a SIP 200 OK response to the proxy server. The 200 OK response notifies User A that the INVITE is successfully processed.
F12	200 OK–Proxy Server to User A	The proxy server forwards the 200 OK response to User A. The 200 OK response notifies User B is successfully placed on hold.
F13	ACK–User A to Proxy Server	User A sends an ACK message to the proxy server. The ACK confirms that User A has received the 200 OK response. The call session is now temporarily inactive. No RTP packets are being sent.
F14	ACK–Proxy Server to User B	The proxy server sends the ACK message to User B. The ACK confirms that the proxy server has received the 200 OK response.


Successful Call Setup and Call Waiting

The following figure illustrates a successful call between Yealink Skype for Business phones in which two parties are in a call, one of the participants receives and answers an incoming call from a third party. In this call flow scenario, the end users are User A, User B, and User C. They are all using Yealink Skype for Business phones, which are connected via an IP network.

The call flow scenario is as follows:

1. User A calls User B.
2. User B answers the call.
3. User C calls User B.

4. User B accepts the call from User C.



Step	Action	Description
F1	INVITE—User A to Proxy Server	User A sends an INVITE message to a proxy server. The INVITE request is an invitation to User B to participate in a call session. In the INVITE request:

Step	Action	Description
		<ul style="list-style-type: none"> The IP address of User B is inserted in the Request-URI field. User A is identified as the call session initiator in the From field. A unique numeric identifier is assigned to the call and is inserted in the Call-ID field. The transaction number within a single call leg is identified in the CSeq field. The media capability User A is ready to receive is specified. The port on which User B is prepared to receive the RTP data is specified.
F2	INVITE–Proxy Server to User B	The proxy server maps the SIP URI in the To field to User B. The proxy server sends the INVITE message to User B.
F3	180 Ringing–User B to Proxy Server	User B sends a SIP 180 Ringing response to the proxy server. The 180 Ringing response indicates that the user is being alerted.
F4	180 Ringing–Proxy Server to User A	The proxy server forwards the 180 Ringing response to User A. User A hears the ring-back tone indicating that User B is being alerted.
F5	200 OK–User B to Proxy Server	User B sends a SIP 200 OK response to the proxy server. The 200 OK response notifies proxy server that the connection has been made.
F6	200 OK–Proxy Server to User A	The proxy server forwards the 200 OK message to User A. The 200 OK response notifies User A that the connection has been made.
F7	ACK–User A to Proxy Server	User A sends a SIP ACK to the proxy server. The ACK confirms that User A has received the 200 OK response. The call session is now active.
F8	ACK–Proxy Server to User B	The proxy server sends the SIP ACK to User B. The ACK confirms that the proxy server has received the 200 OK response. The call

Step	Action	Description
		session is now active.
F9	INVITE–User C to Proxy Server	<p>User C sends a SIP INVITE message to the proxy server. The INVITE request is an invitation to User A to participate in a call session.</p> <p>In the INVITE request:</p> <ul style="list-style-type: none"> • The IP address of User A is inserted in the Request-URI field. • User C is identified as the call session initiator in the From field. • A unique numeric identifier is assigned to the call and is inserted in the Call-ID field. • The transaction number within a single call leg is identified in the CSeq field. • The media capability User C is ready to receive is specified. • The port on which User A is prepared to receive the RTP data is specified.
F10	INVITE–Proxy Server to User A	The proxy server maps the SIP URI in the To field to User A. The proxy server sends the INVITE message to User A.
F11	180 Ringing–User A to Proxy Server	User A sends a SIP 180 Ringing response to the proxy server. The 180 Ringing response indicates that the user is being alerted.
F12	180 Ringing–Proxy Server to User C	The proxy server forwards the 180 Ringing response to User C. User C hears the ring-back tone indicating that User A is being alerted.
F13	INVITE–User A to Proxy Server	User A sends a mid-call INVITE request to the proxy server with new SDP session parameters, which are used to place the call on hold.
F14	INVITE–Proxy Server to User B	The proxy server forwards the mid-call INVITE message to User B.
F15	200 OK–User B to Proxy Server	User B sends a 200 OK to the proxy server. The 200 OK response indicates that the

Step	Action	Description
		INVITE was successfully processed.
F16	200 OK–Proxy Server to User A	The proxy server forwards the 200 OK response to User A. The 200 OK response notifies User B is successfully placed on hold.
F17	ACK–User A to Proxy Server	User A sends an ACK message to the proxy server. The ACK confirms that User A has received the 200 OK response. The call session is now temporarily inactive. No RTP packets are being sent.
F18	ACK–Proxy Server to User B	The proxy server sends the ACK message to User B. The ACK confirms that the proxy server has received the 200 OK response.
F19	200 OK–User A to Proxy Server	User A sends a 200 OK response to the proxy server. The 200 OK response notifies that the connection has been made.
F20	200 OK–Proxy Server User C	The proxy server forwards the 200 OK message to User C.
F21	ACK–User C to Proxy Server	User C sends a SIP ACK to the proxy server. The ACK confirms that User C has received the 200 OK response. The call session is now active.
F22	ACK–Proxy Server to User A	The proxy server forwards the SIP ACK to User A to confirm that User C has received the 200 OK response.

Call Transfer without Consultation

The following figure illustrates a successful call between Yealink Skype for Business phones in which two parties are in a call and then one of the parties transfers the call to a third party without consultation. This is called a blind transfer. In this call flow scenario, the end users are User A, User B, and User C. They are all using Yealink Skype for Business phones, which are connected via an IP network.

The call flow scenario is as follows:

1. User A calls User B.
2. User B answers the call.
3. User B transfers the call to User C.
4. User C answers the call.

Step	Action	Description
F1	INVITE–User A to Proxy Server	<p>User A sends an INVITE message to the proxy server. The INVITE request is an invitation to User B to participate in a call session.</p> <p>In the INVITE request:</p> <ul style="list-style-type: none"> • The IP address of User B is inserted in the Request-URI field. • User A is identified as the call session initiator in the From field. • A unique numeric identifier is assigned to the call and is inserted in the Call-ID field. • The transaction number within a single call leg is identified in the CSeq field. • The media capability User A is ready to receive is specified. • The port on which User B is prepared to receive the RTP data is specified.
F2	INVITE–Proxy Server to User B	The proxy server maps the SIP URI in the To field to User B. The proxy server sends the INVITE message to User B.
F3	180 Ringing–User B to Proxy server	User B sends a SIP 180 Ringing response to the proxy server. The 180 Ringing response indicates that the user is being alerted.
F4	180 Ringing–Proxy Server to User A	The proxy server forwards the 180 Ringing response to User A. User A hears the ring-back tone indicating that User B is being alerted.
F5	200 OK–User B to Proxy Server	User B sends a SIP 200 OK response to the proxy server. The 200 OK response notifies User A that the connection has been made.
F6	200 OK–Proxy Server to User A	The proxy server forwards the 200 OK message to User A. The 200 OK response notifies User A that the connection has been made.
F7	ACK–User A to Proxy Server	User A sends a SIP ACK to the proxy server, The ACK confirms that User A has received the 200 OK response. The call session is

Step	Action	Description
		now active.
F8	ACK–Proxy Server to User B	The proxy server sends the SIP ACK to User B. The ACK confirms that the proxy server has received the 200 OK response. The call session is now active.
F9	REFER–User B to Proxy Server	User B sends a REFER message to the proxy server. User B performs a blind transfer of User A to User C.
F10	202 Accepted–Proxy Server to User B	The proxy server sends a SIP 202 Accept response to User B. The 202 Accepted response notifies User B that the proxy server has received the REFER message.
F11	REFER–Proxy Server to User A	The proxy server forwards the REFER message to User A.
F12	202 Accepted–User A to Proxy Server	User A sends a SIP 202 Accept response to the proxy server. The 202 Accepted response indicates that User A accepts the transfer.
F13	BYE–User B to Proxy Server	User B terminates the call session by sending a SIP BYE request to the proxy server. The BYE request indicates that User B wants to release the call.
F14	BYE–Proxy Server to User A	The proxy server forwards the BYE request to User A.
F15	200OK–User A to Proxy Server	User A sends a SIP 200 OK response to the proxy server. The 200 OK response confirms that User A has received the BYE request.
F16	200OK–Proxy Server to User B	The proxy server forwards the SIP 200 OK response to User B.
F17	INVITE–User A to Proxy Server	User A sends a SIP INVITE request to the proxy server. In the INVITE request, a unique Call-ID is generated and the Contact-URI field indicates that User A requests the call.
F18	INVITE–Proxy Server to User C	The proxy server maps the SIP URI in the To field to User C.
F19	180 Ringing–User C to Proxy	User C sends a SIP 180 Ringing response to the proxy server. The 180 Ringing response

Step	Action	Description
	Server	indicates that the user is being alerted.
F20	180 Ringing–Proxy Server to User A	The proxy server forwards the 180 Ringing response to User A. User A hears the ring-back tone indicating that User C is being alerted
F21	200OK–User C to Proxy Server	User C sends a SIP 200 OK response to the proxy server. The 200 OK response notifies the proxy server that the connection has been made.
F22	200OK–Proxy Server to User A	The proxy server forwards the SIP 200 OK response to User A.
F23	ACK– User A to Proxy Server	User A sends a SIP ACK to the proxy server. The ACK confirms that User A has received the 200 OK response. The call session is now active.
F24	ACK–Proxy Server to User C	The proxy server forwards the ACK message to User C. The ACK confirms that User A has received the 200 OK response. The call session is now active.


Call Transfer with Consultation

The following figure illustrates a successful call between Yealink Skype for Business phones in which two parties are in a call and then one of the parties transfers the call to the third party with consultation. This is called consultative transfer. In this call flow scenario, the end users are User A, User B, and User C. They are all using Yealink Skype for Business phones, which are connected via an IP network.

The call flow scenario is as follows:

1. User A calls User B.
2. User B answers the call.
3. User A calls User C.
4. User C answers the call.
5. User A transfers the call to User C.

Call is established between User B and User C.



Step	Action	Description
F1	INVITE–User A to Proxy Server	<p>User A sends an INVITE message to a proxy server. The INVITE request is an invitation to User B to participate in a call session.</p> <p>In the INVITE request:</p> <ul style="list-style-type: none"> • The IP address of User B is inserted in the Request-URI field. • User A is identified as the call session initiator in the From field. • A unique numeric identifier is assigned to the call and is inserted in the Call-ID field. • The transaction number within a single call leg is identified in the CSeq field. • The media capability User A is ready to receive is specified. • The port on which User B is prepared to receive the RTP data is specified.
F2	INVITE–Proxy Server to User B	The proxy server maps the SIP URI in the To field to User B. The proxy server sends the INVITE message to User B.
F3	180 Ringing–User B to Proxy Server	User B sends a SIP 180 Ringing response to the proxy server. The 180 Ringing response indicates that the user is being alerted.
F4	180 Ringing–Proxy Server to User A	The proxy server forwards the 180 Ringing response to User A. User A hears the ring-back tone indicating that User B is being alerted.
F5	200 OK–User B to Proxy Server	User B sends a SIP 200 OK response to the proxy server. The 200 OK response notifies User A that the connection has been made.
F6	200 OK–Proxy Server to User A	The proxy server forwards the 200 OK message to User A. The 200 OK response notifies User A that the connection has been made.
F7	ACK–User A to Proxy Server	User A sends a SIP ACK to the proxy server, The ACK confirms that User A has received the 200 OK response. The call session is

Step	Action	Description
		now active.
F8	ACK–Proxy Server to User B	The proxy server sends the SIP ACK to User B. The ACK confirms that the proxy server has received the 200 OK response. The call session is now active.
F9	INVITE–User A to Proxy Server	User A sends a mid-call INVITE request to the proxy server with new SDP session parameters, which are used to place the call on hold.
F10	INVITE–Proxy Server to User B	The proxy server forwards the mid-call INVITE message to User B.
F11	200 OK–User B to Proxy Server	User B sends a SIP 200 OK response to the proxy server. The 200 OK response notifies User A that the INVITE was successfully processed.
F12	200 OK–Proxy Server to User A	The proxy server forwards the 200 OK response to User A. The 200 OK response notifies User B is successfully placed on hold.
F13	ACK–User A to Proxy Server	User A sends an ACK message to the proxy server. The ACK confirms that User A has received the 200 OK response. The call session is now temporarily inactive. No RTP packets are being sent.
F14	ACK–Proxy Server to User B	The proxy server sends the ACK message to User B. The ACK confirms that the proxy server has received the 200 OK response.
F15	INVITE–User A to Proxy Server	User A sends a SIP INVITE request to the proxy server. In the INVITE request, a unique Call-ID is generated and the Contact-URI field indicates that User A requests the call.
F16	INVITE–Proxy Server to User C	The proxy server maps the SIP URI in the To field to User C. The proxy server sends the INVITE request to User C.
F17	180 Ringing–User C to Proxy Server	User C sends a SIP 180 Ringing response to the proxy server. The 180 Ringing response indicates that the user is being alerted.

Step	Action	Description
F18	180 Ringing–Proxy Server to User A	The proxy server forwards the 180 Ringing response to User A. User A hears the ring-back tone indicating that User C is being alerted.
F19	200OK–User C to Proxy Server	User C sends a SIP 200 OK response to the proxy server. The 200 OK response notifies User A that the connection has been made.
F20	200OK–Proxy Server to User A	The proxy server forwards the SIP 200 OK response to User A. The 200 OK response notifies User A that the connection has been made.
F21	ACK– User A to Proxy Server	User A sends a SIP ACK to the proxy server. The ACK confirms that User A has received the 200 OK response. The call session is now active.
F22	ACK–Proxy Server to User C	The proxy server forwards the ACK message to User C. The ACK confirms that the proxy server has received the 200 OK response. The call session is now active.
F23	REFER–User A to Proxy Server	User A sends a REFER message to the proxy server. User A performs a transfer of User B to User C.
F24	202 Accepted–Proxy Server to User A	The proxy server sends a SIP 202 Accepted response to User A. The 202 Accepted response notifies User A that the proxy server has received the REFER message.
F25	REFER–Proxy Server to User B	The proxy server forwards the REFER message to User B.
F26	202 Accepted–User B to Proxy Server	User B sends a SIP 202 Accept response to the proxy server. The 202 Accepted response indicates that User B accepts the transfer.
F27	BYE–User A to Proxy Server	User A terminates the call session by sending a SIP BYE request to the proxy server. The BYE request indicates that User A wants to release the call.
F28	BYE–Proxy Server to User B	The proxy server forwards the BYE request to User B.

Step	Action	Description
F29	200OK–User B to Proxy Server	User B sends a SIP 200 OK response to the proxy server. The 200 OK response notifies User A that User B has received the BYE request.
F30	200OK–Proxy Server to User A	The proxy server forwards the SIP 200 OK response to User A.


Call Conference

The following figure illustrates successful 3-way calling between Yealink Skype for Business phones in which User A mixes two RTP channels and therefore establishes a conference between User B and User C. In this call flow scenario, the end users are User A, User B, and User C. They are all using Yealink Skype for Business phones, which are connected via an IP network.

The call flow scenario is as follows:

1. User A calls User B.
2. User B answers the call.
3. User A places User B on hold.
4. User A calls User C.
5. User C answers the call.

6. User A mixes the RTP channels and establishes a conference between User B and User C.



Step	Action	Description
F1	INVITE—User A to Proxy Server	<p>User A sends the INVITE message to a proxy server. The INVITE request is an invitation to User B to participate in a call session.</p> <p>In the INVITE request:</p> <ul style="list-style-type: none"> The IP address of User B is inserted in the Request-URI field. User A is identified as the call session initiator in the From field.

Step	Action	Description
		<ul style="list-style-type: none"> A unique numeric identifier is assigned to the call and is inserted in the Call-ID field. The transaction number within a single call leg is identified in the CSeq field. The media capability User A is ready to receive is specified. The port on which User B is prepared to receive the RTP data is specified.
F2	INVITE–Proxy Server to User B	The proxy server maps the SIP URI in the To field to User B. Proxy server forwards the INVITE message to User B.
F3	180 Ringing–User B to Proxy Server	User B sends a SIP 180 Ringing response to the proxy server. The 180 Ringing response indicates that the user is being alerted.
F4	180 Ringing–Proxy Server to User A	The proxy server forwards the 180 Ringing response to User A. User A hears the ring-back tone indicating that User B is being alerted.
F5	200 OK–User B to Proxy Server	User B sends a SIP 200 OK response to the proxy server. The 200 OK response notifies User A that the connection has been made.
F6	200 OK–Proxy Server to User A	The proxy server forwards the 200 OK message to User A. The 200 OK response notifies User A that the connection has been made.
F7	ACK–User A to Proxy Server	User A sends a SIP ACK to the proxy server. The ACK confirms that User A has received the 200 OK response. The call session is now active.
F8	ACK–Proxy Server to User B	The proxy server sends the SIP ACK to User B. The ACK confirms that the proxy server has received the 200 OK response. The call session is now active.
F9	INVITE–User A to Proxy Server	User A sends a mid-call INVITE request to the proxy server with new SDP session parameters, which are used to place the call on hold.

Step	Action	Description
F10	INVITE–Proxy Server to User B	The proxy server forwards the mid-call INVITE message to User B.
F11	200 OK–User B to Proxy Server	User B sends a SIP 200 OK response to the proxy server. The 200 OK response notifies User A that the INVITE is successfully processed.
F12	200 OK–Proxy Server to User A	The proxy server forwards the 200 OK response to User A. The 200 OK response notifies User A that User B is successfully placed on hold.
F13	ACK–User A to Proxy Server	User A sends the ACK message to the proxy server. The ACK confirms that User A has received the 200 OK response. The call session is now temporarily inactive. No RTP packets are being sent.
F14	ACK–Proxy Server to User B	The proxy server sends the ACK message to User B. The ACK confirms that the proxy server has received the 200 OK response.
F15	INVITE–User A to Proxy Server	User A sends a SIP INVITE request to the proxy server. In the INVITE request, a unique Call-ID is generated and the Contact-URI field indicates that User A requests the call.
F16	INVITE–Proxy Server to User C	The proxy server maps the SIP URI in the To field to User C. The proxy server sends the SIP INVITE request to User C.
F17	180 Ringing–User C to Proxy Server	User C sends a SIP 180 Ringing response to the proxy server. The 180 Ringing response indicates that the user is being alerted.
F18	180 Ringing–Proxy Server to User A	The proxy server forwards the 180 Ringing response to User A. User A hears the ring-back tone indicating that User C is being alerted.
F19	200OK–User C to Proxy Server	User C sends a SIP 200 OK response to the proxy server. The 200 OK response notifies User A that the connection has been made.
F20	200OK–Proxy Server to User A	The proxy server forwards the SIP 200 OK response to User A. The 200 OK response

Step	Action	Description
		notifies User A that the connection has been made.
F21	ACK– User A to Proxy Server	User A sends a SIP ACK to the proxy server. The ACK confirms that User A has received the 200 OK response. The call session is now active.
F22	ACK–Proxy Server to User C	The proxy server sends the ACK message to User C. The ACK confirms that the proxy server has received the 200 OK response.

Index

Numeric

180 Ring Workaround [215](#)
802.1X Authentication [81](#)

A

About This Guide [v](#)
Account Lock [333](#)
Acoustic Echo Cancellation [309](#)
Action URI [268](#)
Allow Mute [233](#)
Allow Trans Exist Call [229](#)
Always On Line [129](#)
Appendix [381](#)
Appendix A: Glossary [381](#)
Appendix B: Time Zones [382](#)
Appendix C: Trusted Certificates [384](#)
Appendix D: SIP [385](#)
Appendix E: SIP Call Flows [394](#)
Audio Codecs [302](#)
Auto Answer [210](#)
Auto-Logout Time [329](#)
Automatic Gain Control (AGC) [310](#)

B

Background Noise Suppression (BNS) [310](#)
Backlight [135](#)
Bluetooth [138](#)
Boss/Admin Feature [239](#)
Boss-Line Ringtone [242](#)
Branch Office Resiliency [91](#)
BToE [250](#)
Busy Tone Delay [212](#)

C

Calendar [244](#)
Call Forward [220](#)
Call Hold [217](#)

Call Number Filter [231](#)
Call Waiting [207](#)
Capturing Packets [364](#)
CDP [59](#)
Central Provisioning [93](#)
Chapters in This Guide [v](#)
Comfort Noise Generation [312](#)
Configuration Files [94](#)
Configuration Methods [92](#)
Configuring Advanced features [259](#)
Configuring Basic Features [111](#)
Configuring Network Parameters Manually [37](#)
Configuring Security Features [325](#)
Connecting the Skype for Business Phones [9](#)
Contact Management [178](#)
Contrast [134](#)
Conventions Used in Yealink Documentations [vii](#)

D

Delegates-call Ringtone [243](#)
Deploying Phones from the Provisioning Server [99](#)
DHCP [22](#)
DHCP Option [26](#)
DHCP VLAN [66](#)
Dial-now [171](#)
Dial Plan [170](#)
Dial Search Delay [204](#)
Documentations [vi](#)
DTMF [316](#)
Dual Headset [299](#)

E

E911 [235](#)
Early Media [215](#)
Enabling the Watch Dog Feature [367](#)
Encrypting Configuration Files [344](#)

EXP40 Expansion Module [254](#)

Expansion Module [6](#)

G

Getting Information from Status Indicators [368](#)

Getting Started [9](#)

H

Headset Prior [295](#)

History Record Contacts Avatar [202](#)

Hotline [175](#)

I

Index [421](#)

Initialization Process Overview [15](#)

IPv6 Support [69](#)

J

Jitter Buffer [314](#)

K

Key As Send [166](#)

Key Features of Skype for Business Phones [5](#)

L

Language [157](#)

Live Dialpad [206](#)

LLDP [55](#)

Loading Language Packs [158](#)

Local Directory [183](#)

M

Missed Call Log [201](#)

Multicast Paging [259](#)

Music on Hold [219](#)

Muting the Ringtone [283](#)

Monitoring Status Changes using EXP Key LED Indicator [255](#)

Monitoring Status Changes using Line Key LED Indicator [181](#)

Memory Information [351](#)

O

Outlook Contacts [194](#)

P

Phone Lock [330](#)

Phone Models [1](#)

Phone Ring Tones [278](#)

Phone User Interface [94](#)

Physical Features of Skype for Business Phones [1](#)

Power Indicator LED

PPPoE [42](#)

Pre Dial Tone [277](#)

Private Line Ring Tone [284](#)

Product Overview [1](#)

Q

Quality of Service [78](#)

Quality of Experience [271](#)

R

Reading Icons [17](#)

Reading the Configuration Parameter Tables [vii](#)

Recommended References [xi](#)

Redial Tone [277](#)

Remembering Password [124](#)

Response Group [227](#)

Return Code When Refuse [214](#)

Ringer Device for Headset [297](#)

S

Save Call Log [198](#)

Sending Volume [300](#)

Setting Up Your Phone Network [21](#)

Setting Up Your Phones with a Provisioning Server [92](#)

Setting Up Your System [21](#)

Signing into Skype for Business [112](#)

Signing Out Skype for Business [126](#)

SIP Components [xiii](#)

SIP Header [390](#)

SIP Responses [391](#)

SIP Request [389](#)

SIP Session Description Protocol Usage [394](#)
Skype for Business Directory [178](#)
Skype for Business Feature License [325](#)
Skype for Business Status [352](#)
Specifying the Language to Use [164](#)
Static DNS [23](#)
Suppress DTMF Display [318](#)

T

Table of Contents [xvii](#)
Team-Call Group [224](#)
Time and Date [140](#)
Tones [287](#)
Transfer via DTMF [320](#)
Transport Layer Security (TLS) [335](#)
Troubleshooting [351](#)
Troubleshooting Methods [351](#)
Troubleshooting Solutions [370](#)

U

Update Checking Time [107](#)
Updating Status Automatically [127](#)
Upgrading Firmware [100](#)
User and Administrator Passwords [327](#)

V

Verifying Startup [16](#)
Viewing Global Log Files [355](#)
VLAN [54](#)
Voice Activity Detection [311](#)
Voice Mail Tone [293](#)
Voice Mail without PIN [234](#)
VoIP Principle [xii](#)

W

What IP Phones Need to Meet [9](#)
Web Server Type [50](#)
Web User Interface [93](#)