

Using Call Completion Feature on Yealink SIP-T3XG Phones

1. Overview

Call Completion is feature allowing some form of alternative interaction between parties who cannot converse directly with each other. For example: A call B, B is busy, A wanna get a notification when B finish the call so that A would be able to call B again promptly.

Call Completion feature need PBX supported, Yealink SIP-T3XG Phones support Call Completion feature in version 40(x.40.x.x) and higher.

2. Setting

Access to phone's Web UI→ Phone→Features→General Information, enabled the Call Completion feature.

The screenshot displays the Yealink web interface for configuring a SIP-T3XG phone. The 'Phone' tab is selected, and the 'General Information' section is expanded. The 'Call Completion' feature is highlighted with a red box and is set to 'Enabled'. Other settings like 'Forward', 'Do Not Disturb', and 'Live Dialpad' are also visible. A 'NOTE' section on the right provides details about the 'Forward' feature.

Feature	Setting
Forward	Disabled
Do Not Disturb	Disabled
Live Dialpad	Disabled
Inter Digit Time(1~14) (seconds)	4
Feature Synchronization	Disabled
Call Waiting	Enabled
Call Completion	Enabled
Auto Redial	Disabled
Auto Redial Interval (seconds)	10
Auto Redial Times	10
Hotline	
Hotline Time-out (seconds)(0~180s)	4
Key As Send	#
Reserve # in User Name	Enabled
Dial-now Time-out (seconds)	4
Busy Tone Timer (seconds)	0
Return Code When Refuse	486 (Busy here)
Return Code When DND	480 (Temporarily not available)
RFC 2543 Hold	Disabled
180 Ringing Workaround	Enabled
Use Outbound Proxy in Dialog	Enabled
Logon Wizard	Disabled
DTMF Repetition	3
Save Call Log	Enabled
Match Remote Phone Book	Disabled
Load Remote Phone Book Interval (120~2592000s)	3600
Login Time-out	5

NOTE

Forward
This feature allows you to forward an incoming call to another phone number.

Target
The number to which the incoming calls will be forwarded.

On Code
The code that will be sent to PBX when it is switched On.

Off Code
The code that will be sent to PBX when it is switched Off.

Call Waiting
This call feature allows your phone to accept other incoming calls during the conversation.

Key As Send
Select * or # as the send key.

Hotline Number
When you pick up the phone, it will dial out the hotline number automatically.

Or from phone interface Menu→Features→Call Completion, use the navigation key to enable Call Completion feature.

