



VC110 Video Conferencing Endpoint Administrator Guide

Version 22.15
Feb. 2017

Copyright

Copyright © 2017 YEALINK(XIAMEN) NETWORK TECHNOLOGY

Copyright © 2017 Yealink Network Technology CO., LTD. All rights reserved. No parts of this publication may be reproduced or transmitted in any form or by any means, electronic or mechanical, photocopying, recording, or otherwise, for any purpose, without the express written permission of Yealink(Xiamen) Network Technology CO., LTD. Under the law, reproducing includes translating into another language or format.

When this publication is made available via the media, Yealink(Xiamen) Network Technology CO., LTD. gives its consent to downloading and printing copies of the content provided in this file for private use only and not for redistribution. No parts of this publication may be subject to alteration, modification or commercial use. Yealink(Xiamen) Network Technology CO., LTD. will not be liable for any damages arising from use of an illegally modified or altered publication.

Warranty

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS GUIDE ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS GUIDE ARE BELIEVED TO BE ACCURATE AND PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR USE OF PRODUCTS.

YEALINK(XIAMEN) NETWORK TECHNOLOGY CO., LTD. MAKES NO WARRANTY OF ANY KIND WITH REGARD TO THIS GUIDE, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. Yealink(Xiamen) Network Technology CO., LTD. shall not be liable for errors contained herein nor for incidental or consequential damages in connection with the furnishing, performance, or use of this guide.

Declaration of Conformity



Hereby, Yealink(Xiamen) Network Technology CO., LTD. declares that this phone is in conformity with the essential requirements and other relevant provisions of the CE, FCC.

You can find the CE and FCC information from the label on the bottom of the VC110 all-in-one unit.

Statements of compliance can be obtained by contacting support@yealink.com.

CE Mark Warning

This device is marked with the CE mark in compliance with EC Directives 2014/30/EU and 2014/35/EU.

Part 15 FCC Rules

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device is compliant with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and

2. This device must accept any interference received, including interference that may cause undesired operation.

Industry Canada (IC)

This Class [B] digital apparatus complies with Canadian ICES-003 Rules.

Class B Digital Device or Peripheral

Note: This device is tested and complies with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experience radio/TV technician for help.

WEEE Warning



To avoid potential effects on the environment and human health as a result of the presence of hazardous substances in electrical and electronic equipment, end users of electrical and electronic equipment should understand the meaning of the crossed-out wheeled bin symbol. WEEE must not be regarded as unsorted municipal waste and must be collected and disposed of separately by a competent authority.

Customer Feedback

We are striving to improve our documentation quality and we appreciate your feedback. Email your opinions and comments to DocsFeedback@yealink.com.

About This Guide

Thank you for choosing the Yealink VC110 full HD video conferencing endpoint. It is an all-in-one unit that supports 1080P-full HD video conferencing and includes outstanding features such as good compatibility, easy deployment and intelligent network adaptability. These make it the best choice for SME.

The Yealink VC110 full-HD video conferencing endpoint is designed to help enterprises organize video conferences easily and efficiently. Users can expect to enjoy the high-quality video conferencing experience very cost-effectively.

The guide is intended for administrators who need to configure, customize, manage, and troubleshoot the video conferencing endpoint properly, rather than for end-users. It provides details on the functionality and configuration of the Yealink VC110 video conferencing endpoint.

Many of the features described in this guide involve network and account settings, which could affect the endpoint's performance in the network. Therefore, an understanding of IP networking and a prior knowledge of VoIP telephony concepts are necessary.

Documentations

This guide covers the VC110 video conferencing endpoint. In addition to the administrator guide, the following related documents are available:

- Quick Start Guide, which describes how to assemble the endpoint and configure basic network features on the endpoint.
- User Guide, which describes how to configure and use basic features available on the endpoints.
- Video Conference Room Deployment Solution, which describes the conference room layout requirements and how to deploy the endpoints.
- Network Deployment Solution, which describes how to deploy network for your systems.

You can download the above documentations online:

<http://support.yealink.com/documentFront/forwardToDocumentFrontDisplayPage>

For support or service, please contact your Yealink reseller or go to Yealink Technical Support online: <http://www.yealink.com/Support.aspx>.

Firmware

Common reasons for updating firmware include fixing bugs or adding features to the device. You can download the latest firmware for your product online:

<http://support.yealink.com/documentFront/forwardToDocumentFrontDisplayPage>

For more information on how to upgrade the endpoint firmware, refer to [Upgrading Firmware](#) on page 255.

In This Guide

This administrator guide includes the following chapters:

- Chapter 1, "[VC110 Video Conferencing Endpoint Introduction](#)" describes endpoint components, icons and Indicator LEDs.
- Chapter 2, "[Getting Started](#)" describes how to install and start up the endpoint and configuration methods.
- Chapter 3, "[Configuring Network](#)" describes how to configure network features on the endpoint.
- Chapter 4, "[Configuring Call Preferences](#)" describes how to configure call preferences on the endpoint.
- Chapter 5, "[Configuring Endpoint Settings](#)" describes how to configure basic, audio and video features on the endpoint.
- Chapter 6, "[Endpoint Management](#)" describes how to manage endpoint contacts and call history.
- Chapter 7, "[Configuring Security Features](#)" describes how to configure security features on the endpoint.
- Chapter 8, "[Endpoint Maintenance](#)" describes how to upgrade endpoint firmware and reset the endpoint.
- Chapter 9, "[Troubleshooting](#)" describes how to troubleshoot the endpoint and provides some common troubleshooting solutions.

Summary of Changes

This section describes the changes to this guide for each release and guide version.

Changes for Release 22, Guide Version 22.15

The following section is new for this version:

- [Logging into the StarLeaf Cloud Platform](#) on page 115
- [Account Polling](#) on page 139

Major updates have occurred to the following sections:

- [H.323 Tunneling](#) on page 82
- [H.460 Firewall Traversal](#) on page 101

- [Methods of Transmitting DTMF Digit](#) on page 142
- [Dual-Stream Protocol](#) on page 191
- [Camera Control Protocol](#) on page 202
- [H.235](#) on page 248

Changes for Release 22, Guide Version 22.5

The following sections are new for this version:

- [Remote Control via Web User Interface](#) on page 40
- [Auto Dialout Mute](#) on page 155
- [Meeting Blacklist](#) on page 178
- [USB Configuration](#) on page 209

Major updates have occurred to the following sections:

- [Icon Instructions](#) on page 33
- [Keep Alive](#) on page 97
- [Configuring Cloud Settings](#) on page 111
- [DTMF](#) on page 141
- [Dual-Stream Protocol](#) on page 191
- [Camera Control Protocol](#) on page 202
- [Secure Real-Time Transport Protocol](#) on page 245

Changes for Release 21, Guide Version 21.20

The following sections are new for this version:

- [Keyboard Input Method](#) on page 183
- [Configuring Cloud Settings](#) on page 111

Major updates have occurred to the following sections:

- [Icon Instructions](#) on page 33
- [Setup Wizard](#) on page 49
- [Directory](#) on page 217

Changes for Release 21, Guide Version 21.15

The following section is new for this edition:

- [IPv6 Support](#) on page 64

- [Video Codecs](#) on page 149
- [Hiding Icons in a Call](#) on page 179
- [Output Resolution](#) on page 208
- [Video Recording](#) on page 210
- [Screenshot](#) on page 212

Major updates have occurred to the following sections:

- [Icon Instructions](#) on page 33
- [Setup Wizard](#) on page 49
- [Configuring LAN Properties](#) on page 56
- [Call Protocol](#) on page 150
- [Dual-Stream Protocol](#) on page 191
- [Far-end Camera Control](#) on page 201
- [Search Source List in Dialing](#) on page 228

Changes for Release 10, Guide Version 10.11

The following section is new for this edition:

- [Default Layout of Single Screen](#) on page 162

Major updates have occurred to the following sections:

- [Codecs](#) on page 147
- [Configuring Camera Settings](#) on page 197
- [Camera Control Protocol](#) on page 202

Table of Contents

About This Guide V

Documentations	v
Firmware	v
In This Guide	vi
Summary of Changes	vi
Changes for Release 22, Guide Version 22.15	vi
Changes for Release 22, Guide Version 22.5	vii
Changes for Release 21, Guide Version 21.20	vii
Changes for Release 21, Guide Version 21.15	vii
Changes for Release 10, Guide Version 10.11	viii

Table of Contents ix

VC110 Video Conferencing Endpoint Introduction 1

VoIP Principles	1
Physical Features of Endpoint.....	2
Packaging Contents	3
VC110 All-in-one Package.....	4
VCM60 Package	5
VCP40 Package	6
VCP41 Package	7
VCM30 Package	8
Endpoint Component Instructions	8
VC110 All-in-one Unit	9
Cable Hub	12
VCM60 Video Conferencing Wireless Microphone.....	12
Video Conferencing Phone	22
CPE80 Expansion Microphone.....	27
VCM30 Video Conferencing Microphone Array	28
VCR10 Remote Control	31
Icon Instructions.....	33
Icons on Display Device	33
Icons on Video Conferencing Phone	35
LED Instructions	36
User Interfaces	38
Web User Interface	38
Remote Control.....	39

Getting Started..... 41

Endpoint Connection and Installation	41
Connecting the VC110 Video Conferencing Endpoint.....	42
Installing the VC110 Video Conferencing Endpoint.....	43
Installing Batteries in the Remote Control.....	45
Powering the Endpoint On or Off.....	46
Endpoint Initialization	48
Endpoint Startup	48
Setup Wizard.....	49
Enabling Communication with Other Endpoints.....	53
Placing a Test Call from the Yealink VC110 endpoint	54

Configuring Network 55

Preparing the Network	55
Configuring LAN Properties	56
DHCP	56
Configuring Network Settings Manually	61
IPv6 Support	64
Configuring Network Speed and Duplex Mode.....	68
VLAN.....	70
LLDP.....	71
Manual Configuration for VLAN	74
DHCP VLAN	75
802.1X Authentication	77
H.323 Tunneling	82
Configuring the Endpoint for Use with a Firewall or NAT	86
Reserved Ports	87
Network Address Translation	89
H.460 Firewall Traversal.....	101
Intelligent Firewall Traversal	102
Quality of Service	103
VPN.....	106

Configuring Call Preferences111

Configuring Cloud Settings	111
Logging into the Yealink Cloud Platform	111
Logging into the StarLeaf Cloud Platform	115
Logging into the Zoom Cloud Platform	116
Registering a Pexip Account.....	119
Logging into the BlueJeans Cloud Platform	121
Logging into the Mind Platform.....	124

Registering a Custom Account	126
Configuring the Third-party Virtual Meeting Room	128
Configuring SIP Settings.....	132
SIP Account.....	132
SIP IP Call	134
Configuring H.323 Settings	136
Account Polling	139
DTMF	141
Methods of Transmitting DTMF Digit.....	142
Codecs	147
Audio Codecs.....	147
Video Codecs	149
Call Protocol.....	150
Do Not Disturb.....	152
Auto Answer.....	153
Auto Dialout Mute	155
Call Match	156
History Record	157
Bandwidth	158
Ringback Timeout	159
Auto Refuse Timeout.....	160
SIP IP Call by Proxy.....	161
Default Layout of Single Screen	162
Configuring Endpoint Settings	165
General Settings	165
Site Name	165
Backlight of the Video Conferencing Phone.....	166
Language	167
Date & Time.....	168
Automatic Sleep Time	174
Hide IP Address.....	175
Reelog Offtime.....	176
Key Tone	177
Meeting Blacklist.....	178
Hiding Icons in a Call	179
Keyboard Input Method	183
Audio Settings.....	184
Audio Output Device	184
Audio Input Device	186
Adjusting MTU of Video Packets	189
Dual-Stream Protocol.....	191
Mix Sending	196
Configuring Camera Settings	197

Far-end Camera Control.....	201
Camera Control Protocol.....	202
Output Resolution.....	208
USB Configuration.....	209
Video Recording	210
Screenshot	212
Tones	213
Endpoint Management	217
Directory	217
LDAP	221
Call History.....	226
Search Source List in Dialing	228
Dual Screen	229
Configuring Security Features.....	233
User Mode	233
Administrator Password	234
Web Server Type.....	235
Transport Layer Security.....	237
Secure Real-Time Transport Protocol	245
H.235.....	248
Attack Defense in Public Network	251
Abnormal Call Answering.....	251
Configuring Safe Mode Call	252
Endpoint Maintenance	255
Upgrading Firmware	255
Importing/Exporting Configuration.....	256
Resetting to Factory	257
SNMP	258
Troubleshooting.....	263
Troubleshooting Methods.....	263
Viewing Log Files	263
Capturing Packets	266
Getting Information from Status Indicators.....	269
Analyzing Configuration Files.....	269
Viewing Call Statistics.....	270
Using Diagnostic Methods	270
Troubleshooting Solutions	272

General Issues	273
Camera Issues	274
Video & Audio Issues	275
Why does the far-site display black screen when local starts a presentation?	277
Endpoint Maintenance	278
Appendix	281
Appendix A: Time Zones	281
Appendix B: Trusted Certificates	284
Index	287

VC110 Video Conferencing Endpoint

Introduction

This chapter contains the following information about VC110 video conferencing endpoint:

- [VoIP Principles](#)
- [Physical Features of Endpoint](#)
- [Packaging Contents](#)
- [Endpoint Component Instructions](#)
- [Icon Instructions](#)
- [LED Instructions](#)
- [User Interfaces](#)

VoIP Principles

VoIP

VoIP (Voice over Internet Protocol) is a technology that uses the Internet Protocol instead of traditional Public Switch Telephone Network (PSTN) technology for voice communications.

It is a family of technologies, methodologies, communication protocols, and transmission techniques for the delivery of voice communications and multimedia sessions over IP networks. The H.323 and Session Initiation Protocol (SIP) are two popular VoIP protocols that are found in widespread implementation.

H.323

H.323 is a recommendation from the ITU Telecommunication Standardization Sector (ITU-T) that defines the protocols to provide audio-visual communication sessions on any packet network. The H.323 standard addresses call signaling and control, multimedia transport and control, and bandwidth control for point-to-point and multi-point conferences.

It is widely implemented by voice and video conference equipment manufacturers, is used within various Internet real-time applications, such as GnuGK and NetMeeting, and is widely deployed by service providers and enterprises for both voice and video services over IP networks.

SIP

SIP (Session Initiation Protocol) is the Internet Engineering Task Force's (IETF's) standard for multimedia conferencing over IP. It is an ASCII-based, application-layer control protocol (defined in RFC 3261) that can be used to establish, maintain, and terminate calls between two or more endpoints. Like other VoIP protocols, SIP is designed to address the functions of signaling and session management within a packet telephony network. Signaling allows call information to be carried across network boundaries. Session management provides the ability to control the attributes of an end-to-end call.

Physical Features of Endpoint

Video conferencing endpoints are in the overall network topology, which are designed to interoperate with other compatible equipment, including application servers, media servers, Internet-working gateways, and other endpoints.

In order to operate endpoints in your network successfully, the endpoints must meet the following requirements:

- A working IP network is established.
- VoIP gateway is configured for SIP or H.323, and H.323 gatekeeper is configured for H.323. You can also deploy Cloud server for Cloud platform.
- The latest (or compatible) firmware of endpoint is available.
- A call server is active and configured to receive and send SIP/H.323 messages.



VC110 All-in-one Unit User Interface

- 2 x HDMI
- 1x DVI-I
- 1 x Line-in (3.5mm)

- 1 x Line-out (3.5mm)
- 2 x USB2.0 port
- Others: 1 x security lock slot, 1 x reset slot

Cable Hub User Interface

- 1x DVI-I
- 1x 10/100Mb (RJ-45)
- 1x VGA
- 1xRJ-45
- Input: AC 100-240V; Output: 12V/2A

Full-HD Camera

- 1920x1080 video resolution
- Pan range: $\pm 100^\circ$
- Tilt range: $\pm 30^\circ$
- Up to 10 preset positions
- Beauty shot feature

Video Resolution

- Full-HD 1080P at 30fps (1920x1080), from 1Mbps
- 720P (1280x720), from 512Kbps
- W448P (768 x 448), WQVGA (400 x 240)
- 4CIF (704x576), CIF (352 x 288)

Packaging Contents

The VC110 video conferencing endpoint can work with the VCM60 video conferencing wireless microphone, VCP40 video conferencing phone, VCP41 video conferencing phone or VCM30 video conferencing microphone array. You can purchase any combination according to your needs:

Note


We recommend that you use the accessories provided or approved by Yealink. The use of unapproved third-party accessories may result in reduced performance

VC110 All-in-one Package


- **VC110 All-in-one Unit**






- **Cable Hub**



- **L-Bracket** (for installing the VC110 one-in-one unit)



- **Mounting Accessories** (for installing the VC110 one-in-one unit)

Expansion bolts		× 4
Screws(Specificaiton: T4×30)		× 4
Screws(Specificaiton: M3×8)		× 2


- **VCR10 Remote Control**



- **AAA Batteries×2**



- **Power Adapter**



- **Cables**



DVI Cable



HDMI-VGA Direct Cable



HDMI Cable



Ethernet Cable
(2m)


- **Velcro×2**



- **Cable Ties×5**




- **VC110 Quick Start Guide**




VCM60 Package


- **VCM60 Video Conferencing Wireless Microphone**



- **Power Adapter**




- **USB Cable**



- **Dongle**




- **VCM60 Quick Start Guide**




VCP40 Package

- **VCP40 Video Conferencing Phone**



- **Ethernet Cable (7.5m)**




Locate the Audio In port of the cable hub, and connect it to the Audio Out port of the VCP40 video conferencing phone with the 7.5m Ethernet cable. VCP40 video conferencing phone can work as an audio device for the VC110 endpoint. You can also place calls, answer calls or view directory and history on the VCP40 video conferencing phone.

VCP41 Package


- **VCP41 Video Conferencing Phone**



- **Expansion Microphone CPE80×2**



- **Ethernet Cable (7.5m)**




- **3.5mm Audio Cable** (for connecting a PC/Mobile device to the VCP41)




Locate the Audio In port on the cable hub, and connect it to the Audio Out port of the VCP41 video conferencing phone with the 7.5m Ethernet cable. VCP41 Video conferencing phone can work as an audio device for the VC110 endpoint. You can also place calls, answer calls or view directory and history on the VCP41 video conferencing phone.

VCM30 Package

- **VCM30 Video Conferencing Microphone Array**



- **Ethernet Cable (7.5m)**



Locate the Audio In port of the cable hub, and connect it to the Audio Out port of the VCM30 with the 7.5m Ethernet cable. VCM30 video conferencing microphone array can work as the audio input device for the VC110 endpoint. For more information, refer to [Audio Input Device](#) on page 186.

Note

Check the list before installation. If you find anything missing, contact your system administrator.

Endpoint Component Instructions

Before installing and using the VC110 video conferencing endpoint, you need to be familiar with the following endpoint components, including:


- [VC110 All-in-one Unit](#)
- [Cable Hub](#)
- [VCM60 Video Conferencing Wireless Microphone](#)
- [Video Conferencing Phone](#)
- [CPE80 Expansion Microphone](#)
- [VCM30 Video Conferencing Microphone Array](#)
- [VCR10 Remote Control](#)

VC110 All-in-one Unit


The VC110 all-in-one unit integrates the camera, the built-in microphone and the codec into a unit. VC110 all-in-one unit compresses outgoing video and audio data, transmits this information to the far end, and decompresses incoming data. It supports 16:9 and 4:3 aspect ratios. It can be compatible with different audio output devices, and can adapt to the display devices automatically.

Lens cover

The lens cover is used for protecting the lens, which shall not receive dust pollution and all possible brush, collision.




The front of VC110 all-in-one unit




The HD camera supports 4xdigital zoom, white balance and automatic gain. You can place the VC110 all-in-one unit on the table or mount it on a wall. The LED indicator in front of the camera indicates different statuses of the endpoint. For more information, refer to [LED Instructions](#) on page 36.

You can use the remote control to adjust the position or focus of the camera. The VC110 camera can be panned (± 100 degrees range), tilted (± 30 degrees range).



Infrared Sensor


The infrared sensor is located within the Yealink logo. Aim the remote control at the camera IR sensor to operate the unit.




Note

When the endpoint is powered on, avoid physically turning the camera. This may cause permanent damage to the camera. Always use the remote control to pan and tilt it.


The right side of the VC110 all-in-one unit



	Port Name	Description
①	USB	<p>Inserts a USB flash drive to one of the two USB ports for storing screenshots, recording videos or capturing packets. Inserts a dongle to one of the two USB ports for connecting the VCM60 video conferencing wireless microphone.</p> <p>Note:</p> <ul style="list-style-type: none"> The wireless microphone dongle and USB flash drive can work at the same time. If two USB flash drives are connected, only the latter one can be identified.

The left side of the VC110 all-in-one unit


	Port Name	Description
②	Security Slot	Allows you to connect a universal security cable to VC110 all-in-one unit, so you can lock it down. The endpoint cannot be removed when locked.

The back of VC110 all-in-one unit

	Port Name	Description
③	Reset Key	Resets the endpoint to factory defaults.
④	DVI Port	Connects to the cable hub.
⑤	Display1	Connects to a display device for displaying video images. When connecting to only one display device, Display1 port on the VC110 all-in-one unit is the only available port.
⑥	Display 2	Connects to secondary display device for displaying video images.
⑦	Line In	Connects to an audio input device using an audio cable (3.5mm).
⑧	Line Out	Connects to an audio output device using an audio cable (3.5mm).


Cable Hub

The front of cable hub:



	Port Name	Description
①	DC12V	Connects to the power source via a power adapter.
②	Internet	Connects to the network device.
③	Audio In	Connects to the video conferencing phone or the VCM30 video conferencing microphone array.
④	PC	Connects to a PC for sharing documents or videos during a call.

The back of cable hub:




	Port Name	Description
⑤	DVI Port	Connects to the VC110 all-in-one unit.

VCM60 Video Conferencing Wireless Microphone

The VCM60 is a video conferencing wireless microphone which can work as the audio input device for VC110 video conferencing endpoint. It supports 360-degree audio pickup at a radius of up to 2 meters. There are a mute button and a battery indicator LED on its top. You can mute or unmute the VCM60 by tapping the mute button.

There is a power switch on its bottom. You can turn off this switch if the VCM60 is not in use for a long period of time.




	Name	Description
①	Battery Indicator LED	Indicates the battery information. For more information on the mute indicator LED, refer to LED Instructions on page 36.
②	Built-in Microphone	Supports 360-degree audio pickup at a radius of up to 2 meters.
③	Mute Button	<ul style="list-style-type: none"> Mutes or unmutes the VCM60. For more information on the mute indicator LED, refer to LED Instructions on page 36. Activates the VCM60 to search the dongle when it is in the offline standby mode. For more information, refer to Standby Mode on page 36. Enters registration mode. For more information, refer to Registering and Unregistering the VCM60 on page 18.
④	Charging Interface	Connects the VCM60 to a power adapter or a computer's USB port using a USB cable to charge the VCM60.
⑤	Switch	Turns on or off the VCM60.

Placing the VCM60

The VCM60 has a rubber pads on its base to prevent it from sliding. You can place the VCM60 on a conference table. Do the following to ensure optimal voice quality:

- For registering to the dongle successfully, make sure the VCM60 video conferencing wireless microphone is less than 30 meters distant from the dongle.
- Place the VCM60 on a stable surface and keep it away from obstacles so that it can

effectively pick up sounds.



Turning On or Off the VCM60


There is a power switch on the bottom of the VCM60. Turn on the power switch to start the VCM60. After the VCM60 starts, it registers with the paired dongle automatically. You can turn off this switch if the VCM60 is not in use for a long period of time.


Connecting VCM60 to the Video Conferencing Endpoint


To ensure good voice quality, VCM60 video conferencing wireless microphone can be connected to the VC110 video conferencing endpoint to work as the audio input device.

To connect the VCM60 to the VC110 video conferencing endpoint, do the following:




1. Connect the dongle to one of the USB ports on the VC110 all-in-one unit.




The display device prompts "Dongle connected!", and the  (unregistered) icon appears on the status bar.




2. Turn on the VCM60.


The VCM60 registers with the dongle automatically. If successful, the  (unregistered) icon will change to  (registered). Current capacity appears on the right side of the  icon. When the standby time is less than 1 hour, please charge the VCM60. For more information, refer to [Charging the VCM60](#) on page 20.



To remove the VCM60 from the VC110 video conferencing endpoint, do the following:

1. Remove the dongle from the VC110 all-in-one unit.

The display device prompts "Dongle remove!". And the icon  disappears from the status bar.



Standby Mode

The VCM60 supports two standby modes: online standby and offline standby.

Online standby:

- When registering with dongle successfully, the VCM60 enters online standby mode and the mute indicator LED changes to green and is in breathing state.

Offline standby:



- If VC110 video conferencing endpoint encounters poor signal, wireless interference or is powered off, the VCM60 may lose connection with the dongle. In this case, the VCM60 will search the dongle again, and the mute indicator LED fast flashes green. If dongle cannot be searched in 2 minutes, the VCM60 will enter offline standby mode automatically and the mute indicator LED slowly flashes orange.
- When the VCM60 is in offline standby mode, you need to tap the mute button to activate VCM60 to search dongle again and the mute indicator LED fast flashes green.

Muting or Unmuting the VCM60



There is a mute button on the top of the VCM6. If VCM60 works as the audio input device of the VC110 video conferencing endpoint, you can mute or unmute it in the following scenarios:

- If you do not want to have your voice broadcast during a conference, you can tap the mute button to mute the VCM60.
- If you want to speak again during a conference, you can tap mute button to unmute the VCM60.

To mute the VCM60 during a call:

1. Tap  again to un-mute the call.
The mute indicator LED illuminates solid red. And the  mute icon appears on the local video image.

To un-mute the VCM60 during a call:

1. Tap  again to un-mute the call.
The mute indicator LED illuminates solid green. And the  mute icon disappears from the local video image.

Viewing VCM60 Information


When the dongle is connected to the USB port of the VC110 one-in one unit, you can view VCM60 status via the remote control or web user interface.

Available information of VCM60 includes:

- Dongle status
- Dongle Version
- Micpod Status
- Micpod Version
- Micpod Model
- Micpod IPEI
- Battery percent
- Idle Time (estimated standby time)
- Work Time(estimated working time)

To view the VCM60 information via web user interface:

1. Click on **Status**.

**To view the VCM60 information via the remote control:**

1. Select **Menu->Status->Wireless Micpod**.

Registering and Unregistering the VCM60


The VCM60 video conferencing wireless microphone and dongle are automatically "paired" at the factory. But In following cases, you may need to deregister or register the VCM60 video conferencing wireless microphone manually.

- The device is broken, new VCM60 or new dongle need to be re-paired.
- VCM60 and dongle need to be paired during the production.

You can only register and unregister the VCM60 via web user interface. The web user interface will display the model and product ID of the dongle and video conferencing wireless microphone.

To deregister the VCM60 via web user interface:


1. Click on **Setting->Wireless Micpod**.
2. Click **DeRegistered**.




3. Click **Confirm** to deregister the video conferencing wireless microphone.
The paired information will be cleared. The VCM60 video conferencing wireless microphone will enter offline standby mode and the mute indicator LED slowly flashes orange.

To register the VCM60 via web user interface:

1. Click on **Setting->Wireless Micpod**.
2. Click **Search Mic**.




The web user interface starts 120-second countdown for pairing the dongle and video conferencing wireless microphone.




3. Tap and hold the mute button on the VCM60 video conferencing wireless microphone for 5 seconds until the mute indicator LED flashes orange.


The VCM60 video conferencing wireless microphone and the dongle will be paired automatically. If this fails, the VCM60 will exit registration mode in 2 minutes.


Charging the VCM60

When the standby time of the VCM60 is less than 1 hour (the battery indicator LED flashes red), the  icon appears on the status bar, and the display device prompts "The battery of wireless micpod is too low, please charge it in time!" every 15 minutes.

To charge the VCM60, connect it to a power adapter or a computer using the supplied USB cable.



The VPM60 can work normally during charging. If you charge the VCM60 when it is working, the display device prompts "The battery is charging!", and the  (charging) icon appears on the status bar.



During charging, the battery LED indicator will flash green. And it will illuminate solid green when the battery capacity reaches 100%.

VCM60 Working Frequency

For reference, the Frequency/Channels of VCM60 used in each Region are tabulated below:

Freq (MHz)	RF Carrier Index (DECT tester Numbering)						
	EU	Taiwan	US	LA	Korea	Brazil	Japan
1881.792	9	9					
1883.520	8	8					
1885.248	7	7					
1886.976	6	6					
1888.704	5	5					
1890.432	4	4					
1892.160	3	3					
1893.888	2	2					
1895.616	1						4(F1)
1897.344	0						3(F2)
1899.072							2(F3)


Freq (MHz)	RF Carrier Index (DECT tester Numbering)						
	EU	Taiwan	US	LA	Korea	Brazil	Japan
1900.800							1(F4)
1902.528							0(F5)
1904.256							
1905.984							
1907.712							
1909.440							
1911.168						4	
1912.896				9		3	
1914.624				8		2	
1916.352				7		1	
1918.080				6		0	
1919.808				5			
1921.536			4	4			
1923.264			3	3			
1924.992			2	2			
1926.720			1	1			
1928.448			0	0			
1787.616					8		
1789.344					7		
1791.072					6		

Video Conferencing Phone


VCP40 Video Conferencing Phone




The VCP40 video conferencing phone supports 360-degree audio pickup to achieve ultra-HD voice.

Connect the VCP40 video conferencing phone to the cable hub. It can work as an audio device for the VC110. You can also place calls, answer calls or view directory and history on the VCP40 video conferencing phone.




Component instructions of the VCP40 video conferencing phone are:

	Item	Description
①	LCD Screen	Shows information about calls, messages, soft keys, time, date and other relevant data: <ul style="list-style-type: none"> • Call information—call duration • Icons (for example, )

	Item	Description
		<ul style="list-style-type: none"> • Missed call information • Time and date
②	Soft Keys	Label automatically to identity their context-sensitive features.
③	On-hook Key	Rejects or ends a call or returns to the previous screen.
④		Scrolls upwards through the displayed information.
⑤		Enters list or answers incoming calls.
⑥		Scrolls downwards through the displayed information.
⑦	Keypad	Generates the digits and special characters ". " "*" "##".
⑧	Off-hook Key	Initiates a call or answers a call.
⑨	Presentation Key	Enables or disables presentation.
⑩	Mute Key	Toggles the mute feature.
⑪	Volume Key	Adjusts the volume of the speakerphone and ringer.
⑫	Microphone	Picks up voice.
⑬	LED Indicators	Indicate phone and call statuses.
⑭	Speakerphone	Provides ringer and hands-free (speakerphone) audio output.
⑮	MIC Port	Connects a CPE80 expansion microphone to one of two MIC ports.
⑯	Security Slot	Allows you to connect a universal security cable to lock down your phone. The phone cannot be removed when locked.
⑰	Audio Out Port	<p>Connects to the video conferencing phone using the 7.5m Ethernet cable labeled Audio in.</p> <p>Provides the power supply for the video conferencing phone.</p>

VCP41 Video Conferencing Phone

The features of VCP41 video conferencing phone are similar to VCP40. For more information, refer to [VCP40 Video Conferencing Phone](#) on page 22. The only difference is that the back of VCP41 has a PC/Mobile port, which allows you to connect an optional PC or Mobile Device to your phone, so that VCP41 can work as the audio input/output device of your PC or mobile device.




	Item	Description
①	PC/Mobile Port	Allows you to connect an optional PC or Mobile Device to your phone so that you can listen to the PC or mobile audio using your VCP41 video conferencing phone.



Connecting a PC or Mobile Device to the VCP41

You can connect a PC or mobile device to the VCP41 when your VC110 video conferencing endpoint is idle, is placing a call or during a call.

To connect a PC or mobile device to your VCP41:

1. Connect one end of the 3.5mm audio cable to the PC/mobile port on the VCP41 phone, and connect the other end to the headset jack on the mobile device or the AUX/MIC jack on the PC.



The  icon will appear on the display device, and the icon  will appear on the video conferencing phone.




As a result, VCP41 will work as the audio input/output device of your PC or mobile device. For example, when the PC or mobile device is playing a video or music, you can listen to the audio on your VCP41. If your PC or mobile device receives an incoming call, you can use VCP41 to listen and speak.

Adjusting the Volume of the PC or Mobile Audio

When your PC or mobile device is during a call, you can adjust the output volume of the PC/mobile device via your VCP41.

To adjust the volume of the PC or mobile device:

1. When your PC or mobile device is during a call, press  on the VCP41 to adjust the volume.


Removing the PC or Mobile Audio

To remove the PC or mobile device, disconnect the 3.5mm audio cable from the VCP41.

CPE80 Expansion Microphone

If your video conferencing room is large, you can add extra CPE80 expansion microphones to the MIC ports on the video conferencing phone to expand the audio range.


Video conferencing phone has two MIC ports. Up to two expansion microphones can be connected to a video conferencing phone. CPE80 is a directional microphone. Its coverage range is a 120 degree. Always ensure that the speaker faces the expansion microphone.



	Item	Description
①	Mute Indicator LED	Toggles and indicates mute feature.
②	Microphone	Transmits sound to other phones.
③	MIC Connector	Allows you to connect to the MIC port on the video conferencing phone.

VCM30 Video Conferencing Microphone Array


The VCM30 is a video conferencing microphone array which can work as the audio input device for VC110 video conferencing endpoint. It has 3 built-in microphones which support 360-degree audio pickup at a radius of up to 3 meters. There is a mute button on its top. You can mute or unmute the VCM30 by tapping the mute button during a call.



	Name	Description
①	Built-in Microphones	Support 360-degree audio pickup at a radius of up to 3 meters.
②	Mute Button	Mutes or unmutes the VCM30. For more information on the mute indicator LED, refer to LED Instructions on page 36.
③	Audio Out Port	Connects to the Audio In port of cable hub using the 7.5m Ethernet cable labeled Audio In. Provides the power supply for the VCM30.

Placing the VCM30

The VCM30 has a rubber pads on its base to prevent it from sliding. You can place the VCM30 on a stable surface and keep it away from obstacles so that it can effectively pick up sounds.





Muting or Unmuting the VCM30

There is a mute button at the top of the VCM30. You can mute or unmute it in the following scenarios:


- If you do not want to have your voice broadcast during a conference, you can tap the mute button to mute the VCM30.
- If you want to speak again during a conference, you can tap mute button to unmute the VCM30.


To mute the VCM30 during a call:

1. Tap  to mute the call.

The mute indicator LED illuminates solid red. And the  mute icon appears on the local video image.

To un-mute the VCM30 during a call:

1. Tap  again to un-mute the call.

The mute indicator LED illuminates solid green. And the  mute icon disappears from the local video image.

Viewing VCM30 Information


When the VCM30 is connected to the Audio In port of cable hub, you can view VCM30 status via the remote control or web user interface.

Available information of VCM30 includes:

- Status
- Model
- Hardware Version
- Serial Number

To view the VCM30 information via web user interface

1. Click **Status**.



The screenshot displays the Yealink VC110 web interface. The top navigation bar includes links for About, Language, and Logout. The main menu has tabs for Home, Status (selected), Account, Network, Setting, Directory, and Security. The left sidebar shows the Status menu item. The main content area displays the following information:


Status	
Model	--
Hardware Version	--
Serial Number	--
Wired Micpod	
Status	Enabled
Model	Yealink VCM30
Hardware Version	56.0.2.0.0.0.0
Serial Number	00000000
Wireless Micpod	
Dongle Status	Registered
Dongle Version	54.10.254.4
Micpod Status	Registered
Micpod Version	55.10.254.10
Micpod Model	Micpod
Micpod IPEI	0227C38F0F
Battery Percent	0%
Idle Time	0 Days 00:00
Work Time	0 Days 00:00

To view the VCM30 information via the remote control:

1. Select **Menu->Status->Wired Micpod**.

VCR10 Remote Control






VCR10 remote control is compact, and has definite function zoning. Users can organize conferences easily using infrared signals.



Hardware components of the remote control:

	Item	Description
①	Sleep Key	Puts the endpoint to sleep or wakes the endpoint up.
②	Red Shortcut Key	Located at the bottom left of the screen. Label automatically identifies context-sensitive features. In the idle screen, this is used to enter the main menu screen and corresponds to the Menu soft key.
③	Yellow Shortcut Key	Located at the bottom center of the screen. Label automatically identifies context-sensitive features. In the idle screen, this is used to enter the pre-dialing screen, and corresponds to the Call soft key.







	Item	Description
④	Blue Shortcut Key	<p>Located at the bottom right of the screen. Label identifies context-sensitive features.</p> <p>In the idle screen, this is used to save and check the camera preset position, and corresponds to the Preset soft key.</p>
⑤	Vol+	Increases the endpoint volume.
⑥	Vol-	Decreases the endpoint volume.
⑦	Zoom out Key	<ul style="list-style-type: none"> Decreases the camera zoom or the captured image magnifications. Behaves as page down in a multiple page list.
⑧	Zoom in Key	<ul style="list-style-type: none"> Increase the camera zoom or the captured image magnifications. Behaves as page up in a multiple page list.
⑨	OK Key	Confirms actions or answers incoming calls.
⑩	Navigation Key	<ul style="list-style-type: none"> In the menu screen, press ◀ or ▶ to change menus, press ▲ or ▼ to select items. In the idle screen, pan and tilt the camera to adjust the viewing angle.
⑪	Mute Key	Toggles the mute feature.
⑫	Home Key	<ul style="list-style-type: none"> Returns to the idle screen when in the menu screen. Enters the pre-dialing screen during a call.
⑬	Video Source Key	Switches the input source between Camera, Camera-PC, or PC.
⑭	Off-hook Key	<ul style="list-style-type: none"> Enters the pre-dialing screen. Places a call. Answers a call.
⑮	Delete key	<ul style="list-style-type: none"> Deletes one character at a time. Long press to delete all characters in the input field. On the idle screen or during a call, long press it for 2 seconds to start capturing packets and long press it for 2 seconds again to stop capturing packets.
⑯	On-hook Key	<ul style="list-style-type: none"> Ends a call or exits from a conference call. Returns to the previous screen when not in a call.






















	Item	Description
⑰	Keypad	<ul style="list-style-type: none"> Enters digits. Long press  to generate a special character "@" in the input field. Enters the pre-dialing screen. Stores the preset position of the camera.
⑱	Video Recording Key	<ul style="list-style-type: none"> Generates a special characters ".". On the idle screen, press  to start/stop recording video. During a call, long press  to start/stop recording video.
⑲	Snapshot Key	<ul style="list-style-type: none"> Generates a pound key (#). Captures the image from the camera. On the idle screen, press  to capture the image from the camera. During a call, long press  to capture the image from the camera.














Icon Instructions

Icons on Display Device

Icons appearing on the display device are described in the following table:





Icon	Description
 (flashing)	Network is disconnected
	Network is available
	Packet loss
	SIP account is registered
	H.323 account is registered
	Log into the Yealink Cloud platform


















Icon	Description
	Log into the StarLeaf/Zoom/Pexip/BlueJeans/ Mind platform
	Lowercase letters input mode of the on-screen keyboard
	Uppercase letters input mode of the on-screen keyboard
	Characters input mode of the on-screen keyboard
	Auto answer
	Missed calls
	Volume is 0
	Do not disturb
	Do not disturb during a call
	Call mute
	Call encryption
	Call Hold
	Output volume is 0 during a call
	The content of the local camera
	Focus content
	Camera position
	Record a video
	Dialed calls (H.323 account/SIP account/IP Call)
	Dialed calls (Cloud platform)
	Received calls (H.323 account/SIP account/IP Call)
	Received calls (Cloud platform)

Icon	Description
	Missed calls (H.323 account/SIP account/IP Call)
	Missed calls (Cloud platform)
	PC/Mobile mode (when a PC or mobile device is connected to the VCP41)
	Dongle is connected, while the VCM60 is unregistered
	Dongle is connected, and the VCM60 is registered
	The VCM60 is charging
	The standby time of VCM60 is less than one hour
	Dual screen mode
	Dual video sources (when a PC is connected to the PC port on the cable hub)
	A USB flash drive is inserted to the USB port of the VC110 all-in-one unit
	Local contact
	Yealink Cloud contact
	VPN is enabled

Icons on Video Conferencing Phone

Icons appearing on the video conferencing phone are described in the following table:

Icon	Description
 (Flashing)	Network is unavailable
	SIP account is registered (the icon flashes when the SIP account is not registered successfully)
	H.323 account is registered (the icon flashes when the H.323 account is not registered successfully)
	Log into the Yealink Cloud platform

Icon	Description
	Log into the StarLeaf/Zoom/Pexip/BlueJeans/Mind platform
	Auto answer
	Do not disturb
	Call is muted
	Volume is 0
	A USB flash drive is inserted to the port of the VC110 all-in-one unit
	Record a video
	Local contact
	Yealink Cloud contact
	Conference call
	Dialed calls (H.323 account/SIP account/IP Call)
	Dialed calls (Cloud platform)
	Received calls (H.323 account/SIP account/IP Call)
	Received calls (Cloud platform)
	Missed calls (H.323 account/SIP account/IP Call)
	Missed calls (Cloud platform)
	PC/Mobile mode (when a PC or mobile device is connected to the VCP41)

LED Instructions

Indicator LED on the VC110 all-in-one unit:

LED Status	Description
Solid green	The VC110 is powered on.
Solid red	The VC110 is in sleep mode.

LED Status	Description
Solid orange	The VC110 is abnormal (e.g., network unavailable, update failure).
Flashing green	Press the key on the remote control.
Off	The VC110 is powered off.

Indicator LED on the video conferencing phone:

LED Status	Description
Solid red	The phone is initializing. The video conferencing phone is muted when the VC110 is during a call.
Flashing red	The phone is ringing.
Solid green	The phone is placing a call. There is an active call on the phone.
Off	The phone is not connected to the cable hub. The phone is idle.

Battery indicator LED on the VCM60 video conferencing wireless microphone:

LED Status	Description
Solid green	The VCM60 is turned on within the first 5 seconds. The battery capacity reaches 100% during charging.
Flashing red	The battery capacity can maintain less than 1 hour.
Flashing green	The VCM60 is charging.
Off	Other status.

Mute indicator LED on the VCM60 video conferencing wireless microphone:

LED Status	Description
Fast flashing green	The VCM60 is searching the dongle.
Green and in breathing state	The VCM60 registers with the dongle, and then enters the online standby mode.
Solid green	The VC110 is placing a call. The VC110 is in a call.
Solid red	The VC110 is muted during a call.
Fast flashing orange	The VCM60 enters registration mode.
Slowly flashing orange	The VCM60 fails to search the dongle, and then enters the offline standby mode.
Off	The VCM60 is turned off. The VCM60 runs out of battery.

Mute Indicator LED on the VCM30 video conferencing microphone array

LED Status	Description
Solid red	The VCM30 is muted when the VC110 is during a call.
Flashing red	The VC110 is ringing.
Solid green	The VCM30 is connected to the cable hub within the first 5 seconds. The VC110 is placing a call. The VCM30 is unmuted when the VC110 is during a call.
Off	The VCM30 is not connected to the cable hub. The VCM30 is idle.

User Interfaces

There are two ways to customize the configurations of your endpoint:

- [Web User Interface](#)
- [Remote Control](#)

The following describes how to configure the VC110 video conferencing endpoint via the two methods above.

Detailed operation steps will be introduced in the feature section.

Web User Interface

You can customize your endpoint via web user interface. To access the web user interface, you need to know the user name and the administrator's password. The default user name is "admin" (case-sensitive), and the default password is "0000". You can also access the web user interface with user credential, which is disabled by default. For more information on how to enable the user credential, refer to [User Mode](#) on page 233.

The endpoint uses the HTTPS protocol to access the web user interface by default. For more information on the access protocol for web user interface access, refer to [Web Server Type](#) on page 235.

Log into the web user interface of the endpoint:


1. Enter the IP address (e.g., 192.168.0.10) in the address bar of a web browser on your computer, and then press the **Enter** key.
2. Enter the administrator user name and password.
3. Click **Login**.

After you log into the web user interface successfully, you can click **Logout** on the top right corner of the web interface to log out.

Administrator has full permission to access every menu in the web user interface. User can log

into the web user interface with user credentials.

The web structure tree of VC110 is shown as below, (the red highlight is hidden for users with user credentials):



You can monitor or place calls via web user interface. You can do the following in the **Home** page.

- Placing or ending calls
- Viewing remote and nearby sites
- Enabling the mute mode or the DND mode for a call
- Changing the video input source
- Adjusting the position and focus of the camera
- Saving the camera preset
- Capturing the video images
- Control the video conferencing endpoint remotely via the virtual remote control

Note

Although the web user interface is used to initiate the call, it is the video conferencing endpoint that is used for the call. It is not the PC running the web user interface.

Remote Control

You can use the remote control and display device to configure and use the VC110 video conferencing endpoint.


For more information on the function of each key on the remote control, refer to [VCR10 Remote Control](#) on page 31. The **Advanced** option is only accessible to the user with the administrator's permission. The default administrator password is "0000".

Remote Control via Web User Interface

In addition to using the remote control, you can also control the video conferencing endpoint via web user interface.

To control video conferencing endpoint via web user interface:

1. Click **Home**->**Remote Control** when the endpoint is idle or during a call.



2. Click the keys on the virtual remote control to control the video conferencing endpoint.
3. Click **Remote Control** to hide the virtual remote control.

Getting Started

This chapter provides basic information and installation instructions for Yealink VC110 endpoints in the following sections:

- [Endpoint Connection and Installation](#)
- [Powering the Endpoint On or Off](#)
- [Endpoint Initialization](#)
- [Endpoint Startup](#)
- [Setup Wizard](#)
- [Enabling Communication with Other Endpoints](#)
- [Placing a Test Call from the Yealink VC110 endpoint](#)

Endpoint Connection and Installation

Placing the Endpoint

Do not place the camera facing a window or other bright light. Ensure sufficient space to connect the cables. Ensure all participants are facing both the display device and the camera at the same time by putting camera and display device together.

Endpoint Components Installation

This section introduces the following:

- Connecting the VC110 video conferencing endpoint
- Installing the VC110 video conferencing endpoint
- Installing batteries in the remote control

Note

Up to two display devices can be connected to the VC110 all-in-one unit. Because the display device is not included in the package, you need to purchase it separately if required. Ensure that the purchased display device supports HDMI input.

When connecting only one display device to the VC110 all-in-one unit, Display1 port is the only available port. If dual screen mode is required, you can connect secondary display device to the Display2 port.


Because DVI cable is tailor-made, please use the Yealink-supplied DVI cable.

To prevent shock, do not connect the power adapter and turn on the power before connecting all endpoint components.


Connecting the VC110 Video Conferencing Endpoint

Do the following:

1. Locate the DVI port on the back of the VC110 all-in-one unit, and connect it to the DVI port of the cable hub with the supplied DVI cable.




2. Locate the Display1 port of the VC110 all-in-one unit, and connect it to the HDMI port on the display device with the supplied HDMI cable (Make sure the display device is powered on).



3. Locate the Internet port on the cable hub, and connect it to the port on the in-line power switch/hub with the supplied 2m Ethernet cable.
4. (Optional.) Locate the Audio In port of the cable hub, and do one of the following:
 - Connect it to the Audio Out port on the video conferencing phone with the 7.5m Ethernet cable that labeled Audio In, and then connect the free end of the expansion microphone cables to MIC ports on the video conferencing phone.
 - Connect it to the Audio Out port of the VCM30 video conferencing microphone array with the 7.5m Ethernet cable labeled Audio In.
5. (Optional.) Locate the PC port of the cable hub and connect it to the HDMI port on the PC with the supplied HDMI-VGA direct cable for sharing content.
6. Locate the DC19V port of the VC110 all-in-one unit, and connect it to an AC power outlet

with the supplied power adapter and power cord.

The cable hub also can be powered from a PoE-compliant switch or hub. For more information, refer to on [Power over Ethernet](#) on page 47.




You can fasten all cables with cable ties after all devices are connected.



Installing the VC110 Video Conferencing Endpoint

Installing the Cable Hub

You can hang the cable hub on the wall. To use this method, you need to purchase the screws (specification: T4×30) separately.




Installing the VC110 All-in-one Unit

You can choose to mount the VC110 all-in-one unit on your TV or a wall, depending on your actual needs.

a) Mounting the VC110 all-in-one unit on a TV

When the thickness of your TV is between 35-120 mm, you can mount the VC110 all-in-one unit on your TV.




Do the following:

1. Lock the VC110 all-in-one unit to the L-bracket.
2. Remove the protection of the Velcro.
3. Put the L-bracket on the top of the TV.
4. Make sure the back of the TV is clean, and then adjust the bracket to ensure close adhesion to the back of the TV with Velcro.

b) Mounting the VC110 all-in-one unit on a wall


You can also mount the VC110 all-in-one unit on a wall. The recommended height for VC110 all-in-one unit positioning is 1.5m-1.8m above the ground.

Do the following:




1. Punch holes into the wall and then insert the expansion bolts.
Installation location for the expansion bolts and punching requirement are shown above.
2. Lock the L-bracket with the M3×8 screws.
3. Move the setscrews on the L-bracket to the left holes.
4. Lock the L-bracket to the wall with T4×30 screws.

5. Connect one end of the DVI cable to the VC110 all-in-one unit and put the other end of the DVI cable through the L-bracket.



6. Lock the VC110 all-in-one unit to the L-bracket, and then connect the other end of the DVI cable to the cable hub.




Installing Batteries in the Remote Control

Do the following:

1. Open the battery cover on the back of the remote control.
2. Insert the batteries with the correct polarity.

3. Replace the battery cover.



Remote Control Battery Safety Information

- Never make wrong polarity connection when charging and discharging battery packs.
- Avoid crushing, puncturing, or putting a high degree of pressure on any battery, as this can cause an internal short-circuit, resulting in overheating.
- Remove the batteries if they are not in use for long period of time. Battery leakage and corrosion can damage the remote control, dispose batteries safely.
- Do not dispose used batteries in domestic waste. Dispose batteries at special collection points or return to stores if applies.
- Do not dispose batteries in a fire.

Powering the Endpoint On or Off

You have two options for power and network connections. Your system administrator will advise you which one to use.


- AC power (Optional)
- Power over Ethernet (PoE)

AC Power (Optional)

To connect the AC power:

1. Locate the DV12V port on the cable hub, and connect it to the electrical power outlet with the supplied power adapter.

2. Locate the Internet port on the cable hub, and connect it to the Internet port on the wall or on the switch/hub device with the supplied 2m Ethernet cable.



Note


The VC110 video conferencing endpoint should be used with Yealink original power adapter (12V/2A) only.

Power over Ethernet

With the included or a regular Ethernet cable, the VC110 video conferencing endpoint can be powered from a PoE-compliant switch or hub.

To connect the PoE:

1. Locate the Internet port on the cable hub, and connect it to the port on the in-line power switch/hub with the Ethernet cable.



Note

If in-line power is provided, you don't need to connect the cable hub to the power adapter. Make sure the switch/hub is PoE-compliant.

Important! Do not remove power from the cable hub while it is updating firmware and configurations.

Remove power to power off the endpoint if long time no use.

Endpoint Initialization

Once you have power on the endpoint, it will begin its initialization process.

During the initialization process, the following events take place:

Loading the ROM file

The ROM file sits in the flash memory of the endpoint. Endpoints come from the factory with a ROM file preloaded. During initialization, endpoints run a bootstrap loader that loads and executes the ROM file.

Configuring the VLAN

If the endpoint is connected to a switch, the switch will notify the endpoint about the VLAN information defined on the switch.

Querying the DHCP (Dynamic Host Configuration Protocol) Server

The endpoint is capable of querying a DHCP server. DHCP is enabled on the endpoint by default. The following network settings can be obtained from the DHCP server during initialization:

- IP Address
- Subnet Mask
- Gateway
- Primary DNS (Domain Name Server)
- Secondary DNS

You need to configure the network settings of the endpoint manually if any of them are not provided by the DHCP server. For more information on configuring network settings manually, refer to [Configuring Network Settings Manually](#) on page 61.

Endpoint Startup

After the initializing process, the endpoint will complete startup by cycling the following steps:

1. The LED indicator on the VC110 all-in-one unit illuminates solid green.
2. The display device displays the boot up screen.
3. The camera pans to the middle position automatically.
4. The display device displays the setup wizard (when you first start up, or reset the endpoint, the display device will display the setup wizard)

For more information on how to complete the setup wizard, refer to [Setup Wizard](#) on page 49.

5. After completing the setup wizard, the display device displays the main screen.

The main screen displays the following:

- Time and date

- Endpoint IP address and site name
 - Status icon
 - Soft key labels
 - Video image
6. The video conferencing phone starts up normally. The phone's LCD screen displays the site name, status icon, soft keys, time and date.

If the endpoint has successfully passed through these steps, it starts up correctly and is ready for use.


Setup Wizard


When you first start up or reset the endpoint, the display device will display the setup wizard.

To complete the setup wizard via the remote control:


1. Set the language displayed on the display device.



The default language is English.






2. Press  (Next soft key) to continue.
3. Set the date and time (e.g., set the time zone, time format, date format and the type of the daylight saving time).

The endpoint obtains the time and date from the NTP server automatically by default. You can also configure the time and date manually. For more information, refer to on [Date & Time](#) page 168.




4. Press  (**Next** soft key) to continue or press  (**Previous** soft key) to return to the previous screen.
5. Edit the site name.
The default site name is "Yealink VC110".



6. Press  (**Next** soft key) to continue or press  (**Previous** soft key) to return to the previous screen.
7. Change the administrator password.



The default administrator password is "0000". For security reasons, the administrator should change the default administrator password as soon as possible.




Note



Do remember the new administrator password or keep a copy of the password in a safe place. If you forget the password, you will need to reset the endpoint to the factory settings, and then reset the password or use the default password "0000".

For more information, refer to [Resetting to Factory](#) on page 257.

8. Press  (**Next** soft key) to continue or press  (**Previous** soft key) to return to the previous screen.


The display device displays firewall port mapping information.





9. Press  (**Next** soft key) to continue or press  (**Previous** soft key) to return to the previous screen.


10. Configure network settings.

The phone will try to contact a DHCP server in your network to obtain network parameters by default. If you uncheck the DHCP checkbox, you will need to configure IPv4 or IPv6 network manually. y. For more information, refer to [Configuring LAN Properties](#) on page 56.



11. Press  (**Next** soft key) to continue or press  (**Previous** soft key) to return to the previous screen.
12. (Optional.) Log into the Cloud platform.

Yealink video conferencing endpoint supports Yealink/StarLeaf/Zoom/Pexip/BlueJeans/Mind/Custom platform. For more information, refer to [Configuring Cloud Settings](#) on page 111.



13. Press  (Complete soft key) to complete the setup wizard.

Enabling Communication with Other Endpoints

- If you use Network Address Translation (NAT) to assign a public IP address to your VC110 endpoint for communication with devices outside your private network, you must enable NAT on your VC110 endpoint before placing calls. For more information, refer to [Network Address Translation](#) on page 89.
- If your VC110 endpoint communicates with other devices through a firewall, you must configure your firewall to allow incoming and outgoing traffic to the VC110 endpoint through the reserved ports specified in [Reserved Ports](#) on page 87. And the required ports specified in [Configuring the Endpoint for Use with a Firewall or NAT](#) on page 86. Users placing calls through a firewall to endpoints may experience one-way audio or video if the firewall is not properly configured.
- If you are using Cloud server in your environment to place calls, refer to [Configuring Cloud Settings](#) on page 111.
- If you are using Session Initiation Protocol (SIP) servers in your environment to place calls using the SIP protocol, refer to [Configuring SIP Settings](#) on page 132.
- If you are using H.323 gatekeepers in your environment and want to place calls using a name or extension with the H.323 protocol, refer to [Configuring H.323 Settings](#) on page 136.

Placing a Test Call from the Yealink VC110 endpoint

Yealink Demo1 to Yealink Demo3 are three default contacts stored in the local directory.

You can place a test call to the default contact, and the test call will be routed to the Yealink demo video conferencing endpoint. Yealink demo contacts can help users to test quickly whether the endpoint is normal after installation.

Configuring Network

This chapter provides information on how to configure network settings for the endpoint. Proper network settings allow the endpoint work efficiently in your network environment.

This chapter provides the following sections:

- [Preparing the Network](#)
- [Configuring LAN Properties](#)
- [Configuring Network Speed and Duplex Mode](#)
- [VLAN](#)
- [802.1X Authentication](#)
- [H.323 Tunneling](#)
- [Configuring the Endpoint for Use with a Firewall or NAT](#)
- [Intelligent Firewall Traversal](#)
- [Quality of Service](#)
- [VPN](#)

Preparing the Network

Before you begin configuring the network options, you must make sure your network is ready for video conferencing.

The following table lists the network information you need to obtain from the network administrator when preparing your network.

Type	Network Information
Type of system	DHCP
	Static IP Address <ul style="list-style-type: none"> • IP address • Subnet mask • Gateway
DNS Server	IP address of DNS server
Call Protocol	Register information of SIP account
	Register information of H.323 account
Cloud Server	Register information of Cloud platform

Type	Network Information
802.1X	Authentication information

Configuring LAN Properties

DHCP

DHCP (Dynamic Host Configuration Protocol) is a network protocol used to dynamically allocate network parameters to network hosts. The automatic allocation of network parameters to hosts eases the administrative burden of maintaining an IP network. The endpoint complies with the DHCP specifications documented in RFC 2131. DHCP by default, which allows the endpoint connected to the network to become operational by obtaining IP addresses and additional network parameters from the DHCP server.

DHCP Option

DHCP provides a framework for passing information to TCP/IP network devices. Network and other control information are carried in tagged data items that are stored in the options field of the DHCP message. The data items themselves are also called options.

DHCP can be initiated by simply connecting the endpoint to the network. The endpoint broadcasts DISCOVER messages to request network information carried in DHCP options. The DHCP server responds with the specific values in the corresponding options.

The following table lists the common DHCP options supported by the endpoint.

Parameter	DHCP Option	Description
Subnet Mask	1	Specifies the client's subnet mask.
Time Offset	2	Specifies the offset of the client's subnet in seconds from Coordinated Universal Time (UTC).
Router	3	Specifies a list of IP addresses for routers on the client's subnet.
Time Server	4	Specifies a list of time servers available to the client.
Domain Name Server	6	Specifies a list of domain name servers available to the client.
Log Server	7	Specifies a list of MIT-LCS UDP servers available to the client.
Host Name	12	Specifies the name of the client.
Domain Server	15	Specifies the domain name that client should use

Parameter	DHCP Option	Description
		when resolving hostnames via DNS.
Broadcast Address	28	Specifies the broadcast address in use on the client's subnet.
Network Time Protocol Servers	42	Specifies a list of the NTP servers available to the client by IP address.
Vendor-Specific Information	43	Identifies the vendor-specific information.
Vendor Class Identifier	60	Identifies the vendor type.
TFTP Server Name	66	Identifies a TFTP server when the 'name' field in the DHCP header has been used for DHCP options.
Bootfile Name	67	Identifies a bootfile when the 'file' field in the DHCP header has been used for DHCP options.

For more information on DHCP options, refer to
<http://www.ietf.org/rfc/rfc2131.txt?number=2131> or
<http://www.ietf.org/rfc/rfc2132.txt?number=2132>.

To make the endpoint gather network settings via DHCP options, you need to contact your network administrator to configure the DHCP server properly.

DHCP feature parameters on the endpoint are described below:

Parameter	Description	Configuration Method
DHCP	Enables or disables the endpoint to obtain network settings from the DHCP server. Default: Enabled Note: If you change this parameter, the endpoint will reboot to make the change take effect.	Remote Control Web User Interface
Host Name	Configures the host name of the endpoint. Default: Blank Note: When the endpoint broadcasts DHCP DISCOVER messages, it will report the configured host name to the DHCP	Web User Interface

Parameter	Description	Configuration Method
	<p>server via DHCP option 12. Host name is optional, so it is not a mandatory configuration item. For more information, contact your network administrator.</p> <p>If you change this parameter, the endpoint will reboot to make the change take effect.</p>	

To configure DHCP via web user interface:

1. Click on **Network->LAN Configuration**.
2. In the **IPv4 Config** block, mark the **DHCP** radio box.
3. (Optional.) Enter the host name of the endpoint in the **Host Name** field.

The screenshot shows the Yealink VC110 web interface. The top navigation bar includes 'About', 'Language', and 'Logout'. The main menu has 'Home', 'Status', 'Account', 'Network' (selected), 'Setting', 'Directory', and 'Security'. On the left, a sidebar shows 'LAN Configuration' (selected), 'NAT/Firewall', 'Advanced', and 'Diagnose'. The main content area is titled 'Internet Port' and shows 'IPv4/IPv6' set to 'IPv4'. Below this is the 'IPv4 Config' section. The 'DHCP' radio button is selected and highlighted with a red box. Below it are fields for 'IP Address', 'Subnet Mask', 'Gateway', 'Static DNS' (set to 'Off'), 'Primary DNS', and 'Secondary DNS'. At the bottom, the 'Host Name' field is set to 'VC110' and is also highlighted with a red box.

4. Click **Confirm** to accept the change.
A dialog box pops up to prompt that settings will take effect after a reboot.
5. Click **Confirm** to reboot the endpoint immediately.

To configure DHCP via the remote control:

1. Select **Menu->Advanced** (default password: 0000) ->**Internet Configuration->IPv4**.
2. Check the **DHCP** checkbox.
3. Press the **Save** soft key to accept the change.
The display device prompts "Reboot now?".
4. Select **OK** to reboot the endpoint immediately.

Static DNS

Even though DHCP is enabled, you can manually configure the static DNS address(es).

Parameters of static DNS on the endpoint are described below:

Parameter	Description	Configuration Method
Static DNS	<p>Triggers the static DNS feature to on or off.</p> <p>Default: Off</p> <p>Note: If it is set to Off, the endpoint will use the IPv4 DNS obtained from DHCP.</p> <p>If it is set to On, the endpoint will use manually configured static IPv4 DNS.</p> <p>It only works if the value of the "IPv4 Config" is set to DHCP. If you change this parameter, the endpoint will reboot to make the change take effect.</p>	<p>Remote Control</p> <p>Web User Interface</p>
Primary DNS	<p>Configures the primary IPv4 DNS server.</p> <p>Default: Blank</p> <p>Note: It only works if the value of the "Static IPv4 DNS" is set to On. If you change this parameter, the endpoint will reboot to make the change take effect.</p>	<p>Remote Control</p> <p>Web User Interface</p>
Secondary DNS	<p>Configures the secondary IPv4 DNS server.</p> <p>Default: Blank</p> <p>Note: It only works if the value of the "Static IPv4 DNS" is set to On. If</p>	<p>Remote Control</p> <p>Web User Interface</p>

Parameter	Description	Configuration Method
	you change this parameter, the endpoint will reboot to make the change take effect.	

To configure static DNS address when DHCP is used via web user interface:

1. Click on **Network->LAN Configuration**.
2. In the **IPv4 Config** block, mark the **DHCP** radio box.
3. In the **Static DNS** block, mark the **On** radio box.
4. Enter the desired values in the **Primary DNS** and **Secondary DNS** fields.

The screenshot shows the Yealink VC110 web interface. The top navigation bar includes links for About, Language, and Logout. The main menu has tabs for Home, Status, Account, Network (selected), Setting, Directory, and Security. On the left, a sidebar shows LAN Configuration, NAT/Firewall, Advanced, and Diagnose. The main content area is titled 'IPv4 Config' and shows the DHCP radio button selected. Below it, the Static DNS section is highlighted with a red box, showing the 'On' radio button selected, and the Primary DNS and Secondary DNS fields filled with the values 192.168.1.166 and 192.168.1.167 respectively. The Host Name field is filled with VC110. The IPv6 Config section is also visible below.

5. Click **Confirm** to accept the change.
A dialog box pops up to prompt that settings will take effect after a reboot.
6. Click **Confirm** to reboot the phone.

To configure static DNS when DHCP is used via the remote control:

1. Select **Menu->Advanced** (default password: 0000) ->**Internet Configuration->IPv4**.
2. Check the **DHCP** checkbox.
3. Check the **Static DNS** checkbox.
4. Enter the desired values in the **DNS Primary Server** and **DNS Secondary Server** fields respectively.
5. Press the **Save** soft key to accept the change.
The display device prompts "Reboot now?".

6. Select **OK** to reboot the endpoint immediately.

Configuring Network Settings Manually

If DHCP is disabled or the endpoint cannot obtain network settings from the DHCP server, you need to configure them manually.

The following parameters should be configured for endpoints to establish network connectivity:

- **IP Address:** Configure the endpoint to use the assigned IP address.
- **Subnet Mask:** Enter the subnet mask address when the endpoint does not automatically obtain the subnet mask.
- **Gateway:** A gateway is a network point that works as an entrance to another network.
- **Primary DNS /Secondary DNS:** Domain Name System (DNS) servers translates domain names (for example: www.example.com), which can be easily memorized by humans, to the numerical IP addresses (192.168.1.15) needed for the purpose of computer services and devices worldwide.

Network parameters need to be configured manually on the endpoint are described below.


Parameter	Description	Configuration Method
Mode (IPv4/IPv6)	Configures the IP address mode. Default: IPv4 Note: If you change this parameter, the IP phone will reboot to make the change take effect.	Remote Control Web User Interface
Static IP	Enables or disables the endpoint to use manually configured network settings. Default: Disabled Note: If you change this parameter, the endpoint will reboot to make the change take effect.	Web User Interface
IP Address	Configures the IP address assigned to the endpoint. Default: Blank Note: If you change this parameter, the endpoint will reboot to make the change take effect.	Remote Control Web User Interface
Subnet Mask	Configures the subnet mask assigned to the endpoint. Default: Blank	Remote Control Web User Interface

Parameter	Description	Configuration Method
	Note: If you change this parameter, the endpoint will reboot to make the change take effect.	
Gateway	Configures the gateway assigned to the endpoint. Default: Blank Note: If you change this parameter, the endpoint will reboot to make the change take effect.	Remote Control Web User Interface
Static DNS	Triggers the static DNS feature to on or off. Default: Off Note: If you change this parameter, the endpoint will reboot to make the change take effect.	Remote Control Web User Interface
Primary DNS	Configures the primary DNS server assigned to the endpoint. Default: Blank Note: If you change this parameter, the endpoint will reboot to make the change take effect.	Remote Control Web User Interface
Secondary DNS	Configures the secondary DNS server assigned to the endpoint. Default: Blank Note: If you change this parameter, the endpoint will reboot to make the change take effect.	Remote Control Web User Interface

To configure the IP address mode via web user interface:

1. Click on **Network->LAN Configuration**.

2. Select desired value from the pull-down list of **IPv4/IPv6**.



Yealink VC110 Home Status Account **Network** Setting Directory Security

LAN Configuration
NAT/Firewall
Advanced
Diagnose

Internet Port

IPv4/IPv6 IPv4

IPv4 Config

☒ DHCP
☐ Static IP

IP Address
Subnet Mask
Gateway


Static DNS ☒ On ☐ Off

Primary DNS 192.168.1.166
Secondary DNS 192.168.1.167
Host Name VC110

3. Click **Confirm** to accept the change.
A dialog box pops up to prompt that settings will take effect after a reboot.
4. Click **OK** to reboot the phone.

To configure a static IPv4 address via web user interface:

1. Click on **Network->LAN Configuration**.
2. In the **IPv4 Config** block, mark the **Static IP** radio box.
3. Enter the desired values in the **IP Address**, **Subnet Mask**, **Gateway**, **Primary DNS** and **Secondary DNS** fields.



Yealink VC110 Home Status Account **Network** Setting Directory Security

LAN Configuration
NAT/Firewall
Advanced
Diagnose

Internet Port

IPv4/IPv6 IPv4

IPv4 Config

☐ DHCP
☒ Static IP

IP Address 192.168.1.10
Subnet Mask 255.255.255.0
Gateway 192.168.1.254

Static DNS ☒ On ☐ Off

Primary DNS 192.168.1.166
Secondary DNS 192.168.1.167
Host Name VC110

4. Click **Confirm** to accept the change.
A dialog box pops up to prompt that settings will take effect after a reboot.
5. Click **Confirm** to reboot the endpoint immediately.

To configure the IP address mode via phone user interface:

1. Select **Menu->Advanced** (default password: 0000) ->**Internet Configuration**.
2. Select **IPv4** or **IPv4 & IPv6** from the **IP Mode** field.
3. Press the **Save** soft key to accept the change.
The IP phone reboots automatically to make settings effective after a period of time.

To configure a static IPv4 address via phone user interface:

1. Select **Menu->Advanced** (default password: 0000) ->**Internet Configuration->IPv4**.
2. Uncheck the **DHCP** checkbox.
3. Enter the desired values in the **IP Address**, **Subnet Mask**, **Gateway**, **DNS Primary Server** and **DNS Secondary Server** fields respectively.
4. Press the **Save** soft key to accept the change.
The display device prompts "Reboot now?".
5. Select **OK** to reboot the endpoint immediately.

IPv6 Support

Because Internet Protocol version 4 (IPv4) uses a 32-bit address, it cannot meet the increased demands for unique IP addresses for all devices that connect to the Internet. Therefore, Internet Protocol version 6 (IPv6) is the next generation network layer protocol, which designed as a replacement for the current IPv4 protocol.

IPv6 is developed by the Internet Engineering Task Force (IETF) to deal with the long-anticipated problem of IPv4 address exhaustion. Yealink IP Phone supports IPv4 addressing mode, IPv6 addressing mode, as well as an IPv4&IPv6 dual stack addressing mode. IPv4 uses a 32-bit address, consisting of four groups of three decimal digits separated by dots; for example, 192.168.1.100. IPv6 uses a 128-bit address, consisting of eight groups of four hexadecimal digits separated by colons; for example, 2026:1234:1:1:215:65ff:fe1f:caa.

VoIP network based on IPv6 can provide end-to-end security capabilities, enhanced Quality of Service (QoS), a set of service requirements to deliver performance guarantee while transporting traffic over the network.

If you configure the network settings on the phone for an IPv6 network, you can set up an IP address for the phone either by using SLAAC (ICMPv6), DHCPv6 or by manually entering an IP address. Ensure that your network environment supports IPv6. Contact your ISP for more information.

IPv6 Address Assignment Method

Supported IPv6 address assignment methods:

- **Manual Assignment:** An IPv6 address and other configuration parameters (e.g., DNS server) for the IP phone can be statically configured by an administrator.
- **Stateful DHCPv6:** The Dynamic Host Configuration Protocol for IPv6 (DHCPv6) has been standardized by the IETF through RFC 3315. DHCPv6 enables DHCP servers to pass configuration parameters such as IPv6 network addresses to IPv6 nodes. It offers the capability of automatic allocation of reusable network addresses and additional configuration flexibility. This protocol is a stateful counterpart to "IPv6 Stateless Address Autoconfiguration" ([RFC 2462](#)), and can be used separately or concurrently with the latter to obtain configuration parameters.

How the IP phone obtains the IPv6 address and network settings?

The following table lists where the IP phone obtains the IPv6 address and other network settings:

DHCPv6	How the IP phone obtains the IPv6 address and network settings?
Disabled	You have to manually configure the static IPv6 address and other network settings.
Enabled	The IP phone can obtain the IPv6 address and the other network settings via DHCPv6.

IPv6 Network parameters need to be configured manually on the endpoints are described below.

Parameter	Description	Configuration Method
Mode (IPv4/IPv6)	Configures the IP address mode. Default: IPv4 Note: If you change this parameter, the IP phone will reboot to make the change take effect.	Remote Control Web User Interface
Static IP	Enables or disables the endpoint to use manually configured IPv6 network settings. Default: Disabled Note: If you change this parameter, the endpoint will reboot to make the change take effect.	Remote Control Web User Interface
IP Address	Configures the IPv6 address assigned to the endpoint.	Remote Control Web User Interface

Parameter	Description	Configuration Method
	Default: Blank Note: If you change this parameter, the endpoint will reboot to make the change take effect.	
IPv6 prefix((0~128)	Configures the IPv6 prefix. Default: Blank Note: If you change this parameter, the endpoint will reboot to make the change take effect.	Remote Control Web User Interface
Gateway	Configures the IPv6 default gateway. Default: Blank Note: If you change this parameter, the endpoint will reboot to make the change take effect.	Remote Control Web User Interface
Static DNS/Static IPv6 DNS	Triggers the static IPv6 DNS feature to on or off. Default: Off Note: If you change this parameter, the endpoint will reboot to make the change take effect.	Remote Control Web User Interface
DNS Primary Server/Primary DNS	Configures the primary IPv6 DNS server. Default: Blank Note: If you change this parameter, the endpoint will reboot to make the change take effect.	Remote Control Web User Interface
DNS Secondary Server/Secondary DNS	Configures the secondary IPv6 DNS server. Default: Blank Note: If you change this parameter, the endpoint will reboot to make the change take effect.	Remote Control Web User Interface

To configure IPv6 address assignment method via web user interface:

1. Click on **Network->LAN Configuration**.
2. Select the desired IP mode (**IPv6** or **IPv4 & IPv6**) from the pull-down list of **IPv4/IPv6**.
3. In the **IPv6 Config** block, mark the **DHCP** or the **Static IP** radio box.

- If you mark the **Static IP** radio box, configure the IPv6 address and other configuration parameters in the corresponding fields.

The screenshot shows the Yealink VC110 Network Configuration page. The 'Network' tab is selected. Under 'IPv6 Config', the 'Static IP' radio button is selected and highlighted with a red box. The configuration fields within the red box are:

- IP Address: 2026:1234:1:1:215:65ff:fe
- IPv6 prefix((0~128): 64
- Gateway: 3036:1:1:c3c7:c11c:5447:
- Static IPv6 DNS: On (selected)
- Primary DNS: 3036:1:1:c3c7:c11c:5447:
- Secondary DNS: 2026:1234:1:1:c3c7:c11c:

- (Optional.) If you mark the **DHCP** radio box, you can configure the static DNS address in the corresponding fields.

The screenshot shows the Yealink VC110 Network Configuration page. Under 'IPv6 Config', the 'DHCP' radio button is selected. The 'Static IPv6 DNS' section is highlighted with a red box, showing the following configuration:


- Static IPv6 DNS: On (selected)
- Primary DNS: 3036:1:1:c3c7:c11c:5447:
- Secondary DNS: 2026:1234:1:1:c3c7:c11c:

4. Click **Confirm** to accept the change.

A dialog box pops up to prompt that the settings will take effect after a reboot.

5. Click **OK** to reboot the phone.

To configure IPv6 address assignment method via phone user interface:

1. Select **Menu->Advanced** (default password: 0000) ->**Internet Configuration**.
2. Select **IPv4 & IPv6** or **IPv6** from the **IP Mode** field.
3. Press **▲** or **▼** to highlight **IPv6** and press  .
4. Select the desired IPv6 address assignment method.

If you uncheck the **DHCP** checkbox, configure the IPv6 address and other network parameters in the corresponding fields.

5. Press the **Save** soft key to accept the change.

The IP phone reboots automatically to make settings effective after a period of time.

To configure static DNS when DHCP is used via phone user interface:

1. Select **Menu->Advanced** (default password: 0000) ->**Internet Configuration->IPv6**.
2. Check the **DHCP** checkbox.
3. Check the **Static DNS** checkbox.
4. Enter the desired values in the **DNS Primary Server** and **DNS Secondary Server** fields respectively.
5. Press the **Save** soft key to accept the change.
6. The display device prompts "Reboot now?".
7. Select **OK** to reboot the endpoint immediately.

Configuring Network Speed and Duplex Mode

You can configure the network speed and duplex mode the endpoint uses. The network speed and duplex mode you select for the endpoint must be supported by the switch. The network speeds and duplex modes supported by the endpoint are:

- Auto
- 10 Mbps Full Duplex
- 100 Mbps Full Duplex
- 10 Mbps Half Duplex
- 100 Mbps Half Duplex

Auto is configured on the endpoint by default.

Auto

Auto means that the switch will negotiate the network speed and duplex mode for the endpoints to transmit voice or data over Ethernet. This process entails devices first sharing transmission capabilities and then selecting the highest performance transmission mode

supported by both endpoints.

Half-duplex

Half-duplex transmission refers to transmitting voice or data in both directions, but in one direction at a time; this means one endpoint can send data on the line, but not receive data simultaneously.

Full-duplex

Full-duplex transmission refers to transmitting voice or data in both directions at the same time; this means one endpoint can send data on the line while also receiving data.

Parameter of network speed feature on the endpoint is described below:

Parameter	Description	Configuration Method
Network Speed	<p>Specifies the network speed and duplex mode for the endpoint to use.</p> <p>Default: Auto</p> <p>Note: If Auto is selected, the network speed and duplex mode will be negotiated by the switch automatically.</p> <p>The network speed and duplex mode you select must be supported by the switch.</p> <p>If you change this parameter, the endpoint will reboot to make the change take effect.</p>	Web User Interface

To configure the network speed via web user interface:

1. Click on **Network->Advanced**.

2. Select the desired value from the pull-down list of **Network Speed**.

The screenshot shows the Yealink VC110 web interface. The left sidebar has 'Advanced' selected. The top navigation bar has 'Network' highlighted. The main content area shows configuration options for Web Server, 802.1x, VPN, and Speed. The 'Speed' section at the bottom is highlighted with a red box, showing 'Network Speed' set to 'Auto'.

3. Click **Confirm** to accept the change.

A dialog box pops up to prompt that settings will take effect after a reboot.

4. Click **Confirm** to reboot the endpoint immediately.

VLAN

VLAN (Virtual Local Area Network) is used to divide a physical network logically into several broadcast domains. VLAN membership can be configured through software instead of physically relocating devices or connections. Grouping devices with a common set of requirements regardless of their physical location can greatly simplify network design. VLANs can address issues such as scalability, security, and network management.

The purpose of VLAN configurations on the endpoint is to insert a tag with VLAN information to the packets generated by the endpoint. When VLAN is configured on the endpoint properly, the endpoint will tag all packets with the VLAN ID. The switch receives and forwards the tagged packets to the corresponding VLAN according to the tag's VLAN ID, as described in IEEE Std 802.3.

In addition to manual configuration, the endpoint also supports automatic VLAN discovery via LLDP or DHCP. The assignment takes effect in the following order: assignment via LLDP, manual configuration, then assignment via DHCP.

For more information on VLAN, refer to [VLAN Feature on Yealink IP Phones](#).

LLDP

LLDP (Linker Layer Discovery Protocol) is a vendor-neutral Link Layer protocol, which allows the endpoint to receive and/or transmit device-related information from/to directly connected devices on the network that are also using the protocol, and store the information about other devices. LLDP transmits information as packets called LLDP Data Units (LLDPDUs). An LLDPDU consists of a set of Type-Length-Value (TLV) elements, each of which contains a particular type of information about the device or port transmitting it.

LLDP-MED (Media Endpoint Discovery)

LLDP-MED is published by the Telecommunications Industry Association (TIA). It is an extension to LLDP that operates between endpoint devices and network connectivity devices. LLDP-MED provides the following capabilities for the endpoint:

- Capabilities Discovery -- allows LLDP-MED endpoint to determine the capabilities that the connected switch supports and has enabled.
- Network Policy -- provides voice VLAN configuration to notify the endpoint which VLAN to use and QoS-related configuration for voice data. It provides a "plug and play" network environment.
- Power Management -- provides information related to how the endpoint is powered, power priority, and how much power the endpoint needs.
- Inventory Management -- provides a means to effectively manage the endpoint and its attributes, such as model number, serial number and software revision.

TLVs supported by the endpoint are summarized in the following table:

TLV Type	TLV Name	Description
Mandatory TLVs	Chassis ID	The network address of the endpoint.
	Port ID	The MAC address of the endpoint.
	Time To Live	Seconds until data unit expires. The default value is 180s.
	End of LLDPDU	Marks end of LLDPDU.
Optional TLVs	System Name	Name assigned to the endpoint. The default value is "VC110".
	System Description	Description of the endpoint. Description includes firmware version of the endpoint.
	System Capabilities	The supported and enabled endpoint capabilities. The Telephone capability is supported and

TLV Type	TLV Name	Description
		enabled by default.
	Port Description	Description of port that sends data unit. The default value is "WAN PORT".
IEEE Std 802.3 Organizationally Specific TLV	MAC/PHY Configuration/Status	Duplex mode and network speed settings of the endpoint. The Auto Negotiation is supported and enabled by default. The advertised capabilities of PMD. Auto-Negotiation is: 100BASE-TX (full duplex mode) 100BASE-TX (half duplex mode) 10BASE-T (full duplex mode) 10BASE-T (half duplex mode)
TIA Organizationally Specific TLVs	Media Capabilities	The MED device type of the endpoint and the supported LLDP-MED TLV type can be encapsulated in LLDPDU. The supported LLDP-MED TLV types are: LLDP-MED Capabilities, Network Policy, Extended Power via MDI-PD, Inventory.
	Network Policy	Port VLAN ID, application type, L2 priority and DSCP value.
	Extended Power-via-MDI	Power type, source, priority and value.
	Inventory - Hardware Revision	Hardware revision of the endpoint.
	Inventory - Firmware Revision	Firmware revision of the endpoint.
	Inventory - Software Revision	Software revision of the endpoint.
	Inventory - Serial Number	Serial number of the endpoint.
	Inventory - Manufacturer Name	Manufacturer name of the endpoint. The default value is "IP_Phone".
	Inventory - Model Name	Model name of the endpoint. The default value is "VC110".

TLV Type	TLV Name	Description
	Asset ID	Assertion identifier of the endpoint.

Parameters of LLDP feature on the endpoint are described below.

Parameter	Description	Configuration Method
LLDP->Active	Enables or disables LLDP feature on the endpoint. Default: Enabled Note: If you change this parameter, the endpoint will reboot to make the change take effect.	Remote Control Web User Interface
Packet Interval(1-3600s)	Configures the interval (in seconds) for the endpoint to send LLDP requests. Default: 60 Note: If you change this parameter, the endpoint will reboot to make the change take effect.	Remote Control Web User Interface

To configure LLDP via web user interface:

1. Click on **Network->Advanced**.
2. In the **LLDP** block, select the desired value from the pull-down list of **Active**.
3. Enter the desired time interval in the **Packet Interval (1-3600s)** field.

The screenshot shows the Yealink VC110 web interface. The top navigation bar includes 'About', 'Language', and 'Logout'. The main menu has 'Home', 'Status', 'Account', 'Network' (selected), 'Setting', 'Directory', and 'Security'. On the left, a sidebar lists 'LAN Configuration', 'NAT/Firewall', 'Advanced' (selected), and 'Diagnose'. The main content area shows the 'LLDP' configuration section, which is highlighted with a red box. It contains two fields: 'Active' with a dropdown menu set to 'Enabled', and 'Packet Interval(1-3600s)' with a text input field containing '60'. Below the LLDP section is the 'VLAN' section, which includes 'Internet Port' (dropdown set to 'Disabled'), 'VID(1-4094)' (text input set to '1'), and 'Priority' (dropdown set to '0').

4. Click **Confirm** to accept the change.
A dialog box pops up to prompt that the settings will take effect after a reboot.
5. Click **Confirm** to reboot the endpoint immediately.

To configure LLDP via the remote control:

1. Select **Menu->Advanced** (default password: 0000) -> **Advanced Network**.
2. In the **LLDP** block, check the **Active** checkbox.
3. Enter the desired value in the **Packet Interval (1-3600s)** field.
4. Press the **Save** soft key to accept the change.
The display device prompts "Reboot now?".
5. Select **OK** to reboot the endpoint immediately.

Manual Configuration for VLAN

VLAN is disabled on endpoints by default. You can configure VLAN manually. Before configuring VLAN on the endpoints, you need to obtain the VLAN ID from your network administrator.

Parameters of manual VLAN on the endpoint are described below.

Parameter	Description	Configuration Method
Internet Port->Active	Enables or disables VLAN for the Internet (WAN) port. Default: Disabled Note: If you change this parameter, the endpoint will reboot to make the change take effect.	Remote Control Web User Interface
VID(1-4094)	Configures VLAN ID for the Internet (WAN) port. Default: 1 Note: If you change this parameter, the endpoint will reboot to make the change take effect.	Remote Control Web User Interface
Priority	Configures VLAN priority for the Internet (WAN) port. Valid values: 0-7 7 is the highest priority, 0 is the lowest priority. Default: 0 Note: If you change this parameter, the endpoint will reboot to make the change take effect.	Remote Control Web User Interface

To configure VLAN for Internet port via web user interface:

1. Click on **Network->Advanced**.

2. In the **VLAN** block, select the desired value from the pull-down list of **Internet Port Active**.
3. Enter the VLAN ID in the **VID (1-4094)** field.
4. Select the desired value (0-7) from the pull-down list of **Priority**.

The screenshot shows the Yealink VC400 web interface. The top navigation bar includes links for About, Language, and Logout. Below this is a green header with the Yealink logo and navigation tabs: Home, Status, Account, Network (selected), Setting, Directory, and Security. On the left, a sidebar lists configuration categories: LAN Configuration, NAT/Firewall, Advanced (selected), and Diagnose. The main content area displays the 'VLAN' configuration. Under the 'VLAN' heading, the 'Internet Port' section is highlighted with a red box. It contains three fields: 'Active' (a dropdown menu set to 'Enabled'), 'VID(1-4094)' (a text input field containing '1'), and 'Priority' (a dropdown menu set to '0'). Below this, the 'DHCP VLAN' section is visible, with 'Active' set to 'Enabled' and 'Option' set to '132'. The 'LLDP' section above the VLAN settings shows 'Active' set to 'Enabled' and 'Packet Interval(1-3600s)' set to '60'.

5. Click **Confirm** to accept the change.
A dialog box pops up to prompt that the settings will take effect after a reboot.
6. Click **OK** to reboot the phone.

To configure VLAN via the remote control:

1. Select **Menu->Advanced** (default password: 0000) -> **Advanced Network**.
2. In the **VLAN** block, check the **Active** checkbox.
3. Enter the VLAN ID in the **VID(1-4094)** field.
4. Enter the priority value (0-7) in the **Priority** field.
5. Press the **Save** soft key to accept the change.
The display device prompts "Reboot now?".
6. Select **OK** to reboot the endpoint immediately.

DHCP VLAN

The endpoint supports VLAN discovery via DHCP. When the VLAN Discovery method is set to DHCP, the endpoint will examine the DHCP option for a valid VLAN ID. The predefined option 132 is used to supply the VLAN ID by default. You can customize the DHCP option used to request the VLAN ID.

Parameters of VLAN feature on the endpoint are described below.

Parameter	Description	Configuration Method
DHCP VLAN->Active	<p>Enables or disables the DHCP VLAN discovery feature on the endpoint.</p> <p>Default: Enabled</p> <p>Note: If you change this parameter, the endpoint will reboot to make the change take effect.</p>	Web User Interface
Option	<p>Configures the DHCP option from which the endpoint obtains the VLAN settings.</p> <p>You can configure at most five DHCP options and separate them by commas.</p> <p>Valid Values: 128-254</p> <p>Default: 132</p> <p>Note: If you change this parameter, the endpoint will reboot to make the change take effect.</p>	Web User Interface

To configure DHCP VLAN discovery via web user interface:

1. Click on **Network->Advanced**.
2. In the **VLAN** block, select the desired value from the pull-down list of **DHCP VLAN Active**.
3. Enter the desired option in the **Option** field.

The default option is 132.

The screenshot shows the Yealink VC110 web interface. The top navigation bar includes 'About', 'Language', and 'Logout'. The main menu has 'Home', 'Status', 'Account', 'Network' (selected), 'Setting', 'Directory', and 'Security'. The left sidebar shows 'LAN Configuration', 'NAT/Firewall', 'Advanced' (selected), and 'Diagnose'. The main content area is divided into sections: 'LLDP' (Active: Enabled, Packet Interval: 60), 'VLAN' (Internet Port: Disabled, VID: 1, Priority: 0), 'DHCP VLAN' (Active: Enabled, Option: 132), and 'QoS' (Audio Priority: 63, Video Priority: 34, Data Priority: 63). The 'DHCP VLAN' section is highlighted with a red rectangular box.

4. Click **Confirm** to accept the change.
A dialog box pops up to prompt that the settings will take effect after a reboot.
5. Click **Confirm** to reboot the endpoint immediately.

802.1X Authentication

IEEE 802.1X authentication is an IEEE standard for Port-based Network Access Control (PNAC), part of the IEEE 802.1 group of networking protocols. It offers an authentication mechanism for devices to connect to a LAN or WLAN. The 802.1X authentication involves three parties: a supplicant, an authenticator and an authentication server. The supplicant is the endpoint that wishes to attach to the LAN or WLAN. With 802.1X port-based authentication, the endpoint provides credentials, such as user name and default password, for the authenticator. The authenticator then forwards the credentials to the authentication server for verification. If the authentication server determines the credentials are valid, the endpoint is allowed to access resources located on the protected side of the network.

The endpoint supports the authentication protocols EAP-MD5, EAP-TLS, PEAP-MSCHAPv2 and EAP-TTLS/EAP-MSCHAPv2 for 802.1X authentication.

For more information on 802.1X authentication, refer to [Yealink 802.1X Authentication](#).

802.1X feature parameters on the endpoint are described below:

Parameter	Description	Configuration Method
802.1x Mode	<p>Specifies the 802.1x authentication mode.</p> <ul style="list-style-type: none"> • Disabled • EAP-MD5 • EAP-TLS • PEAP-MSCHAPv2 • EAP-TTLS/EAP-MSCHAPv2 <p>Default: Disabled</p> <p>Note: If you change this parameter, the endpoint will reboot to make the change take effect.</p>	<p>Remote Control</p> <p>Web User Interface</p>
Identity	<p>Configures the user name for 802.1x authentication.</p> <p>Note: If you change this parameter, the endpoint will reboot to make the change take effect.</p>	Web User Interface
MD5 Password	<p>Configures the password for 802.1x authentication.</p> <p>Note: If you change this parameter, the endpoint will reboot to make the change take effect.</p>	Web User Interface
CA Certificates	<p>Configures the access URL of the CA certificate when the 802.1x authentication mode is configured as EAP-TLS, PEAP-MSCHAPV2 or EAP-TTLS/EAP-MSCHAPV2.</p> <p>Note: If you change this parameter, the endpoint will reboot to make the change take effect.</p>	Web User Interface
Device Certificates	<p>Configures the access URL of the device certificate when the 802.1x authentication mode is configured as EAP-TLS.</p> <p>Note: If you change this parameter, the endpoint will reboot to make the change take effect.</p>	Web User Interface

To configure 802.1X via web user interface:

1. Click on **Network->Advanced**.
2. In the **802.1x** block, select the desired protocol from the pull-down list of **Mode 802.1x**.
 - a) If you select **EAP-MD5**:
 - 1) Enter the user name for authentication in the **Identity** field.
 - 2) Enter the password for authentication in the **MD5 Password** field.

The screenshot displays the Yealink VC110 web management interface. The top navigation bar includes links for About, Language, and Logout. The main menu on the left lists LAN Configuration, NAT/Firewall, Advanced (selected), and Diagnose. The central configuration area is divided into several sections:

- SNMP**: Includes fields for Active (Disabled), Port (161), and Trusted Address.
- Web Server**: Includes fields for HTTP (Enabled), HTTP Port (80), HTTPS (Enabled), and HTTPS Port (443).
- 802.1x**: This section is highlighted with a red rectangle. It contains:
 - 802.1x Mode**: A dropdown menu set to 'EAP-MD5'.
 - Identity**: A text field containing 'yealink'.
 - MD5 Password**: A text field filled with dots to mask the password.
- CA Certificates** and **Device Certificates**: Each has a file selection area with 'Browse...' and 'Upload' buttons.

- b) If you select **EAP-TLS**:
 - 1) Enter the user name for authentication in the **Identity** field.
 - 2) Leave the **MD5 Password** field blank.
 - 3) In the **CA Certificates** field, click **Browse** to locate the desired CA certificate (*.pem, *.crt, *.cer or *.der) from your local endpoint.
 - 4) In the **Device Certificates** field, click **Browse** to locate the desired client certificate (*.pem or *.cer) from your local endpoint.

- 5) Click **Upload** to upload the certificates.

The screenshot shows the Yealink VC110 web interface. The top navigation bar includes 'About', 'Language', and 'Logout'. The main navigation bar has 'Home', 'Status', 'Account', 'Network' (selected), 'Setting', 'Directory', and 'Security'. The left sidebar shows 'LAN Configuration', 'NAT/Firewall', 'Advanced' (selected), and 'Diagnose'. The main content area is divided into sections: 'SNMP' (Active: Disabled, Port: 161, Trusted Address: empty), 'Web Server' (HTTP: Enabled, HTTP Port: 80, HTTPS: Enabled, HTTPS Port: 443), and '802.1x' (highlighted with a red box). The '802.1x' section includes: '802.1x Mode' (EAP-TLS), 'Identity' (yealink), 'MD5 Password' (masked), 'CA Certificates' (C:\fakepath\ca.crt with 'Browse...' and 'Upload' buttons), and 'Device Certificates' (C:\fakepath\client.pem with 'Browse...' and 'Upload' buttons).

- c) If you select **PEAP-MSCHAPv2**:

- 1) Enter the user name for authentication in the **Identity** field.
- 2) Enter the password for authentication in the **MD5 Password** field.
- 3) In the **CA Certificates** field, click **Browse** to locate the desired certificate (*.pem, *.crt, *.cer or *.der) from your local endpoint.

- 4) Click **Upload** to upload the certificate.

The screenshot shows the Yealink VC110 web interface. The top navigation bar includes 'About', 'Language', and 'Logout'. The main menu has 'Home', 'Status', 'Account', 'Network' (selected), 'Setting', 'Directory', and 'Security'. The left sidebar shows 'LAN Configuration', 'NAT/Firewall', 'Advanced' (selected), and 'Diagnose'. The main content area is divided into sections: 'SNMP' with fields for 'Active' (Disabled), 'Port' (161), and 'Trusted Address'; 'Web Server' with fields for 'HTTP' (Enabled), 'HTTP Port' (80), 'HTTPS' (Enabled), and 'HTTPS Port' (443); and '802.1x' (highlighted with a red box) with fields for '802.1x Mode' (PEAP-MSCHAPv2), 'Identity' (yealink), 'MD5 Password' (masked), 'CA Certificates' (C:\fakepath\ca.crt), and 'Device Certificates' (empty). Each certificate field has 'Browse...' and 'Upload' buttons.

- d) If you select **EAP-TTLS/EAP-MSCHAPv2**:

- 1) Enter the user name for authentication in the **Identity** field.
- 2) Enter the password for authentication in the **MD5 Password** field.
- 3) In the **CA Certificates** field, click **Browse** to locate the desired certificate (*.pem, *.crt, *.cer or *.der) from your local endpoint.

- 4) Click **Upload** to upload the certificate.

The screenshot shows the Yealink VC110 web interface. The top navigation bar includes 'About', 'Language', and 'Logout'. The main menu has 'Home', 'Status', 'Account', 'Network' (selected), 'Setting', 'Directory', and 'Security'. The left sidebar shows 'LAN Configuration', 'NAT/Firewall', 'Advanced' (selected), and 'Diagnose'. The main content area is divided into 'SNMP' and 'Web Server' sections. The '802.1x' section is highlighted with a red box and contains the following fields:

802.1x	
802.1x Mode	EAP-TTLS/EAP-MSCHA
Identity	yealink
MD5 Password	••••••••
CA Certificates	C:\fakepath\ca.crt <input type="button" value="Browse..."/> <input type="button" value="Upload"/>
Device Certificates	<input type="text"/> <input type="button" value="Browse..."/> <input type="button" value="Upload"/>

3. Click **Confirm** to accept the change.
A dialog box pops up to prompt that the settings will take effect after a reboot.
4. Click **Confirm** to reboot the endpoint immediately.


To configure the 802.1X via the remote control:

1. Select **Menu->Advanced** (default password: 0000) -> **Advanced Network**.
2. Select the desired mode from the pull-down list of **802.1x Mode**.
3. Press the **Save** soft key to accept the change.
The display device prompts "Reboot now?".
4. Select **OK** to reboot the endpoint immediately.


H.323 Tunneling

The H.245 protocol is a control protocol that manages the media sessions. It is a part of the H.323 protocol suite. The H.245 protocol is used primarily to negotiate the master-slave relationship between communicating endpoints. The H.245 messages can be encapsulated and carried between H.225 controlled endpoints within H.225 messages. This way of "piggy-backing" an H.245 message to the H.225 message is referred to as H.323 Tunneling. The tunneling feature relies on H.225 endpoint-to-endpoint connectivity (via TCP) to pass H.245 messages, and uses the H.225 communication channel without creating a separate TCP socket connection (per H.323 call) for media control.

If H.323 tunneling feature is disabled, the setup processes of an H.323 call are shown below:



If H.323 tunneling feature is enabled on both sites, the setup processes of an H.323 call are shown below:



The parameter of the H.323 tunneling feature on the endpoint is described below:

Parameter	Description	Configuration Method
H.323 Tunneling	Enables or disables the H.323 tunneling on the endpoint. You can configure it for the StarLeaf Cloud platform or H.323 call separately. Default: Disabled	Remote Control Web User Interface

To configure the H.323 tunneling for StarLeaf Cloud platform via web user interface:

1. Click on **Account->Cloud**.
2. Select **StarLeaf** from the pull-down list of **Platform Type**.

3. Select the desired value from the pull-down list of **H.323 Tunneling**.

The screenshot shows the Yealink VC110 web interface. The top navigation bar includes 'About', 'Language', and 'Logout'. The main menu has 'Home', 'Status', 'Account', 'Network', 'Setting', 'Directory', and 'Security'. The left sidebar shows 'Cloud' selected, with sub-items 'H.323', 'SIP Account', 'SIP IP Call', and 'Codec'. The main content area is titled 'Cloud' and contains the following settings:

Register Status	Registered
Cloud Account	Enabled
Platform Type	StarLeaf
QCP Code	367037241953
Advanced Setting	
H.323 Tunneling	Disabled
H.235 Encryption	Disabled
Protocol Monitor Port	1720
DTMF Type	Auto
Local Early Media	Disabled
H.239	Enabled
FECC(H.323)	Enabled

4. Click **Confirm** to accept the change.

To configure H.323 tunneling for H.323 via web user interface:

1. Click on **Account->H.323**.
2. Select the desired value from the pull-down list of **H.323 Tunneling**.

The screenshot shows the Yealink VC110 web interface with the 'H.323' sub-menu selected. The main content area displays the following settings:

Register Status	Registered	
H.323 Protocol	Enabled	
H.323 Account	Enabled	
H.323 Name	9000	
H.323 Extension	9000	
Gatekeeper Mode	Manual	
Gatekeeper IP Address 1	10.2.1.43	Port 1719
Gatekeeper IP Address 2		Port 1719
Gatekeeper Authentication	Disabled	
Gatekeeper Username		
Gatekeeper Password	••••••••	
H.460 Active	Disabled	
H.323 Tunneling	Enabled	
H.235 Encryption	Disabled	
Protocol Monitor Port	1720	


3. Click **Confirm** to accept the change.

To configure H.323 tunneling via the remote control:

1. Select **Menu->Advanced** (default password: 0000) ->**H.323**.
2. Check the **H.323 Tunneling** checkbox.
3. Press the **Save** soft key to accept the change.

Configuring the Endpoint for Use with a Firewall or NAT

A firewall protects an organization's IP network by controlling data traffic from outside the network. Unless the firewall is designed to work with video conferencing equipment, you must configure the firewall to allow incoming and outgoing traffic to the VC110 endpoint through the reserved ports. Users placing calls through a firewall to endpoints may experience one-way audio or video if the firewall is not properly configured.



You must configure your firewall to allow incoming and outgoing traffic through the following ports:

Description	Port Range	Port Type
Gatekeeper	1719	UDP
H.323 signal port	1720	TCP
SIP (default transport protocol)	5060	UDP
SIP (when selecting the TCP transport protocol)	5060	TCP
SIP (when selecting the TLS transport protocol)	5061	TCP
Reserved ports of the endpoint. For more information, refer to Reserved Ports on page 87.	50000-50499 (default range)	TCP/UDP
Web management port (optional)	443	TCP

Reserved Ports

By default, the endpoint communicates through TCP and UDP ports in the 50000 - 54999 range for video, voice, presentations, and camera control. The endpoint uses only a small number of these ports during a call. The exact number depends on the number of participants in the call, the protocol used, and the number of ports required for the type of call: video or voice.

The following tables identify the number of ports required per connection by protocol and the type of call.

Required ports for an H.323 two-way call:

Call Type	Number of Required Ports
Video	8 UDP ports (6 if presentation is disabled) 2 TCP ports
Voice	2 UDP ports 2 TCP ports

Required ports for a SIP two-way call:

Call Type	Number of Required Ports
Video	8 UDP ports (6 if presentation is disabled)
Voice	2 UDP ports

The following table lists the number of UDP and TCP ports needed for the video conferencing endpoint. This information can help you to determine the range of port number to be entered in the **Reserved Port** field.

Endpoint	Maximum Connections	Required Ports for an H.323 Call		Required Ports for a SIP Call	
VC110	Two-way video call and a presentation and an audio call	10 UDP 4 TCP	50000-50009 50000-50003	10 UDP	50000-50009

Parameters for reserved ports on the endpoint are described below:

Parameter	Description	Configuration Method
UDP Port Scope	Configures the range of the UDP ports. Valid values: 1-65535 Default range: 50000-50499 Note: SIP and H.323 calls share the configured ports. If you change this parameter, the endpoint will reboot to make the	Remote Control Web User Interface

Parameter	Description	Configuration Method
	change take effect.	
TCP Port Scope	<p>Configures the range of the TCP ports.</p> <p>Valid values: 1-65535</p> <p>Default range: 50000-50499</p> <p>Note: SIP and H.323 calls share the configured ports.</p> <p>If you change this parameter, the endpoint will reboot to make the change take effect.</p>	<p>Remote Control</p> <p>Web User Interface</p>

To configure reserved ports via web user interface:

1. Click on **Network->NAT/Firewall**.
2. In the **Reserve Port** block, configure the UDP port range in the **UDP Port Scope** field.
3. In the **Reserve Port** block, configure the TCP port range in the **TCP Port Scope** field.

The screenshot shows the Yealink VC110 Web User Interface. The top navigation bar includes 'About', 'Language', and 'Logout'. The main menu has 'Home', 'Status', 'Account', 'Network' (selected), 'Setting', 'Directory', and 'Security'. On the left, a sidebar shows 'LAN Configuration', 'NAT/Firewall' (selected), 'Advanced', and 'Diagnose'. The main content area is titled 'NAT Configuration' and includes sections for 'Static NAT' (Disabled), 'NAT Public IP Address', 'Route Traversal' (Auto), 'STUN Config' (Active: Disabled, STUN Server: , STUN Port: 3478), 'Reserved Port' (highlighted with a red box), and 'Intelligent Firewall Traversal' (On). The 'Reserved Port' section contains two rows: 'UDP Port Scope' and 'TCP Port Scope', both with input fields showing '50000' and '50499' separated by a tilde (~).

4. Click **Confirm** to accept the change.
A dialog box pops up to prompt that the settings will be implemented after a reboot.
5. Click **Confirm** to reboot the endpoint immediately.

To configure reserved ports via the remote control:


1. Select **Menu->Advanced** (default password: 0000) -> **NAT/Firewall**.
2. In the **Reserved** block, configure the range of the UDP ports and TCP ports.

- 3. Press the **Save** soft key to accept the change.
The display device prompts "Reboot now?".
- 4. Select **OK** to reboot the endpoint immediately.

Network Address Translation

NAT device usually connects two networks together, and translates the private (not globally unique) addresses in the internal network into legal addresses. NAT can be configured to advertise only one address for the entire network to the outside world. This provides additional security by effectively hiding the entire internal network behind that address.

Multiple solutions for NAT traversal are available, for example, application layer gateway (ALG), simple traversal of UDP through NAT (STUN), and H.460 firewall traversal.



Static NAT

If NAT/Firewall devices do not support the ALG, VC110 video conferencing endpoint must be configured with the static NAT.

Static NAT defines a one-to-one mapping from one IP subnet to another IP subnet. The mapping includes destination IP address translation in one direction and source IP address translation in the reverse direction. From the NAT device, the original destination address is the virtual host IP address while the mapped-to address is the real host IP address.

If your endpoint is connected to a LAN that uses a NAT, you need to configure NAT Public IP Address so that your endpoint can communicate to WAN.

Note If H.460 firewall traversal is enabled on the endpoint, the endpoint will automatically ignore the static NAT settings for H.323 calls. For more information on H.460 firewall traversal, refer to on [H.460 Firewall Traversal](#) page 101.

Static NAT feature parameters on the endpoint are described below:

Parameter	Description	Configuration Method
Static NAT	<p>Specifies the static NAT type.</p> <ul style="list-style-type: none"> • Disabled—the endpoint does not use the NAT feature. • Manual—the endpoint uses the manually configured NAT public address. • Auto—the endpoint obtains the NAT public address from the Yealink-supplied server. <p>Default: Disabled</p>	<p>Remote Control</p> <p>Web User Interface</p>
NAT Public IP Address	<ul style="list-style-type: none"> • Displays the NAT public address automatically obtained from the Yealink-supplied server if the static NAT is set to Auto. • Configures the NAT public address for the endpoint if the static NAT is set to Manual. 	<p>Remote Control</p> <p>Web User Interface</p>
Route Traversal	<p>Configures the route traversal type.</p> <ul style="list-style-type: none"> • Auto—NAT works only when making a call to public network or receiving a call from the public network. • Compulsory—NAT works when you are in multi-level intranet network to solve the one-way audio or video problem. <p>Default: Auto</p>	<p>Web User Interface</p>
NAT Traversal	<p>Configures the NAT traversal type. You can configure it for the SIP account or SIP IP call separately.</p> <ul style="list-style-type: none"> • Disabled • STUN • StaticNat <p>Default: Disabled</p>	<p>Web User Interface</p>

Parameter	Description	Configuration Method
	Note: Static NAT works only if this parameter is set to StaticNat.	

To configure static NAT via web user interface:

1. Click on **Network->NAT/Firewall**.
2. Select the desired value from the pull-down list of **Static NAT**.
3. Configure the NAT public address in the **NAT Public IP Address** field if **Manual** is selected from the pull-down list of **Static NAT**.
4. If multi-level intranet network has deployed in your environment, and you experience the one-way audio or video problem, select **Compulsory** from the pull-down list of **Route Traversal** to solve this problem.

5. Click **Confirm** to accept the change.

To configure Static NAT for SIP account via web user interface:

1. Click on **Account->SIP Account**.

2. Select **StaticNat** from the pull-down list of **NAT Traversal**.

The screenshot shows the Yealink VC110 web interface with the 'Account' tab selected. The left sidebar contains a menu with 'SIP Account' highlighted. The main content area displays various configuration fields. The 'NAT Traversal' field at the bottom is highlighted with a red rectangular box, and its dropdown menu is open, showing 'StaticNat' as the selected option.

Field	Value
Register Status	Registered
SIP Account	Enabled
Username	9000
Register Name	9000
Password	••••••••
Server Host	10.2.1.48
Port	5060
Enable Outbound Proxy Server	Disabled
Outbound Proxy Server	
Port	5060
Transport	UDP
Server Expires	3600
SRTP	Disabled
DTMF Type	RFC2833
DTMF Info Type	DTMF-Relay
DTMF Payload Type (96~127)	101
NAT Traversal	StaticNat

3. Click **Confirm** to accept the change.

To configure Static NAT for SIP IP call via web user interface:

1. Click on **Account->SIP IP Call**.
2. Select **StaticNat** from the pull-down list of **NAT Traversal**.

The screenshot shows the Yealink VC110 web interface with the 'SIP IP Call' configuration page. The left sidebar contains a menu with 'SIP IP Call' highlighted. The main content area displays various configuration fields. The 'NAT Traversal' field is highlighted with a red rectangular box, and its dropdown menu is open, showing 'StaticNat' as the selected option.

Field	Value
SIP IP Call	Enabled
Transport	TCP
SRTP	Disabled
DTMF Type	RFC2833
DTMF Info Type	DTMF
DTMF Payload Type (96~127)	101
NAT Traversal	StaticNat
RPort	Enabled
BFCP	Enabled
FECC(SIP)	Enabled

3. Click **Confirm** to accept the change.

To configure static NAT via the remote control:

1. Select **Menu->Advanced** (default password: 0000) -> **NAT/Firewall**.
2. Select the desired value from the pull-down list of **Type**.


3. Configure the NAT public address in the **Public IP Address** field if **Manual Settings** is selected from the pull-down list of **Type**.
4. Press the **Save** soft key to accept the change.

To configure static NAT for SIP IP call via the remote control:

1. Select **Menu->Advanced** (default password: 0000) -> **SIP IP Call**.
2. Select **StaticNat** from the pull-down list of **NAT Traversal**.
3. Press the **Save** soft key to accept the change.

STUN

STUN is a network protocol, used in NAT traversal for applications of real-time voice, video, messaging, and other interactive IP communications. The STUN protocol allows entities behind a NAT to first discover the presence of a NAT and the type of NAT (for more information on the NAT types, refer to [NAT Types](#) on page 96.) and to obtain the mapped (public) IP address and port number that the NAT has allocated for the UDP connections to remote parties. The protocol requires assistance from a third-party network server (STUN server) usually located on public Internet. The IP phone can be configured to work as a STUN client, to send exploratory STUN messages to the STUN server. The STUN server uses those messages to determine the public IP address and port used, and then informs the client. For more information, refer to [RFC3489](#).



Capturing packets after you enable the STUN feature, you can find that the VC110 video conferencing endpoint sends Binding Request to the STUN server, and then mapped IP address and port is placed in the Binding Response: Binding Success Response MAPPED-ADDRESS: 59.61.92.59:19232.

No.	Time	Source	Destination	Protocol	Length	Info
444	18.587848	192.168.1.6	218.107.220.74	STUN	62	Binding Request
447	18.711349	218.107.220.74	192.168.1.6	STUN	98	Binding Success Response MAPPED-ADDRESS: 59.61.92.59:19232

STUN feature parameters on the endpoint are described below:

Parameter	Description	Configuration Method
Active	Enables or disables the STUN (Simple Traversal of UDP over NATs)	Remote Control Web User Interface

Parameter	Description	Configuration Method
	feature on the endpoint. Default: Disabled	
STUN Server	Configures the IP address or the domain name of the STUN (Simple Traversal of UDP over NATs) server. Default: Blank	Remote Control Web User Interface
STUN Port	Configures the port of the STUN (Simple Traversal of UDP over NATs) server. Default: 3478	Remote Control Web User Interface
NAT Traversal	Configures the NAT traversal type. You can configure it for the SIP account or SIP IP call separately. <ul style="list-style-type: none">• Disabled• STUN• StaticNat Default: Disabled Note: STUN works only if this parameter is set to STUN.	Web User Interface

To configure STUN server via web user interface:

1. Click on **Network->NAT/Firewall**.
2. In the **STUN Config** block, select the desired value from the pull-down list of **Active**.
3. Enter the IP address or the domain name of the STUN server in the **STUN Server** field.

- Enter the port of the STUN server in the **Port** field.

Yealink VC110 Home Status Account **Network** Setting Directory Security

LAN Configuration
NAT/Firewall
Advanced
Diagnose

NAT Configuration

Static NAT: Manual

NAT Public IP Address: 117.28.234.34

Route Traversal: Auto

STUN Config

Active: Enabled

STUN Server: 218.107.220.201

STUN Port: 3478

Reserved Port

UDP Port Scope: 50000 ~ 50499

TCP Port Scope: 50000 ~ 50499

Intelligent Firewall Traversal

Intelligent Firewall Traversal: On

- Click **Confirm** to accept the change.

To configure STUN for SIP account via web user interface:

- Click on **Account->SIP Account**.
- Select **STUN** from the pull-down list of **NAT Traversal**.

Yealink VC110 Home Status **Account** Network Setting Directory Security

Cloud
H323
SIP Account
SIP IP Call
Codec

Register Name: 9000

Password:

Server Host: 10.2.1.48 Port: 5060

Enable Outbound Proxy Server: Disabled

Outbound Proxy Server: Port: 5060

Transport: UDP

Server Expires: 3600

SRTP: Disabled

DTMF Type: RFC2833

DTMF Info Type: DTMF-Relay

DTMF Payload Type (96~127): 101

NAT Traversal: STUN

Keep Alive Interval: 30

RPort: Enabled

BFCP: Disabled

FECC(SIP): Disabled

3. Click **Confirm** to accept the change.

To configure STUN for SIP IP call via web user interface:

1. Click on **Account->SIP IP Call**.
2. Select **STUN** from the pull-down list of **NAT Traversal**.

The screenshot shows the Yealink VC110 web interface. The top navigation bar includes 'About', 'Language', and 'Logout'. The main menu has 'Home', 'Status', 'Account', 'Network', 'Setting', 'Directory', and 'Security'. The 'Account' menu is expanded, showing 'Cloud', 'H323', 'SIP Account', 'SIP IP Call' (selected), and 'Codec'. The 'SIP IP Call' configuration page displays various settings: 'SIP IP Call' (Enabled), 'Transport' (TCP), 'SRTP' (Disabled), 'DTMF Type' (RFC2833), 'DTMF Info Type' (DTMF), 'DTMF Payload Type (96~127)' (101), 'NAT Traversal' (STUN, highlighted with a red box), 'RPort' (Enabled), 'BFCP' (Enabled), and 'FECC(SIP)' (Enabled).

3. Click **Confirm** to accept the change.

To configure STUN server via the remote control:

1. Select **Menu->Advanced** (default password: 0000) -> **NAT/Firewall**.
Mark the **ON** radio box in the **STUN Active** field.
2. Enter the IP address or the domain name of the STUN server in the **STUN Server** field.
3. Enter the port of the STUN server in the **Port** field.
4. Press the **Save** soft key to accept the change.

To configure STUN server for SIP IP call via the remote control:

1. Select **Menu->Advanced** (default password: 0000) -> **SIP IP Call**.
2. Select **STUN** from the pull-down list of **NAT Traversal**.
3. Press the **Save** soft key to accept the change.

NAT Types

Full Cone:

A full cone NAT is one where all requests from the same internal IP address and port are mapped to the same external IP address and port. Furthermore, any external host can send a packet to the internal host, by sending a packet to the mapped external address.

Restricted Cone:

A restricted cone NAT is one where all requests from the same internal IP address and port are mapped to the same external IP address and port. Unlike a full cone NAT, an external host (with IP address X) can send a packet to the internal host only if the internal host had previously sent a packet to IP address X.

Port Restricted Cone:

A port restricted cone NAT is like a restricted cone NAT, but the restriction includes port numbers. Specifically, an external host can send a packet, with source IP address X and source port P, to the internal host only if the internal host had previously sent a packet to IP address X and port P.

Symmetric:

A symmetric NAT is one where all requests from the same internal IP address and port, to a specific destination IP address and port, are mapped to the same external IP address and port. If the same host sends a packet with the same source address and port, but to a different destination, a different mapping is used. Furthermore, only the external host that receives a packet can send a UDP packet back to the internal host.

Keep Alive

The endpoint can send keep-alive packets to NAT device for keeping the communication port open.

The Keep alive interval parameter on the endpoint is described below:

Parameter	Description	Configuration Method
Keep Alive Interval	<p>Configures the interval (in seconds) that the endpoint sends keep-alive packets to the NAT device. The packet is used to keep the communication port open, so that NAT can continue to effect.</p> <p>You can configure it for the Zoom/Pexip/BlueJeans/Mind/Custom platform or SIP account separately.</p> <p>Default: 30</p> <p>Note: You cannot configure it for the Yealink/StarLeaf Cloud platform.</p>	Web User Interface

To configure the keep-alive interval for Zoom/Pexip/BlueJeans/Mind/Custom platform via web user interface:

1. Click on **Account->Cloud**.
2. Select **Zoom/Pexip/BlueJeans/Mind/Custom** from the pull-down list of **Platform Type**.
3. Enter the keep alive interval in the **Keep Alive Interval** field.

The screenshot shows the Yealink VC110 web interface. The top navigation bar includes 'About', 'Language', and 'Logout'. The main menu has 'Home', 'Status', 'Account' (selected), 'Network', 'Setting', 'Directory', and 'Security'. On the left, a sidebar shows 'Cloud' selected, with options for 'H.323', 'SIP Account', 'SIP IP Call', and 'Codec'. The main content area is titled 'Cloud' and shows the 'Register Status' as 'Registered'. Under 'Cloud Account', 'Cloud Account' is 'Enabled', 'Platform Type' is 'Zoom', and 'Server Host' is 'zoomcrc.com'. The 'Advanced Setting' section includes 'Transport' (TCP), 'Server Expires' (3600), 'SRTP' (Disabled), 'DTMF Type' (RFC2833), 'DTMF Info Type' (DTMF-Relay), 'DTMF Payload Type (96~127)' (101), 'Keep Alive Interval' (30, highlighted with a red box), 'BFCP' (Enabled), and 'FECC(SIP)' (Enabled).

4. Click **Confirm** to accept the change.

To configure the keep-alive interval for SIP account via web user interface:

1. Click on **Account->SIP Account**.

2. Enter the keep alive interval in the **Keep Alive Interval** field.

The screenshot shows the Yealink VC110 web interface. The top navigation bar includes 'About', 'Language', and 'Logout'. Below this is a green header with 'Yealink VC110' and tabs for 'Home', 'Status', 'Account' (selected), 'Network', 'Setting', 'Directory', and 'Security'. On the left, a sidebar lists configuration categories: 'Cloud', 'H323', 'SIP Account' (selected), 'SIP IP Call', and 'Codec'. The main content area displays the 'SIP Account' configuration form. Fields include 'Register Name' (9000), 'Password' (masked), 'Server Host' (10.2.1.48), 'Port' (5060), 'Enable Outbound Proxy Server' (Disabled), 'Outbound Proxy Server' (empty), 'Port' (5060), 'Transport' (UDP), 'Server Expires' (3600), 'SRTP' (Disabled), 'DTMF Type' (RFC2833), 'DTMF Info Type' (DTMF-Relay), 'DTMF Payload Type (96~127)' (101), 'NAT Traversal' (Disabled), 'Keep Alive Interval' (30, highlighted with a red box), 'RPort' (Enabled), 'BFCP' (Disabled), and 'FECC(SIP)' (Disabled).

3. Click **Confirm** to accept the change.

Rport

Rport in [RFC 3581](#), allows a client to request that the server sends the response back to the source port from which the request came. Rport feature depends on support from a SIP server.

The rport parameter on the endpoint is described below:

Parameter	Description	Configuration Method
RPort	Enables or disables NAT Rport feature. You can configure it for the SIP account or SIP IP call separately. Default: Enabled	Web User Interface

To configure rport feature for SIP account via web user interface:

1. Click on **Account->SIP Account**.

2. Select the desired value from the pull-down list of **RPort**.

The screenshot shows the Yealink VC110 web interface. The top navigation bar includes 'About', 'Language', and 'Logout'. Below it, a green bar contains 'Yealink VC110' and tabs for 'Home', 'Status', 'Account', 'Network', 'Setting', 'Directory', and 'Security'. The 'Account' tab is selected. On the left, a sidebar lists 'Cloud', 'H323', 'SIP Account', 'SIP IP Call', and 'Codec'. The 'SIP Account' option is highlighted. The main content area displays various settings for the SIP account, including 'Register Name' (9000), 'Password' (masked), 'Server Host' (10.2.1.48), 'Port' (5060), 'Enable Outbound Proxy Server' (Disabled), 'Outbound Proxy Server' (empty), 'Transport' (UDP), 'Server Expires' (3600), 'SRTP' (Disabled), 'DTMF Type' (RFC2833), 'DTMF Info Type' (DTMF-Relay), 'DTMF Payload Type (96~127)' (101), 'NAT Traversal' (Disabled), 'Keep Alive Interval' (30), 'RPort' (Enabled), 'BFCP' (Disabled), and 'FECC(SIP)' (Disabled). The 'RPort' dropdown menu is highlighted with a red box.

3. Click **Confirm** to accept the change.

To configure rport feature for SIP IP call via web user interface:

1. Click on **Account**->**SIP IP Call**.
2. Select the desired value from the pull-down list of **RPort**.

The screenshot shows the Yealink VC110 web interface with the 'SIP IP Call' settings page. The top navigation bar and the 'Account' tab are the same as in the previous screenshot. In the sidebar, 'SIP IP Call' is now highlighted. The main content area displays settings for SIP IP Call, including 'SIP IP Call' (Enabled), 'Transport' (TCP), 'SRTP' (Disabled), 'DTMF Type' (RFC2833), 'DTMF Info Type' (DTMF), 'DTMF Payload Type (96~127)' (101), 'NAT Traversal' (Disabled), 'RPort' (Enabled), 'BFCP' (Enabled), and 'FECC(SIP)' (Enabled). The 'RPort' dropdown menu is highlighted with a red box.

3. Click **Confirm** to accept the change.

H.460 Firewall Traversal


H.323 includes signaling based on TCP, while the STUN solution cannot realize the NAT traversal of TCP. Before the emergence of H.460, Enterprises have their own firewall/NAT traversal solutions, which are incompatible with each other. Therefore, IP communication between enterprises is difficult. H.460 resolves the compatibility problem.

H.460 enables H.323 signaling and media to traverse firewall. H.460 is a set of extensions to the ITU H.323 standard that include methods to traverse firewalls. Devices that use H.460, implement a set of security policies that a firewall is configurable to accept. Therefore using H.460, video conferencing endpoints can communicate across a firewall. You can configure the endpoint to use standard-based H.460.18 and H.460.19 firewall traversal, which allows the endpoint to establish IP connections across firewalls more easily.

The H.460.18 deals with signaling. The H.460.18 solution perpetually hunts in order to open pinholes from the internal network to the external one. Without using the H.460.18 solution, which permits the gatekeeper to open a connection, the external device could not communicate with internal device, because the firewall would obstruct its attempt to setup a call. H.460.19 extends H.323 by defining the NAT/firewall mechanism for media. In addition, H.460.19 provides a solution for opening RTP and RTCP pinholes and a method for maintaining them using a keep-alive mechanism.

To use H.460, you need to deploy a Traversal Server (TS) at public network.

The following illustration shows how a H.460 traversal server works between two enterprise locations.



The H.460 firewall traversal parameter is described below:

Parameter	Description	Configuration Method
H.460 Active	Enables or disables H.460 firewall traversal feature on the endpoint. Default: Disabled	Remote Control Web User Interface

To configure H.460 firewall traversal for H.323 via web user interface:

1. Click on **Account->H.323**.

2. Select the desired value from the pull-down list of **H.460 Active**.

The screenshot shows the Yealink VC110 web interface. The top navigation bar includes 'About', 'Language', and 'Logout'. The main menu has 'Home', 'Status', 'Account' (selected), 'Network', 'Setting', 'Directory', and 'Security'. On the left, a sidebar lists 'Cloud', 'H323' (selected), 'SIP Account', 'SIP IP Call', and 'Codec'. The main content area displays 'Register Status' as 'Registered'. Below this, various settings are listed: 'H323 Protocol' (Enabled), 'H.323 Account' (Enabled), 'H.323 Name' (9000), 'H.323 Extension' (9000), 'Gatekeeper Mode' (Manual), 'Gatekeeper IP Address 1' (10.2.1.43) with Port 1719, 'Gatekeeper IP Address 2' (empty) with Port 1719, 'Gatekeeper Authentication' (Disabled), 'Gatekeeper Username' (empty), 'Gatekeeper Password' (masked with dots), 'H.460 Active' (Disabled, highlighted with a red box), 'H.323 Tunneling' (Disabled), 'H235 Encryption' (Disabled), and 'Protocol Monitor Port' (1720).

3. Click **Confirm** to accept the change.

To configure H.460 firewall traversal via the remote control:

1. Select **Menu->Advanced** (default password: 0000) -> **H.323**.
2. Check the **H.460** checkbox.
3. Press the **Save** soft key to accept the change.

Intelligent Firewall Traversal

The video conferencing endpoint can provide efficiency and continuous communication for both the head office and a branch office.

In some cases, the head office is in the WAN and lacks a VPN network, while the branch office is the LAN, and no port mapping is configured on its firewall. You can enable the intelligent firewall traversal feature, so that the head office can share content with branch office, or control the camera of branch office.

The intelligent firewall traversal parameter is described below:

Parameter	Description	Configuration Method
Intelligent Firewall Traversal	Enables or disables the intelligent firewall traversal feature on the endpoint. Default: Disabled	Web User Interface

To configure intelligent firewall traversal via web user interface:

1. Click on **Network->NAT/Firewall**.
2. Select the desired value from the pull-down list of **Intelligent Firewall Traversal**.

The screenshot shows the Yealink VC110 web interface. The top navigation bar includes links for About, Language, and Logout. The main menu has tabs for Home, Status, Account, Network (selected), Setting, Directory, and Security. On the left sidebar, there are links for LAN Configuration, NAT/Firewall (selected), Advanced, and Diagnose. The main content area is titled 'NAT Configuration' and contains several sections: 'Static NAT' with a 'Disabled' dropdown, 'NAT Public IP Address' with an empty text field, 'Route Traversal' with an 'Auto' dropdown, 'STUN Config' with 'Active' set to 'Disabled', 'STUN Server' and 'STUN Port' (3478) text fields, 'Reserved Port' with 'UDP Port Scope' and 'TCP Port Scope' both set to '50000 ~ 50499', and 'Intelligent Firewall Traversal' with a dropdown menu set to 'On'. The 'Intelligent Firewall Traversal' dropdown is highlighted with a red rectangular box.

3. Click **Confirm** to accept the change.

Quality of Service

Quality of Service (QoS) is the ability to provide different priorities for different packets in the network. This allows the transport of traffic with special requirements. QoS guarantees are important for applications that require a fixed bit rate and are delay sensitive when the network capacity is insufficient. There are four major QoS factors to be considered when configuring a modern QoS implementation: bandwidth, delay, jitter and loss.

QoS provides a better network service through the following features:

- Supporting dedicated bandwidth
- Improving loss characteristics
- Avoiding and managing network congestion
- Shaping network traffic
- Setting traffic priorities across the network

The Best-Effort service is the default QoS model in the IP networks. It provides no guarantees for data delivery, which means delay, jitter, packet loss and bandwidth allocation are unpredictable. Differentiated Services (DiffServ or DS) is the most widely used QoS model. It provides a simple and scalable mechanism for classifying and managing network traffic and providing QoS on modern IP networks. Differentiated Services Code Point (DSCP) is used to define DiffServ classes

and is stored in the first six bits of the ToS (Type of Service) field. Each router on the network can provide QoS simply based on the DiffServ class. The DSCP value ranges from 0 to 63 with each DSCP specifying a particular per-hop behavior (PHB) applicable to a packet. A PHB refers to the packet scheduling, queuing, policing, or shaping behavior of a node on any given packet.

Four standard PHBs available to construct a DiffServ-enabled network and achieve QoS:

- **Class Selector PHB** – backwards compatible with IP precedence. Class Selector code points are of the form “xxx000”. The first three bits are the IP precedence bits. These class selector PHBs retain almost the same forwarding behavior as nodes that implement IP precedence-based classification and forwarding.
- **Expedited Forwarding PHB** – the key ingredient in DiffServ model for providing a low-loss, low-latency, low-jitter and assured bandwidth service.
- **Assured Forwarding PHB** – defines a method by which BAs (Bandwidth Allocations) can be given different forwarding assurances.
- **Default PHB** – specifies that a packet marked with a DSCP value of “000000” gets the traditional best effort service from a DS-compliant node.

VoIP is extremely bandwidth and delay-sensitive. QoS is a major issue in VoIP implementations, with regard to guaranteeing how that packet traffic is not delayed or dropped due to interference from other lower priority traffic. VoIP can guarantee high-quality QoS only if the voice, video and data packets are given priority over other kinds of network traffic. Yealink video conferencing endpoints support the DiffServ model of QoS. DSCPs for voice, video and data packets that can be specified respectively.

Voice QoS

To make VoIP transmissions intelligible to receivers, voice packets should not be dropped, excessively delayed, or made to suffer varying delay. DiffServ model can guarantee high-quality voice transmission when the voice packets are configured to a higher DSCP value.

Video QoS

To ensure acceptable visual quality for video, video packets emanated from the endpoint should be configured with a high transmission priority.

Data QoS

To ensure good call quality, data packets (e.g., SIP signaling and H.225 call signaling) emanated from the endpoint should be configured with a high transmission priority.

QoS feature parameters on the endpoint are described below.

Parameter	Description	Configuration Method
Audio Priority	Specifies the DSCP value for voice packets. Valid Values: 0-63	Remote Control Web User Interface

Parameter	Description	Configuration Method
	Default: 63 Note: If you change this parameter, the endpoint will reboot to make the change take effect.	
Video Priority	Specifies the DSCP value for video packets. Valid Values: 0-63 Default: 34 Note: If you change this parameter, the endpoint will reboot to make the change take effect.	Remote Control Web User Interface
Data Priority	Specifies the DSCP value for data packets. Valid Values: 0-63 Default: 63 Note: If you change this parameter, the endpoint will reboot to make the change take effect.	Remote Control Web User Interface

To configure QoS via web user interface:

1. Click on **Network**->**Advanced**.
2. In the **QoS** block, enter the desired values in the corresponding fields.

The screenshot shows the Yealink VC110 web interface. The top navigation bar includes 'About', 'Language', and 'Logout'. The main menu has 'Home', 'Status', 'Account', 'Network' (selected), 'Setting', 'Directory', and 'Security'. Under 'Network', the left sidebar shows 'LAN Configuration', 'NAT/Firewall', 'Advanced' (selected), and 'Diagnose'. The main content area displays various network settings. The 'QoS' section is highlighted with a red box and contains the following fields:

Parameter	Value
Audio Priority	63
Video Priority	34
Data Priority	63

Below the QoS section, the 'MTU' section shows 'Video MTU' set to 1500.

3. Click **Confirm** to accept the change.

A dialog box pops up to prompt that the settings will take effect after a reboot.

4. Click **Confirm** to reboot the endpoint immediately.


To configure QoS via the remote control:

1. Select **Menu->Advanced** (default password: 0000) -> **Advanced Network**.
2. In the **Diffserv QoS** block, enter the desired values in the corresponding fields.
3. Press the **Save** soft key to accept the change.
The display device prompts "Reboot now?".
4. Select **OK** to reboot the endpoint immediately.

VPN

VPN (Virtual Private Network) is a secured private network connection built on top of public telecommunication infrastructures, such as the Internet. VPN has become more prevalent due to the benefits of scalability, reliability, convenience and security. VPN provides remote offices or individual users with secure access to their organization's network. There are two types of VPN access: remote-access VPN (connecting an individual device to a network) and site-to-site VPN (connecting two networks together). Remote-access VPN allows employees to access their company's intranet from home or outside the office, and site-to-site VPN allows employees in geographically separated offices to share one cohesive virtual network. VPN can also be classified by the protocols used to tunnel the traffic. It provides security through tunneling protocols: IPSec, SSL, L2TP and PPTP.

The endpoint supports SSL VPN, which provides remote-access VPN capabilities through SSL. OpenVPN is a full featured SSL VPN software solution that creates secure connections in remote access facilities and is designed work with the TUN/TAP virtual networking interface. TUN and TAP are virtual network kernel devices. TAP simulates a link layer device and provides a virtual point-to-point connection, while TUN simulates a network layer device and provides a virtual network segment. The endpoint uses OpenVPN to achieve the VPN feature. To prevent disclosure of private information, tunnel endpoints must authenticate each other before secure VPN tunnel is established. After the VPN feature is configured properly on the endpoint, the endpoint works as a VPN client and uses the certificates to authenticate the VPN server.



To use VPN, the compressed package of VPN-related files should be uploaded to the endpoint in advance. The file format of the compressed package must be *.tar. The VPN-related files are: certificates (ca.crt and client.crt), key (client.key) and the configuration file (vpn.cnf) of the VPN client. For more information, refer to [OpenVPN Feature on Yealink IP Phones](#).

VPN feature parameters on the endpoint are described below.

Parameter	Description	Configuration Method
VPN->Active	<p>Enables or disables VPN feature on the endpoint.</p> <p>Default: Disabled</p> <p>Note: You need to upload the compressed package of VPN-related files to the endpoint first before enabling the VPN feature. If you change this parameter, the endpoint</p>	<p>Remote Control</p> <p>Web User Interface</p>

Parameter	Description	Configuration Method
	will reboot to make the change take effect.	
Upload VPN Config	Uploads the compressed package of VPN-related files (*.tar) to the endpoint.	Web User Interface

To configure VPN via web user interface:

1. Click on **Network->Advanced**.
2. In the **VPN** block, click **Browse** to locate the VPN file (*.tar) from your local endpoint.
3. Click **Upload** to upload the file to the endpoint.
4. Select the desired value from the pull-down list of **Active**.

The screenshot displays the Yealink VC110 web interface. The top navigation bar includes 'About', 'Language', and 'Logout'. The main menu has 'Home', 'Status', 'Account', 'Network' (selected), 'Setting', 'Directory', and 'Security'. On the left, a sidebar shows 'LAN Configuration' with sub-items: 'NAT/Firewall', 'Advanced' (selected), and 'Diagnose'. The main content area is divided into sections: 'SNMP' (Active: Disabled, Port: 161, Trusted Address: empty), 'Web Server' (HTTP: Enabled, HTTP Port: 80, HTTPS: Enabled, HTTPS Port: 443), '802.1x' (802.1x Mode: Disabled, Identity: empty, MD5 Password: masked), and 'VPN' (Active: Enabled, Upload VPN Config: C:\fakepath\openvpn.tar). The 'VPN' section is highlighted with a red rectangle. Below the 'Upload VPN Config' field are 'Browse...' and 'Upload' buttons.

5. Click **Confirm** to accept the change.
A dialog box pops up to prompt that the settings will take effect after a reboot.
6. Click **Confirm** to reboot the endpoint immediately.

To configure VPN via the remote control:

1. Select **Menu->Advanced** (default password: 0000) ->**Advanced Network**.
2. Check the **VPN** checkbox.
3. Press the **Save** soft key to accept the change.
The display device prompts "Reboot now?".
4. Select **OK** to reboot the endpoint immediately.

Configuring Call Preferences

This chapter provides information on how to configure endpoint's call preferences (e.g., call type and network bandwidth).

This chapter provides the following sections:

- [Configuring Cloud Settings](#)
- [Configuring SIP Settings](#)
- [Configuring H.323 Settings](#)
- [Account Polling](#)
- [DTMF](#)
- [Codecs](#)
- [Call Protocol](#)
- [Do Not Disturb](#)
- [Auto Answer](#)
- [History Record](#)
- [Bandwidth](#)
- [Ringback Timeout](#)
- [Auto Refuse Timeout](#)
- [SIP IP Call by Proxy](#)
- [Default Layout of Single Screen](#)

Configuring Cloud Settings

Yealink video conferencing endpoint is compatible with StarLeaf/Zoom/BlueJeans/Pexip/Mind virtual meeting service.

Users can access Virtual Meeting Rooms(VMR) using Yealink video conferencing endpoint, whilst benefiting from both the features provided by Yealink, such as 1080p HD video and audio, and features provided by StarLeaf/Zoom/BlueJeans/Pexip/Mind, including high end customization & interoperability.

You can obtain the account information from your enterprise administrator.

Logging into the Yealink Cloud Platform

Yealink VC110 video conferencing endpoints support Yealink Cloud account. The Yealink Cloud enterprise administrator uses the Yealink web management service to assign each user an

individual Yealink Cloud account. For more information, refer to [Yealink VC Cloud Management Service Administrator Guide](#).

You can log into the Yealink Cloud platform, and dial other Yealink Cloud numbers to establish a conversation. If you want to place a call to a Yealink Cloud contact who is in the same enterprise directory as you, you can enter Yealink Cloud numbers or the extension (the last four Yealink Cloud numbers) to place a call. If you want to place a call to a Yealink Cloud contact who is in different enterprise directory from you, you can only enter complete Yealink Cloud numbers to place a call.

Yealink Cloud platform parameters on the endpoint are described below:

Parameter	Description	Configuration Method
Cloud Account	<p>Enables or disables the Cloud feature.</p> <p>Default: Enabled</p> <p>Note: If it is disabled, the endpoint cannot log into the Yealink Cloud platform.</p>	<p>Remote Control</p> <p>Web User Interface</p>
Platform Type	<p>Configures the platform type.</p> <ul style="list-style-type: none"> • Yealink Cloud • StarLeaf • Zoom • Pexip • BlueJeans • Mind • Custom <p>Default: Yealink Cloud</p>	<p>Remote Control</p> <p>Web User Interface</p>
Login Type	<p>Specifies the method to log into the Yealink Cloud platform.</p> <ul style="list-style-type: none"> • PIN Code Login: This method uses the user's PIN code to log into the Yealink Cloud platform. The PIN code consists of 9 digits. You can only use the PIN code once and it will expire if unused for 7 days. Contact Cloud enterprise administrator when it expires. • user/password: This method uses the user's Yealink Cloud number and password to log into 	<p>Remote Control</p> <p>Web User Interface</p>

Parameter	Description	Configuration Method
	<p>the Yealink Cloud platform.</p> <ul style="list-style-type: none"> • Build-in Cloud Number: This method uses build-in Cloud number to log into the Yealink Cloud platform. The number consists of 7 digits that are generated according to MAC address, and it never expires. <p>Default: PIN Code Login</p>	
Pincode/Pin Code	<p>Specifies the PIN code to log into the Yealink Cloud platform.</p> <p>Default: Blank</p> <p>Note: It only works if the value of Login Type is set to PIN Code Login.</p>	<p>Remote Control</p> <p>Web User Interface</p>
Username	<p>Specifies the user name to log into the Yealink Cloud platform.</p> <p>Default: Blank</p> <p>Note: It only works if the value of Login Type is set to user/password.</p>	<p>Remote Control</p> <p>Web User Interface</p>
Password	<p>Specifies the password associated with the user name when signing into the Yealink Cloud platform.</p> <p>Default: Blank</p> <p>Note: It only works if the value of Login Type is set to user/password.</p>	<p>Remote Control</p> <p>Web User Interface</p>
Remember Me	<p>Enables or disables the endpoint to remember the registration information.</p> <p>Default: ON</p> <p>Note: If it is on, user name and password will be filled automatically next time.</p> <p>It only works if the value of Login Type is set to Username/Password.</p>	<p>Remote Control</p>

To configure Yealink Cloud platform via web user interface:

1. Click on **Account->Cloud**.
2. Select **Enabled** from the pull-down list of **Cloud Account**.


3. Select **Yealink Cloud** from the pull-down list of **Platform Type**.
4. Select the desired sign-in method from the pull-down list of **Login Type**.
 - Select **Build-in Cloud Number**.
 - If you select **PIN Code Login**, enter your PIN code in the **Pin Code** field.
 - If you select **user/password**, enter your Cloud number and password in the corresponding fields.

The screenshot shows the Yealink VC110 web interface. The top navigation bar includes 'About', 'Language', and 'Logout'. The main menu has 'Home', 'Status', 'Account', 'Network', 'Setting', 'Directory', and 'Security'. The 'Account' tab is selected. On the left, there is a sidebar with 'Cloud', 'H.323', 'SIP Account', 'SIP IP Call', and 'Codec'. The 'Cloud' section is active, showing 'Register Status' as 'Unregistered' and 'Cloud Account' as 'Enabled'. The 'Platform Type' is set to 'Yealink Cloud' and 'Login Type' is set to 'PIN Code Login'. The 'Pin Code' field is empty. Below this is the 'Advanced Setting' section with 'DTMF Type' as 'RFC2833', 'DTMF Info Type' as 'DTMF-Relay', and 'DTMF Payload Type (96~127)' as '101'.

5. Click **Confirm** to accept the change.

To configure Yealink Cloud platform via the remote control:

1. Select **Menu->Advanced** (default password: 0000)->**Cloud**.
2. In the **Cloud Account** field, check the **Enabled** checkbox.
3. Select **Yealink Cloud** from the pull-down list of **Platform Type**.
4. Select the desired sign-in method from the pull-down list of **Login Type**.
 - If you select **Build-in Cloud Number**:
Press ▲ or ▼ to scroll to **Onekey Login**, and then press **OK**.
 - If you select **Pincode Login**:
Enter your PIN code in the **Pincode** field, press ▲ or ▼ to scroll to **Log In**, and then press **OK**.
 - If you select **Username/Password**:
Enter your Cloud number and password in the corresponding fields, you can also check the **Remember Me** checkbox to remember your username and password.
Press ▲ or ▼ to scroll to **Log In**, and then press **OK**.

After successful registration, the display device displays  , and the LCD screen of the video conferencing phone displays .

Note

A Yealink Cloud account can be used to log into five Cloud endpoints at most simultaneously. If you register a Yealink Cloud account using build-in Cloud number, you directory will not include the Yealink Cloud contacts, but you can dial the Yealink Cloud accounts to establish a conversation.

Logging into the StarLeaf Cloud Platform

You can log into the StarLeaf Cloud platform.

When you place a call using the StarLeaf Cloud account, you can:

- Call the other StarLeaf Cloud account to establish a point to point call.
- Call the Meeting ID to join the Virtual Meeting Rooms.
- Call between StarLeaf Cloud account and Microsoft Skype for Business/Lync account.

StarLeaf platform parameters on the endpoint are described below:

Parameter	Description	Configuration Method
Cloud Account	Enables or disables the Cloud feature. Default: Enabled Note: If it is disabled, the endpoint cannot log into the StarLeaf Cloud platform.	Remote Control Web User Interface
Platform Type	Configures the platform type. <ul style="list-style-type: none"> • Yealink Cloud • StarLeaf • Zoom • Pexip • BlueJeans • Mind • Custom Default: Yealink Cloud	Remote Control Web User Interface
QCP Code	Specifies the quick access code to log into the StarLeaf Cloud platform. Default: Blank	Remote Control Web User Interface


To configure StarLeaf Cloud platform via web user interface:



1. Click on **Account->Cloud**.
2. Select **Enabled** from the pull-down list of **Cloud Account**.
3. Select **StarLeaf** from the pull-down list of **Platform Type**

The screenshot shows the Yealink VC110 web interface. The top navigation bar includes 'About', 'Language', and 'Logout'. The main navigation bar has 'Home', 'Status', 'Account', 'Network', 'Setting', 'Directory', and 'Security'. The 'Account' tab is selected. On the left sidebar, 'Cloud' is highlighted. The main content area is titled 'Cloud' and contains a red-bordered box around the 'Register Status' (Registered), 'Cloud Account' (Enabled), 'Platform Type' (StarLeaf), and 'QCP Code' (367037241953) fields. Below this is the 'Advanced Setting' section with various options like H.323 Tunneling, H.235 Encryption, Protocol Monitor Port, DTMF Type, Local Early Media, H.239, and FECC(H.323).

4. Configure the StarLeaf Cloud platform.
5. Click **Confirm** to accept the change.

To configure StarLeaf Cloud platform via the remote control:

1. Select **Menu->Advanced** (default password: 0000)->**Cloud**.
2. In the **Cloud Account** field, check the **Enabled** checkbox.
3. Select **StarLeaf** from the pull-down list of **Platform Type**.
4. Enter the 12-digit quick access code in the **Qcp Code** field.
5. Press ▲ or ▼ to scroll to **Log In**, and then press .

After successful registration, the display device displays , and the LCD screen of the video conferencing phone displays .

Note

Endpoints that log into the StarLeaf Cloud platform will upgrade firmware automatically once the current firmware version is different from the one on StarLeaf Server.

Logging into the Zoom Cloud Platform

You can log into the Zoom Cloud platform and join the virtual meeting room.

Zoom Cloud platform parameters on the endpoint are described below:

Parameter	Description	Configuration Method
Cloud Account	Enables or disables the Cloud feature. Default: Enabled Note: If it is disabled, the endpoint cannot log into the Zoom Cloud platform.	Remote Control Web User Interface
Platform Type	Configures the platform type. <ul style="list-style-type: none">• Yealink Cloud• StarLeaf• Zoom• Pexip• BlueJeans• Mind• Custom Default: Yealink Cloud	Remote Control Web User Interface
Server/Server Host	Configures the IP address or domain name of the Zoom Cloud server. Default: zoomcrc.com	Remote Control Web User Interface
Transport	Configures the type of transport protocol for the Zoom Cloud platform. <ul style="list-style-type: none">• UDP—provides best-effort transport via UDP for SIP signaling.• TCP—provides reliable transport via TCP for SIP signaling.• TLS—provides secure communication of SIP signaling.• DNS-NAPTR—performs the DNS NAPTR and SRV queries for the service type and port if no server port is given. Default: TCP	Web User Interface
Server Expires	Configures the registration expiration time (in seconds) of the Cloud server for Cloud platform.	Web User Interface

Parameter	Description	Configuration Method
	Default:3600	

To configure Zoom Cloud platform via web user interface:

1. Click on **Account->Cloud**.
2. Select **Enabled** from the pull-down list of **Cloud Account**.
3. Select **Zoom** from the pull-down list of **Platform Type**.
4. Configure the Zoom Cloud platform.

The screenshot shows the Yealink VC110 web interface. The top navigation bar includes 'About', 'Language', and 'Logout'. The main menu has 'Home', 'Status', 'Account' (selected), 'Network', 'Setting', 'Directory', and 'Security'. On the left, a sidebar lists 'Cloud', 'H.323', 'SIP Account', 'SIP IP Call', and 'Codec'. The 'Cloud' configuration page is displayed, with a red box highlighting the 'Cloud' section. This section includes 'Register Status' (Registered), 'Cloud Account' (Enabled), 'Platform Type' (Zoom), and 'Server Host' (zoomcrc.com). Below this is the 'Advanced Setting' section, which includes 'Transport' (TCP), 'Server Expires' (3600), 'SRTP' (Disabled), 'DTMF Type' (RFC2833), 'DTMF Info Type' (DTMF-Relay), 'DTMF Payload Type (96~127)' (101), 'Keep Alive Interval' (30), 'BFCP' (Enabled), and 'FECC(SIP)' (Enabled).



5. Click **Confirm** to accept the change.

To configure Zoom Cloud platform via the remote control:

1. Select **Menu->Advanced** (default password: 0000)->**Cloud**.
2. In the **Cloud Account** field, check the **Enabled** checkbox.
3. Select **Zoom** from the pull-down list of **Platform Type**.
4. Enter the domain name or IP address of Zoom server in the **Server** field.

The default Zoom server is "zoomcrc.com".

5. Press ▲ or ▼ to scroll to **Log In**, and then press .

After successful registration, the display device displays , and the LCD screen of the video conferencing phone displays .

Registering a Pexip Account

You can register the Pexip account.

When you place a call using the Pexip account, you can:

- Call the device alias to establish a point to point call.
- Call the aliases to join the Virtual Meeting Rooms, Virtual Auditoriums or Virtual Receptions.
- Call between Pexip account and Microsoft Skype for Business/Lync account.

Pexip platform parameters on the endpoint are described below:


Parameter	Description	Configuration Method
Cloud Account	Enables or disables the Cloud feature. Default: Enabled Note: If it is disabled, the endpoint cannot register the Pexip account.	Remote Control Web User Interface
Platform Type	Configures the platform type. <ul style="list-style-type: none"> • Yealink Cloud • StarLeaf • Zoom • Pexip • BlueJeans • Mind • Custom Default: Yealink Cloud	Remote Control Web User Interface
Alias	Specifies the alias when registering a Pexip account. Default: Blank	Remote Control Web User Interface
Username	Specifies the user name when registering a Pexip account. Default: Blank	Remote Control Web User Interface
Password	Specifies the password associated with the user name when registering a Pexip account. Default: Blank	Remote Control Web User Interface
Server/Server Host	Configures the IP address or domain name of the Pexip server. Default: Blank	Remote Control Web User Interface

Parameter	Description	Configuration Method
Port	Configures the port of the Pexip server. Default: 0	Web User Interface
Transport	Configures the type of transport protocol for the Pexip platform. <ul style="list-style-type: none"> • UDP—provides best-effort transport via UDP for SIP signaling. • TCP—provides reliable transport via TCP for SIP signaling. • TLS—provides secure communication of SIP signaling. • DNS-NAPTR—performs the DNS NAPTR and SRV queries for the service type and port if no server port is given. Default: TCP	Web User Interface
Server Expires	Configures the registration expiration time (in seconds) of the Cloud server. Default: 3600	Web User Interface
Remember Password	Enables or disables the endpoint to remember the registration information. Default: ON Note: If it is on, other registration information will be filled automatically when you enter the alias next time.	Remote Control

To configure Pexip platform via web user interface:

1. Click on **Account->Cloud**.
2. Select **Enabled** from the pull-down list of **Cloud Account**.
3. Select **Pexip** from the pull-down list of **Platform Type**.


4. Configure the Pexip account settings.





The screenshot shows the Yealink VC110 web interface. The top navigation bar includes 'About', 'Language', and 'Logout'. The main menu has 'Home', 'Status', 'Account', 'Network', 'Setting', 'Directory', and 'Security'. The 'Account' tab is selected. On the left sidebar, 'Cloud' is selected, with sub-items 'H.323', 'SIP Account', 'SIP IP Call', and 'Codec'. The main content area shows the 'Cloud' settings. A red box highlights the 'Cloud' section, which includes: 'Register Status' (Registered), 'Cloud Account' (Enabled), 'Platform Type' (Pexip), 'Alias' (ff@yealink.com), 'Username' (ff), 'Password' (masked), 'Server Host' (192.168.6.142), and 'Port' (0). Below this is the 'Advanced Setting' section with: 'Transport' (TCP), 'Server Expires' (3600), 'SRTP' (Disabled), 'DTMF Type' (RFC2833), 'DTMF Info Type' (DTMF-Relay), and 'DTMF Payload Type (96~127)' (101).

5. Click **Confirm** to accept the change.

To configure Pexip platform via the remote control:

1. Select **Menu->Advanced** (default password: 0000)->**Cloud**.
2. In the **Cloud Account** field, check the **Enabled** checkbox.
3. Select **Pexip** from the pull-down list of **Platform Type**.
4. Configure the Pexip account settings.
5. Check the **Remember Password** checkbox to remember your registration information.
6. Press ▲ or ▼ to scroll to **Log In**, and then press .

After successful registration, the display device displays , and the LCD screen of the video conferencing phone displays .

Note

You can also register the Pexip account using SIP or H.323 protocol. For more information, refer to [Configuring SIP Settings](#) on page 132 and [Configuring H.323 Settings](#) on page 136.

Logging into the BlueJeans Cloud Platform

You can log into the BlueJeans Cloud platform and join the virtual meeting room.

BlueJeans Cloud platform parameters on the endpoint are described below:

Parameter	Description	Configuration Method
Cloud Account	Enables or disables the Cloud feature. Default: Enabled Note: If it is disabled, the endpoint cannot log into the BlueJeans Cloud platform.	Remote Control Web User Interface
Platform Type	Configures the platform type. <ul style="list-style-type: none">• Yealink Cloud• StarLeaf• Zoom• Pexip• BlueJeans• Mind• Custom Default: Yealink Cloud	Remote Control Web User Interface
Server/Server Host	Configures the IP address or domain name of the BlueJeans server. Default: bjn.vc	Remote Control Web User Interface
Transport	Configures the type of transport protocol for the BlueJeans Cloud platform. <ul style="list-style-type: none">• UDP—provides best-effort transport via UDP for SIP signaling.• TCP—provides reliable transport via TCP for SIP signaling.• TLS—provides secure communication of SIP signaling.• DNS-NAPTR—performs the DNS NAPTR and SRV queries for the service type and port if no server port is given. Default: TCP	Web User Interface
Server Expires	Configures the registration expiration time (in seconds) of the Cloud server.	Web User Interface

Parameter	Description	Configuration Method
	Default:3600	

To configure BlueJeans Cloud platform via web user interface:

1. Click on **Account->Cloud**.
2. Select **Enabled** from the pull-down list of **Cloud Account**.
3. Select **BlueJeans** from the pull-down list of **Platform Type**.
4. Configure the BlueJeans Cloud platform.

The screenshot shows the Yealink VC110 web interface. The top navigation bar includes 'About', 'Language', and 'Logout'. The main menu has 'Home', 'Status', 'Account' (selected), 'Network', 'Setting', 'Directory', and 'Security'. On the left, a sidebar lists 'Cloud', 'H.323', 'SIP Account', 'SIP IP Call', and 'Codec'. The 'Cloud' configuration page is displayed, with a red box highlighting the 'Cloud' section. This section includes 'Register Status' (Registered), 'Cloud Account' (Enabled), 'Platform Type' (BlueJeans), and 'Server Host' (bjn.vc). Below this is the 'Advanced Setting' section, which includes 'Transport' (TCP) and 'Server Expires' (3600). Other settings like SRTP, DTMF Type, DTMF Info Type, DTMF Payload Type, Keep Alive Interval, BFCP, and FECC(SIP) are also visible.



5. Click **Confirm** to accept the change.

To configure BlueJeans Cloud platform via the remote control:

1. Select **Menu->Advanced** (default password: 0000)->**Cloud**.
2. In the **Cloud Account** field, check the **Enabled** checkbox.
3. Select **BlueJeans** from the pull-down list of **Platform Type**.
4. Enter the domain name or IP address of BlueJeans server in the **Server** field.

The default BlueJeans server is "bjn.vc".

5. Press ▲ or ▼ to scroll to **Log In**, and then press .

After successful registration, the display device displays , and the LCD screen of the video conferencing phone displays .

Logging into the Mind Platform

You can log into the Mind platform and join the virtual meeting room.

Mind platform parameters on the endpoint are described below:

Parameter	Description	Configuration Method
Cloud Account	Enables or disables the Cloud feature. Default: Enabled Note: If it is disabled, the endpoint cannot log into the Mind platform.	Remote Control Web User Interface
Platform Type	Configures the platform type. <ul style="list-style-type: none">• Yealink Cloud• StarLeaf• Zoom• Pexip• BlueJeans• Mind• Custom Default: Yealink Cloud	Remote Control Web User Interface
Server/Server Host	Configures the IP address or domain name of the Mind server. Default: Blank	Remote Control Web User Interface
Transport	Configures the type of transport protocol for the Mind platform. <ul style="list-style-type: none">• UDP—provides best-effort transport via UDP for SIP signaling.• TCP—provides reliable transport via TCP for SIP signaling.• TLS—provides secure communication of SIP signaling.• DNS-NAPTR—performs the DNS NAPTR and SRV queries for the service type and port if no server port is given. Default: TCP	Web User Interface

Parameter	Description	Configuration Method
Server Expires	Configures the registration expiration time (in seconds) of the Cloud server. Default:3600	Web User Interface

To configure Mind platform via web user interface:

1. Click on **Account->Cloud**.
2. Select **Enabled** from the pull-down list of **Cloud Account**.
3. Select **Mind** from the pull-down list of **Platform Type**.
4. Configure the Mind platform.

The screenshot shows the Yealink VC110 web interface. The top navigation bar includes 'About', 'Language', and 'Logout'. The main menu has 'Home', 'Status', 'Account', 'Network', 'Setting', 'Directory', and 'Security'. The 'Account' menu is expanded, showing 'Cloud', 'H.323', 'SIP Account', 'SIP IP Call', and 'Codec'. The 'Cloud' configuration page is displayed, with a red box highlighting the 'Cloud' section. This section includes 'Register Status' (Registered), 'Cloud Account' (Enabled), 'Platform Type' (Mind), and 'Server Host' (10.2.1.76). Below this is the 'Advanced Setting' section, which includes 'Transport' (TCP), 'Server Expires' (3600), 'SRTP' (Disabled), 'DTMF Type' (RFC2833), 'DTMF Info Type' (DTMF-Relay), 'DTMF Payload Type (96~127)' (101), 'Keep Alive Interval' (30), 'BFCP' (Enabled), and 'FECC(SIP)' (Enabled).

5. Click **Confirm** to accept the change.

To configure Mind platform via the remote control:

1. Select **Menu->Advanced** (default password: 0000)->**Cloud**.
2. In the **Cloud Account** field, check the **Enabled** checkbox.
3. Select **Mind** from the pull-down list of **Platform Type**.
4. Enter the domain name or IP address of Mind server in the **Server** field.
5. Press ▲ or ▼ to scroll to **Log In**, and then press .

After successful registration, the display device displays , and the LCD screen of the video conferencing phone displays .

Registering a Custom Account

You can register a custom account.

Custom account parameters on the endpoint are described below:

Parameter	Description	Configuration Method
Cloud Account	Enables or disables the Cloud feature. Default: Enabled Note: If it is disabled, the endpoint cannot register the custom account.	Remote Control Web User Interface
Platform Type	Configures the platform type. <ul style="list-style-type: none">• Yealink Cloud• StarLeaf• Zoom• Pexip• BlueJeans• Mind• Custom Default: Yealink Cloud	Remote Control Web User Interface
Label	Configures the account label displayed on the display device when registering a custom account. Default: Blank	Remote Control Web User Interface
Username	Specifies the user name when registering a custom account. Default: Blank	Remote Control Web User Interface
Register Name	Configures the register name when registering a custom account. Default: Blank	Remote Control Web User Interface
Password	Specifies the password associated with the user name when registering a custom account. Default: Blank	Remote Control Web User Interface
Server/Server Host	Configures the IP address or domain name of the custom server. Default: Blank	Remote Control Web User Interface

Parameter	Description	Configuration Method
Port	Configures the port of the custom server. Default: 0	Web User Interface
Transport	Configures the type of transport protocol for the custom platform. <ul style="list-style-type: none"> • UDP—provides best-effort transport via UDP for SIP signaling. • TCP—provides reliable transport via TCP for SIP signaling. • TLS—provides secure communication of SIP signaling. • DNS-NAPTR—performs the DNS NAPTR and SRV queries for the service type and port if no server port is given. Default: TCP	Web User Interface
Server Expires	Configures the registration expiration time (in seconds) of the custom server. Default: 3600	Web User Interface
Remember password	Enables or disables the endpoint to remember the registration information. Default: ON Note: If it is on, other registration information will be filled automatically when you enter the user name next time.	Remote Control

To configure custom account via web user interface:

1. Click on **Account->Cloud**.
2. Select **Enabled** from the pull-down list of **Cloud Account**.
3. Select **Custom** from the pull-down list of **Platform Type**.

4. Configure the custom account settings.

The screenshot shows the Yealink VC110 web interface. The top navigation bar includes 'About', 'Language', and 'Logout'. The main menu has 'Home', 'Status', 'Account' (selected), 'Network', 'Setting', 'Directory', and 'Security'. On the left, a sidebar lists 'Cloud', 'H.323', 'SIP Account', 'SIP IP Call', and 'Codec'. The 'Cloud' section is expanded, showing a 'Cloud' sub-menu. The main content area is titled 'Cloud' and contains a form with the following fields:

- Register Status: Registered
- Cloud Account: Enabled (dropdown)
- Platform Type: Custom (dropdown)
- Label: 584921002
- Username: 584921002
- Register Name: 584921002
- Password: masked with dots
- Server Host: yealinkvc.com
- Port: 0

Below these fields is the 'Advanced Setting' section:

- Transport: TLS (dropdown)
- Server Expires: 3600
- SRTP: Disabled (dropdown)
- DTMF Type: RFC2833 (dropdown)
- DTMF Info Type: DTMF-Relay (dropdown)

5. Click **Confirm** to accept the change.

To configure custom account via the remote control:

1. Select **Menu->Advanced** (default password: 0000)->**Cloud**.
2. In the **Cloud Account** field, check the **Enabled** checkbox.
3. Select **Custom** from the pull-down list of **Platform Type**.
4. Configure the custom account settings.
5. Check the **Remember Password** checkbox to remember your registration information.
6. Press ▲ or ▼ to scroll to **Log In**, and then press **OK**.

Configuring the Third-party Virtual Meeting Room

A Virtual Meeting Room (VMR) is an online space, typically hosted by a Cloud-service provider, where multiple participants can join. Participants usually join by dialing a specific number or an address with a simple name like zoomcrc.com.

If you haven't registered a Cloud account, or you have registered a Yealink Cloud account, you can configure a third-party VMR in advance, so that you can quickly join a VMR without registering a third-party Cloud account.

Up to 5 third-party VMRs can be configured. Third-party VMR is configurable via web user interface only.

3rd-VMR parameters on the endpoint are described below:

Parameter	Description	Configuration Method
VMR Name 1	Configures the virtual meeting room name. Default: Zoom Note: It only works when you do not log into a Cloud platform, or you only register a Yealink Cloud account.	Web User Interface
VMR Server1	Configures the virtual meeting room server address. Default: zoomcrc.com Note: It only works when you do not log into a Cloud platform, or you only register a Yealink Cloud account.	Web User Interface
VMR Name 2	Configures the virtual meeting room name. Default: Blue Jeans Note: It only works when you do not log into a Cloud platform, or you only register a Yealink Cloud account.	Web User Interface
VMR Server 2	Configures the virtual meeting room server address. Default: bjn.vc Note: It only works when you do not log into a Cloud platform, or you only register a Yealink Cloud account.	Web User Interface
VMR Name 3	Configures the virtual meeting room name. Default: Blank Note: It only works when you do not log into a Cloud platform, or you only register a Yealink Cloud account.	Web User Interface
VMR Server 3	Configures the virtual meeting room server address.	Web User Interface

Parameter	Description	Configuration Method
	Default: Blank Note: It only works when you do not log into a Cloud platform, or you only register a Yealink Cloud account.	
VMR Name 4	Configures the virtual meeting room name. Default: Blank Note: It only works when you do not log into a Cloud platform, or you only register a Yealink Cloud account.	Web User Interface
VMR Server 4	Configures the virtual meeting room server address. Default: Blank Note: It only works when you do not log into a Cloud platform, or you only register a Yealink Cloud account.	Web User Interface
VMR Name 5	Configures the virtual meeting room name. Default: Blank Note: It only works when you do not log into a Cloud platform, or you only register a Yealink Cloud account.	Web User Interface
VMR Server 5	Configures the virtual meeting room server address. Default: Blank Note: It only works when you do not log into a Cloud platform, or you only register a Yealink Cloud account.	Web User Interface


To configure the third-party virtual meeting room via web user interface:

1. Click on **Setting**->**3rd-VMR**.

- Enter virtual meeting room name and server address in the corresponding fields respectively.

- Click **Confirm** to accept the change.

On your display device, the VMRs will appear at the path **Call->Dial->Call Type**. You can select the desired third-party platform to call corresponding VMRs quickly.



For more information on how to use third-party platform, refer to the [User Guide](#).

Configuring SIP Settings

Yealink VC110 video conferencing endpoint supports Session Initiation Protocol (SIP). If your server supports SIP, you can use SIP to establish calls.

SIP Account

To establish calls using SIP, you can configure a SIP account for the endpoint.

SIP account parameters on the endpoint are described below:

Parameter	Description	Configuration Method
SIP Account	Enables or disables the SIP account. Default: Enabled	Remote Control Web User Interface
Register Name	Configures the user name of the SIP account for register authentication. Default: Blank	Remote Control Web User Interface
User Name	Specifies the user name to use for authentication when registering with a SIP server. Default: Blank	Remote Control Web User Interface
Password	Specifies the password associated with the user name used to authenticate the endpoint to the SIP server. Default: Blank	Remote Control Web User Interface
Server/Server Host	Configures the IP address or domain name of the SIP server for the SIP account. Default: Blank	Remote Control Web User Interface
SIP Server Port/Port	Configures the port of the SIP server. Valid values: Integer from 0 to 65535. Default: 5060	Web User Interface
Outbound/Enable Outbound Proxy Server	Enables or disables the endpoint to send requests of the SIP account to the outbound proxy server. Default: Disabled	Remote Control Web User Interface
Outbound	Configures the IP address or domain	Remote Control

Parameter	Description	Configuration Method
Server/Outbound Proxy Server	name of the outbound proxy server for the SIP account. Valid values: Integer from 1 to 65535. Default: it is configurable only when the Outbound Proxy Server is enabled.	Web User Interface
Outbound Port/Port	Configures the port of the outbound proxy server. Valid values: Integer from 0 to 65535. Default: 5060	Remote Control Web User Interface
Transport	Configures the type of transport protocol for the SIP account. <ul style="list-style-type: none"> • UDP—provides best-effort transport via UDP for SIP signaling. • TCP—provides reliable transport via TCP for SIP signaling. • TLS—provides secure communication of SIP signaling. • DNS-NAPTR—performs the DNS NAPTR and SRV queries for the service type and port if no server port is given. Default: TCP Note: TLS is available only when the endpoint is registered with a SIP server that supports TLS.	Remote Control Web User Interface
Server Expires	Configures the registration expiration time (in seconds) of the SIP server for SIP account. Default: 3600	Remote Control Web User Interface

To configure SIP account via web user interface:

1. Click on **Account->SIP Account**.

2. Configure the SIP account settings.

3. Click **Confirm** to accept the change.

After successful registration, the display device displays **SIP**, and the LCD screen of the video conferencing phone displays **SIP**.

To configure SIP account via the remote control:

1. Select **Menu->Advanced** (default password: 0000) -> **SIP Account**.
2. Configure the SIP account settings.
3. Press the **Save** soft key to accept the change.

After successful registration, the display device displays **SIP**, and the LCD screen of the video conferencing phone displays **SIP**.

SIP IP Call

When making an IP call using the SIP protocol, the endpoint doesn't support the TLS protocol. So configuration parameters of SIP IP call are divided from the SIP account. You can configure SIP IP call separately.

SIP IP call parameters on the endpoint are described below:

Parameter	Description	Configuration Method
SIP IP Call Enable	Enables or disables the SIP IP Call. Default: Enabled. Note: When it is set to Enabled on	Remote Control Web User Interface

Parameter	Description	Configuration Method
	both sites, the VC110 can call the far site by dialing an IP address directly.	
Transport	<p>Configures the type of transport protocol for the SIP IP call.</p> <ul style="list-style-type: none"> • UDP—provides best-effort transport via UDP for SIP signaling. • TCP—provides reliable transport via TCP for SIP signaling. • DNS-NAPTR—performs the DNS NAPTR and SRV queries for the service type and port if no server port is given. 	<p>Remote Control</p> <p>Web User Interface</p>

To configure SIP IP call via web user interface:

1. Click on **Account->SIP IP Call**.
2. Select the desired value from the pull-down list of **SIP IP Call Enable**.
3. Select the desired value from the pull-down list of **Transport**.

The screenshot shows the Yealink VC110 web interface. The top navigation bar includes 'About', 'Language', and 'Logout'. The main menu has 'Home', 'Status', 'Account', 'Network', 'Setting', 'Directory', and 'Security'. The left sidebar lists 'Cloud', 'H323', 'SIP Account', 'SIP IP Call' (selected), and 'Codec'. The main content area displays the 'SIP IP Call' configuration page. A red box highlights the 'SIP IP Call' and 'Transport' settings. 'SIP IP Call' is set to 'Enabled' and 'Transport' is set to 'TCP'. Other settings visible include 'SRTP' (Disabled), 'DTMF Type' (RFC2833), 'DTMF Info Type' (DTMF), 'DTMF Payload Type (96~127)' (101), 'NAT Traversal' (Disabled), 'RPort' (Enabled), 'BFCP' (Enabled), and 'FECC(SIP)' (Enabled).

4. Click **Confirm** to accept the change.

To configure SIP IP call via the remote control:

1. Select **Menu->Advanced** (default password: 0000)->**SIP IP Call**.
2. Select the desired value from the pull-down list of **SIP IP Call Enable**.
3. Select the desired value from the pull-down list of **Transport**.
4. Press the **Save** soft key to accept the change.

Configuring H.323 Settings

Yealink VC110 video conferencing endpoints support H.323 protocol. If your network uses a gatekeeper, you can register an H.323 account for the endpoint, and specify its H.323 name and extension. This allows others to call the endpoint by entering the H.323 name or extension instead of the IP address.

H.323 settings parameters on the endpoint are described below:

Parameter	Description	Configuration Method
H.323 Protocol	Enables or disables the H.323 protocol. Default: Enabled. Note: Only when it is set to Enabled, can H.323 account be registered. When it is set to Enabled on both sites, the VC110 endpoint can call the far site by dialing IP address directly.	Remote Control Web User Interface
H.323 Account	Enables or disables the H.323 account. Default: Enabled If it is set to disabled, the endpoint cannot place or receive calls with the H.323 protocol.	Remote Control Web User Interface
H.323 Name	Specifies the name that gatekeepers and gateways use to identify this endpoint. You can make point-to-point calls using H.323 names if both endpoints are registered to a gatekeeper. Default: Blank	Remote Control Web User Interface
H.323 Extension	Specifies the extension that gatekeepers and gateways use to identify this endpoint. Default: Blank Note: Users can place point-to-point calls using the extension if both endpoints are registered with a gatekeeper,	Remote Control Web User Interface

Parameter	Description	Configuration Method
Gatekeeper Mode	<p>Configures the gatekeeper mode.</p> <ul style="list-style-type: none"> • Disabled—the endpoint does not use a gatekeeper. • Auto—the endpoint automatically discovers a gatekeeper. • Manual—specify the IP address and port for the gatekeeper manually. <p>Default: Disabled</p>	<p>Remote Control</p> <p>Web User Interface</p>
Gatekeeper IP Address 1	Configures the IP address of the primary gatekeeper.	<p>Remote Control</p> <p>Web User Interface</p>
Gatekeeper IP Address 2	Configures the IP address of the secondary gatekeeper.	<p>Remote Control</p> <p>Web User Interface</p>
Gatekeeper Authentication	<p>Enables or disables support for gatekeeper authentication.</p> <p>Default: Disabled</p> <p>Note: When Gatekeeper Authentication is enabled, the gatekeeper ensures that only trusted H.323 endpoints are allowed to access the gatekeeper.</p>	<p>Remote Control</p> <p>Web User Interface</p>
Gatekeeper Username	<p>Specifies the user name for authentication with gatekeeper.</p> <p>Default: Blank</p>	<p>Remote Control</p> <p>Web User Interface</p>
Gatekeeper Password	<p>Specifies the password for authentication with gatekeeper.</p> <p>Default: Blank</p>	<p>Remote Control</p> <p>Web User Interface</p>
H.460 Active	<p>Enables or disables H.460 firewall traversal feature on the endpoint.</p> <p>Default: Disabled</p> <p>For more information, refer to H.460 Firewall Traversal on page 101.</p>	<p>Remote Control</p> <p>Web User Interface</p>
H.323 Tunneling	<p>Enables or disables the H.323 tunneling on the endpoint.</p> <p>Default: Disabled</p>	<p>Remote Control</p> <p>Web User Interface</p>

Parameter	Description	Configuration Method
	For more information, refer to H.323 Tunneling on page 82.	
H235 Encryption	<p>Specifies the H.235 type during an H.323 call.</p> <ul style="list-style-type: none"> • Disabled—do not use H.235 in H.323 calls. • Optional—negotiate with the far site whether to use H.235 for media encryption in H.323 calls. • Compulsory—compulsory use H.235 for media encryption in H.323 calls. <p>Default: Disabled</p> <p>Note: For more information, refer to H.235 on page 248.</p>	Web User Interface
Protocol Monitor Port	<p>Specifies the port for the H.323 protocol.</p> <p>Valid values: 0-65535</p> <p>Default 1720.</p> <p>Note: It is only applicable to H.323 IP call.</p>	Web User Interface
Local Early Media	<p>Enables or disables local early media feature on the endpoint.</p> <p>Default: Disabled.</p> <p>If it is set to Enabled, the endpoint will send video SDP twice during a call to solve the compatibility between Yealink device and certain devices.</p>	Web User Interface

To configure H.323 account via web user interface:

1. Click on **Account**->**H.323**.

2. Configure the H.323 account settings.

Field	Value
Register Status	Registered
H323 Protocol	Enabled
H.323 Account	Enabled
H.323 Name	9000
H.323 Extension	9000
Gatekeeper Mode	Manual
Gatekeeper IP Address 1	10.2.1.43
Gatekeeper IP Address 2	
Gatekeeper Authentication	Disabled
Gatekeeper Username	
Gatekeeper Password	*****
H.460 Active	Disabled
H.323 Tunneling	Disabled
H235 Encryption	Disabled
Protocol Monitor Port	1720

3. Click **Confirm** to accept the change.

After successful registration, the display device displays **H323**, and the LCD screen of the video conferencing phone displays **H323**.

To configure H.323 account via the remote control:

1. Select **Menu->Advanced** (default password: 0000) -> **H.323**.
2. Configure the H.323 account settings.
3. Press the **Save** soft key to accept the change.

After successful registration, the display device displays **H323**, and the LCD screen of the video conferencing phone displays **H323**.

Account Polling


When you dial account numbers of other endpoint, account polling feature enables your endpoint to use different call types according to this priority: Cloud platform>H.323 account>SIP account. If you cannot call other endpoints using all your registered accounts, then this call fails.

Account polling is disabled by default. When you register multiple accounts (greater than or equal to 2) for your endpoint, you can enable account polling feature.

The following example shows the way calls are placed when account polling is enabled or disabled

Scenario:

1. Endpoint A is registered with a Yealink Cloud account and a SIP account.
2. On endpoint A, select **Auto** from the pull-down list of **Call Type** before calling.



3. On endpoint A, dial the account numbers of endpoint B.

Result:

- If account polling is disabled, endpoint A can only use its Cloud account (highest priority) to call endpoint B.
- If account polling is enabled, endpoint A will use its Cloud account (highest priority) to call endpoint B first. If this call fails, endpoint A continues to use its SIP account (next priority) to call endpoint B.

Account polling parameters on the endpoint are described below:

Parameter	Description	Configuration Method
Account Polling	<p>Enables or disables the account polling feature.</p> <ul style="list-style-type: none"> • Disabled-If call type is set to Auto, the endpoint can only call other endpoints using the call type with the highest priority. • Enabled- If call type is set to Auto, the endpoint will attempt to call other endpoint using different call types according the priority. <p>Default: Disabled</p>	<p>Remote Control</p> <p>Web User Interface</p>

To configure account polling via web user interface:

1. Click on **Setting**->**Call Features**.
2. Select the desired value from the pull-down list of **Account Polling**.

The screenshot shows the Yealink VC110 web interface. The top navigation bar includes 'About', 'Language', and 'Logout'. Below this is a green header with 'Yealink VC110' and tabs for 'Home', 'Status', 'Account', 'Network', 'Setting' (selected), 'Directory', and 'Security'. On the left, a sidebar lists various settings categories: General, Date & Time, Call Features (selected), Video & Audio, Camera, Configuration, Upgrade, Tones, Wireless Micpod, and 3rd-Party VMR. The main content area displays a list of settings with their current values in dropdown menus. The 'Account Polling' setting at the bottom is highlighted with a red rectangular box and is currently set to 'Disabled'.

Setting	Value
Auto Answer Mute	Enabled
Auto Answer Multiway	Disabled
Auto Dialout Mute	Disabled
Call Match	Enabled
History Record	Enabled
Call Protocol	Auto
Uplink Bandwidth	Auto
Downlink Bandwidth	Auto
Abnormal Call Answering	IP Call Answer
Safe Mode Call	Enabled
Ringback Timeout(30-240)	200
Auto Refuse Timeout(30-240)	120
SIP IP Call by Proxy	Off
Default Layout of Single Screen	Remote Full screen
Network Address Adapter	Enabled
Account Polling	Disabled

3. Click **Confirm** to accept the change.

DTMF

DTMF (Dual Tone Multi-frequency), better known as touch-tone, is used for telecommunication signaling over analog telephone lines in the voice-frequency band. DTMF is the signal sent from the IP phone to the network, which is generated when pressing the keypad during a call. Each key pressed on the IP phone generates one sinusoidal tone of two frequencies. One is generated from a high frequency group and the other from a low frequency group.

The DTMF keypad is laid out in a 4×4 matrix, with each row representing a low frequency, and each column representing a high frequency. Pressing a digit key (such as '1') will generate a sinusoidal tone for each of two frequencies (697 and 1209 hertz (Hz)).

DTMF Keypad Frequencies:

	1209 Hz	1336 Hz	1477 Hz	1633 Hz
697 Hz	1	2	3	A
770 Hz	4	5	6	B
852 Hz	7	8	9	C
941 Hz	*	0	#	D

Methods of Transmitting DTMF Digit

Three methods of transmitting DTMF digits on SIP calls:

- **RFC 2833** -- DTMF digits are transmitted by RTP Events compliant to RFC 2833.
- **INBAND** -- DTMF digits are transmitted in the voice band.
- **SIP INFO** -- DTMF digits are transmitted by SIP INFO messages.

The method of transmitting DTMF digits is configurable on a per-line basis.

RFC 2833

DTMF digits are transmitted using the RTP Event packets that are sent along with the voice path. These packets use RFC 2833 format and must have a payload type that matches what the other end is listening for. The default payload type for RTP Event packets is 101 and the payload type is configurable. The VC110 uses the configured value to negotiate with the other end during call establishment.

The RTP Event packet contains 4 bytes. The 4 bytes are distributed over several fields denoted as Event, End bit, R-bit, Volume and Duration. If the End bit is set to 1, the packet contains the end of the DTMF event. You can configure the sending times of the end RTP Event packet.

INBAND

DTMF digits are transmitted within the audio of the IP phone conversation. It uses the same codec as your voice and is audible to conversation partners.

SIP INFO

DTMF digits are transmitted by the SIP INFO messages when the voice stream is established after a successful SIP 200 OK-ACK message sequence. The SIP INFO message is sent along the signaling path of the call. The SIP INFO message can transmit DTMF digits in three ways: DTMF, DTMF-Relay and Telephone-Event.

DTMF parameters on the endpoint are described below:

Parameter	Description	Configuration Method
DTMF Type	<p>Configures the DTMF type. You can configure it for the Cloud platform, SIP account or SIP IP call separately.</p> <ul style="list-style-type: none"> • INBAND—DTMF digits are transmitted in the voice band. • RFC2833—DTMF digits are transmitted by RTP Events compliant to RFC2833. • SIP INFO—DTMF digits are transmitted by the SIP INFO messages. • RFC2833+ SIP INFO—DTMF digits are transmitted by RTP Events compliant to RFC 2833 and the SIP INFO messages. <p>Default: RFC2833.</p>	<p>Remote Control</p> <p>Web User Interface</p>
DTMF Info Type	<p>Configures the DTMF info type when DTMF type is set to SIP INFO or RFC2833+SIP INFO. You can configure it for the Cloud platform, SIP account or SIP IP call separately</p> <ul style="list-style-type: none"> • DTMF-Relay • DTMF • Telephone-Event <p>Default: DTMF-Relay.</p>	<p>Remote Control</p> <p>Web User Interface</p>
DTMF Payload Type (96~127)	<p>Configures the value of DTMF payload. You can configure it for the Cloud platform, SIP account or SIP IP call separately.</p> <p>Default: 101</p>	<p>Web User Interface</p>

To configure DTMF type for Cloud platform via web user interface:

1. Click on **Account->Cloud**.
2. Select the desired value from the pull-down list of **DTMF Type**.
3. If **SIP INFO** or **RFC2833+ SIP INFO** is selected, select the desired value from the pull-down list of **DTMF Info Type**.

- Enter the desired value in the **DTMF Payload Type(96~127)** field.

The screenshot shows the Yealink VC110 web interface. The top navigation bar includes 'About', 'Language', and 'Logout'. The main menu has 'Home', 'Status', 'Account', 'Network', 'Setting', 'Directory', and 'Security'. The 'Account' tab is selected. On the left, a sidebar lists 'Cloud', 'H.323', 'SIP Account', 'SIP IP Call', and 'Codec'. The 'Cloud' section is active. The 'Cloud' settings include: Register Status (Registered), Cloud Account (Enabled), Platform Type (Yealink Cloud), Username (584921002), Password (masked), and Server Host (yealinkvc.com) with Port 0. The 'Advanced Setting' section is highlighted with a red box and contains: DTMF Type (SIP INFO), DTMF Info Type (DTMF-Relay), and DTMF Payload Type (96~127) (101).

- Click **Confirm** to accept the change.

To configure DTMF type for SIP account via web user interface:

- Click on **Account->SIP Account**.
- Select the desired value from the pull-down list of **DTMF Type**.

If **SIP INFO** or **RFC2833+ SIP INFO** is selected, select the desired value from the pull-down list of **DTMF Info Type**.

- Enter the desired value in the **DTMF Payload Type(96~127)** field.

The screenshot shows the Yealink VC110 web interface with the 'SIP Account' tab selected. The left sidebar lists 'Cloud', 'H323', 'SIP Account', 'SIP IP Call', and 'Codec'. The 'SIP Account' settings include: Register Status (Registered), SIP Account (Enabled), Username (9000), Register Name (9000), Password (masked), Server Host (10.2.1.48) with Port 5060, Enable Outbound Proxy Server (Disabled), Outbound Proxy Server (empty) with Port 5060, Transport (UDP), Server Expires (3600), SRTP (Disabled), and NAT Traversal (Disabled). The 'DTMF Type', 'DTMF Info Type', and 'DTMF Payload Type (96~127)' fields are highlighted with a red box and contain the values 'SIP INFO', 'DTMF-Relay', and '101' respectively.

- Click **Confirm** to accept the change.

To configure DTMF type for SIP IP call via web user interface:

- Click on **Account->SIP IP Call**.
- Select the desired value from the pull-down list of **DTMF Type**.
If **SIP INFO** or **RFC2833+ SIP INFO** is selected, select the desired value from the pull-down list of **DTMF Info Type**.
- Enter the desired value in the **DTMF Payload Type(96~127)** field.

The screenshot shows the Yealink VC110 web interface. The 'Account' tab is selected, and the 'SIP IP Call' sub-tab is active. The configuration page includes a sidebar with options like Cloud, H323, SIP Account, SIP IP Call, and Codec. The main content area shows various settings for SIP IP Call, including SIP IP Call (Enabled), Transport (TCP), SRTP (Disabled), DTMF Type (SIP INFO), DTMF Info Type (DTMF), DTMF Payload Type (96~127) (101), NAT Traversal (Disabled), RPort (Enabled), BFCP (Enabled), and FECC(SIP) (Enabled). The DTMF Type, DTMF Info Type, and DTMF Payload Type fields are highlighted with a red rectangle.

- Click **Confirm** to accept the change.

DTMF parameters for H.323 protocol on the endpoint are described below:

Parameter	Description	Configuration Method
DTMF Type	<p>Configures the DTMF type. You can configure it for the StarLeaf Cloud platform or H.323 call separately.</p> <ul style="list-style-type: none"> INBAND—DTMF digits are transmitted in the voice band. Auto—the endpoint automatically negotiates the way (INBAND, RFC2833 or SIP INFO) to transfer DTMF digits. <p>Default: Auto</p>	<p>Remote Control</p> <p>Web User Interface</p>

To configure DTMF type for StarLeaf Cloud platform via web user interface:

- Click on **Account->Cloud**.
- Select **StarLeaf** from the pull-down list of **Platform Type**.

3. Select the desired value from the pull-down list of **DTMF Type**.

The screenshot shows the Yealink VC110 web interface. The top navigation bar includes 'About', 'Language', and 'Logout'. The main navigation bar has 'Home', 'Status', 'Account' (selected), 'Network', 'Setting', 'Directory', and 'Security'. On the left, a sidebar menu lists 'Cloud', 'H.323', 'SIP Account', 'SIP IP Call', and 'Codec'. The main content area is titled 'Cloud' and contains the following settings:

Cloud	
Register Status	Registered
Cloud Account	Enabled
Platform Type	StarLeaf
QCP Code	367037241953
Advanced Setting	
H.323 Tunneling	Disabled
H.235 Encryption	Disabled
Protocol Monitor Port	1720
DTMF Type	Auto
Local Early Media	Disabled
H.239	Enabled
FECC(H.323)	Enabled

4. Click **Confirm** to accept the change.

To configure DTMF type for H.323 via web user interface:

1. Click on **Account**->**H.323**.

2. Select the desired value from the pull-down list of **DTMF Type**.

The screenshot shows the Yealink VC110 web interface. The left sidebar has a menu with 'H323' selected. The main content area is titled 'H.323 Account' and contains various configuration fields. The 'DTMF Type' field, located near the bottom, is a dropdown menu currently set to 'INBAND' and is highlighted with a red rectangular box. Other fields include 'H.323 Name' (9000), 'H.323 Extension' (9000), 'Gatekeeper Mode' (Manual), 'Gatekeeper IP Address 1' (10.2.1.43), 'Gatekeeper IP Address 2' (empty), 'Gatekeeper Authentication' (Disabled), 'Gatekeeper Username' (empty), 'Gatekeeper Password' (masked), 'H.460 Active' (Disabled), 'H.323 Tunneling' (Disabled), 'H235 Encryption' (Disabled), 'Protocol Monitor Port' (1720), 'H.239' (Enabled), and 'FECC(H.323)' (Enabled).

3. Click **Confirm** to accept the change.

Codecs

CODEC is an abbreviation of COMPRESS-DECOMPRESS, and is capable of coding or decoding a digital data stream or signal by implementing an algorithm. The object of the algorithm is to represent the high-fidelity audio/video signal with a minimum number of bits while retaining quality. This can effectively reduce the frame size and the bandwidth required for audio/video transmission.

Audio Codecs

The audio codec that the endpoint uses to establish a call should be supported by the server. When placing a call, the endpoint will offer the enabled audio codec list to the server and then use the audio codec negotiated with the called party according to the priority.

The following table summarizes the supported audio codecs on the endpoint:





Codec	Algorithm	Bit Rate	Sample Rate	Reference
G.722.1c	G.722.1	48 Kbps	32 Ksps	RFC 5577
G.722.1c		32 Kbps	32 Ksps	RFC 5577
G.722.1c		24 Kbps	32 Ksps	RFC 5577

Codec	Algorithm	Bit Rate	Sample Rate	Reference
G.722.1	G.722.1	24 Kbps	16 or 32 Ksps	RFC 5577
G722	G.722	64 Kbps	16 Ksps	RFC 3551
PCMU	G.711	64 Kbps	8 Ksps	RFC 3551
PCMA	G.711	64 Kbps	8 Ksps	RFC 3551


Audio codecs parameters on the endpoint are described below:

Parameter	Description	Configuration Method
Enable Codecs	Specifies the enabled audio codecs for the endpoint to use. Note: All support audio codecs are enabled on the endpoint by default.	Web User Interface
Disable Codecs	Specifies the disabled audio codecs for the endpoint not to use.	Web User Interface
Special audio codec byte sequence	Enables or disables the special audio codec byte sequence. Note: Different devices have different definition about how some Codecs are stored (Big-endian or little-endian), which may lead to the audio incompatibility problems between Yealink and certain devices. You can enable the special audio codec byte sequence feature to solve these incompatibility problems.	Web User Interface

To configure audio codecs via web user interface:

1. Click on **Account->Codec**.
2. Select the desired codec from the **Disable Codecs** or the **Enable Codecs** column.
3. Click  or  to disable or enable the selected codec.
4. Select the desired audio codec from the **Enable Codecs** column, and click  or  to adjust the priority of the selected audio codecs.

5. (Optional.) If Yealink device has audio problems with certain device, select **Enabled** from the pull-down list of **Special audio codec byte sequence**.



6. Click **Confirm** to accept the change.

Video Codecs

The video codec that the endpoint uses to establish a call should be supported by the server. When placing a call, the endpoint will offer the enabled video codec list to the server and then use the video codec negotiated with the called party according to the priority.





The following table summarizes the supported video codecs on the endpoint:


Name	MIME Type	Bit Rate	Frame Rate	Frame Size
H.264 High Profile	H264/90000	90 kbps to 2048 kbps	5 fps to 30 fps	Tx: WQVGA,360P, 448P, 540P, 720P, 1080P
H.264	H264/90000			Rx: Conventional Size Below 1080P
H.263	H263/90000			Tx: CIF, 4CIF RX: QCIF, CIF, 4CIF

Video codecs parameters on the endpoint are described below:

Parameter	Description	Configuration Method
Enable Codecs	Specifies the enabled video codecs for the endpoint to use. Note: All support video codecs are enabled on the endpoint by default.	Web User Interface
Disable Codecs	Specifies the disabled video codecs for the endpoint not to use.	Web User Interface

To configure video codecs via web user interface:

1. Click on **Account->Codec**.
2. Select the desired video codec from the **Disable Codecs** or the **Enable Codecs** column.
3. Click  or  to disable or enable the selected video codec.
4. Select the desired video codec from the **Enable Codecs** column, and click  or  to adjust the priority of the selected video codecs.



5. Click **Confirm** to accept the change.

Call Protocol

The endpoint supports SIP and H.323 protocols for incoming and outgoing calls. H.323 is commonly used to communicate to other video conferencing endpoint. SIP is commonly used


to communicate with other VoIP devices. The default call protocol on the endpoint is Auto. The endpoint preferentially uses the H.323 protocol to place calls. If there is no available H.323 account on the endpoint, the endpoint will switch to the SIP protocol for placing calls. You can specify the desired protocol for the endpoint to place calls. Ensure the remote endpoint supports the same protocol.

The call protocol parameter on the endpoint is described below:

Parameter	Description	Configuration Method
Call Protocol	<p>Specifies the desired call protocol for placing calls.</p> <ul style="list-style-type: none"> Auto—the endpoint automatically uses the available call protocol. SIP—the endpoint uses the SIP protocol for placing calls. H.323—the endpoint uses H.323 protocol for placing calls. <p>Default: Auto</p>	<p>Remote Control</p> <p>Web User Interface</p>

To configure call protocol via web user interface:

1. Click on **Setting->Call Features**.
2. Select the desired value from the pull-down list of **Call Protocol**.



3. Click **Confirm** to accept the change.

To configure call protocol via the remote control:

1. Select **Menu->Call Features ->Call Protocol**.
2. Select the desired value from the pull-down list of **Call Protocol**.
3. Press the **Save** soft key to accept the change.

Do Not Disturb


Do not Disturb allows the endpoint to reject all incoming calls automatically. You can activate the DND mode for the endpoint when it is idle, and the DND mode will be deactivated after the endpoint places a call. You can also activate the DND mode for the endpoint during a call, and the DND mode will be deactivated after the endpoint ends the call.

The DND parameter on the endpoint is described below:


Parameter	Description	Configuration Method
DND	Enables or disables DND mode on the endpoint. Default: Disabled	Remote Control Web User Interface

To configure DND via web user interface:

1. Click on **Setting->Call Features**.
2. Select the desired value from the pull-down list of **DND**.




3. Click **Confirm** to accept the change.

If **Enabled** is selected, the display device will display , and the LCD screen of the video conferencing phone will display **DND**.


To configure DND via the remote control:

1. Select **Menu->Call Features**.
2. Check the **DND** checkbox.
3. Press the **Save** soft key to accept the change.

The display device will display , and the LCD screen of the video conferencing phone will display **DND**.


To configure DND during a call via web user interface:

1. Click **Home**.
2. Check the **DND** checkbox.

The display device will display , and the LCD screen of the video conferencing phone will display **DND**.

To configure DND during a call via the remote control:

1. Press the **More** soft key.
2. Check the **DND** checkbox.
3. Press the **Back** soft key to exit the **More** window.

The display device will display , and the LCD screen of the video conferencing phone will display **DND**.

Auto Answer

The auto answer feature allows the endpoint to answer incoming calls automatically. The auto answer mute feature allows the endpoint to turn off the microphone when an incoming call is answered automatically. The auto answer mute feature is available only when the auto answer feature is enabled. The auto answer multiway feature allows the endpoint to answer new incoming calls automatically during an active call.

Auto answer parameters on the endpoint are described below:

Parameter	Description	Configuration Method
Auto Answer	Enables or disables the auto answer feature on the endpoint. Default: Enabled	Remote Control Web User Interface
Auto Answer Mute	Enables or disables the auto answer mute feature on the endpoint. Default: Enabled	Remote Control Web User Interface

Parameter	Description	Configuration Method
	Auto answer mute feature is configurable only when the auto answer is enabled.	
Auto Answer Multiway	<p>Enables or disables the auto answer multiway feature on the endpoint.</p> <p>Default: Disabled</p> <p>The auto answer multiway feature is available only when the auto answer is enabled.</p>	<p>Remote Control</p> <p>Web User Interface</p>

To configure auto answer via web user interface:

1. Click on **Setting->Call Features**.
2. Select the desired value from the pull-down list of **Auto Answer**.
3. Select the desired value from the pull-down list of **Auto Answer Mute**.
4. Select the desired value from the pull-down list of **Auto Answer Multiway**.

The screenshot shows the Yealink VC110 WUI with the 'Setting' tab selected. The left sidebar lists various configuration categories, with 'Call Features' highlighted. The main content area displays a list of settings. A red rectangle highlights the 'Auto Answer', 'Auto Answer Mute', and 'Auto Answer Multiway' settings, all of which are currently set to 'Enabled', 'Enabled', and 'Disabled' respectively. Other settings like 'Auto Dialout Mute', 'Call Match', 'History Record', 'Call Protocol', 'Uplink Bandwidth', 'Downlink Bandwidth', 'Abnormal Call Answering', 'Safe Mode Call', 'Ringback Timeout(30-240)', 'Auto Refuse Timeout(30-240)', and 'SIP IP Call by Proxy' are also visible with their respective values.

5. Click **Confirm** to accept the change.

If **Enabled** is selected, the display device will display **AA**, and the LCD screen of the video conferencing phone will display **AA**.

To configure auto answer via the remote control:

1. Select **Menu->Call Features**.
2. Check the **Auto Answer** checkbox.

3. Check the **Auto Answer Mute** checkbox.
4. Check the **Auto Answer Multiway** checkbox.
5. Press the **Save** soft key to accept the change.

The display device will display **AA**, and the LCD screen of the video conferencing phone will display **AA**.

Auto Dialout Mute


The auto dialout mute feature allows the endpoint to turn off the microphone when placing a call, so that the other party cannot hear you.

Auto dialout mute parameter on the endpoint is described below:


Parameter	Description	Configuration Method
Auto Dialout Mute	Enables or disables the auto dialout mute feature on the endpoint. Default: Disabled	Web User Interface

To configure auto dialout mute feature via web user interface:

1. Click on **Setting->Call Features**.
2. Select the desired value from the pull-down list of **Auto Dialout Mute**.



3. Click **Confirm** to accept the change.

If **Enabled** is selected, your video image will display mute icon () when you place a call.

Call Match


The call match feature allows the endpoint to search entries automatically from the search source list based on the entered string. Once matched, the results will be displayed on the screen. If no list is added to the search source list, the endpoint will not perform a search even if call match is enabled. For more information on how to search source list in dialing, refer to [Search Source List in Dialing](#) on page 228.

Parameter of call match on the endpoint is described below:

Parameter	Description	Configuration Method
Call Match	Enables or disables the call match feature on the endpoint. Default: Enabled	Remote Control Web User Interface

To configure call match via web user interface:

1. Click on **Setting->Call Features**.
2. Select the desired value from the pull-down list of **Call Match**.



3. Click **Confirm** to accept the change.

To configure call match via the remote control:

1. Select **Menu->Call Features**.
2. Check the **Call Match** checkbox.
3. Press the **Save** soft key to accept the change.

History Record


The endpoint maintains a local call history, which contains call information such as remote party identification, time and date, and call duration. Users can manage call history list via the remote control, web user interface and video conferencing phone. To save call history, you must enable the history record feature on the endpoint in advance. If history record feature is disabled, the endpoint will not save call log and prompt the missed call.

The history record parameter on the endpoint is described below:

Parameter	Description	Configuration Method
History Record	Enables or disables the history record feature on the endpoint. Default: Enabled	Remote Control Web User Interface

To configure history record via web user interface:

1. Click on **Setting->Call Features**.
2. Select the desired value from the pull-down list of **History Record**.



3. Click **Confirm** to accept the change.

To configure history record via the remote control:

1. Select **Menu->Call Features**.
2. Check the **History Record** checkbox.
3. Press the **Save** soft key to accept the change.

Bandwidth

The endpoint automatically detects the available bandwidth for call connection by default. The VC110 supports connecting to other devices with different bandwidth. If a device with lower bandwidth joins a call, the video quality will stay the same or will not reduce a lot. You can specify the uplink and downlink bandwidths for the endpoint to achieve the best result. Uplink bandwidth is the max bandwidth of outgoing calls. And downlink bandwidth is the max bandwidth of incoming calls. The configurable bandwidths on the endpoint are: 256 kb/s, 384 kb/s, 512 kb/s, 640 kb/s, 768 kb/s, 1024 kb/s, 1280 kb/s, 1500 kb/s, 2000 kb/s, 3000 kb/s, 4000 kb/s. You can configure which bandwidth is to be used when in the dialing screen. The optional maximum bandwidth in dialing screen is the uplink bandwidth.

Note

The actual bandwidth depends on the performance of the remote endpoint, and is affected by the quality of the communication channel.

Bandwidth settings parameters on the endpoint are described below:

Parameter	Description	Configuration Method
Uplink Bandwidth	Specifies the maximum transmitting bandwidth for the endpoint. Default: Auto If Auto is selected, the endpoint will negotiate the appropriate uplink bandwidth automatically.	Remote Control Web User Interface
Downlink Bandwidth	Specifies the maximum receiving bandwidth for the endpoint. Default: Auto If Auto is selected, the endpoint will negotiate the appropriate downlink bandwidth automatically.	Remote Control Web User Interface

To configure bandwidth via web user interface:

1. Click on **Setting->Call Features**.
2. Select the desired value from the pull-down list of **Uplink Bandwidth**.

3. Select the desired value from the pull-down list of **Downlink Bandwidth**.

The screenshot shows the Yealink VC110 web interface. The 'Setting' tab is active. On the left sidebar, 'Call Features' is selected. The main content area shows various settings. 'Uplink Bandwidth' and 'Downlink Bandwidth' are highlighted with a red box, both set to 'Auto'. Other settings include DND (Disabled), Auto Answer (Enabled), Auto Answer Mute (Enabled), Auto Answer Multiway (Disabled), Auto Dialout Mute (Disabled), Call Match (Enabled), History Record (Enabled), Call Protocol (Auto), Abnormal Call Answering (IP Call Answer), Safe Mode Call (Enabled), Ringback Timeout(30-240) (200), Auto Refuse Timeout(30-240) (120), and SIP IP Call by Proxy (Off).

4. Click **Confirm** to accept the change.

To configure bandwidth via the remote control:

1. Select **Menu->Call Features->Bandwidth Settings**.
2. Select the desired value from the pull-down list of **Uplink Bandwidth**.
3. Select the desired value from the pull-down list of **Downlink Bandwidth**.
4. Press the **Save** soft key to accept the change.

Note

The priority of bandwidth is as follows: System bandwidth>Contact bandwidth (refer to [add local contacts](#)).

For example: the system bandwidth is 512kbps, if contact bandwidth is set to a value greater than 512bps, then the actual contact bandwidth will be 512bps. If contact bandwidth is set to a value less than 512bps, then the actual contact bandwidth will be the value set by user.

Ringback Timeout

Ringback timeout defines a specific period of time within which the VC110 video conferencing endpoint will cancel the dialing if the call is not answered.


The ringback timeout parameter on the endpoint is described below:

Parameter	Description	Configuration Method
Ringback Timeout	Configures the duration time (in	Web User Interface

Parameter	Description	Configuration Method
(30-240)	seconds) in the ringback state. Default: 200 If it is set to 200, the endpoint will cancel the dialing if the call is not answered within 200s.	

To configure ringback timeout via web user interface:

1. Click on **Setting->Call Features**.
2. Select the desired value from the pull-down list of **Ringback Timeout(30-240)**.



3. Click **Confirm** to accept the change.

Auto Refuse Timeout

Auto refuse timeout defines a specific period of time within which the video conferencing endpoint will stop ringing if the call is not answered.


The auto refuse timeout parameters on the endpoint are described below:

Parameter	Description	Configuration Method
Auto Refuse Timeout (30-240)	Configures the duration time (in seconds) in the ringing state. Default: 120	Web User Interface

Parameter	Description	Configuration Method
	If it is set to 120, the endpoint will stop ringing if the call is not answered within 120s.	

To configure auto refuse timeout via web user interface:

1. Click on **Setting->Call Features**.
2. Select the desired value from the pull-down list of **Auto Refuse Timeout (30-240)**.



3. Click **Confirm** to accept the change.

SIP IP Call by Proxy

If the account of far site is an URI address (Username@Server), near site can use SIP IP call or SIP account to connect to the far site.


The SIP IP call by proxy parameters on the endpoint are described below:

Parameter	Description	Configuration Method
SIP IP Call by Proxy	<p>Configures the SIP IP call by proxy.</p> <ul style="list-style-type: none"> • Off—when dialing the URI of the far site, the endpoint actually uses SIP IP address to establish a connection. • On—when dialing the URI of 	Web User Interface

Parameter	Description	Configuration Method
	the far site, the endpoint uses SIP account to establish a connection. The outbound proxy server should be configured to resolve hostname before dialing. Default: Off	

To configure the SIP IP call by proxy via web user interface:

1. Click on **Setting->Call Features**.
2. Select the desired value from the pull-down list of **SIP IP Call by Proxy**.



3. Click **Confirm** to accept the change.

Default Layout of Single Screen

When only one display device is connected to the VC110 all-in-one unit (single screen), you can configure the default screen layout when a call is established.

The parameters of default layout of single screen are described below:

Parameter	Description	Configuration Method
Default Layout of Single Screen	Configures the default layout of single screen when a call is	Web User Interface

Parameter	Description	Configuration Method
	<p>established.</p> <ul style="list-style-type: none"> • Remote big Local small • Remote Full screen • Equal <p>Default: Remote Full screen</p> <p>If it is set to Remote big Local small, the remote video image is shown in big size, and the local video image along the right side of the screen is shown in small size when a call is established.</p> <p>If it is set to Remote Full screen, the remote video image is shown in full size when a call is established.</p> <p>If it is set to Equal, the remote and local video images are shown in the same size when a call is established.</p>	

To configure default layout of single screen via web user interface:

1. Click on **Setting->Call Features**.

2. Select the desired value from the pull-down list of **Default Layout of Single Screen**.

The screenshot displays the Yealink VC110 web interface. The top navigation bar includes 'About', 'Language', and 'Logout'. The main menu has 'Home', 'Status', 'Account', 'Network', 'Setting' (highlighted), 'Directory', and 'Security'. On the left, a sidebar lists various settings categories: General, Date & Time, Call Features (selected), Video & Audio, Camera, Configuration, Upgrade, Tones, Wireless Micpod, and 3rd-Party VMR. The main content area shows a list of settings with their current values:

Setting	Value
Auto Answer	Enabled
Auto Answer Mute	Enabled
Auto Answer Multiway	Disabled
Auto Dialout Mute	Disabled
Call Match	Enabled
History Record	Enabled
Call Protocol	Auto
Uplink Bandwidth	Auto
Downlink Bandwidth	Auto
Abnormal Call Answering	IP Call Answer
Safe Mode Call	Enabled
Ringback Timeout(30-240)	200
Auto Refuse Timeout(30-240)	120
SIP IP Call by Proxy	Off
Default Layout of Single Screen	Remote Full screen
Network Address Adapter	Enabled

At the bottom of the settings list, there are 'Confirm' and 'Cancel' buttons.

3. Click **Confirm** to accept the change.

Configuring Endpoint Settings

This chapter provides information for making configuration changes for the endpoint, such as language, time and date, backlight of the video conferencing phone, video & audio settings and camera settings:

Topics include:

- [General Settings](#)
- [Audio Settings](#)
- [Adjusting MTU of Video Packets](#)
- [Dual-Stream Protocol](#)
- [Mix Sending](#)
- [Configuring Camera Settings](#)
- [Far-end Camera Control](#)
- [Camera Control Protocol](#)
- [Output Resolution](#)
- [USB Configuration](#)
- [Video Recording](#)
- [Screenshot](#)
- [Tones](#)

General Settings

Site Name

When the endpoint is idle, the site name is displayed on the status bar of display device and video conferencing phone. You can make an IP address call to the far site, the site name will be displayed on the display device of the far site. Site name can consist of letters, numbers or special characters. You can configure the site name of the endpoint via the remote control or web user interface.


The site name parameter is described below:

Parameter	Description	Configuration Method
Site Name	Configures the site name of the endpoint. Valid values: String within 64	Remote Control Web User Interface

Parameter	Description	Configuration Method
	characters Default: Yealink VC110	

To configure the site name via web user interface:

1. Click on **Setting**->**General**.
2. Edit the site name in the **Site Name** field.



3. Click **Confirm** to accept the change.

The LCD screen of the display device and video conferencing phone will display the changed site name.

To configure the site name via the remote control:

1. Select **Menu**->**Basic**.
2. Edit the site name in the **Site Name** field.
3. Press the **Save** soft key to accept the change.

The LCD screen of the display device and video conferencing phone will display the changed site name.

Backlight of the Video Conferencing Phone

Backlight determines the brightness of the LCD screen display, allowing users to read easily in dark environments. Backlight time specifies the delay time to turn off the backlight when the phone is inactive.

You can configure the backlight time as one of the following types:

- **Always On:** Backlight is turned on permanently.
- **15 s, 30 s, 10 min, 20 min, 30 min, 1 Hour, 2 Hour, 3 Hour, 4 Hour:** Backlight is turned off when the phone is inactive after a preset period of time. It is automatically turned on if the status of the phone changes or any key is pressed.

The backlight parameter on video conferencing phone is described below:

Parameter	Description	Configuration Method
Backlight Time	Configures the backlight time of the video conferencing phone. Default: Always On	Web User Interface

To configure the backlight time of the video conferencing phone via web user interface:

1. Click on **Setting**->**General**.
2. Select the desired value from the pull-down list of **Backlight Time**.

The screenshot shows the Yealink VC110 web interface. The 'Setting' tab is active, and the 'General' sub-tab is selected. Under 'General Information', the 'Backlight Time' is set to 'Always On'. A red rectangle highlights the 'Backlight Time' dropdown menu. Other settings include Site Name (Yealink VC110), Automatic Sleep Time (10 Min), Hide IP Address (Disabled), ReLogOffTime (5), and Key Tone (On). There is also a 'Hide Icon in Call' checkbox.

3. Click **Confirm** to accept the change.

Language

The default language of the LCD screen of the display device and the video conferencing phone is English, and you can change it via the remote control. The video conferencing phone will detect and use the same language as the display device.

The default language of the web user interface is English. You can change the language of the web user interface via web user interface. The available languages for endpoint are English, Chinese Simplified, Chinese Traditional, French, German, Italian, Polish, Portuguese, Spanish, Turkish and Russian.


The language parameters on the endpoint are described below:

Parameter	Description	Configuration Method
Language	Specifies the language for the web user interface	Web User Interface
Language	Specifies the language for the LCD screen of the display device and the video conferencing phone.	Remote Control

Parameter	Description	Configuration Method
	Default: English	

To specify the language for the web user interface via web user interface:

1. Click **Language** at the top of the web page.
2. Select the desired language from the pull-down list of **Language**.



To specify the language for the display device and the video conferencing phone via the remote control:

1. Select **Menu->Basic**.
2. Select the desired language from the pull-down list of **Language**.
3. Press the **Save** soft key to accept the change.

Date & Time

Time and date are displayed on the idle screen of the display device and the video conferencing phone. Time and date are synced automatically from the NTP server by default. The default NTP server is cn.pool.ntp.org. The NTP server is configurable manually or obtained by DHCP via DHCP Option 42. The phone will use the NTP server obtained by DHCP preferentially. If the endpoint cannot obtain the time and date from the NTP server, you need to manually configure them. The time and date can use one of several different formats.

Time Zone

A time zone is a region on Earth that has a uniform standard time. It is convenient for areas in close commercial or other communication to keep the same time. When configuring the endpoint to obtain the time and date from the NTP server, you must set the time zone.

Daylight Saving Time

Daylight Saving Time (DST) is the practice of temporary advancing clocks during the summertime so that evenings have more daylight and mornings have less. Typically, clocks are adjusted forward one hour at the start of spring and backward in autumn. Many countries have used DST at various times, details vary by location. DST can be adjusted automatically from the time zone configuration. Typically, there is no need to change this setting.

DST parameters are described below:

Parameter	Description	Configuration Method
DHCP Time	Enables or disables the endpoint to update time with the offset time obtained from the DHCP server. Default: Disabled Note: it is only available to GMT 0.	Web User Interface
Time Zone	Configures the time zone. Default: +8 China (Beijing)	Remote Control Web User Interface
Primary Server/NTP Primary Server	Configures the primary NTP server. Default: cn.pool.ntp.org	Remote Control Web User Interface
Secondary Server/NTP Secondary Server	Configures the secondary NTP server. Default: cn.pool.ntp.org	Remote Control Web User Interface
Synchronism (15~86400s)	Configures the interval (in minutes) for the endpoint to synchronize time and date with NTP server. Default: 1000.	Web User Interface
Daylight Saving Time	Configures the Daylight Saving Time (DST) type. The available types for the endpoint are: <ul style="list-style-type: none"> • Disabled-not use DST. • Enabled-use DST. You can manually configure the start time, end time and offset according to your	Remote Control Web User Interface

Parameter	Description	Configuration Method
	<p>needs.</p> <ul style="list-style-type: none"> • Automatic-use DST. DST will be configured automatically. You do not need to manually configure the start time, end time and offset. <p>Default: Automatic</p>	
Fixed Type	<p>Configures the DST calculation methods.</p> <ul style="list-style-type: none"> • By Date- specifies the month, day and hour to be the DST start /end date. • By Week- specifies the month, week, day and hour the DST start /end date. <p>Note: It only works if the value of Daylight Saving Time is set to Enabled.</p>	Web User Interface
Start Date	<p>When the DST calculation method is set to By Date. Configures the time to start DST.</p> <p>Note: It only works if the value of the Daylight Saving Time is set to Enabled.</p>	Web User Interface
End Date	<p>When the DST calculation method is set to By Date. Configures the time to end DST.</p> <p>Note: It only works if the value of the Daylight Saving Time is set to Enabled.</p>	Web User Interface
DST Start Month	<p>When the DST calculation method is set to By Week. Configures the time to start DST.</p> <p>Note: It only works if the value of the Daylight Saving Time is set</p>	Web User Interface
DST Start Day of Week		
DST Start Day of Week Last in Month		

Parameter	Description	Configuration Method
Start Hour of Day	to Enabled.	
DST Stop Month	When the DST calculation method is set to By Week , Configures the time to end DST. Note: It only works if the value of the Daylight Saving Time is set to Enabled.	Web User Interface
DST Stop Day of Week		
DST Stop Day of Week Last in Month		
End Hour of Day		
Offset(minutes)	Configures the DST offset time (in minutes). Valid values: -300 to +300. Note: It only works if the value of the Daylight Saving Time is set to Enabled.	Web User Interface
Time Type	Configures the DST time type. <ul style="list-style-type: none"> SNTP: obtain the time and date from the NTP server automatically. Manual Time: configure the time and date manually. Default: SNTP	Remote Control Web User Interface
Time Format/ Time	Configures the time format. <ul style="list-style-type: none"> Hour12 Hour24 Default: Hour 24	Remote Control Web User Interface
Date Format/Date	Configures the date format. <ul style="list-style-type: none"> WWW MMM DD DD-MMM-YY YYYY-MM-DD DD/MM/YYYY MM/DD/YY DD MMM YYYY WWW DD MMM Default: YYYY-MM-DD	Remote Control Web User Interface

To configure the NTP server, time zone and DST via web user interface:

1. Click on **Setting**->**Date& Time**.
2. Select **Disabled** from the pull-down list of **Manual Time**.
3. Select the desired time zone from the pull-down list of **Time Zone**.
4. Enter the domain names or IP addresses in the **Primary Server** and **Secondary Server** fields respectively.
5. Enter the desired time interval in the **Synchronism (15~86400s)** field.
6. Select the desired value from the pull-down list of **Daylight Saving Time**.

If you select **Enabled**, do one of the following:

- Mark the **DST By Date** radio box in the **Fixed Type** field.

Enter the start time in the **Start Date** field.

Enter the end time in the **End Date** field.

- Mark the **DST By Week** radio box in the **Fixed Type** field.

Select the desired values from the pull-down lists of **DST Start Month**, **DST Start Day of Week**, **DST Start Day of Week Last in Month**, **DST Stop Month**, **DST Stop Day of Week** and **DST Stop Day of Week Last in Month**.

Enter the desired time in the **Start Hour of Day** field.

Enter the desired time in the **End Hour of Day** field.

The screenshot shows the Yealink VC110 web interface. The 'Setting' tab is selected. On the left sidebar, 'Date & Time' is highlighted. The main content area shows various settings. A red box highlights the 'Fixed Type' section, which includes:

- Fixed Type:** Radio buttons for 'DST By Date' and 'DST By Week' (selected).
- DST Start Month:** Dropdown menu set to 'January'.
- DST Start Day of Week:** Dropdown menu set to 'Sunday'.
- DST Start Day of Week Last in Month:** Dropdown menu set to 'First In Month'.
- Start Hour of Day:** Text input field.
- DST Stop Month:** Dropdown menu set to 'January'.
- DST Stop Day of Week:** Dropdown menu set to 'Sunday'.
- DST Stop Day of Week Last in Month:** Dropdown menu set to 'First In Month'.
- End Hour of Day:** Text input field.
- Offset(minutes):** Text input field.

7. Enter the desired offset time in the **Offset (minutes)** field.

8. Click **Confirm** to accept the change.

To configure the time and date manually via web user interface:

1. Click on **Setting->Date& Time**.
2. Select **Manual Time** from the pull-down list of **Time Type**.
3. Enter the current date in the **Date** field.
4. Enter the current time in the **Time** field.
5. Select the desired value from the pull-down list of **Time Format**.
6. Select the desired value from the pull-down list of **Date Format**.

The screenshot shows the Yealink VC110 web interface. The 'Setting' tab is selected. On the left sidebar, 'Date & Time' is highlighted. The main content area shows the 'Date & Time' settings. A red box highlights the 'Manual Time' section, which includes:

- Time Type:** Dropdown menu set to 'Manual Time'.
- Date:** Fields for Year (2016), Month (9), and Day (14).
- Time:** Fields for Hour (11), Minute (11), and Second (38).
- Time Format:** Dropdown menu set to 'Hour 24'.
- Date Format:** Dropdown menu set to 'YYYY-MM-DD'.

- Click **Confirm** to accept the change.

To configure the time and date format via the remote control:

- Select **Menu->Basic->Date & Time**.
- Configure the desired values.
- Press the **Save** soft key to accept the change.

The time and date displayed on the LCD screen of the display device and video conferencing phone will change accordingly.

Automatic Sleep Time

The endpoint will enter the sleep mode automatically when it has been inactive for a period of time (the default time is 10 minutes). When the endpoint is in sleep mode, it can still accept incoming calls. The display device will prompt "No Signal", and the LCD screen of the video conferencing phone prompts "Sleeping Press any key to resume". You can press any key on the remote control or the video conferencing phone to wake the endpoint up. When receiving a call, the endpoint will be woken up automatically.

You can change the automatic sleep time via the remote control or web user interface. You can also press the sleep key on the remote control to make the endpoint sleep immediately.

The automatic sleep time is described below:

Parameter	Description	Configuration Method
Automatic Sleep Time	<p>Configures the inactive time (in minutes) before the endpoint enter sleep mode.</p> <p>Default: 10 Min</p> <p>Note: During setup wizard, the automatic sleep time feature is disabled automatically. To protect the display device, you should configure the automatic sleep time immediately.</p>	<p>Remote Control</p> <p>Web User Interface</p>

To configure the automatic sleep time via web user interface:

- Click on **Setting->General**.

2. Select desired value from the pull-down list of **Automatic Sleep Time**.

The screenshot shows the Yealink VC110 web interface. The 'Setting' tab is selected. Under 'General Information', the 'Automatic Sleep Time' is set to '10 Min'. A red box highlights this dropdown menu. Other settings include Site Name (Yealink VC110), Backlight Time (Always On), Hide IP Address (Disabled), ReLogOffTime (5), and Key Tone (On). The 'Hide Icon in Call' option is also visible at the bottom of the settings list.

3. Click **Confirm** to accept the change.

To configure the automatic sleep time via the remote control:

1. Select **Menu->Basic**.
2. Select desired value from the pull-down list of **Automatic Sleep Time**.
3. Press the **Save** soft key to accept the change.

Hide IP Address

When the endpoint is idle, the display device displays shortcut keys and the status bar. The status bar displays time and date, site name, IP address, SIP, H.323 or Cloud account (when SIP, H.323 or Cloud account are registered). You can hide the endpoint IP address.

The hide IP address parameter is described below:

Parameter	Description	Configuration Method
Hide IP address	Enables or disables the endpoint to hide IP address. Default: Disabled	Web User Interface

To enable the hide IP address feature via web user interface:

1. Click on **Setting->General**.
2. Select **Enabled** from the pull-down list of **Hide IP Address**.

The screenshot shows the Yealink VC110 web interface. The top navigation bar includes 'About', 'Language', and 'Logout'. Below this is a green header with 'Yealink VC110' and tabs for 'Home', 'Status', 'Account', 'Network', 'Setting' (selected), 'Directory', and 'Security'. On the left, a sidebar lists various settings categories: General (selected), Date & Time, Call Features, Video & Audio, Camera, Configuration, Upgrade, Tones, Wireless Micpod, and 3rd-Party VMR. The main content area is titled 'General Information' and contains several settings: Site Name (Yealink VC110), Automatic Sleep Time (10 Min), Backlight Time (Always On), Hide IP Address (Enabled, highlighted with a red box), ReLogOffTime(1-1000min) (5), and Key Tone (On). At the bottom, there is a section for 'Hide Icon in Call'.

3. Click **Confirm** to accept the change.

The IP address is hidden from the status bar of the display device.

ReLog Offtime

The endpoint will log out of the web user interface automatically after being inactive for a period of time (default: 5 minutes). You need to re-enter the user name and password to login. You can only configure the relog offtime via web user interface.

The relog offtime parameter is described below:

Parameter	Description	Configuration Method
ReLogOffTime (1-1000min)	Configures the inactive time (in minutes) before the endpoint logs out of the web user interface automatically. Default: 5	Web User Interface

To configure the relog offtime via web user interface:

1. Click on **Setting->General**.

- Enter the desired time in the **ReLogOffTime (1-1000min)** field.

The screenshot shows the Yealink VC110 web interface. The top navigation bar includes links for About, Language, and Logout. The main menu has tabs for Home, Status, Account, Network, Setting (highlighted), Directory, and Security. On the left, a sidebar lists various settings categories: General, Date & Time, Call Features, Video & Audio, Camera, Configuration, Upgrade, Tones, Wireless Micpod, and 3rd-Party VMR. The 'General Information' section is active, displaying several configuration fields: Site Name (Yealink VC110), Automatic Sleep Time (10 Min), Backlight Time (Always On), Hide IP Address (Enabled), ReLogOffTime(1-1000min) (5, highlighted with a red box), and Key Tone (On). A 'Hide Icon in Call' option is also visible at the bottom of the section.

- Click **Confirm** to accept the change.

Key Tone

You can enable the key tone feature for the endpoint to make a keyboard click sound effect (key tone) when pressing a key on the remote control. If you disable this feature or endpoint ringer volume is adjusted to 0, the endpoint will not play a key tone when you press the key on the remote control.

Key tone is configurable via the remote control or web user interface.

The key tone parameter is described below:

Parameter	Description	Configuration Method
Key Tone	Enables or disables the key tone. Default: On	Remote Control Web User Interface

To configure the key tone via web user interface:

- Click on **Setting->General**.

2. Select the desired value from the pull-down list of **Key Tone**.

The screenshot shows the Yealink VC110 web interface. The top navigation bar includes 'About', 'Language', and 'Logout'. The main menu has 'Home', 'Status', 'Account', 'Network', 'Setting' (highlighted), 'Directory', and 'Security'. On the left, a sidebar lists various settings categories: General, Date & Time, Call Features, Video & Audio, Camera, Configuration, Upgrade, Tones, Wireless Micpod, and 3rd-Party VMR. The 'General Information' section is active, displaying several configuration fields. The 'Key Tone' field is highlighted with a red rectangle, showing a dropdown menu with 'On' selected. Other fields include Site Name (Yealink VC110), Automatic Sleep Time (10 Min), Backlight Time (Always On), Hide IP Address (Enabled), and ReLogOffTime (5 min). A 'Hide Icon in Call' option is also visible at the bottom of the section.

3. Click **Confirm** to accept the change.

To configure the key tone via the remote control:

1. Select **Menu->Basic**.
2. Mark the radio box in the **Key Tone** field.
3. Press the **Save** soft key to accept the change.

Meeting Blacklist

You can add the IP address, account or domain name of the remote endpoint to the meeting blacklist. VC110 will refuse incoming calls from the blacklist automatically. VC110 will not remind incoming calls and save call history from blacklist.

VC110 supports up to 100 blacklist records. Blacklist is configurable via web user interface only.

The blacklist parameter is described below:

Parameter	Description	Configuration Method
Meeting Blacklist Number	Add the IP address, account or domain name of the remote endpoint to the meeting blacklist. Default: blank	Web User Interface

To add the blacklist numbers via web user interface:

1. Click on **Directory->Blacklist**.
2. Enter the user's IP address, account or domain name in the **Meeting Blacklist Number** field.

3. Click **Add**.

The screenshot shows the Yealink VC110 web interface. On the left, there is a sidebar with options: Local Directory, History, LDAP, Meeting Blacklist (selected), and Setting. The main area has a table with two columns: 'Meeting Blacklist Number' and 'Operation'. The 'Meeting Blacklist Number' column contains the text '10.2.5.123'. The 'Operation' column has a '+ Add' button, which is highlighted with a red rectangular box.

4. Repeat step 2-3 to add more numbers to the meeting blacklist.

To delete the blacklist numbers via web user interface:

1. Click on **Directory**->**Blacklist**.
2. Click **Delete** beside the numbers that you want to delete.

The screenshot shows the Yealink VC110 web interface. On the left, there is a sidebar with options: Local Directory, History, LDAP, Meeting Blacklist (selected), and Setting. The main area has a table with two columns: 'Meeting Blacklist Number' and 'Operation'. The 'Meeting Blacklist Number' column contains the text '10.2.5.123'. The 'Operation' column has a '- Delete' button, which is highlighted with a red rectangular box.

The web user interface prompts the message "Warning: Are you sure delete the black number?".




3. Click **Confirm**.



Hiding Icons in a Call



During a call, the endpoint will display some information and icons (such as call time, mute icon and recording icon) by default, you can know the call status from these information and icons. You can also hide these icons as needed to achieve the best video effects.

Parameters of hiding icons in a call feature on the endpoint are described below:

Parameter	Description	Configuration Method
Time Icon	<p>Enables or disables the endpoint to hide call time during a call.</p> <ul style="list-style-type: none"> • Disabled- the endpoint does not display call time during a call. • Hide with UI- the endpoint displays call time during a call, 	Web User Interface

Parameter	Description	Configuration Method
	<p>but the call time will hide with UI.</p> <ul style="list-style-type: none"> • Enabled- the endpoint displays call time during a call. <p>Default: Hide with UI</p>	
Mute Icon	<p>Enables or disables the endpoint to hide mute icon () during a call.</p> <ul style="list-style-type: none"> • Disabled- the endpoint does not display mute icon during a call. • Hide with UI- the endpoint displays mute icon during a call, but the mute icon will hide with UI. • Enabled- the endpoint displays mute icon during a call. <p>Default: Disabled</p>	Web User Interface
Camera Icon	<p>Enables or disables the endpoint to hide camera icon () during a call.</p> <ul style="list-style-type: none"> • Disabled- the endpoint does not display camera icon during a call. • Hide with UI- the endpoint displays camera icon during a call, but the camera icon will hide with UI. • Enabled- the endpoint displays camera icon during a call. <p>Default: Disabled</p>	Web User Interface
Recording Icon	<p>Enables or disables the endpoint to hide recording icon () during a call.</p> <ul style="list-style-type: none"> • Disabled- the endpoint does not display recording icon 	Web User Interface

Parameter	Description	Configuration Method
	<p>during a call.</p> <ul style="list-style-type: none"> • Hide with UI- the endpoint displays recording icon during a call, but the recording icon will hide with UI. • Enabled- the endpoint displays recording icon during a call. <p>Default: Disabled</p>	
Sitename Icon	<p>Enables or disables the endpoint to hide site name icon during a call.</p> <ul style="list-style-type: none"> • Disabled- the endpoint does not display site name icon during a call. • Hide with UI- the endpoint displays site name icon during a call, but the site name icon will hide with UI. • Enabled- the endpoint displays site name icon during a call. <p>Default: Disabled</p>	Web User Interface
Hold Icon	<p>Enables or disables the endpoint to hide hold icon () during a call.</p> <ul style="list-style-type: none"> • Disabled- the endpoint does not display hold icon during a call. • Hide with UI- the endpoint displays hold icon during a call, but the hold icon will hide with UI. • Enabled- the endpoint displays hold icon during a call. <p>Default: Disabled</p>	Web User Interface
Encrypt Icon	<p>Enables or disables the endpoint to hide encrypt icon () during a call.</p>	Web User Interface

Parameter	Description	Configuration Method
	<ul style="list-style-type: none"> • Disabled- the endpoint does not display encrypt icon during a call. • Hide with UI- the endpoint displays encrypt icon during a call, but the encrypt icon will hide with UI. • Enabled- the endpoint displays encrypt icon during a call. <p>Default: Disabled</p>	
OutPut Mute Icon	<p>Enables or disables the endpoint to hide output mute icon (output volume is set to 0: ) during a call.</p> <ul style="list-style-type: none"> • Disabled- the endpoint does not display output mute icon during a call. • Hide with UI- the endpoint displays output mute icon during a call, but the output mute icon will hide with UI. • Enabled- the endpoint displays output mute icon during a call. <p>Default: Disabled</p>	Web User Interface
Gazeat Icon	<p>Enables or disables the endpoint to hide gazeat icon () during a call.</p> <ul style="list-style-type: none"> • Disabled- the endpoint does not display gazeat icon during a call. • Hide with UI- the endpoint displays gazeat icon during a call, but the gazeat icon will hide with UI. • Enabled- the endpoint displays gazeat icon during a 	Web User Interface

Parameter	Description	Configuration Method
	call. Default: Disabled	

To enable the hiding icons in a call feature via web user interface:

1. Click on **Setting->General**.
2. Select the desired values from the pull-down lists of **Time Icon**, **Mute Icon**, **Camera Icon**, **Recording Icon**, **Sitename Icon**, **Hold Icon**, **Encrypt Icon**, **OutPut Mute Icon**, and **Gazeat Icon**.

Hide Icon in Call		
Time Icon		Hide with UI
Mute Icon		Disabled
Camera Icon		Disabled
Recording Icon		Disabled
Sitename Icon		Disabled
Hold Icon		Disabled
Encrypt Icon		Disabled
OutPut Mute Icon		Disabled
Gazeat Icon		Disabled

3. Click **Confirm** to accept the change.



Keyboard Input Method



The on-screen keyboard supports English and Russian input methods.


You can enter characters using the input method only when the input method is enabled.

Changing keyboard input method is configurable via web user interface only.

To configure keyboard input method via web user interface:




1. Click on **Setting ->General**.
2. In the **Keyboard IME** block, select the desired list from the **Disabled** column and click  .
The selected input method appears in the **Enabled** column.
3. Repeat step 2 to add more input methods to the **Enabled** column.
4. (Optional.) To remove a list from the **Enabled** column, select the desired list and then click  .

- To adjust the display order of the enabled input methods, select the desired list, and click  or .



- Click **Confirm** to accept the change.

To change keyboard input method via the remote control:

- Press  (**Keyboard** soft key) or  (**Keyboard** soft key).
The display device appears the on-screen keyboard.
- Press  (**abc** soft key) to change the input method.

Audio Settings

Audio Output Device

The endpoint supports the following audio output devices:

- **Auto**
- **VCS Phone**
- **HDMI**
- **Line Output**

By default, the endpoint automatically selects the audio output devices with highest priority. The priority is: VCS Phone> HDMI>Line Output. If the audio output device with highest priority is removed from the VC110, the VC110 will select the next highest priority device.

You can also specify the desired audio output device via the remote control or the web user interface.

The audio output device parameter is described below:

Parameter	Description	Configuration Method
Audio Output	<p>Specifies the audio output device for the endpoint.</p> <p>Valid values:</p> <ul style="list-style-type: none"> • Auto - selects the audio output device with higher priority. • HDMI - selects the built-in speakerphone of the display device. • Line Output - selects the speakerphone connected to the Line Out port on the VC110 all-in-one unit. • VCS Phone - selects the video conferencing phone. <p>Default: Auto.</p> <p>If VCS Phone is selected as the audio output device manually or automatically, the audio input device must be VCS Phone or Line In+VCS Phone.</p>	<p>Remote Control</p> <p>Web User Interface</p>

To configure the audio output device feature via web user interface:

1. Click on **Setting->Video & Audio**.

2. Select the desired value from the pull-down list of **Audio Output**.

The screenshot shows the Yealink VC400 web interface. The top navigation bar includes 'About', 'Language', and 'Logout'. Below this is a green header with 'Yealink VC400' and a menu with 'Home', 'Status', 'Account', 'Network', 'Setting' (highlighted), 'Directory', and 'Security'. On the left, a sidebar lists various settings categories: General, Date & Time, Call Features, Video & Audio (highlighted), Camera, Configuration, Upgrade, Tones, Wireless Micpod, and 3rd-Party VMR. The main content area is titled 'Audio Settings' and contains several sections: 'Audio Settings' with 'Audio Input' set to 'Auto(Wired Micpod)' and 'Audio Output' set to 'Auto(HDMI)' (highlighted with a red box); 'Presentation' with 'Mix' set to 'On'; 'Far-end Camera Control' with 'Not FECC in call(0~300s)' set to '15', 'Far Control Near Camera' set to 'Enabled', 'Far Set of Camera Presets' set to 'Disabled', and 'Far Move to Camera Presets' set to 'Disabled'; and 'Output Resolution' with 'Display1' set to 'Auto(1920 x 1080 60Hz)' and 'Display2' set to 'No devices'.

3. Click **Confirm** to accept the change.

To configure the audio output device via the remote control:


1. Select **Menu->Video & Audio->Audio Settings**.
2. Select the desired value from the pull-down list of **Audio Output**.
3. Press the **Save** soft key to accept the change.

Audio Input Device

The endpoint supports the following audio input devices:

- **Auto** (select the audio input device with highest priority)
- **VCS Phone** (video conferencing phone)
- **Wired Micpod** (VCM30)
- **Wireless Micpod** (VCM60)
- **Built-in Micphone** (built-in micphone of VC110)
- **Line Input** (microphone connected to the Line In port on the VC110 all-in-one unit)
- **Line In + VCS Phone**
- **Line In + Wired Micpod**
- **Line In + Wireless Micpod**

The priority of audio input device is:



By default, the VC110 automatically selects the audio input devices with the highest priority. If you select “Line In + device” option, the VC110 will use microphone connected to the Line In port and the device to pick up audio at the same time.

You can also specify the desired audio input device via the remote control or the web user interface.

The audio input device parameter is described below:


Parameter	Description	Configuration Method
Audio Input	<p>Specifies the audio input device for the endpoint.</p> <p>Valid values:</p> <ul style="list-style-type: none"> • Auto- selects the audio input device with highest priority. • VCS Phone- selects the video conferencing phone. • Wired Micpod- selects the VCM30 video conferencing microphone array • Wireless Micpod -selects the VCM60 video conferencing wireless microphone. • Built-in Microphone-selects the vc110 built-in microphone. • Line Input- selects the microphone connected to the Line In port on the VC110 all-in-one unit. • Line In +VCS Phone- selects microphone connected to the Line In port on the VC110 all-in-one unit and video conferencing phone. • Line In + Wired Micpod - selects microphone connected 	<p>Remote Control</p> <p>Web User Interface</p>

Parameter	Description	Configuration Method
	<p>to the Line In port on the VC110 all-in-one unit and VCM30 video conferencing microphone array.</p> <ul style="list-style-type: none"> • Line In + Wireless Micpod- selects the microphone connected to the Line In port on the VC110 all-in-one unit and VCM60 video conferencing wireless microphone. <p>Default: Auto.</p> <ul style="list-style-type: none"> • If Line Input is selected as the audio input device, the near-end audio output device will not play sound from the Line Input device. • If "Line In + device" is selected as the audio input device, the near-end audio output device will play sound from the Line Input device. <p>During a video training for main office and branch office, both offices need to hear the video sound, you can select this option.</p>	

To configure the audio input device via web user interface:

1. Click on **Setting->Video & Audio**.

2. Select the desired value from the pull-down list of **Audio Input**.



The screenshot shows the Yealink VC110 web interface. The top navigation bar includes links for About, Language, and Logout. The main menu has options for Home, Status, Account, Network, Setting (highlighted), Directory, and Security. On the left, a sidebar lists various settings categories: General, Date & Time, Call Features, Video & Audio (selected), Camera, Configuration, Upgrade, Tones, Wireless Micpod, and 3rd-Party VMR. The main content area is titled 'Audio Settings' and contains several sections: 'Audio Settings' with 'Audio Input' (set to Auto(Wired Micpod)) and 'Audio Output' (set to Auto(HDMI)); 'Presentation' with 'Mtx' (set to On); 'Far-end Camera Control' with 'Not FECC in call(0~300s)' (set to 15), 'Far Control Near Camera' (set to Enabled), 'Far Set of Camera Presets' (set to Disabled), and 'Far Move to Camera Presets' (set to Disabled); and 'Output Resolution' with 'Display1' (set to Auto(1920 x 1080 60Hz)) and 'Display2' (set to No devices).

3. Click **Confirm** to accept the change.

To configure the audio input device via the remote control:

1. Select **Menu->Video & Audio->Audio Settings**.
2. Select the desired value from the pull-down list of **Audio Input**.
3. Press the **Save** soft key to accept the change.

Adjusting MTU of Video Packets

Video packets that exceed the maximum transmission unit (MTU) size for any router or segment along the network path may be fragmented or dropped. This results in poor quality video at the receiving device. You can set the maximum MTU size of the video packets sent by the endpoint. The default value is 1500 bytes. Specify the MTU size used in calls based on the network bandwidth settings. If the video becomes blocky or network errors occur, packets may be too large; decrease the MTU. If the network is burdened with unnecessary overhead, packets may be too small, increase the MTU.

The MTU parameter on the endpoint is described below.

Parameter	Description	Configuration Method
Video MTU	<p>Specifies the maximum MTU size (in bytes) of video packets sent by the endpoint.</p> <p>Valid Values: Integer from 1000 to 1500</p> <p>Default: 1500</p> <p>Note: If you change this parameter, the endpoint will reboot to make the change take effect.</p>	<p>Remote Control</p> <p>Web User Interface</p>

To configure MTU via web user interface:

1. Click on **Network->Advanced**.
2. In the **MTU** block, enter the desired value in the **Video MTU** field.

The screenshot shows the Yealink VC110 Web User Interface. The top navigation bar includes 'About', 'Language', and 'Logout'. The main navigation bar has 'Home', 'Status', 'Account', 'Network' (selected), 'Setting', 'Directory', and 'Security'. On the left, a sidebar menu shows 'LAN Configuration', 'NAT/Firewall', 'Advanced' (selected), and 'Diagnose'. The main content area is titled 'QoS' and contains several configuration sections: 'QoS' with 'Audio Priority' (63), 'Video Priority' (34), and 'Data Priority' (63); 'MTU' with 'Video MTU' (1500, highlighted with a red box); 'SNMP' with 'Active' (Enabled), 'Port' (161), and 'Trusted Address'; and 'Web Server' with 'HTTP' (Enabled), 'HTTP Port' (80), 'HTTPS' (Enabled), and 'HTTPS Port' (443).

3. Click **Confirm** to accept the change.
A dialog box pops up to prompt that the settings will take effect after a reboot.
4. Click **Confirm** to reboot the endpoint immediately.

To configure MTU via the remote control:

1. Select **Menu->Advanced** (default password: 0000) -> **Advanced Network**.
2. Enter the desired value in the **Video MTU(1000-1500)** field.

3. Press the **Save** soft key to accept the change.
The display device prompts "Reboot now?".
4. Select **OK** to reboot the endpoint immediately.

Dual-Stream Protocol

To enhance the process of communicating with others over video, the dual-stream protocol provides the ability to share content from a computer, such as video clips or documentation. Both the video and the documentation can be transmitted to the far site simultaneously, thus meeting the requirements of different conference scenarios, such as training or medical consultation.

The Yealink video conferencing endpoint supports the standard H.239 protocol and BFCP (Binary Floor Control Protocol). H.239 protocol is used when sharing content with the far site in H.323 calls. BFCP protocol is used when sharing content with the far site in SIP calls. Before enabling the desired protocol, ensure that the protocol is supported and enabled by the far site you wish to call. If the far site does not support the protocol for sharing content, MCU will automatically mix the content and camera video, and send them in one channel. For more information on mix sending, refer to [Mix Sending](#) on page 196.

Dual-stream protocol parameters on the endpoint are described below.

Parameter	Description	Configuration Method
H.239	Enables or disables the H.239 protocol for sharing content. You can configure it for the StarLeaf Cloud platform or H.323 call separately. Default: Enabled	Web User Interface
BFCP	Enables or disables the BFCP protocol for sharing content. You can configure it for Zoom/Pexip/BlueJeans/Mind/Custom platform, SIP account or SIP IP call separately. Default: For Zoom/Pexip/BlueJeans/Mind/Custom platform and SIP IP call, the default value is Enabled. For SIP account, the default value is Disabled. Note: You cannot configure it for the Yealink/StarLeaf Cloud platform.	Web User Interface

To configure H.239 dual-stream protocol for StarLeaf Cloud platform via web user interface:

1. Click on **Account->Cloud**.

2. Select **StarLeaf** from the pull-down list of **Platform Type**.
3. Select the desired value from the pull-down list of **H.239**.

The screenshot shows the Yealink VC110 web interface. The top navigation bar includes 'About', 'Language', and 'Logout'. The main menu has 'Home', 'Status', 'Account', 'Network', 'Setting', 'Directory', and 'Security'. The 'Account' tab is selected, and the 'Cloud' sub-tab is active. On the left sidebar, 'Cloud' is selected, with options for 'H.323', 'SIP Account', 'SIP IP Call', and 'Codec'. The main content area is titled 'Cloud' and contains the following settings:

Cloud	
Register Status	Registered
Cloud Account	Enabled
Platform Type	StarLeaf
QCP Code	367037241953
Advanced Setting	
H.323 Tunneling	Disabled
H.235 Encryption	Disabled
Protocol Monitor Port	1720
DTMF Type	Auto
Local Early Media	Disabled
H.239	Enabled
FECC(H.323)	Enabled

4. Click **Confirm** to accept the change.

To configure H.239 dual-stream protocol for H.323 call via web user interface:

1. Click on **Account**->**H.323**.

2. Select the desired value from the pull-down list of **H.239**.

The screenshot shows the Yealink VC110 web interface. The top navigation bar includes 'About', 'Language', and 'Logout'. Below this is a green header with 'Yealink VC110' and tabs for 'Home', 'Status', 'Account' (selected), 'Network', 'Setting', 'Directory', and 'Security'. On the left, a sidebar lists 'Cloud', 'H323' (selected), 'SIP Account', 'SIP IP Call', and 'Codec'. The main content area displays the 'H.323 Account' settings. A red box highlights the 'H.239' setting, which is currently set to 'Enabled'. Other settings include 'H.323 Account' (Enabled), 'H.323 Name' (9000), 'H.323 Extension' (9000), 'Gatekeeper Mode' (Manual), 'Gatekeeper IP Address 1' (10.2.1.43) and 'Port' (1719), 'Gatekeeper IP Address 2' (empty) and 'Port' (1719), 'Gatekeeper Authentication' (Disabled), 'Gatekeeper Username' (empty), 'Gatekeeper Password' (masked), 'H.460 Active' (Disabled), 'H.323 Tunneling' (Disabled), 'H235 Encryption' (Disabled), 'Protocol Monitor Port' (1720), 'DTMF Type' (Auto), and 'FECC(H.323)' (Enabled).

H.323 Account	Enabled
H.323 Name	9000
H.323 Extension	9000
Gatekeeper Mode	Manual
Gatekeeper IP Address 1	10.2.1.43
Port	1719
Gatekeeper IP Address 2	
Port	1719
Gatekeeper Authentication	Disabled
Gatekeeper Username	
Gatekeeper Password	••••••••
H.460 Active	Disabled
H.323 Tunneling	Disabled
H235 Encryption	Disabled
Protocol Monitor Port	1720
DTMF Type	Auto
H.239	Enabled
FECC(H.323)	Enabled

3. Click **Confirm** to accept the change.

To configure BFCP dual-stream protocol for Zoom/Pexip/BlueJeans/Mind/Custom platform via web user interface:

1. Click on **Account->Cloud**.
2. Select **Zoom/Pexip/BlueJeans/Mind/Custom** from the pull-down list of **Platform Type**.

3. Select the desired value from the pull-down list of **BFCP**.

The screenshot shows the Yealink VC110 web interface. The top navigation bar includes 'About', 'Language', and 'Logout'. The main navigation bar has 'Home', 'Status', 'Account' (selected), 'Network', 'Setting', 'Directory', and 'Security'. On the left, a sidebar menu shows 'Cloud' (selected), 'H.323', 'SIP Account', 'SIP IP Call', and 'Codec'. The main content area is titled 'Cloud' and contains the following settings:

Cloud	
Register Status	Registered
Cloud Account	Enabled
Platform Type	Zoom
Server Host	zoomcrc.com
Advanced Setting	
Transport	TCP
Server Expires	3600
SRTP	Disabled
DTMF Type	RFC2833
DTMF Info Type	DTMF-Relay
DTMF Payload Type (96~127)	101
Keep Alive Interval	30
BFCP	Enabled
FECC(SIP)	Enabled

4. Click **Confirm** to accept the change.

To configure BFCP dual-stream protocol for SIP call via web user interface:

1. Click on **Account->SIP Account**.

2. Select the desired value from the pull-down list of **BFCP**.

The screenshot shows the Yealink VC110 web interface with the 'Account' tab selected. The left sidebar lists 'Cloud', 'H323', 'SIP Account', 'SIP IP Call', and 'Codec'. The main content area displays various SIP settings. The 'BFCP' dropdown menu is highlighted with a red box and is set to 'Enabled'.

Setting	Value
Register Name	9000
Password	••••••••
Server Host	10.2.1.48
Port	5060
Enable Outbound Proxy Server	Disabled
Outbound Proxy Server	
Port	5060
Transport	UDP
Server Expires	3600
SRTP	Disabled
DTMF Type	RFC2833
DTMF Info Type	DTMF-Relay
DTMF Payload Type (96~127)	101
NAT Traversal	Disabled
Keep Alive Interval	30
RPort	Enabled
BFCP	Enabled
FECC(SIP)	Disabled

3. Click **Confirm** to accept the change.

To configure BFCP dual-stream protocol for SIP IP call via web user interface:

1. Click on **Account->SIP IP Call**.
2. Select the desired value from the pull-down list of **BFCP**.

The screenshot shows the Yealink VC110 web interface with the 'SIP IP Call' tab selected. The left sidebar lists 'Cloud', 'H323', 'SIP Account', 'SIP IP Call', and 'Codec'. The main content area displays various SIP IP Call settings. The 'BFCP' dropdown menu is highlighted with a red box and is set to 'Enabled'.

Setting	Value
SIP IP Call	Enabled
Transport	TCP
SRTP	Disabled
DTMF Type	SIP INFO
DTMF Info Type	DTMF
DTMF Payload Type (96~127)	101
NAT Traversal	Disabled
RPort	Enabled
BFCP	Enabled
FECC(SIP)	Enabled

3. Click **Confirm** to accept the change.

Mix Sending

Content sharing allows users to share content with other conference participants during a call. When a PC is connected to the PC port on the VC110 all-in-one unit, the display device can display both the camera video and the shared content. The content sharing feature is very useful in the conference scenario in which content sharing is needed (e.g., a slide or a flash).


During a conference call, the far site may not support receiving shared content. In this case, you can enable mix sending feature on the endpoint. Mix sending feature allows the sender to compound multiple video streams (local image+shared content) to one video stream, and then send it to the far site.

The mix sending parameter on the endpoint is described below.

Parameter	Description	Configuration Method
Mix	Enables or disables the mix sending feature on the endpoint. Default: Enabled	Web User Interface

To configure mix sending via web user interface:

1. Click on **Setting**->**Video & Audio**.
2. In the **Presentation** block, select the desired value from the pull-down list of **Mix**.



3. Click **Confirm** to accept the change.

Configuring Camera Settings

To display high quality video image, you can configure camera settings as required, such as white balance, exposure and sharpness.

Camera settings parameters are described below.

Parameter	Description	Configuration Method
Exposure Compensation	<p>Configures the value of camera exposure compensation.</p> <ul style="list-style-type: none"> Off 1 2 3 <p>Exposure compensation is used to compensate the camera effectively when the camera is shooting in a backlight environment. If the environment light is dark, you can increase the compensation value.</p> <p>Default: 1</p>	<p>Remote Control</p> <p>Web User Interface</p>
Flicker	<p>Configures the value of camera flicker frequency.</p> <ul style="list-style-type: none"> 50Hz 60Hz <p>Default: 50Hz</p> <p>Note: Indoor lights powered by a 50Hz or 60Hz power source can produce a flicker. You can adjust the camera flicker frequency according to the power source the light is powered by.</p>	<p>Remote Control</p> <p>Web User Interface</p>
White Balance Mode	<p>Configures the white balance mode of the camera.</p> <ul style="list-style-type: none"> Auto—Yealink recommends this setting for most situations. It calculates the best white balance setting based on lighting conditions in the 	<p>Remote Control</p> <p>Web User Interface</p>

Parameter	Description	Configuration Method
	<p>room.</p> <ul style="list-style-type: none"> • Cool Daylight • Neutral Daylight • Florescent • Incandescent • Manual—Manually set red and blue gain. <p>Default: Auto</p>	
Red Gain	<p>Configures the red gain of the camera.</p> <p>Valid Values: 0-100</p> <p>Default: 0</p> <p>Note: You can set this parameter only when the white balance mode is configured to Manual.</p>	<p>Remote Control</p> <p>Web User Interface</p>
Blue Gain	<p>Configures the blue gain of the camera.</p> <p>Valid Values: 0-100</p> <p>Default: 0</p> <p>Note: You can set this parameter only when the white balance mode is configured to Manual.</p>	<p>Remote Control</p> <p>Web User Interface</p>
Saturation	<p>Configures the saturation of the camera.</p> <p>Valid Values: 0-14</p> <p>Default: 7</p>	<p>Remote Control</p> <p>Web User Interface</p>
Sharpness	<p>Configures the sharpness of the camera.</p> <p>Valid Values: 0-14</p> <p>Default: 5</p> <p>Note: The picture will be sharp and clear, but moderate to heavy motion at low call rates can cause some frames to be dropped.</p>	<p>Remote Control</p> <p>Web User Interface</p>
Brightness	<p>Configures the brightness of the camera.</p>	<p>Remote Control</p> <p>Web User Interface</p>

Parameter	Description	Configuration Method
	Valid Values: 0-100 Default: 50	
Contrast	Configures the contrast of the camera. Valid Values: 0-100 Default: 50	Remote Control Web User Interface
Noise Reduction (2D)	Specifies the noise reduction (2D) mode. <ul style="list-style-type: none"> Off Low Middle High Default: Low	Remote Control Web User Interface
Hangup Mode	Enables or disables the camera to flip the image view when camera is handed at up-side-down position Default: Off	Remote Control Web User Interface
Camera Pan Direction	Configures the pan direction of the camera. <ul style="list-style-type: none"> Normal Reversed Default: Normal If the camera reversed mode is enabled, the camera pan direction will be reversed when pressing the left and right navigation keys on the remote control. In this case, you can set the camera pan direction to Reversed.	Remote Control Web User Interface
Camera Map	Enables or disables the preview of camera presets. Default: On Note: If it is set to On, you can view the pre-saved camera presets.	Remote Control Web User Interface
Clear Preset	Clears all camera presets.	Remote Control

Parameter	Description	Configuration Method
		Web User Interface
Reset Camera	Reset the camera settings to factory defaults. Note: The camera presets will also be cleared.	Remote Control Web User Interface

To configure camera settings via web user interface:

1. Click on **Setting->Camera**.
2. Configure the camera settings.

3. Click **Confirm** to accept the change.

To configure camera settings via the remote control:

1. Select **Menu->Video & Audio->Camera General Settings**.
2. Configure the camera settings.
3. Press the **Save** soft key to accept the change.

Far-end Camera Control

Local video is displayed on the display device of the far site during a call. For the best view, you can enable the Far Control of Near Camera feature to allow the far site to control the focus and angle of the local camera. You can also specify whether the far site is allowed to store and use the local camera presets.

Far control of the near camera parameters are described below.

Parameter	Description	Configuration Method
Not FECC in call(0~300s)	Configures the duration time (in seconds) when far site cannot control the local camera during a call. Default: 15 If it is set to 15, the far site is not allowed to control the local camera in the first 15 seconds of the call.	Web User Interface
Far Control Near Camera	Enables or disables the far site to control the near site camera. Default: Enabled	Remote Control Web User Interface
Far Set of Camera Presets	Enables or disables the far site to store the camera presets. Default: Disabled	Remote Control Web User Interface
Far Move to Camera Presets	Enables or disables the far site to use the camera presets. Default: Disabled	Remote Control Web User Interface

To configure far-end camera control via web user interface:

1. Click on **Setting->Video & Audio**.
2. Enter the desired time in the **Not FECC in call(0~300s)** field.
3. Select the desired values from the pull-down lists of **Far Control Near Camera**.
4. Select the desired values from the pull-down lists of **Far Set of Camera Presets**.

5. Select the desired values from the pull-down lists of **Far Move to Camera Presets**.

The screenshot shows the Yealink VC110 web interface. The left sidebar contains a menu with options: General, Date & Time, Call Features, Video & Audio (selected), Camera, Configuration, Upgrade, Tones, Wireless Micpod, and 3rd-Party VMR. The main content area is titled 'Setting' and contains several sections: Audio Settings, Presentation, Far-end Camera Control, and Output Resolution. The 'Far-end Camera Control' section is highlighted with a red box and contains the following settings:

Parameter	Value
Not FECC in call(0~300s)	15
Far Control Near Camera	Enabled
Far Set of Camera Presets	Disabled
Far Move to Camera Presets	Disabled

6. Click **Confirm** to accept the change.

To configure far-end camera control feature via the remote control:

1. Select **Menu->Video & Audio->Far-end Camera Control**.
2. Make the desired changes.
3. Press the **Save** soft key to accept the change.

Camera Control Protocol

VC110 video conferencing endpoint supports camera control protocols: FECC (Far End Camera Control). You can enable the FECC protocol for SIP call or H.323 call.

If far site wants to control the local camera, both the far site and near site should enable the camera control protocol simultaneously. If the FECC protocol is not enabled on either site, far-end camera control cannot be performed. For example, a SIP call is established between two sites, the two sites must enable FECC (SIP) protocol simultaneously to perform far-end camera control. If FECC (SIP) protocol and FECC (H.323) protocol are both enabled, the endpoint will select the appropriate camera control protocol according to the protocol (SIP or H.323) the call uses.

Camera control protocol parameters are described below:


Parameter	Description	Configuration Method
FECC(H.323)	Enables or disables the FECC (H.323) protocol for far site to control near	Web User Interface

Parameter	Description	Configuration Method
	<p>camera. You can configure it for the StarLeaf Cloud platform or H.323 call separately.</p> <p>Default: Enabled</p>	
FECC(SIP)	<p>Enables or disables the FECC (SIP) protocol for far site to control near camera. You can configure it for the Zoom/Pexip/BlueJeans/Mind/Custom platform, SIP account or SIP IP call separately.</p> <p>Default:</p> <p>For Zoom/Pexip/BlueJeans/Mind/Custom platform and SIP IP call, the default value is Enabled.</p> <p>For SIP account, the default value is Disabled.</p> <p>Note: You cannot configure it for the Yealink/StarLeaf Cloud platform.</p>	Web User Interface

To configure FECC(H.323) camera control protocol for StarLeaf Cloud platform via web user interface:

1. Click on **Account->Cloud**.
2. Select **StarLeaf** from the pull-down list of **Platform Type**.

3. Select the desired value from the pull-down list of **FECC(H.323)**.



The screenshot shows the Yealink VC110 web interface. The top navigation bar includes 'About', 'Language', and 'Logout'. The main navigation bar has 'Home', 'Status', 'Account' (selected), 'Network', 'Setting', 'Directory', and 'Security'. The left sidebar shows 'Cloud' (selected), 'H.323', 'SIP Account', 'SIP IP Call', and 'Codec'. The main content area is divided into 'Cloud' and 'Advanced Setting' sections. In the 'Cloud' section, 'Register Status' is 'Registered', 'Cloud Account' is 'Enabled', 'Platform Type' is 'StarLeaf', and 'QCP Code' is '367037241953'. In the 'Advanced Setting' section, 'H.323 Tunneling' is 'Disabled', 'H.235 Encryption' is 'Disabled', 'Protocol Monitor Port' is '1720', 'DTMF Type' is 'Auto', 'Local Early Media' is 'Disabled', 'H.239' is 'Enabled', and 'FECC(H.323)' is 'Enabled' (highlighted with a red box).

4. Click **Confirm** to accept the change.

To configure FECC(H.323) camera control protocol for H.323 calls via web user interface:

1. Click on **Account->H.323**.

2. Select the desired value from the pull-down list of **FECC(H.323)**.

The screenshot shows the Yealink VC110 web interface. The top navigation bar includes 'About', 'Language', and 'Logout'. The main menu has 'Home', 'Status', 'Account', 'Network', 'Setting', 'Directory', and 'Security'. The 'Account' tab is selected, and the 'H323' sub-tab is active. On the left sidebar, 'Cloud', 'H323', 'SIP Account', 'SIP IP Call', and 'Codec' are listed. The main content area displays various H.323 settings:

- H.323 Account: Enabled
- H.323 Name: 9000
- H.323 Extension: 9000
- Gatekeeper Mode: Manual
- Gatekeeper IP Address 1: 10.2.1.43 (Port: 1719)
- Gatekeeper IP Address 2: (Port: 1719)
- Gatekeeper Authentication: Disabled
- Gatekeeper Username:
- Gatekeeper Password:
- H.460 Active: Disabled
- H.323 Tunneling: Disabled
- H235 Encryption: Disabled
- Protocol Monitor Port: 1720
- DTMF Type: INBAND
- H.239: Enabled
- FECC(H.323): Enabled** (highlighted with a red box)

3. Click **Confirm** to accept the change.

To configure FECC(SIP) camera control protocol for Zoom/Pexip/BlueJeans/Mind/Custom platform via web user interface:

1. Click on **Account->Cloud**.
2. Select **Zoom/Pexip/BlueJeans/Mind/Custom** from the pull-down list of **Platform Type**.

3. Select the desired value from the pull-down list of **FECC(SIP)**.

The screenshot shows the Yealink VC110 web interface. The top navigation bar includes 'About', 'Language', and 'Logout'. The main navigation bar has 'Home', 'Status', 'Account' (highlighted), 'Network', 'Setting', 'Directory', and 'Security'. On the left, a sidebar menu shows 'Cloud' (selected), 'H.323', 'SIP Account', 'SIP IP Call', and 'Codec'. The main content area is titled 'Cloud' and contains the following settings:

Cloud	
Register Status	Registered
Cloud Account	Enabled
Platform Type	Zoom
Server Host	zoomcrc.com
Advanced Setting	
Transport	TCP
Server Expires	3600
SRTP	Disabled
DTMF Type	RFC2833
DTMF Info Type	DTMF-Relay
DTMF Payload Type (96~127)	101
Keep Alive Interval	30
BFCP	Enabled
FECC(SIP)	Enabled

4. Click **Confirm** to accept the change.

To configure FECC(SIP) camera control protocol for SIP calls via web user interface:

1. Click on **Account->SIP Account**.

2. Select the desired value from the pull-down list of **FECC(SIP)**.

The screenshot shows the Yealink VC110 web interface. The 'Account' tab is selected in the top navigation bar. On the left sidebar, 'SIP Account' is highlighted. The main configuration area shows various SIP settings. At the bottom, the 'FECC(SIP)' dropdown menu is highlighted with a red box and is currently set to 'Disabled'.

Register Name	9000
Password	••••••••
Server Host	10.2.1.48
Port	5060
Enable Outbound Proxy Server	Disabled
Outbound Proxy Server	
Port	5060
Transport	UDP
Server Expires	3600
SRTP	Disabled
DTMF Type	RFC2833
DTMF Info Type	DTMF-Relay
DTMF Payload Type (96~127)	101
NAT Traversal	Disabled
Keep Alive Interval	30
RPort	Enabled
BFCP	Disabled
FECC(SIP)	Disabled

3. Click **Confirm** to accept the change.

To configure FECC(SIP) c camera control protocol for SIP IP call via web user interface:

1. Click on **Account->SIP IP Call**.
2. Select the desired value from the pull-down list of **FECC(SIP)**.

The screenshot shows the Yealink VC110 web interface. The 'Account' tab is selected in the top navigation bar. On the left sidebar, 'SIP IP Call' is highlighted. The main configuration area shows various SIP IP Call settings. At the bottom, the 'FECC(SIP)' dropdown menu is highlighted with a red box and is currently set to 'Enabled'.

SIP IP Call	Enabled
Transport	TCP
SRTP	Disabled
DTMF Type	RFC2833
DTMF Info Type	DTMF
DTMF Payload Type (96~127)	101
NAT Traversal	STUN
RPort	Enabled
BFCP	Enabled
FECC(SIP)	Enabled

3. Click **Confirm** to accept the change.

Output Resolution

VC110 video conferencing endpoint supports output resolution adjustment. You can adjust output resolution of primary/secondary display device respectively.

Make sure the display device has connected to the VC110 all-in-one unit before configuration.

The output resolution parameters on the endpoint are described below.

Parameter	Description	Configuration Method
Display1	<p>Configures the output resolution of primary display device.</p> <ul style="list-style-type: none"> • Auto—Automatically select the highest resolution supported by the display device. • 1920×1080 60Hz • 1280×720 60 Hz • 720×480 60 Hz • 640×480 60 Hz <p>Default: Auto.</p> <p>Note: The available output resolutions depend on the display device.</p>	Web User Interface
Display2	<p>Configures the output resolution of secondary display device.</p> <ul style="list-style-type: none"> • Auto—Automatically select the highest resolution supported by the display device. • 1920×1080 60Hz • 1280×720 60 Hz • 720×480 60 Hz • 640×480 60 Hz <p>Default: Auto</p> <p>Note: The available output resolutions depend on the display device.</p>	Web User Interface

To configure output resolution via web user interface:

1. Click on **Setting->Video & Audio**.
2. Select the desired value from the pull-down list of **Display1**.
3. Select the desired value from the pull-down list of **Display2**.

The screenshot shows the Yealink VC110 web interface. The left sidebar contains a menu with options: General, Date & Time, Call Features, Video & Audio (selected), Camera, Configuration, Upgrade, Tones, Wireless Micpod, and 3rd-Party VMR. The main content area is titled 'Audio Settings' and includes sections for 'Audio Settings', 'Presentation', 'Far-end Camera Control', and 'Output Resolution'. The 'Output Resolution' section is highlighted with a red box, showing two dropdown menus: 'Display1' set to 'Auto(1920 x 1080 60Hz)' and 'Display2' set to 'No devices'.

4. Click **Confirm** to accept the change.

USB Configuration

If you have high requirement for data security, you can disable the USB feature. If you disable the USB feature, you cannot view the videos and screenshots stored in the USB flash driver via the remote control, and cannot record video or capture screenshots too.

The USB configuration parameter on the endpoint is described below.

Parameter	Description	Configuration Method
USB Enable	Enables or disables the USB feature. Default: Enabled	Web User Interface

To configure USB configuration via web user interface:

1. Click on **Setting->Video & Audio**.

2. Select the desired value from the pull-down list of **USB Enable**.

The screenshot displays the Yealink VC110 WUI. The top navigation bar includes 'About', 'Language', and 'Logout'. The main menu has 'Home', 'Status', 'Account', 'Network', 'Setting' (active), 'Directory', and 'Security'. The left sidebar lists configuration categories: General, Date & Time, Call Features, Video & Audio (selected), Camera, Configuration, Upgrade, Tones, Wireless Micpod, and 3rd-Party VMR. The main content area shows settings for 'Mix' (On), 'Far-end Camera Control' (Not FECC in call: 15, Far Control Near Camera: Enabled, Far Set of Camera Presets: Disabled, Far Move to Camera Presets: Disabled), 'Output Resolution' (Display1: No devices, Display2: No devices), 'Record' (Recording: Enabled, Auto Recording: Disabled, Screenshot: Enabled), and 'USB Config' (USB Enable: Enabled, highlighted with a red box).

3. Click **Confirm** to accept the change.

Video Recording

When the endpoint is idle, you can record local video via the remote control. During a call, the video and presentation which are shown on the display device can be recorded via the remote control and video conferencing phone.

Before recording video, you need to insert a USB flash drive to the USB port on the VC110 all-in-one unit to store recorded video. Make sure the USB feature is enabled.


The video recording parameters on the endpoint are described below.

Parameter	Description	Configuration Method
Recording	Enables or disables the video recording feature on the endpoint. Default: Enabled If it is set to Disabled, you cannot record video.	Web User Interface
Auto Recording	Enables or disables the endpoint to start recording automatically once a call is established. Default: Disabled.	Web User Interface

Parameter	Description	Configuration Method
	Note: The auto recording feature is available only when the recording feature is enabled.	



To configure video recording via web user interface:

1. Click on **Setting**->**Video & Audio**.
2. Select the desired value from the pull-down list of **Recording**.
3. Select the desired value from the pull-down list of **Auto Recording**.









4. Click **Confirm** to accept the change.

To record video when the endpoint is idle via the remote control:


1. Press  to start recording and press  again to stop recording.

To record video during a call via the remote control:


1. Do one of the following:
 - Long press  to start recording and long press  again to stop recording.
 - Press **More** soft key to open **More** screen.
Press  or  to scroll to **USB Recording**, and then press  to start recording.
Open the **More** screen, scroll to **USB Recording** again, and then press  to stop recording.

To record video during a call via the video conferencing phone:

1. Press the **Start REC** soft key to start recording and press the **Stop REC** soft key again to stop recording.

When you start recording, the display device will show  and the recording time. When you stop recording, the recording icon disappears from the screen. The display device prompts "Successfully video recording!"

Note

If you start recording during a call, both your display device and remote display devices will show the  icon on your video image.

Screenshot

You can capture the screenshot from the camera via the remote control or web user interface. Before capturing the screenshot, you need to insert a USB flash drive to the USB port on the VC110 all-in-one unit to store screenshots. Make sure the USB feature is enabled.


The screenshot parameter on the endpoint is described below.

Parameter	Description	Configuration Method
Screenshot	<p>Enables or disables the screenshot feature on the endpoint.</p> <p>Default: Enabled</p> <p>If it is set to Disabled, you cannot capture screenshot.</p>	Web User Interface

To configure screenshot via web user interface:

1. Click on **Setting->Video & Audio**.

2. Select the desired value from the pull-down list of **Screenshot**.



3. Click **Confirm** to accept the change.





To capture screenshots via web user interface:

1. Click **Home**->**Screenshot** when the endpoint is idle or during a call.

To capture screenshots when the endpoint is idle via the remote control:

1. Press .

To capture screenshots during a call via the remote control:

1. Do one of the following:
 - Long press .
 - Press **More** soft key to open **More** screen.
Press  or  to scroll to **Screenshot**, and then press  to capture screenshot.

Tones

When automatically answering an incoming call, the endpoint will play a warning tone. You can customize tones or select specialized tone sets (vary from country to country) to indicate different conditions of the endpoint. The default tones used on the endpoint are the US tone sets. Available tone sets for the endpoint:

- Australia

- Austria
- Brazil
- Belgium
- China
- Chile
- Czech
- Czech ETSI
- Denmark
- Finland
- France
- Germany
- Great Britain
- Greece
- Hungary
- Lithuania
- India
- Italy
- Japan
- Mexico
- New Zealand
- Netherlands
- Norway
- Portugal
- Spain
- Switzerland
- Sweden
- Russia
- United States

Configured tones can be heard on the endpoint for the following conditions:

Condition	Description
Ring Back	Ring-back tone
Busy	When the callee is busy
Call Waiting	Call waiting tone

Condition	Description
Auto Answer	When answering a call automatically

Tones parameters on the endpoint are described below:


Parameter	Description	Configuration Method
Select Country	Customizes tones or selects the desired country tone set. Default: Custom	Web User Interface
Ring Back	<p>Customizes the ring-back tone for the endpoint.</p> <p>tone = element1[,element2][,element3]...[,element8]</p> <p>Where</p> <p>element =</p> <p>[!]Freq1[+Freq2][+Freq3][+Freq4] /Duration</p> <p>Freq: the frequency of the tone (ranges from 200Hz to 7000 Hz). If it is set to 0Hz, it means the tone is not played. A tone consists of at most four different frequencies.</p> <p>Duration: the duration (in milliseconds) of the dial tone, ranges from 0 to 30000ms.</p> <p>You can configure at most eight different tones for one condition, and separate them by commas. (e.g., 250/200, 0/1000, 200+300/500, 600+700+800+1000/2000).</p> <p>If you want the endpoint to play tones once, add an exclamation mark "!" before tones (e.g., !250/200, 0/1000, 200+300/500, 600+700+800+1000/2000).</p> <p>Default: Blank</p> <p>Note: It only works if the parameter "Select Country" is set to Custom.</p>	Web User Interface
Busy	Customizes the busy tone for the endpoint. For more information on how to	Web User Interface

Parameter	Description	Configuration Method
	customize the tone, refer to the parameter "Ring Back". Default: Blank Note: It only works if the parameter "Select Country" is set to Custom.	
Call Waiting	Customizes the call waiting tone for the endpoint. For more information on how to customize the tone, refer to the parameter "Ring Back". Default: Blank Note: It only works if the parameter "Select Country" is set to Custom.	Web User Interface
Auto Answer	Customizes the auto answer tone for the endpoint. For more information on how to customize the tone, refer to the parameter "Ring Back". Default: Blank Note: It only works if the parameter "Select Country" is set to Custom.	Web User Interface

To configure tones via web user interface:

1. Click on **Setting**->**Tones**.
2. Select the desired value from the pull-down list of **Select Country**.

If you select **Custom**, you can customize the tone for indicating each condition of the endpoint.



3. Click **Confirm** to accept the change.

Endpoint Management

This chapter provides operating instructions, such as managing directory, call history and dual screen. Topics include:

- [Directory](#)
- [LDAP](#)
- [Call History](#)
- [Search Source List in Dialing](#)
- [Dual Screen](#)

Directory

The VC110 endpoint can store up to 500 local contacts. You can add multiple numbers for a contact (at most 3).

You can import or export the contact list to share the local directory. The endpoint only supports the XML and CSV format contact lists. You can view local directory via web user interface, remote control and the video conferencing phone. But you can only edit or delete the local directory via web user interface and remote control.

If you register a Yealink Cloud account, Yealink Cloud contacts will display in your directory menu. Yealink Cloud contacts are created by your Yealink Cloud enterprise administrator. Only Yealink Cloud enterprise administrator can add, edit and delete Yealink Cloud contacts on the Yealink web management service, these operations will update to VC110 automatically. You do not have the permission to do the operations on your VC110. You can only search and place calls to the Yealink Cloud contacts. For more information on Yealink web management service, refer to [Yealink VC Cloud Management Service Administrator Guide](#).

Note


StarLeaf/Zoom/Pexip/BlueJeans/Mind platform does not provide Cloud contacts for video conferencing endpoint.

The following sections give you detailed steps on how to manage the directory.

To add local contacts via web user interface:


1. Click on **Directory**->**Local Directory**.
2. Click **New Contact**, and select **Local**.
3. Enter the desired name in the **Name** field.
4. Enter the desired number in the **Number** field.
5. Click **Add Number**, enter other number of the contact.
6. Select the desired contact bandwidth from the pull-down list of **Bandwidth**.


The default contact bandwidth is **Auto**. The endpoint will select the appropriate bandwidth automatically



7. Click **Confirm** to accept the change.

To edit local contacts via web user interface:



1. Click on **Directory**->**Local Directory**.
2. Hover your cursor over the local contact you want to edit.
3. Click  in the pop-up detail box.




4. Edit the contact information.
5. Click **Confirm** to accept the change.

To place calls to contacts from the local directory via web user interface:

1. Click on **Directory**->**Local Directory**.
2. Hover your cursor over the desired contact.


3. Click  or  in the pop-up detail box to place a video or audio call.



The web user interface prompts "Connecting, please wait!" and jumps automatically to the **Home** screen.

To import an XML file of the local contact list via web user interface:

1. Click on **Directory->Local Directory**.
2. Click **Import/Export**, and select **Import**.
3. Click **Browse** to locate a contact list file (file format must be *.xml) from your local endpoint.



4. Click **Confirm** to import the contact list.

The web user interface prompts "Contacts imported successfully!".

To import a CSV file of local contact list via web user interface:

1. Click on **Directory->Local Directory**.
2. Click **Import/Export**, and select **Import**.
3. Click **Browse** to locate a contact list file (file format must be *.csv) from your local endpoint.
4. Click **Confirm**.

The web user interface is shown below:

Import CSV File Preview

☐ The first line as the title ☐ Delete Old Contacts

	Ignore ▼	Ignore ▼	Ignore ▼	Ignore ▼	Ignore ▼	Ignore ▼
1	display_name	group	number1	number2	number3	ct bandwidth
2	Danial	Local	6008			0
3	Jack	Local	6001	6002		0
4	Merry	Local	6005			0
5	Yealink Demo1	Local	117.28.251.50	xmdemo1.vcs.yealink.com		0
6	Yealink Demo2	Local	117.28.251.51			0
7	Yealink Demo3	Local	117.28.251.54			0

5. (Optional.) Check the **The first line as the title** checkbox.
It will prevent importing the title of the contact information which is located in the first line of the CSV file.
6. (Optional.) Check the **Delete Old Contacts** checkbox.
It will delete all existing contacts while importing the contact list.
7. Select the desired value from the pull-down list.
 - If **Ignore** is selected, this column will not be imported to the endpoint.
 - If **Display Name** is selected, this column will be imported to the endpoint as the contacts' name.

- If **number1/2/3** is selected, this column will be imported to the endpoint as the contacts' number.

	Display Name	Group	number1	number2	number3	Bandwidth
1	display_name	group	number1	number2	number3	ct bandwidth
2	Danial	Local	6008			0
3	Jack	Local	6001	6002		0
4	Merry	Local	6005			0
5	Yealink Demo1	Local	117.28.251.50	xmdemo1.vcs.yealink.com		0
6	Yealink Demo2	Local	117.28.251.51			0
7	Yealink Demo3	Local	117.28.251.54			0

8. Click **Confirm** to complete importing the contact list.

The web user interface prompts "Contacts imported successfully!".

To export a XML/CSV file of the local contact list via web user interface:

1. Click on **Directory->Local Directory**.
2. Click **Import/Export**, and select **Export XML** or **Export CSV**.
3. The contact list is saved to your local endpoint.

LDAP

LDAP (Lightweight Directory Access Protocol) is an application protocol for accessing and maintaining information services for the distributed directory over an IP network. Yealink VC110 endpoint is configurable to interface with a corporate directory server that supports LDAP version 2 or 3. The following LDAP servers are supported:

- Microsoft Active Directory
- Sun ONE Directory Server
- Open LDAP Directory Server
- Microsoft Active Directory Application Mode (ADAM)

The biggest plus for LDAP is that users can access the central LDAP directory of the corporation using the endpoint. Therefore they do not have to maintain the local directory. Users can search and dial out from the LDAP directory and save LDAP entries to the local directory. LDAP entries

displayed on the display device screen are read only. They cannot be added to, edited or deleted by users. When an LDAP server is configured properly, the endpoint can look up entries from the LDAP server in a wide variety of ways. The LDAP server indexes all the data in its entries, and "filters" may be used to select the desired entry or group, and retrieve the desired information.

Configurations on the endpoint limit the amount of displayed entries when querying from the LDAP server, and decide how the attributes are displayed and sorted.

Performing a LDAP search on the endpoint:

- Enter search content in the dialing screen. (Ensure that the LDAP is in the enabled search source lists)
- In the **Directory** screen, select **Company** to enter the LDAP search screen, and then enter a few characters which you want to search.

The endpoint will send the search request to the LDAP server, the LDAP server then performs a search based on the entered content and configured filter condition, and returns results to the endpoint.

LDAP Attributes

The following table lists the most common attributes used to configure the LDAP lookup on the endpoint:

Abbreviation	Name	Description
gn	givenName	First name
cn	commonName	LDAP attribute is made up from given name joined to surname.
sn	surname	Last name or family name
dn	distinguishedName	Unique identifier for each entry
dc	dc	Domain component
-	company	Company or organization name
-	telephoneNumber	Office phone number
mobile	mobilephoneNumber	Mobile or cellular phone number
ipPhone	IPphoneNumber	Home phone number

LADP parameters are described below:

Parameter	Description	Configuration Method
LDAP Enable	Enables or disables the LDAP feature on the endpoint. Default: Disabled	Web User Interface
LDAP Name Filter	Configures the name attribute for	Web User Interface

Parameter	Description	Configuration Method
	LDAP searching. Example: ((cn=*)(sn=*))	
LDAP Number Filter	Configures the number attribute for LDAP searching. Example: ((telephoneNumber=*)(mobile=*))	Web User Interface
LDAP TLS Mode	Configures the connection mode between the LDAP server and video conferencing endpoint. <ul style="list-style-type: none">• LDAP—Unencrypted connection between LDAP server and the endpoint (port 389 is used by default).• LDAP TLS Start—TLS/SSL connection between LDAP server and the endpoint (port 389 is used by default).• LDAPS—TLS/SSL connection between LDAP server and the endpoint (port 636 is used by default). Default: LDAP	Web User Interface
LDAP Server Address	Configures the domain name or IP address of the LDAP server.	Web User Interface
Port	Configures the LDAP server port. Default: 389	Web User Interface
LDAP User Name	Configures the user name used to log into the LDAP server. Note: The user name is provided by the server administrator. If the LDAP server allows 'anonymous' to login, you don't need to provide the user name to access the LDAP server.	Web User Interface
LDAP Password	Configures the password to log into the LDAP server.	Web User Interface

Parameter	Description	Configuration Method
	Note: The password is provided by the server administrator. If the LDAP server allows 'anonymous' to login, you don't need to provide the user password to access the LDAP server.	
LDAP Base	Configures the root path of the LDAP search base. Example: cn=manager,dc=yealink,dc=cn	Web User Interface
Max Hit(1~32000)	Configures the maximum number of search results to be returned by the LDAP server.	Web User Interface
LDAP Name Attributes	Configures the name attributes of each record to be returned by the LDAP server. Note: multiple name attributes should be separated by spaces. Example: cn sn	Web User Interface
LDAP Number Attributes	Configures the number attributes of each record to be returned by the LDAP server. Note: multiple numbers attributes should be separated by spaces. Example: telephoneNumber mobile	Web User Interface
LDAP Display Name	Configures the display name of the contact record displayed on the LCD screen. Note: multiple numbers attributes should be separated by spaces. Example: %cn	Web User Interface
Protocol	Configures the protocol for the LDAP server. Note: Make sure the protocol value corresponds with the version assigned on the LDAP server.	Web User Interface
Match Incoming Call	Enables or disables the endpoint to match caller numbers with LDAP contacts.	Web User Interface

Parameter	Description	Configuration Method
	Default: Disabled Note: If the match is successful, the endpoint will display the caller name when receives an incoming call.	
Match Outgoing Call	Enables or disables the endpoint to match outgoing call numbers with LDAP contacts. Default: Enabled Note: If the match is successful, the endpoint will display the contact name when places a call.	Web User Interface
LDAP Sorting Results	Enables or disables the endpoint to sort the search results in alphabetical order or numerical order. Default: Disabled	Web User Interface

For more information on string representations of LDAP query filters, refer to [RFC 2254](#).

To configure LDAP via web user interface:

1. Click on **Directory->LDAP**.
2. Enter the desired values in the corresponding fields.

3. Select the desired values from the corresponding pull-down lists.

4. Click **Confirm** to accept the change.

Call History


The VC110 video conferencing endpoint maintains call history lists of All Calls, Missed Calls, Placed Calls and Received Calls. Call history lists supports up to 100 entries (local entries and Cloud entries). You can view the call history, place a call or delete an entry from the call history list. You can view the call history and place a call from the call history list via web user interface or the remote control, but you can delete call history only via web user interface.

History record feature is enabled by default. If it is disabled, the call history won't be saved. For more information, refer to [History Record](#) on page 157.

To view call history via web user interface:

1. Click on **Directory**->**History**.

The web user interface displays all call history.




2. Click **All Calls**, select the desired call history list.

To place a call from the call history list via web user interface:

1. Click on **Directory**->**History**.

The web user interface displays all call history.

2. Hover your cursor over the entry you want to call.
3. Click or in the pop-up detail box to place a video or audio call.



The web user interface prompts "Connecting, please wait!" and jumps automatically to the **Home** screen.


To delete an entry from the call history list via web user interface:

1. Click on **Directory**->**History**.


The web user interface displays all call history.

2. Check the checkbox for the entry you want to delete.

- Click **Delete Callog**, and select **Selected**.



The web user interface prompts "Delete the callog 'xxx'? "



- Click **Confirm** to delete the call log.


You can also select **Delete All** from the pull-down list of **Delete Callog** to delete all call log.

Search Source List in Dialing




When you enter a few characters in the dialing screen, the endpoint will search for contacts from the enabled search source lists, and display the result in the dialing screen. The lists can be History, Local Directory, Cloud Contacts and LDAP.


To match the desired list, you need to enable the search source list first. If you want to match the LDAP list, make sure LDAP is already configured. For more information on how to configure LDAP, refer to [LDAP](#) on page 221.

To configure search source list in dialing via web user interface:

- Click on **Directory->Setting**.
- In the **Search Source List In Dialing** block, select the desired list from the **Disabled** column and click  .


The selected list appears in the **Enabled** column.

3. Repeat step 2 to add more lists to the **Enabled** column.
4. (Optional.) To remove a list from the **Enabled** column, select the desired list and then click .
5. To adjust the display order of the enabled list, select the desired list, and click  or .



6. Click **Confirm** to accept the change.

Dual Screen


The VC110 has two display ports. When connecting only one display device to the VC110 all-in-one unit, Display1 port is the only available port. To make it easier for users to view video images, users can connect two display devices to Display1 and Display2 ports respectively. When two display devices are connected to the VC110 all-in-one unit, the status bar of the primary display device will display .

Two display devices (dual screen) are connected to the VC110 all-in-one unit:

- When the endpoint is idle and does not start a presentation.

In the primary display device, the local video image is shown in full size.

In the secondary display device, the local video image is shown in full size (no menu and status bar).




Primary display device

Secondary display device

- When the endpoint is idle and starts a presentation.

In the primary display device, the local video image is shown in full size.

In the secondary display device, the presentation is shown in full size (no menu and status bar).



Primary display device

Secondary display device

- When the endpoint is during a call and does not start a presentation.

In the primary display device, the remote video image is shown in full size.

In the secondary display device, the local video image is shown in full size.



Primary display device

Secondary display device

- When the endpoint is during a call and starts a presentation.

In the primary display device, the remote video image is shown in big size, local video image along the right side of the screen is shown in small size.

In the secondary display device, the presentation is shown in full size.







Primary display device

Secondary display device

You can specify the display content on the secondary display device via the remote control.

To specify the display content on the secondary display device via the remote control:

- Press the **More** soft key during an active call.
- Select **Focus (Display2)**, and then press .
- Press  or  to select the desired content, and then press .

The secondary display device displays the selected content. The  icon is displayed on

the focus content.

After reassigning the display content on the secondary display device, the presentation will automatically be displayed on the primary display device.

Configuring Security Features

This chapter provides information for making configuration changes for the following security-related features:

- [User Mode](#)
- [Administrator Password](#)
- [Web Server Type](#)
- [Transport Layer Security](#)
- [Secure Real-Time Transport Protocol](#)
- [H.235](#)
- [Attack Defense in Public Network](#)

User Mode

Users can access the endpoint menus directly (except the “Advanced” menu) on the display device. The “Advanced” menu requires administrator credentials. You can enable the user mode to provide two levels of access for the menus. You need to configure a password for the user when the user mode is enabled. Users are prompted to enter the password when accessing the menus (except the “Status” menu). After the user mode is enabled, the user can log into the web user interface of the endpoint with user credentials. The default user name is “user”.

User mode parameters on the endpoint are described below:

Parameter	Description	Configuration Method
User Type	Specifies the user type. Default: Administrator Note: To enable the user type, you need to select User for this parameter.	Web User Interface
User Mode	Enables or disables the user mode. Default: Disabled Note: It is only applicable to the user mode. The administrator mode is enabled by default.	Web User Interface
User Password	Configures a password for the user to access the menus or log into the web user interface.	Web User Interface

Parameter	Description	Configuration Method
	Note: It can only be configured when the user mode is enabled. The endpoint supports ASCII characters 32-126(0x20-0x7E) in passwords. You can leave the password blank.	

To configure user mode via web user interface:

1. Click on **Security->Security**.
2. Select **User** from the pull-down list of **User Type**.
3. Select **Enabled** from the pull-down list of **User Mode**.
4. Configure a password or leave it blank in the **User Password** field.

5. Click **Confirm** to accept the change.

Administrator Password

The default enabled user type is administrator. Users can log into the web user interface and access the "Advanced" menu with administrator privilege by default. The default administrator password is "0000" and can be only changed by an administrator. For security reasons, the administrator should change the default administrator password as soon as possible. The endpoint supports ASCII characters 32-126(0x20-0x7E) in passwords.

Administrator password parameters on the endpoint are described below:

Parameter	Description	Configuration Method
User Type	Specifies the user type. Default: Administrator Note: To configure a new administrator password, you need to select Administrator for this parameter.	Web User Interface
Old Password	Enters the old administrator password. Note: The default administrator password is "0000".	Remote Control Web User Interface

Parameter	Description	Configuration Method
New Password	Configures a new administrator password. Note: You can leave the password blank.	Remote Control Web User Interface
Confirm Password	Enters the new configured administrator password. Note: The entered password must be the same as the one configured by the parameter "New Password".	Remote Control Web User Interface

To configure administrator password via web user interface:

1. Click on **Security**->**Security**.
2. Select **Administrator** from the pull-down list of **User Type**.
3. Enter the old administrator password in the **Old Password** field.
4. Enter a new password in the **New Password** field.
5. Enter the new password or leave it blank in the **User Password** field.

6. Click **Confirm** to accept the change.

To configure administrator password via the remote control:

1. Select **Menu**->**Advanced** (default password: 0000)->**Password Reset**.
2. Enter the old password in the **Current Password** field.
3. Configure a new password in the **New Password** and **Confirm Password** fields.
4. Press the **Save** soft key to accept the change.

Web Server Type

Web server type determines the access protocol of the endpoint's web user interface. The endpoint supports both HTTP and HTTPS protocols for accessing the web user interface. HTTP is an application protocol that runs on top of the TCP/IP suite of protocols. HTTPS is a web protocol that encrypts and decrypts user page requests as well as the pages returned by the web server. Both the HTTP and HTTPS port numbers are configurable.

Web server type parameters on the endpoint are described below:

Parameter	Description	Configuration Method
HTTP	Enables or disables the user to access the web user interface of the endpoint using the HTTP protocol. Default: Enabled Note: If you change this parameter, the endpoint will reboot to make the change take effect.	Remote Control Web User Interface
HTTP Port	Specifies the HTTP port for the user to access the web user interface of the endpoint. Valid Values: 1-65535 Default: 80 Note: Ensure that the configured port is not used. If you change this parameter, the endpoint will reboot to make the change take effect.	Web User Interface
HTTPS	Enables or disables the user to access the web user interface of the endpoint using the HTTPS protocol. Default: Enabled Note: If you change this parameter, the endpoint will reboot to make the change take effect.	Remote Control Web User Interface
HTTPS Port	Specifies the HTTPS port for the user to access the web user interface of the endpoint. Valid Values: 1-65535 Default: 443 Note: Ensure that the configured port is not used. If you change this parameter, the endpoint will reboot to make the change take effect.	Web User Interface

To configure web server type via web user interface:

1. Click on **Network->Advanced**.
2. Select the desired value from the pull-down list of **HTTP**.
3. Enter the desired HTTP port in the **HTTP Port** field.

4. Select the desired value from the pull-down list of **HTTPS**.
5. Enter the desired HTTPS port in the **HTTPS Port** field.

The screenshot shows the Yealink VC110 web interface. The top navigation bar includes 'About', 'Language', and 'Logout'. The main navigation bar has 'Home', 'Status', 'Account', 'Network' (selected), 'Setting', 'Directory', and 'Security'. The left sidebar shows 'LAN Configuration', 'NAT/Firewall', 'Advanced' (selected), and 'Diagnose'. The main content area is titled 'Web Server'. A red box highlights the 'Web Server' configuration fields: 'HTTP' (Enabled), 'HTTP Port' (80), 'HTTPS' (Enabled), and 'HTTPS Port' (443). Below this, the '802.1x' section is visible, with '802.1x Mode' set to 'Disabled'. There are input fields for 'Identity', 'MD5 Password', 'CA Certificates', and 'Device Certificates', each with a 'Browse...' button and an 'Upload' button.

6. Click **Confirm** to accept the change.
A dialog box pops up to prompt that the settings will take effect after a reboot.
7. Click **Confirm** to reboot the endpoint immediately.

To configure web server type via the remote control:

1. Select **Menu->Advanced** (default password: 0000) -> **Advanced Network**.
2. Select the desired value from the pull-down list of **Web Server Type**.
3. Press the **Save** soft key to accept the change.
The display device prompts "Reboot now?".
4. Select **OK** to reboot the endpoint immediately.

Transport Layer Security

TLS is a commonly-used protocol for providing communications privacy and managing the security of message transmission, allowing the endpoint to communicate with other remote parties and connect to the HTTPS URL for provisioning in a way that is designed to prevent eavesdropping and tampering.

TLS protocol is composed of two layers: TLS Record Protocol and TLS Handshake Protocol. The TLS Record Protocol completes the actual data transmission and ensures the integrity and privacy of the data. The TLS Handshake Protocol allows the server and client to authenticate each other and negotiate an encryption algorithm and cryptographic keys before data is exchanged.

The endpoint supports TLS 1.0. A cipher suite is a named combination of authentication, encryption, and message authentication code (MAC) algorithms used to negotiate the security

settings for a network connection using the TLS/SSL network protocol. The endpoint supports the following cipher suites:

- DHE-RSA-AES256-SHA
- DHE-DSS-AES256-SHA
- AES256-SHA
- EDH-RSA-DES-CBC3-SHA
- EDH-DSS-DES-CBC3-SHA
- DES-CBC3-SHA
- DHE-RSA-AES128-SHA
- DHE-DSS-AES128-SHA
- AES128-SHA
- IDEA-CBC-SHA
- DHE-DSS-RC4-SHA
- RC4-SHA
- RC4-MD5
- EXP1024-DHE-DSS-DES-CBC-SHA
- EXP1024-DES-CBC-SHA
- EDH-RSA-DES-CBC-SHA
- EDH-DSS-DES-CBC-SHA
- DES-CBC-SHA
- EXP1024-DHE-DSS-RC4-SHA
- EXP1024-RC4-SHA
- EXP1024-RC4-MD5
- EXP-EDH-RSA-DES-CBC-SHA
- EXP-EDH-DSS-DES-CBC-SHA
- EXP-DES-CBC-SHA
- EXP-RC4-MD5

The following figure illustrates the TLS messages exchanged between the endpoint and TLS server to establish an encrypted communication channel:

No.	Time	Source	Destination	Protocol	Info
1	0.000000	192.168.3.86	192.168.0.230	SSLV3	Client Hello
2	0.021345	192.168.0.230	192.168.3.86	SSLV3	Server Hello, Certificate, Server Key Exchange, Server Hello Done
3	0.054947	192.168.3.86	192.168.0.230	SSLV3	Client Key Exchange, Change Cipher Spec, Encrypted Handshake Message
4	0.070099	192.168.0.230	192.168.3.86	SSLV3	Change Cipher Spec, Encrypted Handshake Message
5	1.012295	192.168.3.86	192.168.0.230	SSLV3	Application Data, Application Data
6	1.013562	192.168.0.230	192.168.3.86	SSLV3	Application Data
7	1.013667	192.168.0.230	192.168.3.86	SSLV3	Application Data

Frame 13: 652 bytes on wire (5216 bits), 652 bytes captured (5216 bits)
 Ethernet II, Src: Vmware_72:c9:2e (00:0c:29:72:c9:2e), Dst: Xiamenye_11:12:b7 (00:15:65:11:12:b7)
 Internet Protocol, Src: 192.168.0.230 (192.168.0.230), Dst: 192.168.3.86 (192.168.3.86)
 Transmission Control Protocol, Src Port: https (443), Dst Port: rnmserver (2244), Seq: 1482, Ack: 437, Len: 586
 Secure Socket Layer

Step1: The endpoint sends “Client Hello” message proposing SSL options.

Step2: Server responds with “Server Hello” message selecting the SSL options, sends its public key information in “Server Key Exchange” message and concludes its part of the negotiation with “Server Hello Done” message.

Step3: The endpoint sends key session information (encrypted by server’s public key) in the “Client Key Exchange” message.

Step4: Server sends “Change Cipher Spec” message to activate the negotiated options for all future messages it will send.

The endpoint can encrypt SIP with TLS, which is called SIPS. When TLS is enabled for the SIP account, the message of the SIP account will be encrypted after the successful TLS negotiation.

Certificates

The endpoint can serve as a TLS client or a TLS server. The TLS requires the following security certificates to perform the TLS handshake:

- Trusted Certificate:** When the endpoint requests a TLS connection with a server, the endpoint should verify the certificate sent by the server to decide whether it is trusted based on the trusted certificates list. The endpoint has 33 built-in trusted certificates. You can upload up to 10 custom certificates to the endpoint. The format of the certificates must be *.pem, *.cer, *.crt and *.der. For more information on 33 trusted certificates, refer to [Appendix B: Trusted Certificates](#) on page 284.
- Server Certificate:** When clients request a TLS connection with the endpoint, the endpoint sends the server certificate to the clients for authentication. The endpoint has two types of built-in server certificates: a unique server certificate and a generic server certificate. You can only upload one server certificate to the endpoint. The old server certificate will be overridden by the new one. The format of the server certificate files must be *.pem and *.cer.
 - A unique server certificate:** It is installed by default and is unique to a endpoint (based on the MAC address) and issued by the Yealink Certificate Authority (CA).
 - A generic server certificate:** It is installed by default and is issued by the Yealink Certificate Authority (CA). Only if no unique certificate exists, the endpoint may send a generic certificate for authentication.

The endpoint can authenticate the server certificate based on the trusted certificates list. The trusted certificates list and the server certificates list contain the default and custom certificates. You can specify the type of certificates the endpoint accepts: default certificates, custom certificates, or all certificates.

Common Name Validation feature enables the endpoint to mandatorily validate the common name of the certificate sent by the connecting server. And Security verification rules are compliant with RFC 2818.

TLS parameters on the endpoint are described below:

Parameter	Description	Configuration Method
Transport	<p>Configures the type of transport protocol. You can configure it for the Zoom/Pexip/BlueJeans/Mind/Custom platform, or SIP account separately.</p> <ul style="list-style-type: none"> • UDP—provides best-effort transport via UDP for the SIP signaling. • TCP—provides reliable transport via TCP for SIP signaling. • TLS—provides secure communication for SIP signaling. • DNS-NAPTR—performs the DNS NAPTR and SRV queries for the service type and port if no server port is given. <p>Default: For Zoom/Pexip/BlueJeans/Mind/Custom platform, the default value is TCP. For SIP account, the default value is UDP.</p> <p>Note: You cannot configure it for the Yealink/StarLeaf Cloud platform.</p>	<p>Remote Control Web User Interface</p>
Only Accept Trusted Certificates	<p>Enables or disables the endpoint to only trust the server certificates in the Trusted Certificates list.</p> <p>Default: Enabled</p> <p>Note: If it is enabled, the endpoint will authenticate the server certificate based on the trusted certificates list. Only when the authentication succeeds, will the endpoint trust the server.</p> <p>If you change this parameter, the endpoint will reboot to make the change take effect.</p>	<p>Web User Interface</p>

Parameter	Description	Configuration Method
Common Name Validation	<p>Enables or disables the endpoint to mandatorily validate the CommonName or SubjectAltName of the certificate sent by the server.</p> <p>Default: Disabled</p> <p>Note: If you change this parameter, the endpoint will reboot to make the change take effect.</p>	Web User Interface
CA Certificates	<p>Configures the type of certificates in the Trusted Certificates list for the endpoint to authenticate for the TLS connection.</p> <ul style="list-style-type: none"> • Default Certificates • Custom Certificates • All Certificates <p>Default: Default Certificates</p> <p>Note: If you change this parameter, the endpoint will reboot to make the change take effect.</p>	Web User Interface
Upload Trusted Certificate File	<p>Upload the custom CA certificate to the endpoint.</p> <p>Note: A maximum of 10 CA certificates can be uploaded to the endpoint. The certificate you want to upload must be in *.pem, *.crt, *.cer or *.der format.</p>	Web User Interface
Device Certificates	<p>Upload the customized CA certificate to the endpoint.</p> <ul style="list-style-type: none"> • Default Certificates • Custom Certificates <p>Default: Default Certificates</p> <p>Note: If you change this parameter, the endpoint will reboot to make the change take effect.</p>	Web User Interface
Upload Server Certificate File	<p>Upload the custom device certificate to the endpoint.</p> <p>Note: Only one device certificate can be uploaded to the endpoint. The device certificate you want to upload must be in</p>	Web User Interface

Parameter	Description	Configuration Method
	*.pem or *.cer format.	

To configure the trusted certificate feature via web user interface:

1. Click on **Security->Trusted Certs.**
2. Select the desired value from the pull-down list of **Only Accept Trusted Certificates.**
3. Select the desired value from the pull-down list of **Common Name Validation.**
4. Select the desired value from the pull-down list of **CA Certificates.**

5. Click **Confirm** to accept the change.
A dialog box pops up to prompt that the settings will take effect after a reboot.
6. Click **Confirm** to reboot the endpoint immediately.

To configure TLS for the Zoom/Pexip/BlueJeans/Mind/Custom platform via web user interface:

1. Click on **Account->Cloud**
2. Select **Zoom/Pexip/BlueJeans/Mind/Custom** from the pull-down list of **Platform Type.**

3. Select **TLS** from the pull-down list of the **Transport**.

The screenshot shows the Yealink VC110 web interface. The top navigation bar includes 'About', 'Language', and 'Logout'. The main menu has 'Home', 'Status', 'Account', 'Network', 'Setting', 'Directory', and 'Security'. The left sidebar shows a tree view with 'Cloud' selected. The main content area is titled 'Cloud' and contains the following settings:

Register Status	Registered
Cloud Account	Enabled
Platform Type	Zoom
Server Host	zoomcrc.com
Advanced Setting	
Transport	TLS
Server Expires	3600
SRTP	Disabled
DTMF Type	RFC2833
DTMF Info Type	DTMF-Relay
DTMF Payload Type (96~127)	101

4. Click **Confirm** to accept the change.

To configure TLS for the SIP account via web user interface:

1. Click on **Account->SIP Account**.
2. Select **TLS** from the pull-down list of the **Transport**.

The screenshot shows the Yealink VC110 web interface. The top navigation bar includes 'About', 'Language', and 'Logout'. The main menu has 'Home', 'Status', 'Account', 'Network', 'Setting', 'Directory', and 'Security'. The left sidebar shows a tree view with 'SIP Account' selected. The main content area is titled 'SIP Account' and contains the following settings:

Register Status	Registered	
SIP Account	Enabled	
Username	9000	
Register Name	9000	
Password	••••••••	
Server Host	10.2.1.48	Port: 5060
Enable Outbound Proxy Server	Disabled	
Outbound Proxy Server		Port: 5060
Transport	TLS	
Server Expires	3600	
SRTP	Disabled	
DTMF Type	RFC2833	
DTMF Info Type	DTMF-Relay	
DTMF Payload Type (96~127)	101	
NAT Traversal	Disabled	

3. Click **Confirm** to accept the change.

To upload a CA certificate via web user interface:

1. Click on **Security**->**Trusted Certs**.
2. Click **Browse** to locate the certificate (*.pem,*.crt, *.cer or *.der) from your local endpoint.

3. Click **Upload** to upload the certificate.

To configure the device certificate via web user interface:


1. Click on **Security**->**Server Certs**.
2. Select the desired value from the pull-down list of **Device Certificates**.

3. Click **Confirm** to accept the change.
A dialog box pops up to prompt that the settings will take effect after a reboot.
4. Click **Confirm** to reboot the endpoint immediately.

To upload a device certificate via web user interface:

1. Click on **Security**->**Server Certs**.

- Click **Browse** to locate the certificate (*.pem or *.cer) from your local endpoint.



- Click **Upload** to upload the certificate.

Secure Real-Time Transport Protocol

During a confidential call, you can configure Secure Real-Time Transport Protocol (SRTP) to encrypt RTP streams to avoid interception and eavesdropping. Both RTP and RTCP signaling may be encrypted using an AES algorithm as described in RFC3711. Encryption modifies the data in the RTP streams so that, if the data is captured or intercepted, it cannot be understood—it sounds like noise. Only the receiver knows the key to restore the data. To use SRTP encryption for SIP calls, the participants in the call must enable SRTP simultaneously. When this feature is enabled on both endpoints, the encryption algorithm utilized for the session is negotiated between the endpoints. This negotiation process is compliant with RFC 4568.

When a site places a call on the SRTP enabled endpoint, the endpoint sends an INVITE message with the RTP encryption algorithm to the destination endpoint.

The following is an example of the RTP encryption algorithm carried in the SDP of the INVITE message:

```
m=audio 11780 RTP/SAVP 0 8 18 9 101
a=crypto:1 AES_CM_128_HMAC_SHA1_80 inline:NzFINTUwZDk2OGVIOTc3YzNkYTkwZWVkbMTM1YWVj
a=crypto:2 AES_CM_128_HMAC_SHA1_32
inline:NzkyM2FjNzQ2ZDgxYjg0MzQwMGVmMGUxMzdmNWVm
a=crypto:3 F8_128_HMAC_SHA1_80 inline:NDliMWIzZGE1ZTAwZjA5ZGFhNjQ5YmEANTMzYzA0
a=rtpmap:0 PCMU/8000
a=rtpmap:8 PCMA/8000
a=rtpmap:18 G729/8000
a=fmtp:18 annexb=no
a=rtpmap:9 G722/8000
a=fmtp:101 0-15
a=rtpmap:101 telephone-event/8000
a=ptime:20
```

```
a=sendrecv
```

The callee receives the INVITE message with the RTP encryption algorithm, and then answers the call by responding with a 200 OK message which carries the negotiated RTP encryption algorithm.

The following is an example of the RTP encryption algorithm carried in the SDP of the 200 OK message:


```
m=audio 11780 RTP/SAVP 0 101
a=rtpmap:0 PCMU/8000
a=rtpmap:101 telephone-event/8000
a=crypto:1 AES_CM_128_HMAC_SHA1_80 inline:NGY4OGViMDYzZjQzYTNiOTNkOWRiYzRiMjM0Yzcz
a=sendrecv
a=ptime:20
a=fmtp:101 0-15
```

The SRTP parameter on the endpoint is described below:

Parameter	Description	Configuration Method
SRTP	<p>Specifies the SRTP type. You can configure it for the Zoom/Pexip/BlueJeans/Mind/Custom platform, SIP account or SIP IP call separately.</p> <ul style="list-style-type: none"> Disabled—do not use SRTP in SIP calls. Optional—negotiate with the far site whether to use SRTP for media encryption in SIP calls. Compulsory—compulsory use SRTP for media encryption in SIP calls. <p>Default: Disabled</p> <p>Note: You cannot configure it for the Yealink/StarLeaf Cloud platform.</p>	Web User Interface

Rules of SRTP for media encryption in SIP calls:

Far \ Near	Compulsory	Optional	Disabled
Compulsory	SRTP Call	SRTP Call	Fail to establish call
Optional	SRTP Call	SRTP Call	RTP Call
Disabled	Fail to establish call	RTP Call	RTP Call

When SRTP is enabled on both endpoints, RTP streams will be encrypted, and the lock icon  is displayed.

appears on the display device of each endpoint after successful negotiation.

Note

If SRTP is enabled for the Cloud platform or SIP account, you should also configure the transport type to TLS. This ensures the security of SRTP encryption. For more information on TLS, refer to [Transport Layer Security](#) on page 237.

To configure SRTP for Zoom/Pexip/BlueJeans/Mind/Custom platform via web user interface:

1. Click on **Account->Cloud**.
2. Select **Zoom/Pexip/BlueJeans/Mind/Custom** from the pull-down list of **Platform Type**.
3. Select the desired value from the pull-down list of **SRTP**.

The screenshot displays the Yealink VC110 web interface. The top navigation bar includes 'About', 'Language', and 'Logout'. The main menu has 'Home', 'Status', 'Account' (selected), 'Network', 'Setting', 'Directory', and 'Security'. On the left, a sidebar shows 'Cloud' selected, with options for 'H.323', 'SIP Account', 'SIP IP Call', and 'Codec'. The main content area is titled 'Cloud' and shows the following configuration:

Register Status	Registered
Cloud Account	Enabled
Platform Type	Zoom
Server Host	zoomcrc.com
Advanced Setting	
Transport	TCP
Server Expires	3600
SRTP	Compulsory
DTMF Type	RFC2833
DTMF Info Type	DTMF-Relay
DTMF Payload Type (96~127)	101
Keep Alive Interval	30
BFCP	Enabled
FECC(SIP)	Enabled

4. Click **Confirm** to accept the change.

To configure SRTP for SIP account via web user interface:

1. Click on **Account->SIP Account**.

2. Select the desired value from the pull-down list of **SRTP**.

The screenshot shows the Yealink VC110 web interface. The top navigation bar includes 'About', 'Language', and 'Logout'. The main menu has 'Home', 'Status', 'Account' (selected), 'Network', 'Setting', 'Directory', and 'Security'. On the left, a sidebar lists 'Cloud', 'H323', 'SIP Account' (selected), 'SIP IP Call', and 'Codec'. The main content area displays various settings for the selected 'SIP Account'. The 'SRTP' setting is highlighted with a red box and is set to 'Compulsory'. Other settings include 'Register Status' (Registered), 'SIP Account' (Enabled), 'Username' (9000), 'Register Name' (9000), 'Password' (masked), 'Server Host' (10.2.1.48), 'Port' (5060), 'Enable Outbound Proxy Server' (Disabled), 'Outbound Proxy Server' (empty), 'Port' (5060), 'Transport' (UDP), 'Server Expires' (3600), 'DTMF Type' (RFC2833), 'DTMF Info Type' (DTMF-Relay), 'DTMF Payload Type (96~127)' (101), and 'NAT Traversal' (Disabled).

3. Click **Confirm** to accept the change.

To configure SRTP for SIP IP call via web user interface:

1. Click on **Account->SIP IP Call**.
2. Select the desired value from the pull-down list of **SRTP**.

The screenshot shows the Yealink VC110 web interface with the 'SIP IP Call' settings page selected. The top navigation bar and main menu are the same as in the previous screenshot. The sidebar now has 'SIP IP Call' selected. The main content area displays settings for 'SIP IP Call'. The 'SRTP' setting is highlighted with a red box and is set to 'Compulsory'. Other settings include 'SIP IP Call' (Enabled), 'Transport' (TCP), 'DTMF Type' (RFC2833), 'DTMF Info Type' (DTMF-Relay), 'DTMF Payload Type (96~127)' (101), 'NAT Traversal' (Disabled), 'RPort' (Enabled), 'BFCP' (Enabled), and 'FECC(SIP)' (Enabled).

3. Click **Confirm** to accept the change.

H.235

Yealink VC110 video conferencing endpoints support H.235 128-bit AES algorithm using the


Diffie-Hellman key exchange protocol in H.323 calls. To use H.235 feature for H.323 calls, the participants in the call must enable the H.235 feature simultaneously. When a site places a call on the H.235 feature enabled endpoint, the endpoint negotiates the encryption algorithm with the destination endpoint.

The H.235 parameter on the endpoint is described below:

Parameter	Description	Configuration Method
H.235 Encryption	<p>Specifies the H.235 type. You can configure it for the StarLeaf Cloud platform or H.323 call separately.</p> <ul style="list-style-type: none"> • Disabled—do not use H.235 in H.323 calls. • Optional—negotiate with the far site whether to use H.235 in H.323 calls. • Compulsory—compulsively use H.235 in H.323 calls. <p>Default: Disabled</p>	Web User Interface

Rules of H.235 security in H.323 calls:


Far \ Near	Compulsory	Optional	Disabled
Compulsory	H.235 Call	H.235 Call	Fail to establish call
Optional	H.235 Call	H.235 Call	RTP Call
Disabled	Fail to establish a call	RTP Call	RTP Call

When H.235 is enabled on both endpoints, calls will be encrypted, and the lock icon  appears on the display device of each endpoint during a call.

To configure H.235 for StarLeaf Cloud platform via web user interface:

1. Click on **Account->Cloud**.
2. Select **StarLeaf** from the pull-down list of **Platform Type**.

3. Select the desired value from the pull-down list of **H.235 Encryption**.




The screenshot shows the Yealink VC110 web interface. The top navigation bar includes 'About', 'Language', and 'Logout'. The main menu has 'Home', 'Status', 'Account' (selected), 'Network', 'Setting', 'Directory', and 'Security'. On the left, a sidebar lists 'Cloud', 'H.323', 'SIP Account', 'SIP IP Call', and 'Codec'. The 'Cloud' section is expanded, showing 'Register Status' as 'Registered'. Under 'Advanced Setting', the 'H.235 Encryption' dropdown is highlighted with a red box, showing 'Disabled' as the selected value. Other settings include 'Cloud Account' (Enabled), 'Platform Type' (StarLeaf), 'QCP Code' (367037241953), 'H.323 Tunneling' (Disabled), 'Protocol Monitor Port' (1720), 'DTMF Type' (Auto), 'Local Early Media' (Disabled), 'H.239' (Enabled), and 'FECC(H.323)' (Enabled).

4. Click **Confirm** to accept the change.

To configure H.235 for H.323 via web user interface:

1. Click on **Account->H.323**
2. Select the desired value from the pull-down list of **H.235 Encryption**.



The screenshot shows the Yealink VC110 web interface. The top navigation bar includes 'About', 'Language', and 'Logout'. The main menu has 'Home', 'Status', 'Account' (selected), 'Network', 'Setting', 'Directory', and 'Security'. On the left, a sidebar lists 'Cloud', 'H323' (selected), 'SIP Account', 'SIP IP Call', and 'Codec'. The 'H323' section is expanded, showing 'Register Status' as 'Registered'. Under 'H323 Protocol', the 'H235 Encryption' dropdown is highlighted with a red box, showing 'Compulsory' as the selected value. Other settings include 'H323 Protocol' (Enabled), 'H.323 Account' (Enabled), 'H.323 Name' (9000), 'H.323 Extension' (9000), 'Gatekeeper Mode' (Manual), 'Gatekeeper IP Address 1' (10.2.1.43), 'Gatekeeper IP Address 2' (empty), 'Gatekeeper Authentication' (Disabled), 'Gatekeeper Username' (empty), 'Gatekeeper Password' (masked), 'H.460 Active' (Disabled), 'H.323 Tunneling' (Disabled), and 'Protocol Monitor Port' (1720).

3. Click **Confirm** to accept the change.

Attack Defense in Public Network

VoIP phones often suffer from network attacks in public network, which results in communication failure. To ensure the safety of the enterprise VoIP phone, you can configure abnormal call answering feature for handling abnormal calls using the SIP protocol. For abnormal calls using the H.323 protocol, you can configure safe mode call feature to handle them.

Abnormal Call Answering

The abnormal call answering parameters on the endpoint are described below:

Parameter	Description	Configuration Method
Abnormal Call Answering	<p>Specifies the account type for answering SIP incoming call from public network.</p> <ul style="list-style-type: none"> • Disabled—reject the SIP incoming call from public network. • Account Answer—use first SIP account to answer the SIP incoming call from public network. • IP Call Answer—use endpoint IP to answer the SIP incoming call from public network. <p>Default: IP Call Answer</p>	Web User Interface

To configure abnormal call answering via web user interface:

1. Click on **Setting**->**Call Features**.

2. Select the desired value from the pull-down list of **Abnormal Call Answering**.

The screenshot shows the Yealink VC110 WUI. The 'Setting' tab is active. On the left, a sidebar lists various settings categories: General, Date & Time, Call Features (selected), Video & Audio, Camera, Configuration, Upgrade, Tones, Wireless Micpod, and 3rd-Party VMR. The main area displays a list of settings. The 'Abnormal Call Answering' setting is highlighted with a red rectangle, showing a dropdown menu with 'IP Call Answer' selected. Other settings include 'Auto Answer' (Enabled), 'Auto Answer Mute' (Enabled), 'Auto Answer Multiway' (Disabled), 'Auto Dialout Mute' (Disabled), 'Call Match' (Enabled), 'History Record' (Enabled), 'Call Protocol' (Auto), 'Uplink Bandwidth' (Auto), 'Downlink Bandwidth' (Auto), 'Safe Mode Call' (Enabled), 'Ringback Timeout(30-240)' (200), 'Auto Refuse Timeout(30-240)' (120), 'SIP IP Call by Proxy' (Off), 'Default Layout of Single Screen' (Remote Full screen), and 'Network Address Adapter' (Enabled). At the bottom, there are 'Confirm' and 'Cancel' buttons.

3. Click **Confirm** to accept the change.

Configuring Safe Mode Call

You can configure safe mode call feature to handle abnormal H.323 calls.

The safe mode call parameters on the endpoint are described below:

Parameter	Description	Configuration Method
Safe Mode Call	<p>Enables or disables the safe mode call feature for H.323 incoming call from public network.</p> <ul style="list-style-type: none"> • Disabled—do not use safe mode call. • Enabled—use safe mode call. <p>Default: Enabled</p> <p>Note: If it is enabled, the endpoint will reject H.323 incoming call from public network. If it is disabled, any H.323 incoming call from public network can be accepted.</p>	Web User Interface

To configure safe mode call via web user interface:

1. Click on **Setting**->**Call Features**.
2. Select the desired value from the pull-down list of **Safe Mode Call**.

The screenshot shows the Yealink VC110 web interface. The top navigation bar includes links for About, Language, and Logout. Below this is a green header with the Yealink VC110 logo and a menu with Home, Status, Account, Network, Setting (highlighted), Directory, and Security. On the left, a sidebar lists various settings categories: General, Date & Time, Call Features (highlighted), Video & Audio, Camera, Configuration, Upgrade, Tones, Wireless Micpod, and 3rd-Party VMR. The main content area displays the 'Call Features' settings. A list of settings is shown, each with a label and a pull-down menu. The 'Safe Mode Call' setting is highlighted with a red rectangular box and is currently set to 'Enabled'. Other settings include Auto Answer (Enabled), Auto Answer Mute (Enabled), Auto Answer Multiway (Disabled), Auto Dialout Mute (Disabled), Call Match (Enabled), History Record (Enabled), Call Protocol (Auto), Uplink Bandwidth (Auto), Downlink Bandwidth (Auto), Abnormal Call Answering (IP Call Answer), Ringback Timeout(30-240) (200), Auto Refuse Timeout(30-240) (120), SIP IP Call by Proxy (Off), Default Layout of Single Screen (Remote Full screen), and Network Address Adapter (Enabled). At the bottom of the settings list are 'Confirm' and 'Cancel' buttons.

Setting	Value
Auto Answer	Enabled
Auto Answer Mute	Enabled
Auto Answer Multiway	Disabled
Auto Dialout Mute	Disabled
Call Match	Enabled
History Record	Enabled
Call Protocol	Auto
Uplink Bandwidth	Auto
Downlink Bandwidth	Auto
Abnormal Call Answering	IP Call Answer
Safe Mode Call	Enabled
Ringback Timeout(30-240)	200
Auto Refuse Timeout(30-240)	120
SIP IP Call by Proxy	Off
Default Layout of Single Screen	Remote Full screen
Network Address Adapter	Enabled

3. Click **Confirm** to accept the change.

Endpoint Maintenance

This chapter provides basic endpoint maintenance, including upgrading firmware, managing configurations, resetting endpoints and how to monitor network via SNMP. Topics include:


- [Upgrading Firmware](#)
- [Importing/Exporting Configuration](#)
- [Resetting to Factory](#)
- [SNMP](#)

Upgrading Firmware

The newly released firmware version may add new features. Because of this, Yealink recommends you to update the latest firmware. You can upgrade the endpoint firmware via web user interface. The firmware name of the VC110 video conferencing endpoint is: 50.x.x.x.rom (x is the actual firmware version). You can download the latest firmware version from the Yealink website.

To upgrade firmware via web user interface:

1. Click on **Setting**->**Upgrade**.
2. Click **Browse** to locate the firmware from your local endpoint.



3. Click **Upgrade** to upgrade the firmware.

The browser pops up the dialog box "Firmware of the video conference endpoint will be updated. It will take 5 minutes to complete. Please don't power off!".

- Click **Confirm** to confirm upgrading.

Note

Caution! Don't remove the Ethernet cable and power cord during the upgrade process. Don't close or refresh the web page when upgrading the firmware via web user interface.

Importing/Exporting Configuration

We may need you to provide the endpoint configurations for the Yealink field application engineers to help analyze problems. You can import configurations to your endpoint to configure your endpoint quickly. The file format of configuration file must be *.bin.

To export the endpoint configurations via web user interface:

- Click on **Setting**->**Configuration**.
- Click **Export**.


The screenshot shows the Yealink VC110 web interface. The top navigation bar includes links for About, Language, and Logout. Below this is a green header with the Yealink logo and navigation tabs: Home, Status, Account, Network, Setting (selected), Directory, and Security. On the left, a sidebar lists various configuration categories: General, Date & Time, Call Features, Video & Audio, Camera, Configuration (selected), Upgrade, Tones, Wireless Micpod, and 3rd-Party VMR. The main content area is titled 'Configuration' and contains several settings. At the top, there are 'Import Configuration' and 'Export Configuration' buttons. The 'Export Configuration' button is highlighted with a red rectangular box. Below this, there are settings for 'Pcap Feature' (with Start, Stop, and Export buttons), 'Packet Capture Count' (set to 5), 'Packet Capture Clip Bytes' (set to 1024), 'Pcap Filter Type' (set to Custom), and 'Packet Filter String'. At the bottom, there are 'Export System Log' options (Local and Server) and a 'System Log Level' dropdown set to 6.

- Click **Confirm** to export the configurations.

To import the endpoint configurations via web user interface:

- Click on **Setting**->**Configuration**.

- Click **Browse** to locate a configuration file from your local endpoint.



- Click **Import** to import the configuration file.

Resetting to Factory

Reset the endpoint to factory configurations after you have tried all appropriate troubleshooting suggestions but still have not solved your problems.

When factory resetting the video endpoint, the following happens:

- The call logs will be deleted.
- Passwords will be reset to default.
- All system parameters will be reset to default values.
- All custom files will be deleted. Such as, certificates, local contacts and registered accounts.

It is not possible to undo a factory reset. But you can export the configuration first, and then you can re-import the configuration to recovery the endpoint after the reset.

You can reset the endpoint via the reset key on the VC110 all-in-one unit, remote control or web user interface.

Note

Reset of the endpoint may take a few minutes. Do not power off until the phone starts up successfully.

To reset the endpoint via web user interface:


- Click on **Setting** -> **Upgrade**.
- Click **Reset to Factory Setting** in the **Reset to Factory** field.

The web user interface prompts the message "Reset your machine?".


3. Click **Confirm** to confirm the resetting.

To reset the endpoint via the remote control:

1. Select **Menu** -> **Advanced** (default password: 0000)-> **Reboot & Reset**

2. Select **Reset**, and then press  .

The display device prompts "Reset to Factory? "


3. Select **OK**, and then press  .

The endpoint reboots automatically. The endpoint will reset to factory successfully after startup.

To reset the endpoint via the rest key on the VC110 all-in-one unit:

Using tiny objects (for example, the paper clip) to press and hold the reset button for 15 seconds until the screen turns black.

Do not power off the endpoint during the factory restore process. The endpoint reverts to the default factory settings and restarts automatically. This will take a few minutes.



SNMP

SNMP (Simple Network Management Protocol) is an Internet-standard protocol for managing devices on IP networks. It is used mostly in network management endpoints to monitor network-attached devices for conditions that warrant administrative attention. SNMP exposes management data in the form of variables on the managed endpoints, which describe the endpoint configuration. These variables can then be queried (and sometimes set) by managing applications. The variables accessible via SNMP are organized in hierarchies, which are described by Management Information Bases (MIBs).

Yealink endpoints support SNMPv1 and SNMPv2. They work as SNMP clients, receiving requests from the SNMP server. The SNMP server may send requests from any available source port to the configured port on the client, while the client responds to the source port on the SNMP server. Yealink endpoints only support the GET request from the SNMP server.

You can download SNMP application to monitor and manage information on a network entity.

The following table lists the basic object identifiers (OIDs) supported by the endpoint.

MIB	OID	Description
YEALINK-MIB	1.3.6.1.2.1.37459.2.1.1.0	The textual identification of the contact person for the endpoint, together with the contact information. For example, Sysadmin (root@localhost)
YEALINK-MIB	1.3.6.1.2.1.37459.2.1.2.0	An administratively-assigned name for the endpoint. If the name is unknown, the value is a zero-length string. For example, Yealink VC110.
YEALINK-MIB	1.3.6.1.2.1.37459.2.1.3.0	The physical location of the endpoint. For example, Server Room
YEALINK-MIB	1.3.6.1.2.1.37459.2.1.4.0	The time (in milliseconds) since the network management portion of the endpoint was last re-initialized.
YEALINK-MIB	1.3.6.1.2.1.37459.2.1.5.0	The firmware version of the endpoint.
YEALINK-MIB	1.3.6.1.2.1.37459.2.1.6.0	The hardware version of the endpoint.
YEALINK-MIB	1.3.6.1.2.1.37459.2.1.7.0	The endpoint's model.
YEALINK-MIB	1.3.6.1.2.1.37459.2.1.8.0	The MAC address of the endpoint.
YEALINK-MIB	1.3.6.1.2.1.37459.2.1.9.0	The IP address of the endpoint.
YEALINK-MIB	1.3.6.1.2.1.37459.2.1.10.0	The target version to which the current version is updated automatically. Format: MacVersion[*]ComVersion[*] For example, MacVersion[0.0.0.1]ComVersion[0.0.0.1]
YEALINK-MIB	1.3.6.1.2.1.37459.2.1.11.0	The command of the endpoint reboot. Format: snmpset -v 2c XXXX public 37459.2.1.11.0 s reboot XXXX refers to the IP address of the endpoint.

SNMP parameters on the endpoint are described below:

Parameter	Description	Configuration Method
SNMP->Active	Enables or disables SNMP feature on the endpoint. Default: Disabled Note: If you change this parameter, the endpoint will reboot to make the change take effect.	Web User Interface
Port	Specifies the SNMP port. Valid Values: 1-65535 Default: 161 Note: If you change this parameter, the endpoint will reboot to make the change take effect.	Web User Interface
Trusted Address	Configures IP address(es) or domain name of the trusted SNMP server. Multiple IP addresses or domain names should be separated by spaces. Note: If it is left blank, the endpoint accepts and handles GET requests from any SNMP server. If you change this parameter, the endpoint will reboot to make the change take effect.	Web User Interface

To configure SNMP via web user interface:

1. Click on **Network->Advanced**.
2. In the **SNMP** block, select **Enabled** from the pull-down list of **Active**.
3. Enter the SNMP port in the **Port** field.
4. Enter the IP address or domain name of the SNMP server in the **Trusted Address** field.

Multiple IP addresses or domain names should be separated by spaces.

The screenshot shows the Yealink VC110 Network Configuration interface. The 'Advanced' tab is selected in the left sidebar. The 'SNMP' section is highlighted with a red box, showing the following settings:

Section	Parameter	Value
SNMP	Active	Enabled
	Port	161
	Trusted Address	192.168.10.50 192.168.1.3
QoS	Audio Priority	60
	Video Priority	34
	Data Priority	63
MTU	Video MTU	1500
Web Server	HTTP	Enabled
	HTTP Port	80
	HTTPS	Enabled
	HTTPS Port	443
802.1x	802.1x Mode	Disabled
	Identity	
	MD5 Password	••••••••
	CA Certificates	

Buttons: Browse... Upload

5. Click **Confirm** to accept the change.
A dialog box pops up to prompt that the settings will take effect after a reboot.
6. Click **Confirm** to reboot the endpoint immediately.

Troubleshooting

This chapter provides an administrator with general information for troubleshooting some common problems that he (or she) may encounter while using the VC110 video conferencing endpoint.

Troubleshooting Methods

The endpoint can provide feedback in a variety of forms, such as log files, packets, status indicators and so on, which can help an administrator to find the endpoint problem more easily and resolve it.

The following sections will help you to better understand and resolve the working status of the endpoint.

- [Viewing Log Files](#)
- [Capturing Packets](#)
- [Getting Information from Status Indicators](#)
- [Analyzing Configuration Files](#)
- [Viewing Call Statistics](#)
- [Using Diagnostic Methods](#)

Viewing Log Files

The log files are Yealink specific debug files which may be requested by the Yealink support organization if you need technical support. The current log files are time stamped event log files. You can export the log files to a syslog server or the local endpoint. The administrator can specify the location where the log will be exported to and the severity level of the log.

Endpoint Log Level specifies the log level to be recorded. The default endpoint log level is 6.

Endpoint log level parameters are described below:

Parameter	Description	Configuration Method
Export System Log	<p>Specify where the endpoint log will be exported.</p> <p>Valid values:</p> <ul style="list-style-type: none">• Local-export the endpoint log to the local computer.• Server-export the endpoint log to the specified server.	Web User Interface

Parameter	Description	Configuration Method
	Default: Local	
Server Name	Specify the server address where the log will be exported. Note: It only works if the parameter "Export System Log" is set to Server.	Web User Interface
System Log Level	Specify the endpoint log level. Note: The supported level is 0-9. Higher value indicates more detailed content. Default: 6	Web User Interface

To configure the endpoint log level via web user interface:

1. Click on **Setting**->**Configuration**.
2. Select the desired level from the pull-down list of **Endpoint System Level**.

The screenshot displays the Yealink VC110 Web User Interface. The top navigation bar includes links for About, Language, and Logout. The main menu has tabs for Home, Status, Account, Network, Setting (selected), Directory, and Security. On the left, a sidebar lists various configuration categories: General, Date & Time, Call Features, Video & Audio, Camera, Configuration (selected), Upgrade, Tones, Wireless Micpod, and 3rd-Party VMR. The main content area shows the 'Configuration' page with several settings. At the bottom, the 'System Log Level' is set to 6, which is highlighted by a red rectangular box.

3. Click **Confirm** to accept the change.

To export a log file to the local endpoint via web user interface:

1. Click on **Setting->Configuration**.
2. Mark the **Local** radio box in the **Export System Log** field.

The screenshot shows the Yealink VC110 web interface. The top navigation bar includes links for About, Language, and Logout. The main menu has tabs for Home, Status, Account, Network, Setting (selected), Directory, and Security. On the left, a sidebar lists various configuration categories: General, Date & Time, Call Features, Video & Audio, Camera, Configuration (selected), Upgrade, Tones, Wireless Micpod, and 3rd-Party VMR. The main content area displays the 'Configuration' page. Under the 'Export System Log' section, the 'Local' radio button is selected, and the 'Export' button is visible. Other settings like 'Packet Capture Count' (5) and 'System Log Level' (6) are also shown.

3. Click **Export** to open the file download window, and then save the file to your local endpoint.

The following figure shows a portion of a log file:

```

496 root      8876 SW  /yealink/bin/ggsvca_ipp
497 root      8876 SW  /yealink/bin/ggsvca_ipp
498 root      8876 SW  /yealink/bin/ggsvca_ipp
499 root      8876 SW  /yealink/bin/ggsvca_ipp
500 root      8876 SW  /yealink/bin/ggsvca_ipp
501 root      8876 SW  /yealink/bin/ggsvca_ipp
507 root      16424 SW  /yealink/bin/Screen.exe
508 root      10344 SW  /yealink/bin/sipServer.exe
509 root      10344 SW  /yealink/bin/sipServer.exe
515 root      16424 SW  /yealink/bin/Screen.exe
517 root      16424 SW  /yealink/bin/Screen.exe
519 root      10344 SW  /yealink/bin/sipServer.exe
521 root      16424 SW  /yealink/bin/Screen.exe
522 root      16424 SW  /yealink/bin/Screen.exe
523 root      16424 SW  /yealink/bin/Screen.exe
524 root      10344 SW  /yealink/bin/sipServer.exe
525 root      SW< [IRQ 45]
526 root      10344 SW  /yealink/bin/sipServer.exe
527 root      16424 SW  /yealink/bin/Screen.exe
528 root      16424 SW  /yealink/bin/Screen.exe
529 root      16424 SW  /yealink/bin/Screen.exe
1147 root     1788 SWN  sleep 1000
1227 root     10120 SWN  ConfigManApp.com
1228 root      4624 SW  /yealink/bin/mini_httpd -p 80 -d /yealink/html -c cgi
1229 root      2812 SWN  sh -c cd /tmp;ifconfig >> Messages;ps >> Messages;tar
1230 root      2812 RWN  ps
Feb 29 06:01:09 mini_httpd[388]: mini_httpd.c(1510):child process 1227 exit!
Feb 29 06:01:12 mini_httpd[1232]: mini_httpd.c(1997):path:/cgi-bin/ConfigManApp.com, query:Id=27
Feb 29 06:01:12 mini_httpd[388]: mini_httpd.c(1510):child process 1232 exit!
Feb 29 06:01:12 mini_httpd[1233]: mini_httpd.c(1997):path:/cgi-bin/ConfigManApp.com, query:Id=27
Feb 29 06:01:12 mini_httpd[388]: mini_httpd.c(1510):child process 1233 exit!
Feb 29 06:01:12 mini_httpd[1234]: mini_httpd.c(1997):path:/cgi-bin/ConfigManApp.com, query:Id=27
Feb 29 06:01:12 mini_httpd[388]: mini_httpd.c(1510):child process 1234 exit!

```

To export a log file to a syslog server via web user interface:

1. Click on **Setting->Configuration**.
2. Mark the **Server** radio box in the **Export System Log** field.

- Enter the IP address or domain name of the syslog server in the **Server Name** field.

The screenshot shows the Yealink VC110 web interface. The 'Configuration' menu is selected on the left sidebar. In the main content area, the 'Export System Log' section is highlighted with a red rectangle. It contains two radio buttons: 'Local' (unselected) and 'Server' (selected). To the right of these buttons is an 'Export' button. Below the radio buttons is a text field labeled 'Server Name' with the value '10.3.6.118' entered. Other configuration options visible include 'Import Configuration', 'Export Configuration', 'Pcap Feature' (Start/Stop/Export buttons), 'Packet Capture Count' (5), 'Packet Capture Clip Bytes' (1024), 'Pcap Filter Type' (Custom), and 'Packet Filter String'.

A dialog box pops up to prompt that settings will take effect after a reboot.

- Click **Confirm** to reboot the endpoint immediately.

Capturing Packets

The administrator can capture packets in three ways: capturing the packets via web user interface, remote control or using the Ethernet software. Engineers can analyze the packets to troubleshoot problems.

Packets parameters are described below:



Parameter	Description	Configuration Method
Pcap Feature	Start and stop capturing packets or export the captured packets.	Web User Interface
Packet Capture Count	Configures the count of the number of packets to capture. Default: 5	Web User Interface
Packet Capture Clip Bytes	Configures the number of bytes (in kb) of the packet to capture. Default: 1024	Web User Interface
Pcap Filter Type	Configures the filter type of the packet to capture. Valid Values: <ul style="list-style-type: none"> Custom—Customize the packet 	Web User Interface

Parameter	Description	Configuration Method
	<p>filter string.</p> <ul style="list-style-type: none"> • SIP or H245 or H225—Capture SIP, H245 and H225 packets. • RTP—Capture RTP packets. <p>Default: Custom</p>	
Packet Filter String	<p>Customizes the packet filter string.</p> <p>Syntax:</p> <p>Protocol+Direction+Host(s)+ Value +Logical Operations+Other Expression</p> <p>Protocol:</p> <p>Values: ether, fddi, ip, arp, rarp, decnet, lat, sca, moprc, mopdl, tcp and udp.</p> <p>Application-level protocol, such as http, dns and sip are not supported.</p> <p>If no protocol is specified, all the protocols are used.</p> <p>Direction:</p> <p>Values: src, dst, src and dst, src or dst</p> <p>If no source or destination is specified, the "src or dst" keywords are applied.</p> <p>For example: "host 10.2.2.2" is equivalent to "src or dst host 10.2.2.2".</p> <p>Host(s):</p> <p>Values: net, port, host, portrange.</p> <p>If no host(s) is specified, the "host" keyword is used.</p> <p>For example: "src 10.1.1.1" is equivalent to "src host 10.1.1.1".</p> <p>Logical Operations:</p> <p>Values: not, and, or.</p> <p>Negation ("not") has highest precedence. Alternation ("or") and concatenation ("and") have equal precedence and associate left to right.</p> <p>For example:</p> <p>"not tcp port 3128 and tcp port 23" is equivalent to "(not tcp port 3128) and</p>	Web User Interface

Parameter	Description	Configuration Method
	<p>tcp port 23".</p> <p>"not tcp port 3128 and tcp port 23" is NOT equivalent to "not (tcp port 3128 and tcp port 23)".</p> <p>Example: (src host 10.4.1.12 or src net 10.6.0.0/16) and tcp dst port range 200-10000 and dst net 10.0.0.0/8</p> <p>Displays packets with source IP address 10.4.1.12 or source network 10.6.0.0/16, the result is then concatenated with packets having destination TCP port range from 200 to 10000 and destination IP network 10.0.0.0/8.</p> <p>Default: Blank</p> <p>Note: It only works if the parameter "Pcap Filter Type" is set to Custom.</p>	

To capture packets via the remote control:

Before capturing packets, you need to insert a USB flash drive to the USB port on the VC110 all-in-one unit to store packets. Make sure the USB feature is enabled.

1. Long press  when the endpoint is idle or during a call.
The display device prompts "Onekey-capture is running, press the Backspace key for 2s to turn off it".
2. Long press  for 2 seconds to stop capturing packets.
The packets are saved in the yealink.debug folder on your USB flash driver.

To capture packets via web user interface:

1. Click on **Setting->Configuration**.
2. Enter the desired value in the **Packet Capture Count** field.
3. Enter the desired value in the **Packet Capture Clip Bytes** field.
4. Select the desired value from the pull-down list of **Pcap Filter Type**.
If **Custom** is selected, enter the desired packet filter string in the **Packet Filter String** field.
5. Click **Start** to start capturing signal traffic.
6. Reproduce the issue to get stack traces.
7. Click **Stop** to stop capturing.

8. Click **Export** to open the file download window, and then save the file to your local endpoint.


The screenshot shows the Yealink VC110 web interface. The top navigation bar includes links for About, Language, and Logout. The main menu has tabs for Home, Status, Account, Network, Setting (selected), Directory, and Security. On the left, a sidebar lists various configuration categories: General, Date & Time, Call Features, Video & Audio, Camera, Configuration (selected), Upgrade, Tones, Wireless Micpod, and 3rd-Party VMR. The main content area is divided into sections: Import Configuration (with a file input and Import button), Export Configuration (with an Export button), Pcap Feature (highlighted with a red box, containing Start, Stop, and Export buttons, and input fields for Packet Capture Count: 5, Packet Capture Clip Bytes: 1024, Pcap Filter Type: Custom, and Packet Filter String), Export System Log (with radio buttons for Local and Server, and an Export button), and System Log Level (set to 6).

To capture packets using the Ethernet software:

Connect the Internet ports of the endpoint and the PC to the same HUB, and then use Sniffer, Ethereal or Wireshark software to capture the signal traffic. You can also set mirror port on a switch to monitor the port connected to the endpoint.

Getting Information from Status Indicators

In some instances, status indicators are helpful for finding endpoint troubles. Status indicators may consist of the power LED, icons on the status bar of the display device or prompt messages. The following shows two examples of obtaining the endpoint information from status indicators:

- If a LINK failure of the endpoint is detected, the icon  will appear on the status bar of the display device, indicating the current network is not available.
- If the power LED does not light, it indicates the endpoint is not powered on.

For more information on the icons, refer to [Icon Instructions](#) on page 33.

Analyzing Configuration Files

Wrong configurations may have an impact on your endpoint use. You can export configuration file to check the current configuration of the endpoint and troubleshoot if necessary. For more information on how to export endpoint configuration, refer to [Importing/Exporting Configuration](#) on page 256.

Viewing Call Statistics

You can enter the view call statistics screen during an active call. Information includes:

- **Total Bandwidth:** Uplink Bandwidth and Downlink Bandwidth.
- **Video:** Resolution, Codec, Bandwidth, Frame Rate, Jitter, Total Packet Lost, Packet Lost(%).
- Protocol used during a call.
- Device information of the far site.
- **Audio:** Codec, Bandwidth, Sample Rate, Jitter, Total Packet Lost, Packet Lost(%)
- **Share:** Resolution, Codec, Bandwidth, Frame Rate.



Use the remote control to select **More->Call Statistics** during an active call to view call statistics.

Using Diagnostic Methods




The endpoint supports the following diagnostic methods:

- **Audio Diagnose:** Check whether the audio input device and audio output device are working properly.
- **Camera Diagnose:** Check whether the camera can pan and change focus normally.
- **Ping:** Check whether the endpoint can establish contact with the IP address that you specify.
- **Trace Route:** Display the route (path) and measure transit delays of packets across an Internet Protocol (IP) network.

To diagnose audio via the remote control:



1. Select **Menu->Diagnose** menu.
2. Select **Audio Diagnose**, and then press .
3. Speak into the microphone.
4. Check whether the microphone can pick up audio and play back the audio properly.
If the endpoint plays back the audio normally, it means that audio works well.
5. Press  to stop audio diagnostics.

To diagnose the camera via the remote control:

1. Select **Menu->Diagnose** menu.
2. Select **Camera Diagnose**, and then press .
3. Press navigation keys to adjust the camera position.
4. Press  or  to adjust the focus.
If the camera can move and zoom normally, it means that the camera works properly.



5. Press the **Back** soft key to stop camera diagnose.

To diagnose network via the remote control:

1. Select **Menu**->**Diagnose** menu.
 2. Select **Ping**, and then press .
 3. Enter IP address (for example, the IP address of the far site).
 4. Press **Start**, and then press .
- The display device displays the network diagnose information.
5. Press the **Back** soft key to return to the Diagnose menu.

It measures the round-trip time from transmission to reception and reports errors and packet loss. The results of the test include a statistical summary of the response packets received, including the minimum, maximum, and the mean round-trip times.


Trace Route:

1. Select **Menu**->**Diagnose** menu.
 2. Select **Trace Route**, and then press .
 3. Enter IP address (for example, the IP address of the far site).
 4. Press **Start**, and then press .
- The display device displays the network diagnose information.
5. Press the **Back** soft key to return to the Diagnose menu.

If the test is successful, the VC110 endpoint lists the hops between the endpoint and the IP address you entered. You can check whether congestion happens via the time cost between hops.

To diagnose network via web user interface:

1. Click on **Network** ->**Diagnose**.
2. Select the desired diagnostic method from the pull-down list of **Command**.
3. Enter IP address in the **IP Address** field.



Yealink VC110		About	Language ▼	Logout
Home	Status	Account	Network	Setting Directory Security
LAN Configuration	Diagnose <div> <div>Command</div> <div>Ping ▼</div> </div> <div> <div>IP Address</div> <div>10.3.6.109</div> </div>			

4. Click **Start** to start diagnosing.

The web page displays the diagnosis:

The screenshot shows the Yealink VC110 web interface. The top navigation bar includes links for About, Language, and Logout. Below this is a green header with the Yealink VC110 logo and a menu with Home, Status, Account, Network (selected), Setting, Directory, and Security. On the left, a sidebar menu lists LAN Configuration, NAT/Firewall, Advanced, and Diagnose (selected). The main content area is titled 'Diagnose' and contains a form with 'Command' set to 'Ping' and 'IP Address' set to '10.3.6.109'. Below the form, the command 'PING 10.3.6.109' is executed, showing 14 successful pings. Each line of output shows '64 bytes from 10.3.6.109: seq=[number] ttl=64 time=[time] ms'. At the bottom of the page, there are three buttons: Start, Stop, and Copy.

Command	IP Address
Ping	10.3.6.109

PING 10.3.6.109

PING 10.3.6.109 (10.3.6.109): 56 data bytes

64 bytes from 10.3.6.109: seq=0 ttl=64 time=1.714 ms

64 bytes from 10.3.6.109: seq=1 ttl=64 time=0.490 ms

64 bytes from 10.3.6.109: seq=2 ttl=64 time=0.507 ms

64 bytes from 10.3.6.109: seq=4 ttl=64 time=0.487 ms

64 bytes from 10.3.6.109: seq=6 ttl=64 time=0.530 ms

64 bytes from 10.3.6.109: seq=7 ttl=64 time=0.492 ms

64 bytes from 10.3.6.109: seq=8 ttl=64 time=0.475 ms

64 bytes from 10.3.6.109: seq=5 ttl=64 time=0.493 ms

64 bytes from 10.3.6.109: seq=9 ttl=64 time=0.461 ms

64 bytes from 10.3.6.109: seq=10 ttl=64 time=0.495 ms

64 bytes from 10.3.6.109: seq=11 ttl=64 time=0.485 ms

64 bytes from 10.3.6.109: seq=12 ttl=64 time=0.477 ms

64 bytes from 10.3.6.109: seq=13 ttl=64 time=0.498 ms

Start Stop Copy

5. Click **Stop** to complete diagnosing.

You can click **Copy** to copy the content to the clipboard.

Troubleshooting Solutions

This chapter provides general troubleshooting solutions to help you solve the problems you might encounter when using your endpoint.

Ensure that the endpoint has not been physically damaged when experiencing a problem. Check whether the cables are loose and the connections are correct and secure. These are common causes of problems.

If problems you encounter are not mentioned in this chapter, you can contact your distributor or Yealink FAE.

General Issues

Why is the display device black?

- Check whether the display device is connected properly to the VC110 all-in-one unit.
- Check whether the endpoint is in sleep mode. Press any key on the video conferencing phone or remote control to resume endpoint operation.
- Check whether the display device is in sleep mode or is turned off. Press the power button on the remote control or on the display device.
- Check whether you have selected the correct video input source. You can try to change video input source.

Why doesn't the display device display time and date correctly?

- If you have configured the endpoint to obtain the time and date from the NTP server automatically, ensure that SNTP server and time zone are configured correctly in the endpoint and whether the connection between the endpoint and NTP server is working properly.
- If you have configured the endpoint to obtain the time and date manually, ensure that you have configured the time and date correctly.

Why doesn't the remote control work?

- Check whether the endpoint is powered on.
- Check whether the positive and negative charges of the battery are connected correctly.
- Check whether the battery has sufficient power left.
- Check whether no special fluorescent or neon signs nearby.

Why does the endpoint fail to call the far site?

- Check whether the network of the near site is available.
- Check whether the network of the far site is available.
- Check whether the far site enables the DND feature.
- Check whether the accounts have been registered correctly, and the endpoint uses the appropriate account to call the far site.
- Ensure that the number you are calling is correct.
- Check whether the far site rejects your call.
- Check whether the firewall blocks the inbound traffics from the other site.
- Check whether the far site has already up to maximum call-in limitation.
- If the near site is forced to use encryption, ensure that the far site enables encryption too. For more information on call encryption, refer to [Secure Real-Time Transport Protocol](#) on

page [245](#) and [H.235](#) on page [248](#).

- Ensure that the far site supports the same call protocol as the near site.

Why does the endpoint fail to call the far site via IP address?

- Ensure that at least one call protocol is enabled on both sites. For more information, refer to [Configuring SIP Settings](#) on page [132](#) and [Configuring H.323 Settings](#) on page [136](#).
- Ensure that the network is connected correctly.
- Ensure that the network is configured correctly. For more information, refer to [Configuring LAN Properties](#) on page [56](#).
- Ping the IP address of the far site. Contact your system administrator if it fails. For more information, refer to [Using Diagnostic Methods](#) on page [270](#).

Why doesn't the status bar of the display device display IP address?

- Check whether the network is available.
- Check whether the LAN property is configured correctly. For more information on LAN property configuration, refer to [Configuring LAN Properties](#) on page [56](#).
- Check whether the endpoint has enabled the hide IP address feature. For more information on disabling the hide IP address feature, refer to [Hide IP Address](#) on page [175](#).
- Check whether the endpoint has configured firewall and NAT correctly. For more information on, refer to [Configuring the Endpoint for Use with a Firewall or NAT](#) on page [86](#).

Why does the network keep losing packets?

- Check whether the network is available and the LED indicator on the left of the Internet port illuminates green.
- Try to use the low speed connection to check whether packets are lost. Deficient bandwidth is an important reason for packet loss.
- Check the configuration of the network speed and duplex mode on the endpoint, switch and router.

Camera Issues

Why can't I adjust the camera angle and focus?

- You can adjust the camera when the endpoint is idle or during a call. The camera cannot be adjusted when the endpoint is in the menu screen.
- Ensure that the batteries in the remote control are in good working condition, and installed correctly.
- Aim the remote control at the sensor when operating the unit.

- Ensure that no objects are obstructing the sensor on the front of the camera.
- Ensure that the LED on the front of the camera flashes green when you use the remote control to operate the unit.
- Ensure that what you are controlling is the local camera.
- Reboot the endpoint.
- If the above suggestions cannot solve your problem, perhaps the remote control is broken. You can contact your endpoint administrator for help.

Why can't adjust the remote camera during an active call?

- Use the remote control to control the local camera to check whether the remote control can be used normally.
- Ensure that the far site has enabled the far-end camera control feature. For more information, refer to [Far-end Camera Control](#) on page 201.
- Ensure that what you are controlling is the remote camera. Select **More->Near/Far Camera** during an active call and then select the remote video image.
- Ensure that the far site supports the same call protocol as the near site. For more information, refer to [Camera Control Protocol](#) on page 202.

Why is the video quality bad?

- Ensure that the display device has suitable resolution.
- Check whether the packet has been lost. For more information on packet loss, refer to [Viewing Call Statistics](#) on page 270.
- Ensure that camera settings are configured correctly, such as brightness and white balance.
- Avoid high-intensity indoor light or direct sunlight on the camera.

Video & Audio Issues

Why can't I hear the audio during a call?

- Ensure that the local audio output device is connected correctly.
- Use audio diagnose to check whether the audio device is working normally.
- Ensure that the ringer volume is not set to the minimum.
- Check whether the far site is muted.

Why can't the far site hear the local audio?

- Ensure that the local audio input device is connected correctly.
- Check whether the near site is muted.
- Check whether the endpoint has enabled the auto answer mute feature.

- Check whether the endpoint has enabled the auto dialout mute feature.

Why can't I hear the other site clearly during a call?

- Ensure that the speaker volume of the far site is not set too low.
- Muffled audio reception from the far side may be caused by highly reverberant rooms. Speak in close proximity to the phone.
- Adjust the priority order for your audio codec if you have chosen a low-bandwidth audio codec to be first. For more information, refer to [Audio Codecs](#) on page 147.
- Dust and debris may cause audio quality. Do not use any kind of liquid or aerosol cleaner on the phone. A soft, slightly damp cloth should be sufficient to clean the top surface of the phone if necessary.

Why is the voice quality poor?

Users may receive poor voice quality during a call, such as intermittent voice, low volume, echo or other noise. It is difficult to diagnosis the root causes of the voice anomalies. The possible reasons are:

- Users sit too far from or near to the microphone.
- The audio pickup device is moved frequently.
- Intermittent voice is probably caused by voice packet loss or jitter. Voice packet loss may occur due to network congestion. Jitter may occur due to information reorganization of the transmission or receiving equipment, such as, delay processing, retransmission mechanism or buffer overflow.
- Noise devices, such as computers or fans, may make it difficult to hear each other's voices clearly.
- Wires may also cause this problem. Replace the old with the new cables, and then reconnect to check whether the new cables provide better connectivity.

Why can't I view the local video image?

- Check whether the near site camera is connected to the VC110 all-in-one unit correctly.
- Check whether camera is powered on, and the LED indicator illuminates green.
- Check whether the camera is selected for the current video input source.
- Check the screen layout to see whether the remote video image is shown in full size.

Why can't I view the menu?

- Check whether the Display1 port of VC110 all-in-one unit is connected to the HDMI port on the display device.

Why can't I start presentation?

- Check whether a PC is connected to the VC110 all-in-one unit.
- Check whether the PC is sending a signal.
- Check the call statistics to see whether the endpoint is sharing content.
- Ensure that dual-stream is configured correctly. For more information, refer to [Dual-Stream Protocol](#) on page 191.

Why does the far-site display black screen when local starts a presentation?

This situation may due to the difference between Signaling Server address and the Media Server address.

The actual address is different from the negotiated address, so that start a presentation in this situation will result in the failure of sending packets to the correct address. You can disable the network adaptive feature, so that the endpoint will send packets to the negotiated address other than the actual address.

Network address adapter parameter is described below:

Parameter	Description	Configuration Method
Network address adapter	<p>Enable or disable the network address adapter feature.</p> <p>Valid values:</p> <ul style="list-style-type: none"> • Enabled-send packets to the actual address. • Disabled- send packets to the negotiated address other than the actual address. <p>Default: Enabled</p>	Web User Interface

To configure the network address adapter via web user interface:

1. Click on **Setting**->**Call Features**.

2. Select the desired level from the pull-down list of **Network Address Adapter**.

The screenshot shows the Yealink VC110 web interface. The top navigation bar includes links for About, Language, and Logout. Below this is a green header with the Yealink VC110 logo and tabs for Home, Status, Account, Network, Setting (selected), Directory, and Security. On the left, a sidebar lists various settings categories: General, Date & Time, Call Features (highlighted), Video & Audio, Camera, Configuration, Upgrade, Tones, Wireless Micpod, and 3rd-Party VMR. The main content area displays a list of settings with their current values in dropdown menus. The 'Network Address Adapter' setting at the bottom is highlighted with a red rectangle and is set to 'Enabled'. At the bottom of the interface are 'Confirm' and 'Cancel' buttons.

Setting	Value
Auto Answer	Enabled
Auto Answer Mute	Enabled
Auto Answer Multiway	Disabled
Auto Dialout Mute	Disabled
Call Match	Enabled
History Record	Enabled
Call Protocol	Auto
Uplink Bandwidth	Auto
Downlink Bandwidth	Auto
Abnormal Call Answering	IP Call Answer
Safe Mode Call	Enabled
Ringback Timeout(30-240)	200
Auto Refuse Timeout(30-240)	120
SIP IP Call by Proxy	Off
Default Layout of Single Screen	Remote Full screen
Network Address Adapter	Enabled

3. Click **Confirm** to accept the change.

Endpoint Maintenance

How to prevent monitor burn-in?

Refer to your monitor's documentation for specific recommendations and instructions. The following guidelines help prevent image burn-in:

- Ensure that static images are not displayed for long periods.
- Be aware that meetings that last more than an hour without much movement can have the same effect as a static image.
- Configure the automatic sleep time to be 1 hours or less.
- Consider decreasing the monitor's sharpness, brightness, and contrast settings if they are set to their maximum values.


How to reboot the endpoint?

When you do one of the following, the endpoint will reboot:

- Reboot endpoint
- Reset endpoint

- Upgrade firmware
- Configure some features need to take effect after a reboot

You can reboot the endpoint in the following ways:

- Select **Menu->Advanced** (default password: 0000) ->**Reboot & Reset->Reboot**, and then press  .
- Log into web user interface and click on **Setting->Upgrade->Reboot**, and then click **Confirm**.

Why does the endpoint fail to upgrade?

- Ensure that the firmware is different from the firmware currently in use.
- Ensure that the downloaded firmware applies to the endpoint.
- Ensure that the endpoint is powered on normally, and the network is available during the upgrade process.
- When upgrading firmware via web user interface, ensure that the web user interface is not refreshed or closed during the upgrade process.

Appendix

Appendix A: Time Zones

Time Zone	Time Zone Name
-11:00	Samoa
-10:00	United States-Hawaii-Aleutian
-10:00	United States-Alaska-Aleutian
-09:30	French Polynesia
-09:00	United States-Alaska Time
-08:00	Canada(Vancouver, Whitehorse)
-08:00	Mexico(Tijuana, Mexicali)
-08:00	United States-Pacific Time
-07:00	Canada(Edmonton, Calgary)
-07:00	Mexico(Mazatlan, Chihuahua)
-07:00	United States-Mountain Time
-07:00	United States-MST no DST
-06:00	Canada-Manitoba(Winnipeg)
-06:00	Chile(Easter Islands)
-06:00	Mexico(Mexico City, Acapulco)
-06:00	United States-Central Time
-05:00	Bahamas(Nassau)
-05:00	Canada(Montreal, Ottawa, Quebec)
-05:00	Cuba(Havana)
-05:00	United States-Eastern Time
-04:30	Venezuela(Caracas)
-04:00	Canada(Halifax, Saint John)
-04:00	Chile(Santiago)
-04:00	Paraguay(Asuncion)
-04:00	United Kingdom-Bermuda(Bermuda)
-04:00	United Kingdom(Falkland Islands)
-04:00	Trinidad&Tobago
-03:30	Canada-New Foundland(St.Johns)
-03:00	Denmark-Greenland(Nuuk)
-03:00	Argentina(Buenos Aires)
-03:00	Brazil(no DST)
-03:00	Brazil(DST)
-02:30	Newfoundland and Labrador
-02:00	Brazil(no DST)
-01:00	Portugal(Azores)

Time Zone	Time Zone Name
0	GMT
0	Greenland
0	Denmark-Faroe Islands(Torshavn)
0	Ireland(Dublin)
0	Portugal(Lisboa, Porto, Funchal)
0	Spain-Canary Islands(Las Palmas)
0	United Kingdom(London)
0	Morocco
+01:00	Albania(Tirane)
+01:00	Austria(Vienna)
+01:00	Belgium(Brussels)
+01:00	Caicos
+01:00	Chad
+01:00	Spain(Madrid)
+01:00	Croatia(Zagreb)
+01:00	Czech Republic(Prague)
+01:00	Denmark(Kopenhagen)
+01:00	France(Paris)
+01:00	Germany(Berlin)
+01:00	Hungary(Budapest)
+01:00	Italy(Rome)
+01:00	Luxembourg(Luxembourg)
+01:00	Macedonia(Skopje)
+01:00	Netherlands(Amsterdam)
+01:00	Namibia(Windhoek)
+01:00	Poland (Warsaw)
+02:00	Estonia(Tallinn)
+02:00	Finland(Helsinki)
+02:00	Gaza Strip(Gaza)
+02:00	Greece(Athens)
+02:00	Israel(Tel Aviv)
+02:00	Jordan(Amman)
+02:00	Latvia(Riga)
+02:00	Lebanon(Beirut)
+02:00	Moldova(Kishinev)
+02:00	Russia(Kaliningrad)
+02:00	Romania(Bucharest)
+02:00	Syria(Damascus)
+02:00	Turkey(Ankara)
+02:00	Ukraine(Kyiv, Odessa)
+03:00	East Africa Time

Time Zone	Time Zone Name
+03:00	Iraq(Baghdad)
+03:00	Russia(Moscow)
+03:30	Iran(Teheran)
+04:00	Armenia(Yerevan)
+04:00	Azerbaijan(Baku)
+04:00	Georgia(Tbilisi)
+04:00	Kazakhstan(Aktau)
+04:00	Russia(Samara)
+04:30	Afghanistan(Kabul)
+05:00	Kazakhstan(Aqtobe)
+05:00	Kyrgyzstan(Bishkek)
+05:00	Pakistan(Islamabad)
+05:00	Russia(Chelyabinsk)
+05:30	India(Calcutta)
+05:45	Nepal(Katmandu)
+06:00	Kazakhstan(Astana, Almaty)
+06:00	Russia(Novosibirsk, Omsk)
+06:30	Myanmar(Naypyitaw)
+07:00	Russia(Krasnoyarsk)
+07:00	Thailand(Bangkok)
+08:00	China(Beijing)
+08:00	Singapore(Singapore)
+08:00	Australia(Perth)
+08:00	Russia(Irkutsk, Ulan-Ude)
+08:45	Eucla
+09:00	Korea(Seoul)
+09:00	Japan(Tokyo)
+09:00	Russia(Yakutsk, Chita)
+09:30	Australia(Adelaide)
+09:30	Australia(Darwin)
+10:00	Australia(Sydney, Melbourne, Canberra)
+10:00	Australia(Brisbane)
+10:00	Australia(Hobart)
+10:00	Russia(Vladivostok)
+10:30	Australia(Lord Howe Islands)
+11:00	New Caledonia(Noumea)
+11:00	Russia(Srednekolymsk Time)
+11:30	Norfolk Island
+12:00	New Zealand(Wellington, Auckland)
+12:00	Russia(Kamchatka Time)
+12:45	New Zealand(Chatham Islands)

Time Zone	Time Zone Name
+13:00	Tonga(Nukualofa)
+13:30	Chatham Islands
+14:00	Kiribati

Appendix B: Trusted Certificates

Yealink video conferencing endpoint trusts the following CAs by default:

- DigiCert High Assurance EV Root CA
- Deutsche Telekom AG Root CA-2
- Equifax Secure Certificate Authority
- Equifax Secure eBusiness CA-1
- Equifax Secure Global eBusiness CA-1
- GeoTrust Global CA
- GeoTrust Global CA2
- GeoTrust Primary CA
- GeoTrust Primary CA G2 ECC
- GeoTrust Universal CA
- GeoTrust Universal CA2
- Thawte Personal Freemail CA
- Thawte Premium Server CA
- Thawte Primary Root CA - G1 (EV)
- Thawte Primary Root CA - G2 (ECC)
- Thawte Primary Root CA - G3 (SHA256)
- Thawte Server CA
- VeriSign Class 1 Public Primary Certification Authority
- VeriSign Class 1 Public Primary Certification Authority - G2
- VeriSign Class 1 Public Primary Certification Authority - G3
- VeriSign Class 2 Public Primary Certification Authority - G2
- VeriSign Class 2 Public Primary Certification Authority - G3
- VeriSign Class 3 Public Primary Certification Authority
- VeriSign Class 3 Public Primary Certification Authority - G2
- VeriSign Class 3 Public Primary Certification Authority - G3
- VeriSign Class 3 Public Primary Certification Authority - G4
- VeriSign Class 3 Public Primary Certification Authority - G5
- VeriSign Class 4 Public Primary Certification Authority - G2
- VeriSign Class 4 Public Primary Certification Authority - G3

- VeriSign Universal Root Certification Authority
- ROOT CA
- IntermediateCA
- ssl_certificate

Note

Yealink endeavors to maintain a built-in list of most common used CA Certificates. Due to memory constraints, we cannot ensure a complete set of certificates. If you are using a certificate from a commercial Certificate Authority not in the list above, you can send a request to your local distributor. At this point, you can upload your particular CA certificate into your phone. For more information on uploading custom CA certificate, refer to [Transport Layer Security](#) on page 237.

Index

Numeric

802.1x Authentication [77](#)

A

Abnormal Call Answering [251](#)
 About This Guide [v](#)
 Account Polling [139](#)
 Adjusting MTU of Video Packets [189](#)
 Administrator Password [234](#)
 Analyzing Configuration Files [269](#)
 Appendix A: Time Zones [281](#)
 Appendix B: Trusted Certificates [284](#)
 Attack Defense in Public Network [251](#)
 Audio Input Device [186](#)
 Audio Output Device [184](#)
 Auto Answer [153](#)
 Auto Dialout Mute [155](#)
 Automatic Sleep Time [174](#)
 Auto Refuse Timeout [160](#)

B

Backlight of the Video Conferencing Phone [166](#)
 Bandwidth [158](#)

C

Call History [226](#)
 Call Match [155](#)
 Call Protocol [150](#)
 Camera Control Protocol [202](#)
 Camera Issues [274](#)
 Codecs [147](#)
 Configuring Call Preferences [111](#)
 Configuring Camera Settings [197](#)
 Configuring Cloud Settings [111](#)
 Configuring Endpoint Settings [165](#)
 Configuring H.323 Setting [135](#)
 Configuring LAN Properties [56](#)

Configuring Network [55](#)
 Configuring Network Settings Manually [61](#)
 Configuring Network Speed and Duplex Mode [68](#)
 Configuring Packets [266](#)
 Configuring Safe Mode Call [252](#)
 Configuring Security Features [233](#)
 Configuring SIP Settings [111](#)
 Configuring the Endpoint for Use with a Firewall or NAT [86](#)
 Configuring the Third-party Virtual Meeting Room [128](#)
 CPE80 Expansion Microphone [27](#)

D

Date and Time [168](#)
 Default Layout of Single Screen [162](#)
 DHCP [56](#)
 Directory [217](#)
 Documentations [v](#)
 Do Not Disturb [152](#)
 DTMF [139](#)
 Dual Screen [229](#)
 Dual-Stream Protocol [191](#)

E

Enabling Communication with Other Endpoints [49](#)
 Endpoint Component Instructions [8](#)
 Endpoint Connection and Installation [41](#)
 Endpoint Maintenance [278](#)
 Endpoint Startup [48](#)

F

Far-end Camera Control [201](#)
 Firmware [v](#)

G

General Issues [273](#)
Getting Information from Status Indicators [269](#)
Getting Started [41](#)

H

H.235 [248](#)
H.323 Tunneling [82](#)
H.460 Firewall Traversal [101](#)
Hide IP Address [175](#)
Hiding Icons in a Call [178](#)
History Record [157](#)

I

Icon on Display Device [33](#)
Icon on Video Conferencing Phone [35](#)
Importing/Exporting Configuration [256](#)
Index [287](#)
Intelligent Firewall Traversal [102](#)
In This Guide [vi](#)
IPv6 Support [64](#)

K

Keep Alive [97](#)
Keyboard Input Method [183](#)
Key Tone [177](#)

L

Language [167](#)
LDAP [221](#)
LED Instructions [36](#)
LLDP [71](#)
Logging into the BlueJeans Cloud Platform [121](#)
Logging into the Mind Platform [124](#)
Logging into the StarLeaf Cloud Platform [115](#)
Logging into the Yealink Cloud Platform [111](#)
Logging into the Zoom Cloud Platform [116](#)

M

Manual Configuration for VLAN [74](#)

Meeting Blacklist [178](#)
Methods of Transmitting DTMF Digit [142](#)
Mix Sending [191](#)

N

Network Address Translation [89](#)

O

Output Resolution [208](#)

P

Packaging Contents [3](#)
Physical Features of Endpoint [2](#)
Placing a Test Call from the Yealink Video Conferencing Endpoint [54](#)
Powering the Endpoint On and Off [46](#)
Preparing the Network [55](#)

Q

Quality of Service [103](#)

R

Reboot Offtime [176](#)
Remote Control [39](#)
Remote Control via Web User Interface [40](#)
Registering a Custom Account [126](#)
Registering a Pexip Account [119](#)
Reserved Ports [87](#)
Resetting to Factory [257](#)
Ringback Timeout [159](#)
Rport [99](#)

S

Screenshot [211](#)
Search Source List in Dialing [228](#)
Secure Real-Time Transport Protocol [245](#)
Setup Wizard [49](#)
SIP IP Call by Proxy [161](#)
Site Name [165](#)
SNMP [258](#)

Static DNS [59](#)
STUN [93](#)
Summary of Changes [vi](#)

T

Table of Contents [ix](#)
Tones [213](#)
Transport Layer Security [237](#)
Troubleshooting [263](#)
Troubleshooting Methods [263](#)
Troubleshooting Solutions [272](#)

U

Upgrading Firmware [255](#)
USB Configuration [209](#)
User Interfaces [38](#)
User Mode [233](#)
Using Diagnostic Methods [270](#)

V

VC110 All-in-One Unit [8](#)
VC110 Video Conferencing Endpoint Introduction
[1](#)
VCM30 Video Conferencing Microphone Array [22](#)
VCM60 Video Conferencing Wireless Microphone
[12](#)
VCR10 Remote Control [31](#)
Video & Audio Issues [275](#)
Video Conferencing Phone [22](#)
Video Recording [209](#)
Video Size Mode [159](#)
Viewing Call Statistics [270](#)
Viewing Log Files [263](#)
VLAN [70](#)
VoIP Principles [1](#)
VPN [106](#)

W

Web Server Type [235](#)
Web User Interface [38](#)