

Wall Mount Quick Installation Guide for SIP-T21(P) E2/T23G IP Phones (V1.0)

This quick installation guide provides step-by-step instructions for mounting your IP phone to a wall.

This guide applies to the following phone's wall mount installation:

- SIP-T21(P) E2 IP Phone
- SIP-T23G IP Phone

The stand is required for wall mount installation, which is included with your IP phone.

Screws, wall anchors and applicable tools are also required for wall mount installation. These are not included with your IP phones. You need to purchase them separately.


Adjusting the Hookswitch Tab

The IP phone is packaged with the hookswitch tab in desk mount position. Before mounting the IP phone to a wall, you must set the hookswitch tab to wall mount position.

To adjust the hookswitch tab:

1. Pull the hookswitch tab in the handset cradle.
2. Rotate the hookswitch tab 180 degrees.
3. Reinsert the hookswitch tab.

Adjust the hookswitch tab as shown below:



The hookswitch tab has a lip which allows the handset to stay on-hook when the IP phone is mounted vertically.

Adjusting the Stand


SIP-T21(P) E2 and SIP-T23G IP phones are mounted to the wall via the stand which consists of the reversible bracket and the base, as shown below:



To adjust the stand

- 1. Detach the reversible bracket from the stand.
- 2. Rotate the reversible bracket 180 degrees.
- 3. Attach the reversible bracket to the base.


Adjust the stand as shown below:



Attaching the Stand to the IP Phone


To attach the stand to the IP phone

1. Insert the stand into the slots on the back of IP phone. And then slide the stand up.




Mounting the Wall Mount Bracket

Yealink provides two kinds of the wall mount drilling templates, which locate and mark the position for mounting the screws (not provided) on the wall, as shown below:



You can also download the wall mount drilling template online:
<http://support.yealink.com/>.

Following the drilling template above, you can mount the IP phone to the wall, as shown below:



About us

Founded in 2001, Yealink, the global TOP 3 SIP phone provider and a leading provider of VoIP Phone and IP communication solutions, has been focusing on VoIP products characterized by reliable quality, easy deployment and affordable price for more than a decade. Today, customers from over 140 countries rely on Yealink as the backbone of global collaboration to extend the value of network communications.

More about Yealink

Since 2001, Yealink has continued to develop state-of-the art, hi-tech VoIP communication terminals that include IP video phones, IP phones and USB phones. With a worldwide market in more than 140 countries, the company has also established a first-class international service network.

Our priorities are quality, functionality, ease-of-use, customer support and competitive pricing. To provide new solutions for the future in this fast-evolving sector, Yealink's large, talented and highly-experienced VoIP R&D team is totally committed to the pursuit of excellence.

To date, we have passed more than 80 interoperability tests and meet certification requirements set by leading VoIP system and platforms. Yealink works in close partnership with T-Mobile, Telefonica, Portugal Telecom and other leading telecommunication service providers.

