


How to Make Ringtone for Yealink SIP-T2XP Phones

1. You could install the tool of **Cooledit** to make the ringtone you like.


[Note]:

- a. The ringtone which you update must less than 100k in total;
- b. The parameter of ringtone is "Sample Rate: 8000 & Channels: Mono & Resolution: 16-bit";
- c. The ringtone format is "A/mu-Law Wave(*.wav)"


2. Open the ring file by Cooledit.




3. After choosing the ring, then press  key to listen to the ring.



4. Select the segment of ringtone you chosen and copy it to the new created file.
4a: select the segment of ringtone(**Ctrl + C**)




4b: Create a new file via File→New.




4c: Paste it to the new created file (Ctrl + V).


[Note]: The ringtone format as picture:




5. Save the ringtone via **File→Save As..**
Note: please choose the save type as "A/mu-Law Wave(*.wav)".




6. Open your phone's **webpage**→**Phone**→**Preference**.
Note: the ringtone must be less than 100k in total.




7. Choose the ringtone you saved.





8. Choose the ringtone 121.wav as the default ringtone of incoming calls.



9. Press **confirm** to complete the settings.

