




T46G-Skype for Business[®] Edition



Quick Start Guide (V8.60)

Packaging Contents

The following items are included in your package. If you find anything missing, contact your system administrator.



Skype for Business Phone




Handset




Handset Cord




Quick Start Guide




Ethernet Cable
(2m CAT5E FTP Cable)



Stand



Power Adapter
(Optional)







Wall Mount Bracket
(Optional)

Note: We recommend that you use the accessories provided or approved by Yealink. The use of unapproved third-party accessories may result in reduced performance.

Assembling the Phone



1. Attach the stand, as shown below:



Desk Mount Method

Note: You can also mount the phone to a wall. For more information on how to attach the wall mount bracket, refer to Yealink Wall Mount Quick Installation Guide for SIP-T29 T27 T46 T48 IP Phones.

2. Connect the handset and optional headset, as shown below:




Note: The headset or wireless headset adapter EHS36 should be purchased separately.

The EXT port can also be used to connect the expansion module EXP40. For more information on how to use the EHS36 and EXP40, refer to Yealink EHS36 User Guide and Yealink T46G-Skype for Business Edition User Guide.

3. Connect the optional Bluetooth USB Dongle, as shown below:


You can connect a Bluetooth USB dongle to your phones for connecting a Bluetooth headset.



Note: The Bluetooth USB dongle BT40 should be purchased separately.
For more information on how to use the BT40, refer to Yealink Bluetooth USB Dongle BT40 User Guide.

4. Connect the network and power, as shown below:


You have two options for network and power connections. Your system administrator will advise you which one to use.



Note: The Skype for Business phone should be used with Yealink original power adapter (5V/2A) only. The use of the third-party power adapter may cause the damage to the phone. If you are connecting a PC to your phone, we recommend that you use the Ethernet cable provided by Yealink.
If inline power (PoE) is provided, you don't need to connect the power adapter. Make sure the hub/switch is PoE-compliant.



Startup

After the Skype for Business phone is connected to the network and supplied with power, it automatically begins the initialization process. After startup, the sign-in screen appears on the phone LED screen. Refer to **Sign-in** on page 3 to sign into the Skype for Business Server.



Sign-in




The sign-in screen displays after initializing. You can sign into Skype for Business Server using following method.

1. Press the **Sign in** soft key to enter the sign-in screen.
2. Press  ,  or the **Switch** soft key to select the desired sign-in method.
 - a. If you select **PIN Authentication** (Only applicable to Onprem account):
 - 1) Enter the extension and extension PIN in the corresponding field.
 - 2) Press the **Sign in** soft key.
 - b. If you select **User Sign-in** (Applicable to Onprem account and Online account):
 - 1) Enter the user's sign-in address, user name and password in the corresponding field.
 - 2) Press the **Sign in** soft key.
 - c. If you select **Web Sign-in** (Only applicable to Online account):
 - 1) Press the **Sign in** soft key, the LCD screen will show the pairing code and URL.
 - 2) Enter the URL in the address bar of the web browser on your computer, and then press **Enter**.
 - 3) Enter your email address to check its validity. If your email address passes validation, enter your Online account and password, and then enter the pairing code to pair with the phone. The phone will sign into the Skype for Business Server automatically.

If the Skype for Business Server is configured to forcibly lock the phone. You need to configure an unlock PIN at the initial sign-in.




Note: Make sure the network connection is correct before login. By default, the phone attempts to contact a DHCP server in your network to obtain its valid network settings. Contact your system administrator for more information.

To sign out of the Skype for Business Server:

1. Press  when the phone is idle.
2. Press  or  to select **Sign Out**.






Update Presence Status

Your presence status displays your availability and activity to your contacts. It is constantly updated by the Skype for Business Server. You can also update your presence status manually.

1. Press  when the phone is idle.
2. Press  or  to select the desired presence status.

You can select **Reset Status** to reset the presence status to "Available".

Presence Status Icons on the LCD Screen:

- | | | |
|--|--|---|
|  (Green)Available |  (Red) Busy |  (Red and white) DND |
|  (Grey) Off Line |  (Yellow) Be Right Back\Off Work\Away | |

Note: Contact your system administrator if any error appears during the sign-in process or if a specific configuration is required.


Basic Call Features

Placing a Call

Using the handset:

1. Pick up the handset.
2. Enter the number, and then press the **Call** soft key.

Using the speakerphone:



1. With the handset on-hook, press .
2. Enter the number, and then press the **Call** soft key.

Using the headset:

1. With the headset connected, press  to activate the headset mode.
2. Enter the number, and then press the **Call** soft key.


Note: During a call, you can alternate between the headset, hands-free speakerphone and handset modes by pressing the HEADSET key, the Speakerphone key or by picking up the handset. Headset mode requires a connected headset.

Answering a Call


- If you are using the handset, pick up the handset.
- If you are using the speakerphone, press .
- If you are using the headset, press .

Note: You can reject an incoming call by pressing **More->Reject**.



Ending a Call

- If you are using the handset, hang up the handset or press the **EndCall** soft key.
- If you are using the speakerphone, press  or press the **EndCall** soft key.
- If you are using the headset, press the **EndCall** soft key.

Redial

- Press  when the phone is idle to dial out the last dialed number.

Call Mute and Un-mute




- Press  to mute the microphone during a call.
- Press  again to un-mute the call.

Call Hold and Resume

To place a call on hold:

1. Press  or press the Hold soft key during an active call. The first line key LED slowly flashes green.



To resume the call, do one of the following:

- If there is only one call on hold, press  or press the **Resume** soft key.
- If there is more than one call on hold, press  or  to select the call you want to resume, and then press or the **Resume** soft key.





Call Transfer

You can transfer a call in the following ways:

Blind Transfer:


1. Press  or press the **Transfer** soft key during an active call. The call is placed on hold.
2. Enter the number you want to transfer to.
3. Press  or press the **Transfer** soft key.

Consultative Transfer:

1. Press  or press the **Transfer** soft key during an active call. The call is placed on hold.
2. Enter the number you want to transfer to, then press  or .
3. Press  or press the **Transfer** soft key when the second party answers.

Call Forward

To enable call forward:

1. When the phone is idle, press ******* -> **Features**-> **Call Forward**, or you can also press  to enter the call forward setting screen.
2. Do one of the following:
 - a. Select **Forward to Voice Mail**.
Incoming calls will be forwarded to voice mail automatically.
 - b. Select **Forward Calls to Number or Contact**.
Enter the desired number or press the **Directory** soft key to select the desired contact.
Incoming calls will be forwarded to the preset number automatically.
 - c. Select **Simultaneously Ring**.
Enter the desired number or press the **Directory** soft key to select the desired contact.
The preset number will ring simultaneously when the phone receives an incoming call.
3. Press the **Save** soft key to accept the change.

To disable call forward:

1. When the phone is idle, press ******* -> **Features**-> **Call Forward**., or you can also press  to enter the call forward setting screen.
2. Select **Forward off**.
3. Press the **Save** soft key to accept the change.

To forward an incoming call to a number dynamically:

1. Press the **FWD** soft key when the phone receives an incoming call.
2. Do one of the following:
 - Enter the number you want to forward the incoming call to, and then press the **Call** soft key.
 - Press the **Directory** soft key to select the desired contact from the contact list, and then press the **FWD** soft key.



To forward an incoming call to the voice mail dynamically:

1. Press **More**-> **FWD VM** to forward an incoming call to voice mail directly.

Skype for Business Conference

To initiate a Skype for Business conference call from the phone:

1. Press ******* -> **Meet Now** to initiate a Skype for Business conference call directly.
2. Press the **Add** soft key to invite a new party.

3. Enter the number of the new party, and then press  ,  or the **Call** soft key.



The new party answers the call to join the conference automatically.

4. Repeat the steps 2-3 to add more parties to the conference.
5. During the Skype for Business conference, you can hold the conference, view the conference participants, mute or unmute the participants, promote or demote conference participants, remove conference participants, enable or disable the announcement, lock or unlock the conference and view the dial-in number and conference ID.

Voice Mail

When receiving a new voice mail, the phone will play a warning tone, and the power LED will slowly flash red. A number icon (indicating the number of voice mails you haven't retrieved) appears on the top-right of the **Message** menu.

When you sign into the phone using User Sign-in/Web Sign-in/Sign in via PC method:

1. Press **...** -> **Message**.
2. Press  or  to select the desired voice mail, you can do one of the following:
 - Press the **Message** soft key to enter the Message Center.
 - Press the **Play** soft key to listen to the selected voice mail.
 - Press the **Detail** soft key to view the detailed information about the voice mail.
 - Press the **Mark as Read** soft key to mark the unread voice mail as read.
 - Press the **Delete** soft key to delete the voice mail.
 - Press the **Call** soft key to redial the one who leaves the voice mail.




When you sign into the phone using PIN Authentication method:

1. Press **...** -> **Message**.
2. Follow the voice prompts to listen to your voice mails.

Note: You can following the voice prompts to listen to the voice mail by pressing  .

Phone Features

Call History

1. Press  when the phone is idle, press  or  to select the desired list.
2. Select an entry from the list, you can do one of the following:
 - Press the **Call** soft key to place a call.
 - Press the **Delete** soft key to delete the entry from the list.
 - Press the **Detail** soft key to view the detailed information about the entry.

Directory

The directory list displays Skype for Business directory and local directory. You can only manage Skype for Business directory through the Skype for Business client and manage the local directory on the phone.

Skype for Business Directory

To add a Skype for Business contact:


1. Open your Skype for Business client, and then enter the number of the desired contact in the **Search** field.
2. Right-click the avatar of a contact, and then click **Add to Contacts List**.
3. Click the desired group.

The contact is added to the selected group.


If you want to add the Skype for Business contacts as favorites, do the following:

1. Right-click the avatar of a contact.

2. Click **Add to Favorites**.


The contact will be added to the phone at the path:  -> **Favorites**.

To search for contacts in the Skype for Business directory:




1. Press .
2. Press the **Search** soft key.
3. Enter the first few continuous characters of the contact name or the contact number (e.g., press the digit key 5 to search the letter "5, j, k and l"). The Skype for Business contacts whose name or phone number matches the characters entered will appear on the LCD screen.

Local Directory




To add a local contact:

1. Press  -> **Local Directory**-> **All Contact**.
2. Press the **Add** soft key to add a contact.
3. Enter a unique contact name in the **Name** field and other information in the corresponding fields.
4. Press the **Save** soft key to accept the change.

To edit a local contact:

1. Press  -> **Local Directory**-> **All Contact**.
2. Press  or  to highlight the desired contact.
3. Press the **Option** soft key, and then select **Detail**.
4. Edit the contact's information.
5. Press the **Save** soft key to accept the change.

To delete a local contact:





1. Press  -> **Local Directory**-> **All Contacts**.
2. Press  or  to highlight the desired contact.
3. Press the **Option** soft key, and then select **Delete**.
4. Press the **OK** soft key when the LCD screen prompts "Delete selected item?".

Note: You can also delete all contacts by pressing the **Option** soft key, and then select **Delete All**.



Local Favorites

Local favorites are the contacts in your local directory that you call most often.

To add a local favorite via phone user interface:

1. Press  -> **Local Directory**-> **Favorites**.
2. Press the **Add** soft key.
3. Enter a unique contact name in the **Name** field and other information in the corresponding fields.
4. Press ,  or the **Switch** soft key to select the index number from the **Index** field.
Local favorites display consecutively, according to their index number. The contact with the lowest index number displays first. If you select **Null** from the **Index** field, the contact displays first. Contacts that have a favorite index number will display .
5. Press the **Save** soft key to accept the change.

Volume Adjustment







- Press  during a call to adjust the receiver volume of the handset/speakerphone/headset.
- Press  to adjust the ringer volume when the phone is idle or ringing.

Using the Calendar

To use the calendar feature on your phone, you must sign into the phone using **User Sign-in, Web Sign-in**

or **Sign in via PC** method. When you set up Skype conferences, appointments, meetings, events, or receive conferences invitation in Outlook® application, your phone will display all schedules in the **Calendar** menu.

To view the calendar:

1. Press ******* -> **Calendar**.
2. Press the **Month** soft key.
3. Press  or  to select the desired month.
4. Press  or  to select the desired day.
5. Press the **Enter** soft key to view schedules of the specific day.
6. Press  or  to select a desired schedule.
7. Press the **Detail** soft key to view details of the specific schedule.

Schedule Reminder


The phone displays a schedule reminder 15 minutes before a schedule starts.

- Press the **Ignore** soft key to permanently remove the reminder and stop reminding.
- Press the **Snooze** soft key to temporarily remove the reminder, until the next schedule reminder. The reminder will appear every 5 minutes and also appear 1 minute before the schedule starts.
- Press the **Detail** soft key to view details of the specific schedule.
- If you receive a Skype conference reminder, press the **Join** soft key to join the Skype conference.

Boss-Admin

The Boss-Admin feature enables a boss to assign delegates to manage boss's incoming call. A "boss" and a "delegate" phone will ring simultaneously when a user calls the boss.


To assign delegates in the Skype for Business client:

1. Open Skype for Business client, and then sign into Skype for Business client as the person who wants to assign a delegate.
2. Click  and then click **Call Forwarding Settings**.
3. Mark the radio box of **Simultaneously ring**.
4. Select **My Delegates** from the pull-down list of **Simultaneously ring**.
5. In the **Delegates** dialog box, click **Add** and select the desired delegates from the **Choose a Delegate** dialog box.

To view a list of bosses on your phone:

1. Press  -> **Bosses**.

To view a list of delegates on your phone:

1. Press  -> **Delegates**.

The boss answers an incoming call:

1. Press the **Answer** soft key when the boss receives a call. The delegate's phone stops ringing.

The delegate answers an incoming call for a boss:

1. Press the **Answer** soft key when the boss receives a call. The boss's phone stops ringing.

The boss places a call on hold on a boss's phone:

1. During a call, the boss presses the **Hold** soft key to place the call on hold.
The fifth line key (**Boss Admin** key) LED of the delegate's phone flashes green.

The delegate places a call on hold on a delegate's phone:

1. During a call, the delegate presses the **Hold** soft key to place the call on hold.
The fifth line key (**Boss Admin** key) LED of the boss's phone flashes green.

The boss resumes a call held by a delegate:

1. Press the fifth line key (**Boss Admin** key) to view the calls that are held by a delegate.
2. Select the desired call.
3. Press the **Resume** soft key.

The delegate resumes a call held by a boss:

1. Press the fifth line key (**Boss Admin** key) to view the calls that are held by a boss.
2. Select the desired call.
3. Press the **Resume** soft key.

The delegate transfers a delegation call to the boss's voice mail, do one of the following:



- Press the **Boss VM** soft key when the phone is ringing.
- Press **More->Boss VM** after the delegate answers the call.

The delegate makes a safe transfer to a boss's phone:

1. Press **More->Safe Tran** during a call. The call is placed on hold.

Note: If the boss is not available to answer the transferred call or rejects the transferred call, the delegate's phone displays as "Transfer failed" and the delegate can resume the call.

The delegate places a call on behalf of an assigned boss:

1. Press  -> **Bosses**, and then select the desired boss.
2. Press the **Option** soft key and select **On behalf** from the prompt list.
3. Enter the number or press the **Directory** soft key to select the desired contact.
4. Press  or the **Call** soft key.

The call displays as "Calling on behalf of" boss's line on the delegate and third-party's phones.

The delegate adds a boss's line to a Skype for Business conference call:



1. Press the **Answer** soft key to join an incoming conference call.
2. Press the **Invite** soft key to invite the boss's line to the conference.
3. Press the **OK** soft key to send the invitation.

When the boss joins the conference call, the delegate can choose to continue or leave the conference.

Common Area Phone

Common area phone is the Skype for Business phone that is not associated with an individual user. It is typically located in some places where a large number of people are likely to gather. Common area phone supports the basic call features, including placing a call, answering a call, placing a call on hold, resuming a held call, muting or unmuting a call and ending a call like a regular phone. Contact your system administrator for the common area account, and you must sign into the phone using **PIN Authentication** or **Web Sign-in** method to use the common area phone.

To switch a common area account to a Skype for Business account:

1. Press the **User Sign in** soft key when the common area phone is idle.
2. Press  ,  or **Switch** soft key to select the desired sign-in method.
3. Refer to **Sign-in** on page 3 to sign into your Skype for Business account.

No matter whether you sign out of the Skype for Business account, the phone will sign into the last common area account automatically after a period of time.





To sign out of a common area phone:

1. Press *****->Advanced** (admin or the unlock PIN)->**CAP Sign Out->Sign Out**.
2. Press the **CAP sign out** soft key.

Better Together over Ethernet (BToE)

Better Together over Ethernet (BToE) enables you to place, hold, and answer calls on your phone and Skype for Business client on your computer. You must download the Yealink BToE Connector application before enabling BToE. You can find the application on the Yealink Website.

To enable BToE feature via phone user interface:

1. Press ******* -> **Features** -> **BToE**.
2. Press  ,  or the **Switch** soft key to select **Enabled** from the **BToE** field.
3. Press  ,  or the **Switch** soft key to select **Auto** or **Manual** from the **BToE Pairing Mode** field.
4. Press the **Save** soft key to accept the change.


Before you can begin using BToE, you must pair your phone and your computer.

To pair your phone with your computer:

1. Sign into your Skype for Business client on your computer.
2. Install and start the Yealink BToE Connector application on your computer.
3. Connect an Ethernet cable from your computer to the PC port on your phone, check the **Wired** checkbox on the BToE application so that the IP address of your phone will be filled automatically. If your computer is not connected to the PC port on the phone, uncheck the **Wired** checkbox, and then enter the IP address manually.
4. Click **Pair** on the BToE application.
 - If **BToE Pairing Mode** is **Auto**, your phone will pair with your computer directly.
 - If **BToE Pairing Mode** is **Manual**, your phone will generate a pairing code. You should enter the pairing code in the **Pair code** field on the BToE application to pair your phone with your computer.

After your phone and computer are paired, you can sign into your phone via PC.


Sign in via PC

- If your phone is not signed in, a dialog box is displayed on your computer asking for your Skype for Business login credentials. You should enter your login credentials in the dialog box.
- If your phone and Skype for Business client are signed into with different user accounts, right-click  in the System Tray to select **Sign in via client(L)** , and then enter your login credentials in the dialog box displayed on your computer.


Now the same user account is signed into the phone and the Skype for Business client, your computer and phone are paired, and BToE is activated. Your phone is set as primary device in your client automatically.

Using Better Together over Ethernet (BToE)

To place a call, do one of the following:

- Hover your cursor over the avatar of the contact, and then click  in the Skype for Business client.
- Select a contact or enter the phone number, and then press the **Call** soft key on your phone.




To answer a call, do one of the following:

- Click  in the Skype for Business client.
- Press the **Answer** soft key on your phone.

To hold a call, do one of the following:

- Click  , and then click  in the Skype for Business client.
- Press the **Hold** soft key or press  on your phone.

To resume a call, do one of the following:

- Click  , and then click  in the Skype for Business client.
- Press the **Resume** soft key or press  on your phone.

To change the audio device during a call in the Skype for Business client:

1. Click  , and then click  to change the audio device.

About us

Founded in 2001, Yealink, a leading provider of VoIP Phone and IP communication solutions, has been focusing on VoIP products characterized by reliable quality, easy deployment and affordable price for more than a decade. Today, customers from over 140 countries rely on Yealink as the backbone of global collaboration to extend the value of network communications.

More about Yealink

Since 2001, Yealink has continued to develop state-of-the art, hi-tech VoIP communication terminals that include IP video phones, IP phones and USB phones. With a worldwide market in more than 140 countries, the company has also established a first-class international service network.

Our priorities are quality, functionality, ease-of-use, customer support and competitive pricing. To provide new solutions for the future in this fast-evolving sector, Yealink's large, talented and highly-experienced VoIP R&D team is totally committed to the pursuit of excellence.

To date, we have passed more than 80 interoperability tests and meet certification requirements set by leading VoIP system and platforms. Yealink works in close partnership with T-Mobile, Telefonica, Portugal Telecom and other leading telecommunication service providers.



YEALINK(XIAMEN) NETWORK TECHNOLOGY CO.,LTD.
Web: www.yealink.com
Addr: 309, 3th Floor, No.16, Yun Ding North Road, Huli District, Xiamen City, Fujian, P.R. China
Copyright©2017YEALINK(XIAMEN) NETWORK TECHNOLOGY CO.,LTD.All rights reserved.